
10 ERASE LAMP

10-1. Erase Lamp


- The Erase Lamp (LA2) consists of an array of eight tungsten lamps mounted on the PWB. It lights up to neutralize any residual potential on the surface of the cleaned PC Drum to enable even charging.



4811M041CA

10-2. Erase Lamp ON/OFF Control

- The Erase Lamp (LA2) is turned on/off in synchronization with the rotation of the Main Motor (M1). The Lamp is lit when 24VDC is output from PJ2A-1 on PWB-A.



4811C06MCA

FUNCTION/ ADJUSTMENT MODE