RICOH

RICOH M60 (A715)

PARTS CATALOG

First Edition Sep 1994

RICOH COMPANY,

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

M60 (A715)

M60 (A715)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.HOUSING (A715) 2
2.UPPER HALF(SCANNER) (A715) 4
3.OPTICAL SECTION UPPER (A715) 6
4.OPTICAL SECTION LOWER (A715) 8
5.LOWER HALF 1 (A715) 10
6.LOWER HALF 2 (A715) 12
7.FUSING /IMAGING UNIT (A715) 14
8.DRIVE SECTION (A715) 16
9.FEEDING SECTION (A715) 18
10.CASSETTE (A715) 20
11.ASSEMBLED PARTS (A715) 22
Parts Index 25

1. HOUSING (A715)




1. HOUSING (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0029	Cover Top	1
2	A715 0026	Cover Rear	1
3	A715 0028	Cover Right	1
4	A715 0027	Cover Left	1
5	A715 0030	Front Cover	1
6	A715 0032	Scanner Glass	1

Index No.	Part No.	Description	Q'ty P Assen

2. UPPER HALF(SCANNER) (A715)




2. UPPER HALF(SCANNER) (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0003	Terminal	1
2	A715 0035	Terminal	1
3	A715 0007	Temperature Fuse Assy	1
4	A715 0089	Exposure Lamp	1
5	A715 0056	Wire Rope	1

Index No.	Part No.	Description	Q'ty P Assen

3. OPTICAL SECTION UPPER (A715)




3. OPTICAL SECTION UPPER (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0084	DC-Fan	1
2	A715 0008	Ozone Filter	1
3	A715 0091	Main Switch	1
4	A715 0055	Gear T=46	1
5	A715 0061	Idle Gear T=39	1
6	A715 0054	Sprocket T=22	2
7	A715 0057	Sprocket T=15	2
8	A715 0051	Unlocking Handle	1

Index No.	Part No.	Description	Q'ty P Assen

4. OPTICAL SECTION LOWER (A715)




4. OPTICAL SECTION LOWER (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0039	Ground Contact	1
2	A715 0037	Ground Contact	1
3	A715 0021	Corona Resistor	1

Index No.	Part No.	Description	Q'ty P Assen

5. LOWER HALF 1 (A715)





5. LOWER HALF 1 (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0087	Eraser Lamp	1
2	A715 0020	PWB - A Logic Assy	1
3	A715 0013	PWB- D	1
4	A715 0015	HV 1	1

Index No.	Part No.	Description	Q'ty P Assen

6. LOWER HALF 2 (A715)






6. LOWER HALF 2 (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0083	Main Motor	1
2	A715 0014	PWB - C Switching Power Supply	1
3	A715 0070	Actuator	1
4	A715 0085	Timing Clutch	1
5	A715 0077	S1 - Roller	1

Index No.	Part No.	Description	Q'ty P Assen

7. FUSING /IMAGING UNIT (A715)




7. FUSING /IMAGING UNIT (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0088	Fusing Lamp 230 V	1
2	A715 0081	Fusing Roller	1
3	A715 0095	Thermistor	1
4	A715 0079	Separator	3
5	A715 0002	Temperature Fuse Assy	1
6	A715 0093	Reed Switch	1
7	A715 0078	Suspension Bracket	1



Index No.	Part No.	Description	Q'ty P Assen

8. DRIVE SECTION (A715)




8. DRIVE SECTION (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0059	Timing Belt T=286	1
2	A715 0094	Photo Interruptor	1
3	A715 0058	Double Gear T=19/20	1
4	A715 0080	Silicone Roller	1
5	A715 0023	Main Gear Assy	1

Index No.	Part No.	Description	Q'ty P Assen

9. FEEDING SECTION (A715)




9. FEEDING SECTION (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0076	Pinion T=13	1
2	A715 0074	Counter Pressure Axle	1
3	A715 0050	Clutch Fork	1
4	A715 0086	Solenoid	1
5	A715 0072	Gear T=40	1
6	A715 0025	Pressure Bracket Assy	1

Index No.	Part No.	Description	Q'ty P Assen

10. CASSETTE (A715)




10. CASSETTE (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0068	Cassette Cover Assy	1


Index No.	Part No.	Description	Q'ty P Assen

11. ASSEMBLED PARTS (A715)


1




4




7




2




5




8




3



6



9



11. ASSEMBLED PARTS (A715)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A715 0012	Operation Panel Assy	1
2	A715 0067	Cassette Assy	1
3	A715 0016	Fusing Unit	1
4	A715 0017	Driving Assy	1
5	A715 0018	Original Cover Assy	1
6	A715 0019	Paper Feeding Assy	1
7	A715 0022	Renovating Unit	1
8	A715 8605	Operating Instructions	1
9	5214 9500	Test Chart OS-A4 (10 pcs/set)	1
9	5214 9501	Test Chart OS-A4 (100 pcs/set)	1

Index No.	Part No.	Description	Q'ty P Assen

PARTS INDEX

Part No.	Description	Page and Index No.
A715 0002	Temperature Fuse Assy	15- 5
A715 0003	Terminal	5- 1
A715 0007	Temperature Fuse Assy	5- 3
A715 0008	Ozone Filter	7- 2
A715 0012	Operation Panel Assy	23- 1
A715 0013	PWB- D	11- 5
A715 0014	PWB - C Switching Power Supply	11- 2
A715 0015	HV 1	11- 6
A715 0016	Fusing Unit	23- 3
A715 0017	Driving Assy	23- 4
A715 0018	Original Cover Assy	23- 5
A715 0019	Paper Feeding Assy	23- 6
A715 0020	PWB - A Logic Assy	11- 2
A715 0021	Corona Resistor	9- 3
A715 0022	Renovating Unit	23- 7
A715 0023	Main Gear Assy	17- 5
A715 0025	Pressure Bracket Assy	19- 6
A715 0026	Cover Rear	3- 2
A715 0027	Cover Left	3- 4
A715 0028	Cover Right	3- 3
A715 0029	Cover Top	3- 1
A715 0030	Front Cover	3- 5
A715 0032	Scanner Glass	3- 6
A715 0035	Terminal	5- 2
A715 0037	Ground Contact	9- 2
A715 0039	Ground Contact	9- 1
A715 0050	Clutch Fork	19- 3
A715 0051	Unlocking Handle	7- 8
A715 0054	Sprocket T=22	7- 6
A715 0055	Gear T=46	7- 4
A715 0056	Wire Rope	5- 5
A715 0057	Sprocket T=15	7- 7
A715 0058	Double Gear T=19/20	17- 3
A715 0059	Timing Belt T=286	17- 1
A715 0061	Idle Gear T=39	7- 5

Part No.	Description	Page and Index No
A715 0067	Cassette Assy	23- 2
A715 0068	Cassette Cover Assy	21- 1
A715 0070	Actuator	13- 3
A715 0072	Gear T=40	19- 5
A715 0074	Counter Pressure Axle	19- 2
A715 0076	Pinion T=13	19- 1
A715 0077	S1 - Roller	13- 5
A715 0078	Suspension Bracket	15- 7
A715 0079	Separator	15- 4
A715 0080	Silicone Roller	17- 4
A715 0081	Fusing Roller	15- 2
A715 0083	Main Motor	11- 1
A715 0084	DC-Fan	7- 1
A715 0085	Timing Clutch	13- 4
A715 0086	Solenoid	19- 4
A715 0087	Eraser Lamp	11- 1
A715 0088	Fusing Lamp 230 V	15- 1
A715 0089	Exposure Lamp	5- 4
A715 0091	Main Switch	7- 3
A715 0093	Reed Switch	15- 6
A715 0094	Photo Interruptor	17- 2
A715 0095	Thermistor	15- 3
A715 8605	Operating Instructions	23- 8
5214 9500	Test Chart OS-A4 (10 pcs/set)	23- 9
5214 9501	Test Chart OS-A4 (100 pcs/set)	23- 9