Part No.	Part Name	Q'ty	Page	Unit Value
000-01169-106	Support Roller; Drum	6	15,19	
000-01327-100	Adj. Plate; Guide Roller; CE	1	13	
000-01328-107	Adj. Eccentric; Guide Roller; CE	1	13	
000-01515-004	Collar; Separator	1	29	
000-02211-009	Spring; Squeegee Gap	4	15,19	
000-02254-506	Ink Blocking Plate (Front)	2	15,19	
000-02255-502	Ink Blocking Plate (Back)	2	15,19	
000-06123-007	Stopper; Paper Guide Roller	2	5	
000-07119-100	Coil Spring; Inking Pump	2	16,20	
000-10148-030	Spring B	1	51	
002-11210-109	Load Spring; Guide Roller	2	13	
002-11220-007	Cam; Guide Roller	1	9	
002-11225-009	Support Block; Slide Plate	2	9	
002-11227-001	Spacer; Slide Plate	6	9	
002-11291-109	Sector Gear	1	9	
002-11402-008	Adjuster; Press.-Roll. Support	2	13	
002-11404-108	Roller Holder; Pressure	4	13	
002-11405-007	Center Shaft; Pressure	1	13	
002-11412-003	Shaft Catch; Guide Roller	1	13	
002-11421-100	Adj. Plate; Timing Lever	1	27	
002-11717-009	Collar; Elevator	2	5	
002-11719-303	Rack; Elevator	2	5	
002-12209-007	Adj. Collar A; Squeegee	2	15,19	
002-12210-005	Adj. Collar B; Squeegee	2	15,19	
002-12213-101	Sector Adjustor; Squeegee	2	15,19	
002-12219-002	Adj. Boss; Ink Blocking	4	15,19	
002-12229-105	Tensioner; Squeegee	2	15,19	
002-12233-005	Spring; Tensioner; Squeegee	2	15,19	
002-12234-001	Spring; Adj. Plate (Front)	4	15,19	
002-12238-104	Axis; Drive Shaft; Squeegee	2	15,19	
002-12240-001	Shaft Catch; Drive; Squeegee	2	15,19	
002-12303-305	Bracket; Inking Motor	2	15,19	
002-12304-107	Piston Inking Pump	2	15,19	
002-12307-203	Linking Disc; Inking Pump	2	16,20	
002-12308-013	Linking Plate; Inking Pump	2	16,20	
002-12309-001	Collar; Inking Pump	4	16,20	
002-12310-107	Collar Holder; Inking Pump	4	16,20	
002-12407-003	Boss A; Drum Lever	4	15,19	
002-12409-103	Support Shaft; Support Roller	4	15,19	
002-12410-004	Adj. Plate; Support Roller	2	15,19	
002-12418-102	Spacer; Drum Lever	4	15,19	
002-12537-403	Protection Sheet	1	27	
002-13352-202	Spring; Separator	1	29	
002-14517-000	Pulley; Duct	1	51	
002-17006-007	Shaft Catch; Front Cover	2	59	

Part No.	Part Name	Q'ty	Page	Unit Value
002-17016-002	Cover Catch A; Front	1	59	
002-17017-203	Cover Catch B; Front	1	3	
005-24114-003	Shaft Gear; Original Holder	1	59	
006-11216-106	Bearing House A; Main Shaft	1	9	
006-11224-109	Slide Plate (Front)	1	9	
006-11303-009	Gear; Guide Roller	1	13	
006-11304-005	Guide Shaft	1	13	
006-11305-109	One-Way Spring	1	13	
006-11306-008	Gear A; Guide Roller	1	13	
006-11307-004	Gear B; Timing Roller	1	13	
006-11308-108	Timing Lever	1	27	
006-11311-206	Spring; Timing Lever; R3	1	27	
006-11332-009	Core; Pickup Roller	2	5	
006-91440-001	Unit/Adj. Plate; Timing Lever	1	27	
007-13121-100	Spring; Release Lever	1	29	
007-13124-109	Base Block; Paper Guide; Rcv.	3	33	
007-14113-100	Spring; Vertical Transport	3	51	
007-17121-104	Master Removal Hook	2	51	
009-35214-009	Pulley PM (16); Exit Roller	1	27	
011-11208-103	Base Shaft Plate; Slide Plate	1	9	
011-11220-006	Shaft Base Block; Slide Plate	1	9	
011-11227-000	Reinforce Plate; Slide Plate	1	9	
011-11230-001	Shaft; Slide Plate	1	9	
011-11231-008	Shaft Block; Slide Plate	1	9	
011-11232-004	Gear; Slide Plate	1	9	
011-11234-104	Main Bracket; Face Plate	2	10	
011-11240-309	Cam; Timing Roller	1	9	
011-11244-002	Gear; Pressure Control Motor	1	27	
011-11245-009	Gear; Pressure Adj. Screw	1	9	
011-11254-202	Tension Pulley	1	10	
011-11255-004	Pressure Sensor Disc	1	9	
011-11280-106	Pressure Hook	1	9	
011-11289-006	Bracket; Hook Lever Spring	1	9	
011-11296-002	Spring; Sector Gear	1	9	
011-11509-200	Side Guide R; P. -F. -T.	1	7	
011-11510-209	Side Guide L; P. -F. -T.	1	7	
011-11513-003	Collar; Slide Rack; P. -F. -T.	2	7	
011-11514-000	Gear; Slide Rack; P. -F. -T.	1	7	
011-11516-002	L.O. Sheet	1	7	
011-11522-002	Paper Guide Roller	2	5	
011-11523-106	Adj. Nut; P. -F. -T.	1	7	
011-11524-005	Adj. Dial	1	7	
011-11713-002	L Plate; Guide Plate	2	13	
011-11810-105	P.-F. Pressure Adj. Lever	1	5	
011-11815-000	Spring: P.-F. Pressure Adj. Lever	1	5	

Part No.	Part Name	Q'ty	Page	Unit Value
011-12114-005	Shaft; Clamp Plate	1	23	
011-12116-202	Drum Cover R	1	23	
011-12124-108	Compensator	1	23	
011-12130-000	Clamp Magnet B	1	23	
011-12139-008	Drum Seal	2	23	
011-12147-108	Coil Spring; Inking Pump; RC	2	16,20	
011-12151-008	Valve; Inking Pump	4	16,20	
011-12155-208	Screw; Angular Magnet	1	23	
011-12205-000	Pulley; Squeegee Roller	2	15,19	
011-12206-406	Ass'y; Shaft Joint	2	15,19	
011-12208-000	Bottle Guide (Over)	2	15,19	
011-12211-302	Side Frame; Squeegee	2	15,19	
011-12213-100	Drum Cover F (Upper)	2	15,19	
011-12218-005	Boss; Bottle Set SW	2	16,20	
011-12221-006	Fulcrum; Tensioner; Squeegee	2	15,19	
011-12222-401	Bracket R; Drum Cover F	2	15,19	
011-12223-408	Bracket L; Drum Cover F	2	15,19	
011-12224-005	Drum Cover F (Lower)	2	15,19	
011-12241-007	Shaft Support II; Squeegee	2	15,19	
011-12311-005	Drum Catch (L)	1	25	
011-13122-109	Bracket; Magnet Catch; P. -Rcv.-T.	1	3	
011-13204-008	Pulley; Suction Motor	1	31	
011-13206-205	Suction Fan Cover	1	31	
011-13220-003	Transfer Belt	3	31	
011-13301-208	Lever; Separator	1	29	
011-13306-005	Collar A; Separator	2	29	
011-13307-206	Adj. Stopper; Separator	1	29	
011-13310-002	Hook Plate	2	29	
011-13311-106	Release Lever	1	29	
011-13916-008	Boss; JS Bracket	2	65	
011-14115-009	Linking Plate; M. -Rmv. Hook	1	51	
011-14121-106	Pulley B; M. -Rmv.	1	51	
011-14408-006	Bracket; Disposal Box SW	1	51	
011-14421-207	Guide Cam; Disposal Box	2	53	
011-14422-203	Guide Spring; Disposal Box	1	53	
011-14428-007	Lock Spring (Right)	1	53	
011-14429-003	Lock Spring (Left)	1	53	
011-15001-007	Support Shaft	2	45	
011-15004-006	Fulcrum; TPH	2	47	
011-15013-005	Open/Close Hook	2	47	
011-15037-109	Bracket; Loading Pulse Motor	1	27	
011-15098-000	Hook Spring	2	47	
011-15110-000	Pulley; Loading Roller (Lower)	1	45	
011-15117-005	Cam; Thermal Pressure Motor	1	47	
011-15146-102	Bracket; Write Pulse Motor	1	27	

Part No.	Part Name	Q'ty	Page	Unit Value
011-15708-208	Switch Cam	1	47	
011-17102-005	Magnet Catch Plate; Front	1	59	
011-17105-306	Front Left Cover	1	59	
011-17206-005	Bracket E; Keyboard	1	3	
011-17209-004	Set Plate; Front Right Cover	1	3	
011-17231-000	Set Plate Upper; Front Right Cover	1	3	
011-34502-009	Inner Cover; CE	1	3	
011-37211-005	Switch Box; CE	1	59	
011-60007-008	Rotation SW; A Position	1	59	
011-60020-004	Front Cover Set SW	1	59	
011-60027-106	Photoelectron Disc.	1	9	
011-65022-200	Counter	1	55	
011-70508-005	LCD; DMF5005N	1	63	
011-92106-008	Ass'y; Angular Magnet Plate	1	23	
011-93110-009	Magnet Catch Ass'y; P.-Rcv.-T.	1	3	
014-11114-100	Bottom Cover; A3; CE	1	3	
014-11301-202	Guide Roller; A3	1	13	
014-11303-205	Timing Roller; A3	1	13	
014-11404-206	Guide Cover; Pressure; A3	1	13	
014-11405-008	De-electricity Brush; A3	1	13	
014-11406-209	Pressure Roller Support; A3; CE	1	13	
014-11410-001	Support Collar; A3	2	13	
014-11502-003	Shaft A; P. -F. -T.	1	7	
014-11529-203	Feed Board Cover	1	7	
014-11533-006	Spring; Slide Rack	1	7	
014-12101-002	Drum Body; A3	1	23	
014-12103-005	Drum Body Support (Left); A3	1	23	
014-12114-007	Seal Tape; A3	1	23	
014-12115-003	Clamp Sub-Plate	1	23	
014-12116-301	Ink Blocking Sheet; A3	1	23	
014-12121-607	Sheet; Clamp Plate; A3	1	23	
014-12130-002	Drum Body; A4W	1	23	
014-12201-104	Squeegee Stay; A3	2	15,19	
014-12211-002	Inking Pump Body; A3	2	16,20	
014-12213-005	Ink Distributor; A3	2	16,20	
014-12216-101	Bottle Guide II Ass'y	1	15,19	
014-12217-000	Bottle Guide II (Base)	2	15,19	
014-12221-407	Squeegee Roller; A3	2	15,19	
014-12226-000	Doctor Roller II; A3	2	15,19	
014-12227-103	Reverse Rotation Stopper AII	2	15,19	
014-12251-004	Adj. Shaft; Squeegee; A3	2	15,19	
014-12252-000	Drive Shaft; Squeegee; A3	2	15,19	
014-12295-001	Lever; Bottle Stopper	2	15,19	
014-12297-004	Spring; Stopper Lever	2	15,19	
014-12301-109	Rail; Drum; A3	2	25	

Part No.	Part Name	Q'ty	Page	Unit Value
014-12310-108	Rail Bracket; Drum	1	25	
014-12311-007	Shaft; Lock	1	25	
014-12322-106	Lock Hook; Drum Lock	1	25	
014-12324-109	Bracket; Drum Lock	1	25	
014-12326-004	Spring; Lock	1	25	
014-13310-004	Nozzle (Lower); Separation	1	29	
014-13311-108	Nozzle (Upper); Separation	1	29	
014-13312-007	Bracket; Separation Fan	1	29	
014-14119-405	Front Cover; M.-Rmv.; A3; CE	1	3	
014-14465-001	Lock Shaft; Disposal Box; A3	1	53	
014-14469-007	Shaft; Disposal Box Cover; A3	1	53	
014-15007-007	Load Roller	1	47	
014-15008-003	Shaft; Open/Close Hook; A3	1	47	
014-15011-004	De-electricity Bar; M. -M.; A3	2	47	
014-15013-007	Sheet; Light Absorber; M. -M.	1	47	
014-15018-009	Catch Roller (Upper); A3	1	47	
014-15021-107	Fulcrum III; M. -M.; CE	2	47	
014-15028-004	Reinforce Shaft	1	47	
014-15102-000	Load Roller (Lower); M. -M.	1	45	
014-15116-205	Set Sheet E	2	49	
014-15144-209	Spring Hanger L; Master Guide Plate; CE	1	45	
014-15145-205	Spring Hanger R; Master Guide Plate; CE	1	45	
014-15146-007	Spring; Master Guide Plate	2	45	
014-15155-006	Mount; Loading Pulse Motor	1	27	
014-15182-003	Fixing Plate; Pulley G	1	45	
014-15191-100	Guide Plate; Load; A3	1	45	
014-15214-002	Set Plate; Cover	1	45	
014-17101-000	Back Cover; A3	1	59	
014-17207-100	Back Cover; Counter	1	55	
014-37203-004	Cover; Drum Lock; CE	1	25	
014-91320-008	Guide Roller Ass'y; A3	1	13	
014-91410-309	Pressure Shaft Ass'y; A3; CE	1	13	
014-91412-000	Pressure Shaft; A3	1	13	
014-91420-002	Pressure Roller Ass'y; A3	1	13	
014-92351-004	Unit/Drum Lock	1	25	
015-27128-001	Balance Weight; FB	4	43	
015-35223-102	Slide Base; P. -Rcv. -T.	3	33	
015-35225-300	Plate Spring; P. -Rcv. -T.	3	33	
015-35226-004	Slide Plate; P. -Rcv. -T.	3	33	
015-35244-304	Flap Adj. Plate; P. -Rcv. -T.	4	33	
015-35246-005	Adj. Lever; P. -Rcv. -T.	4	33	
015-58000-003	Image Flexible Wire	1	43	
015-71001-000	Image Scanner 600	1	43	
017-11201-200	Bracket A; Sensor	1	9	
017-11202-001	Bracket B; Sensor	2	9	

Part No.	Part Name	Q'ty	Page	Unit Value
017-11208-000	Base Shaft Plate; Pressure	1	10	
017-11209-108	Face Plate; Main Shaft	1	9	
017-11214-000	Pressure Link; Top	1	9	
017-11215-006	Pressure Link; Bottom	1	9	
017-11216-002	Link Boss A	1	9	
017-11217-009	Link Boss B	1	9	
017-11223-009	Linking Plate; Drive Base	1	9	
017-11224-005	Link Spacer	1	9	
017-11225-001	Spring; Pressure Link	1	9	
017-11227-004	Pressure Adj. Screw	1	9	
017-11229-007	Bracket; Pressure Control Motor	1	27	
017-11231-001	Bracket A; Pressure Control	1	9	
017-11232-202	Bracket B; Pressure Control	1	9	
017-11234-000	Spring; Linking Plate	1	9	
017-11240-108	Print Positioning Motor	1	27	
017-11516-103	Size Gear; P. -F. -T.	1	7	
017-11519-102	Lead SW Cover; P. -F. -T.; CE	1	7	
017-11602-301	Link Plate; Elevator	1	5	
017-11640-009	Bracket; Elevator Spring	1	5	
017-11648-000	Bracket; Lower Limit Sensor	1	5	
017-11649-006	Gear; Elevator	1	5	
017-11805-008	Bracket; P.-F. Pressure Adj. Lever	1	5	
017-11808-007	Hook; P.-F. Pressure Adj.	1	5	
017-11812-004	Shaft; Scraper	1	5	
017-11818-002	Scraper Collar	1	5	
017-11819-009	Spring F; Safety SW	1	5	
017-11820-007	Spring B; Safety SW	1	5	
017-12201-602	Frame; Drum	1	15,19	
017-12203-001	Bracket B; Connector; Drum	1	25	
017-12205-101	Position A Plate	1	23	
017-12211-004	Bracket; Stopper Lever	2	15,19	
017-12213-007	Inner Cover; Drum	2	15,19	
017-12215-107	PCB Cover; Drum	2	16,20	
017-12216-103	Drum Lever	2	15,19	
017-12409-009	Bracket; Angular Sensors	1	27	
017-12601-309	Drum Holder	1	25	
017-12604-103	Lever; Drum Holder	1	25	
017-12605-100	Lever Base; Drum Holder	1	25	
017-12606-009	Shaft; Drum Holder	1	25	
017-12607-005	Spring; Drum Holder	1	25	
017-13201-800	Face Cover W; Suction	1	31	
017-13205-202	Shaft; Jump Wing	2	31	
017-13208-007	Wing Plate; Suction	2	31	
017-13210-001	Spring; Belt Roller; Suction	1	31	
017-13211-008	Shaft Plate; Belt Roller; Suction	1	31	

Part No.	Part Name	Q'ty	Page	Unit Value
017-13216-000	Belt Roller; Suction	1	31	
017-13219-300	Suction Cover W (Upper)	1	31	
017-13220-104	Cover; Paper Rcv. Sensor 1	1	31	
017-13221-208	Cover; Paper Rcv. Sensor 2	1	31	
017-13222-107	Shaft; Wing Cam; Suction	1	31	
017-13223-006	Cam Gear; Suction	1	31	
017-13224-207	Wing Cam (F); Suction	1	31	
017-13225-106	Roller Cam; Suction	1	31	
017-13226-102	Wing Cam (R); Suction	1	31	
017-13228-105	SW Cam; Suction	1	31	
017-13229-209	Adj. SW Plate; Suction	1	31	
017-13232-102	Bracket; Suction Fan	1	31	
017-13233-001	Seal	1	31	
017-13235-004	Idler Shaft; Suction	1	31	
017-13236-205	Belt Idler; Suction	1	31	
017-13237-104	Fulcrum Plate II; Gear Pulley; Suction	1	31	
017-13239-000	Spring; Jump Wing (F)	1	31	
017-13240-008	Stay; Suction	1	31	
017-13241-004	Spring; Jump Wing (R)	1	31	
017-13242-000	Shaft Plate; Wing Gear	1	31	
017-13246-006	Wing Gear; Suction	1	31	
017-13247-002	Drive Shaft; Suction	1	31	
017-13248-009	Pulley; Wing Motor	1	31	
017-13252-006	Side Flap (F); Suction	1	31	
017-13255-005	Side Flap (R); Suction	1	31	
017-13257-008	Spring; Side Flap; Suction	2	31	
017-13258-004	De-electricity Brush; Suction	1	31	
017-13301-007	Release Lever; Separator	1	29	
017-13901-004	Positioning Bracket; JS III	1	65	
017-13902-000	Bracket; JS III	1	65	
017-14111-309	Sensor Bracket; M. -Rmv.	1	51	
017-14114-006	Set Collar; M. -Rmv.	2	51	
017-14115-002	Screw; M. -Rmv.	2	51	
017-14116-009	Fulcrum; Master Guide; M. -Rmv.	2	51	
017-14122-106	Bracket; M. -Rmv. Solenoid	1	51	
017-14159-107	H. -Lever (F); Disposal Box	1	53	
017-14161-101	H. -Lever (R); Disposal Box	1	53	
017-14163-007	Disposal Shaft	1	53	
017-14166-103	Compression Plate; Disposal Box	1	53	
017-14167-002	Guide Spring B; Disposal Box	1	53	
017-15009-001	Load Roller	2	47	
017-15213-008	Holder Stay R	1	45	
017-15214-004	Holder Stay F	1	45	
017-15306-006	Bracket; Master Positioning Sensor	1	49	
017-16021-005	Rack Cover; ADF Cover	1	59	

Part No.	Part Name	Q'ty	Page	Unit Value
017-16121-000	Bracket; Upper Cover Set SW	1	3	
017-16122-006	Shaft A; Upper Cover Set SW	1	3	
017-16123-002	Shaft B; Upper Cover Set SW	1	3	
017-16124-106	Spring; Upper Cover Set SW	1	3	
017-16530-007	Pulley A; ADF	2	37	
017-16538-008	Gear; ADF	1	37	
017-16542-005	Roller (Lower); ADF	3	35	
017-16546-000	De-electricity Brush B; ADF	1	37	
017-16555-000	Roller (Spring); ADF	3	35	
017-16562-006	Spring; Read Roller	2	37	
017-16588-005	Belt; 44	1	37	
017-16595-001	Mount; Read Pulse Motor	1	37	
017-17050-106	Bracket A; Keyboard	1	55	
017-17051-005	Bracket B; Keyboard	1	55	
017-17105-008	Slide Rack; Original Holder	2	59	
017-17210-103	Bottom Plate (Right)	1	3	
017-17217-205	Bottom Plate (Left); CE	1	3	
017-17220-109	Carrying Grasp	4	3	
017-17221-008	Mount; Connector	1	3	
017-17222-004	Blind Plate C; Connector	2	3	
017-17223-000	Blind Plate D; Connector	2	3	
017-17232-204	Side Cover; Power Supply	1	55	
017-21108-208	Bracket; Wire Harness	1	25	
017-22301-001	Bracket II; Drum Control PCB2	2	15,19	
017-23314-000	Bracket II; P. -Rcv. Sensor II (Receive)	1	29	
017-23405-307	Bracket D; Magnet Catch; P. -Rcv.-T.; CE	1	3	
017-24108-101	Bracket; Disposal Box Master Sensor	1	51	
017-24109-108	Actuator; M. -Rmv. Hook Sensor	1	51	
017-24110-009	Bracket; M. -Rmv. Hook Sensor	1	51	
017-24138-000	Guide Boss; M. -Rmv.	2	51	
017-24139-104	Knob; M. -Rmv.	2	51	
017-24140-005	Knob Shaft; M. -Rmv.	2	51	
017-24141-001	Lock Plate	2	51	
017-24148-200	Disposal Box Guide; CE	1	41	
017-24151-007	Guide Collar; Disposal Box Guide	2	41	
017-24152-100	Bracket F; Master Removal Fan	1	45	
017-24153-107	Bracket R; Master Removal Fan	1	45	
017-24154-103	Sensor Cover; Disposal Box Guide; CE	1	41	
017-37224-003	Mount II; Connector; CE	1	3	
017-44101-103	Right-Side Frame; M. -Rmv.; CE	1	51	
017-44104-102	Left-Side Frame; M. -Rmv.; CE	1	51	
017-44111-001	Set Plate F; M. -Rmv.; CE	1	51	
017-44112-008	Set Plate R; M. -Rmv.; CE	1	51	
017-44113-004	Fixing Plate F; M. -Rmv.; CE	1	51	
017-44114-000	Fixing Plate R; M. -Rmv.; CE	1	51	

Part No.	Part Name	Q'ty	Page	Unit Value
017-51032-001	ADF PCB	1	37	
017-55017-007	Wire Harness; Motor Con.-System	1	57	
017-55028-106	Wire Harness; Drum (R)	2	15,19	
017-55029-005	Wire Harness; Drum (L)	2	15,19	
017-55031-204	Wire Harness; Elevator Motor	1	57	
017-55039-108	Wire Harness; Guide Plate; 49	1	13	
017-55049-006	Wire Harness; RA-RC Sorter Inner	1	65	
017-55054-000	Inner COM Wire Harness; SF	1	65	
017-55062-002	Wire Harness; EXE-I/F	1	65	
017-60001-208	Master Removal Sensor	1	51	
017-60003-006	Paper Sensor	1	13	
017-60007-001	Upper Limit Sensor	1	5	
017-60010-002	Switch A	1	51	
017-60016-000	Angular Sensor	1	27	
017-60020-300	Drum PCB	2	16,20	
017-60025-000	Micro-SW Ass'y 3	1	5	
017-60031-000	Encoder Sensor	1	9	
017-60037-105	Master Sensor II	1	51	
017-65003-004	M. -Rmv. Vertical Transport Motor	1	51	
017-65005-309	Pressure Control Motor	1	27	
017-65006-003	Wing Motor; Suction	1	31	
017-65011-007	Loading Fan; Stocker	1	45	
017-65015-207	Loading Pulse Motor	1	27	
017-65016-602	Inking Motor	2	16,20	
017-91206-002	Pressure Det. Ass'y	1	9	
017-91240-103	Unit/Print Positioning Motor	1	27	
017-91266-005	Pressure Control Motor Ass'y	1	27	
017-91620-003	Unit/Elevator Motor	1	5	
017-92300-002	Unit/Drum Frame	1	15,19	
017-93110-100	Magnet Catch Ass'y D; P. -Rcv.-T.; CE	1	3	
017-93220-002	Angular Sensor Ass'y	1	27	
017-95050-007	Unit/Loading Pulse Motor	1	27	
017-97300-108	Wire Harness; JS III; CE	1	65	
018-16017-005	Drive Pulley Shaft; FB-Scanner	1	43	
018-16019-008	Belt Stand Plate; FB-Scanner	1	43	
018-16020-006	Belt Holder Plate; FB-Scanner	1	43	
018-16022-009	Tension Shaft; FB-Scanner	1	43	
018-16023-005	Tension Holder; FB-Scanner	1	43	
018-16024-001	Tension Plate; FB-Scanner	1	43	
018-16027-000	Tension Spring; FB-Scanner	1	43	
018-16031-105	Bracket; FB-Pos. Sensor	2	41	
018-16032-101	Actuator Stage Cover Sensor	1	41	
018-16035-003	Actuator Spring; Stage Cover Sensor	1	41	
018-16039-106	Glass Holder (R)	1	41	
018-16064-003	Blind Plate; FB-Back Frame	1	41	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16067-207	Shading Plate (R)	2	41	
018-16071-000	Protection Tape; Stage Glass	2	41	
018-16073-002	Shock-Absorbent Rubber	1	41	
018-16202-007	Stepped Screw; M6 x 10	2	3	
018-16218-000	Shaft; Hook Base	2	41	
018-16220-200	Hook Base (F); FB-Hook Shaft	1	41	
018-16222-105	Hook Base (R); FB-Hook Shaft	1	41	
018-16223-004	Spring; Hook Shaft	2	41	
018-16229-100	Hook Plate (F): FB; CE	1	3	
018-16239-105	Bracket B; Interlock Switch FB	1	55	
018-16241-100	Bracket; Damper Stopper; CE	1	3	
018-16242-009	Spring; Damper Stopper	1	3	
018-16243-102	Cap; Damper Stopper	1	3	
018-16250-206	Damper Hook; FB-Scanner; CE	2	41	
018-16254-007	Plate Spring; Interlock Switch FB	1	55	
018-16305-507	Cover B; FB-ADF	1	35	
018-16309-200	Original Tray; FB	1	59	
018-16310-101	Original Side Guide	2	59	
018-16312-007	Shaft; Original Tray	2	59	
018-16401-204	Stage Cover; FB	1	61	
018-16403-100	LCD Cover; Digitizer	1	63	
018-16406-206	PCB Cover; Stage Cover	2	61,63	
018-16411-102	Original Holder Cover (Upper); Stage Cover	1	61	
018-16412-400	Original Holder Cover (Lower); Stage Cover	1	61	
018-16413-008	Cover B; Stage Cover	1	61	
018-16415-701	Balance Weight A; Stage Cover	1	61	
018-16416-104	Balance Weight B; Stage Cover	1	61	
018-16417-100	Balance Weight C; Stage Cover	1	61	
018-16418-000	Cord Cap; Stage Cover	1	61	
018-16420-004	Actuator Plate; Stage Cover	2	61,63	
018-16425-006	Stage Pad (W); Stage Cover	2	61,63	
018-16427-203	Stylus Pen III	1	63	
018-16431-006	LCD Filter; Digitizer	1	63	
018-16435-001	LCD Cover; Digitizer; CE	1	63	
018-16502-108	Glass Plate; Image Scanner	1	35	
018-16503-104	Main Gear; FB-ADF	1	37	
018-16504-003	Stepped Screw; M4 x 13	1	37	
018-16506-006	Stopper Plate; FB-ADF	1	37	
018-16507-100	Tension Plate; FB-ADF	1	37	
018-16508-203	Side Frame L; FB-ADF	1	35	
018-16510-003	Tension Pulley B; FB-ADF	1	37	
018-16513-002	Transfer Roller; FB-ADF	1	37	
018-16514-009	Exit Roller (Upper); FB-ADF	1	37	
018-16516-109	Read Roller	1	37	
018-16518-101	Motor Cover; FB-ADF	1	37	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16522-001	Bracket; ADF Motor	1	37	
018-16526-007	Spacer; WHG	1	37	
018-16532-007	Open Lever; FB-ADF	1	37	
018-16533-100	Glass Holder R; Image Scanner	1	35	
018-16534-107	Glass Holder L; Image Scanner	1	35	
018-16535-103	Bracket; Original Out Sensor	1	37	
018-16536-002	Bracket; Original Det. Sensor	1	37	
018-16537-009	Bracket; Original Regist. Sensor	1	37	
018-16541-006	Collar; Stripper Roller	1	37	
018-16543-009	Tension Pulley A; FB-ADF	2	37	
018-16544-005	Pulley; Read Roller	1	37	
018-16545-001	Exit Pulley; FB-ADF	1	37	
018-16546-008	Spacer; Main Gear; FB-ADF	1	37	
018-16547-004	Metal; 8P	2	37	
018-16548-000	Metal; 8M	5	35,37	
018-16549-007	Housing; Exit Roller	2	37	
018-16550-102	Housing; Read Roller	2	37	
018-16551-001	Metal; 6	2	37	
018-16552-008	Spacer; Exit Roller	1	37	
018-16554-000	Metal; Exit Roller	1	35	
018-16555-007	De-electricity Brush A; FB-ADF	2	37	
018-16558-006	Spring R; FB-ADF	1	37	
018-16559-002	Spring L; FB-ADF	1	37	
018-16561-104	ADF Motor; FB	1	37	
018-16563-000	Read Pulse Motor; FB-ADF	1	37	
018-16564-006	Original Det. Sensor	1	37	
018-16565-002	Original Regist. Sensor	1	37	
018-16566-009	Original Out Sensor	1	37	
018-16567-005	Original IN Sensor (Send)	1	37	
018-16568-001	Original IN Sensor (Receive); FB-ADF	1	35	
018-16569-008	Wire Harness; Original IN Sensor	1	35	
018-16570-006	ADF SW; FB	1	35	
018-16571-002	Wire Harness; FB-ADF SW	1	35	
018-16572-009	Belt B; 56	1	37	
018-16575-008	Collar; Pickup Roller; FB-ADF	1	37	
018-16577-000	Bushing; FB-ADF	3	37	
018-16578-201	Free Bushing	1	35	
018-16580-001	Spacer; Stripper; FB-ADF	1	35	
018-16581-008	Bushing (1); ADF Motor	1	37	
018-16582-004	Bushing (2); ADF Motor	1	37	
018-16583-000	Bushing (3); ADF Motor	1	37	
018-16585-003	Belt; 118	1	37	
018-16590-104	Roller Spring II; ADF	2	35	
018-16591-003	Guide Plate; FB-ADF	1	37	
018-16592-000	Original Guide Base (R); FB-ADF	1	35	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16593-006	Exit Wheel; ADF; FB	2	35	
018-16598-105	Bracket; ADF SW	1	35	
018-16600-002	Actuator; ADF SW	1	35	
018-36227-103	Bracket (R); Hook Shaft	1	41	
018-51004-803	Digitizer PCB III	1	63	
018-55001-108	Wire Harness; FB	1	41	
018-55015-001	Wire Harness; Digitizer III ; CE	2	63,65	
018-55016-008	Wire Harness; Image-Digitizer; CE	2	57,65	
018-60000-101	Original Det. Sensor; FB	1	43	
018-65000-002	R Pulse Motor; FB	1	41	
018-70017-002	INF ROM (OP); Digitizer	1	63	
018-70018-009	INF ROM (ST); Digitizer	1	63	
018-70019-005	INF ROM (OP1); Digitizer	1	63	
018-70020-003	INF ROM (OP2); Digitizer	1	63	
018-96200-115	Unit/Stage Cover	1	61	
018-96210-005	Stage Cover Hinge Ass'y	2	61	
018-96230-200	Ass'y/Digitizer Stage Cover; FB; CE	1	63	
018-96600-008	Original Tray Ass'y; FB	1	59	
019-11201-000	Idler Pulley	4	9	
019-11209-000	Slide Plate (Base)	1	9	
019-11213-008	Base Plate; P. -F. Clutch	1	9	
019-11214-004	Bracket; Print Positioning Motor	1	27	
019-11220-101	Bracket; P. -F. Clutch; CE	1	9	
019-11222-007	Cover; Paper Feed Clutch; CE	1	10	
019-11223-003	Spring; Pressure Link	1	10	
019-11224-000	Face Plate; Pressure Shaft	1	9	
019-11225-006	Resting Position Plate; Pressure Lever	1	9	
019-11226-002	Hook Lever	1	9	
019-11230-000	Spring; Hook Lever	1	9	
019-11231-103	Shaft; Hook Lever	1	9	
019-11235-001	P Disc	1	9	
019-11238-000	Range Adj. Plate; P Disc	1	9	
019-11240-102	Pressure Lever	1	9	
019-11501-208	Bracket; Ground Finger	2	3	
019-11502-000	Connector Cover	1	7	
019-11520-105	Support Plate R; Feed Board; CE	1	7	
019-11521-101	Support Plate L; Feed Board; CE	1	7	
019-11522-108	Link Plate; Side Guide; P. -F. -T.	2	7	
019-11524-100	Slide Sheet; P. -F. -T.	4	7	
019-11702-009	Sheet; Guide Plate	1	13	
019-11731-009	Stripper Sheet (SHRT); 80	1	13	
019-11733-109	Base; Stripper Sheet	1	13	
019-11734-202	Cover (STND); Stripper Sheet	1	13	
019-11737-104	Shaft; Stripper (Dial)	1	13	
019-11738-003	Spring; Stripper (Dial)	1	13	

Part No.	Part Name	Q'ty	Page	Unit Value
019-11739-000	Adj. Dial; Stripper	2	13	
019-11740-105	Spring Stopper; Stripper (Dial)	1	13	
019-11741-101	Bracket; Stripper Shaft (Dial)	1	13	
019-11742-108	Housing; Stripper (Dial)	1	13	
019-11744-003	Bracket; Stripper Unit (Dial)	1	13	
019-11748-009	Bracket; Stripper Base (Dial)	1	13	
019-11749-102	Actuator Plate II; Stack P.-F. SW	1	13	
019-11750-100	Worm Gear Box; Stripper (Dial)	1	13	
019-11755-005	Bracket II; Stack Paper Feed SW	1	13	
019-11756-001	Spring; Stack Paper Feed SW	1	13	
019-11760-106	Cam Plate; Stripper (Dial)	1	13	
019-11801-104	Holder Plate; Scraper; CE	1	5	
019-11803-000	Upper Arm; Scraper	1	5	
019-11804-006	Spring; Scraper	1	5	
019-11806-106	Rubber Roller; Pickup	2	5	
019-11810-103	Pickup Roller Ass'y	2	5	
019-11811-100	Spring B; P.-F. Pressure Adj.	1	5	
019-11812-106	Lock Ring	4	5	
019-11814-206	Bracket; Upper Limit Sensor	1	5	
019-12206-005	Adj. Plate (Front); Squeegee	2	15,19	
019-12207-001	Adj. Plate (Back); Squeegee	2	15,19	
019-12208-008	Spacer; 18 x 10 x 1.8	4	15,19	
019-12209-004	Holder; Bottle SW	1	20	
019-12210-002	Set Plate; Bottle SW	2	16,20	
019-12211-009	Spring; Bottle SW	1	20	
019-12214-008	Position C2 Plate	1	23	
019-12215-004	Position C1 Plate	1	23	
019-12223-007	Bracket A; Connector; Drum	1	25	
019-12301-008	Rail B; Drum	1	25	
019-12302-101	Drum Cover (Upper)	1	20	
019-12303-108	Drum Cover (Lower)	1	20	
019-12304-007	Guide Block; Drum Holder	1	25	
019-12307-006	Spring; Locking Plate; Drum	2	15,19	
019-12308-002	Drum Catch (R) II	1	25	
019-12314-002	Locking Plate II; Drum	2	15,19	
019-12315-009	Shaft; Locking Plate II; Drum	2	15,19	
019-13102-009	Paper Guide F; P. -Rcv. -T.	1	33	
019-13103-005	Paper Guide R; P. -Rcv. -T.	1	33	
019-13112-004	Reinforce Plate; P. -Rcv. -T.	2	33	
019-13113-108	Back Stop; P. -Rcv. -T.	1	33	
019-13115-208	Flap; P. -Rcv. -T.	16	33	
019-13116-107	Flap Cover; P. -Rcv. -T.	4	33	
019-13119-009	Lock Plate; P. -Rcv.-T.	2	3	
019-13125-106	Receiving Tray Plate	1	33	
019-13126-005	Frame; P. -Rcv. -T.	1	33	

Part No.	Part Name	Q'ty	Page	Unit Value
019-13130-002	Ground Plate; P. -Rcv. -T.	1	33	
019-13131-106	Slide Rail A; P. -Rcv. -T.	1	33	
019-13132-102	Slide Rail B; P. -Rcv. -T.	2	33	
019-13133-109	Catch Plate; P. -Rcv. -T.	1	33	
019-13137-007	Jump Wing (F); Suction; A3	1	31	
019-13138-003	Jump Wing (R); Suction; A3	1	31	
019-13143-007	Job Separator Bracket EX	1	65	
019-13203-000	Gear Pulley 38; Suction	1	31	
019-13301-109	Separator II	1	29	
019-13501-000	Cylinder; Air Pump	1	29	
019-13503-003	Cam Pulley; Air Pump	1	29	
019-13504-000	Cam Plate; Air Pump	1	29	
019-13507-106	Bracket; Air Pump	1	29	
019-13511-103	Arm; Air Pump	1	29	
019-13512-002	Arm Shaft; Air Pump	1	29	
019-13514-005	Air Hose; Separator	1	29	
019-13516-105	Piston Head II; Air Pump	1	29	
019-13517-004	Cylinder Valve II; Air Pump	1	29	
019-13518-000	Cylinder Valve Sheet; Air Pump	1	29	
019-13601-200	Gear A; Clutch	1	27	
019-13602-001	Gear B; Clutch	1	27	
019-13603-105	Drive Gear; Clutch	1	27	
019-13604-004	Idler Gear; Clutch	1	27	
019-13610-209	Bracket; Tension Pulley	1	10	
019-14231-007	Hinge Reinforcement; Disposal Box	1	53	
019-15125-006	Base Plate; Write Pulse Motor	1	27	
019-15253-004	Damper Gear	1	45	
019-15254-000	Shaft Flange; Master Holder	1	45	
019-15255-007	Stopper; Guide Flange	1	45	
019-15270-006	Damper Case	1	45	
019-15273-005	Spring; Master Holder	1	45	
019-16066-003	Cap I; CE	1	41	
019-16067-000	Cap 2; CE	1	3	
019-16214-100	Shaft; Damper Bottom Bracket	2	41	
019-16215-009	Damper Bottom Bracket	2	41	
019-16236-103	Bracket; Interlock Switch FB	1	55	
019-17008-007	Mylar Sheet; Panel SW	1	55	
019-17009-100	Sheet B; Panel	1	55	
019-17010-109	Sheet A; Panel	2	55	
019-17011-008	Door; Panel	1	55	
019-17090-307	Reinforce Plate; Panel; CE	1	55	
019-17099-002	Grand Plate; Panel	1	55	
019-17101-104	Front Cover	1	59	
019-17104-308	Front Right Cover	1	59	
019-17202-008	Upper Hinge	1	3	

Part No.	Part Name	Q'ty	Page	Unit Value
019-17205-007	Bracket C; Keyboard	1	3	
019-17206-003	Bracket D; Keyboard	1	3	
019-17215-002	Lower Hinge; Front	1	59	
019-17236-204	Bracket; Motor Control PCB	1	57	
019-17241-305	Shaft Stopper; Damper; CE	1	41	
019-17242-107	Bracket; Power Supply Fan	1	55	
019-17251-203	Lock Plate; Support Shaft	1	3	
019-17252-307	Hook Plate (R): FB; CE	1	3	
019-17255-004	Support Shaft Lock	1	41	
019-18051-100	Guide; Motor Wire Harness; CE	1	10	
019-18121-001	Cover Plate; Power Supply	1	55	
019-18129-002	Bracket E; Option PCB; CE	1	57	
019-18130-000	Bracket F; Option PCB; CE	1	57	
019-21201-105	Cam; Pressure Roller; A3	1	9	
019-21202-004	Spring C; Pressure Link	1	9	
019-21301-002	Shaft; Timing Roller	1	13	
019-21302-009	Bracket; Timing Roller	1	13	
019-21501-001	Shaft B; P. -F. -T.	1	7	
019-21512-100	Slide Rack F; P. -F. -T.; CE	1	7	
019-21513-107	Slide Rack; P. -F. -T.; CE	1	7	
019-21514-308	Actuater Plate; P. -F. -T.; CE	1	7	
019-21518-109	Bracket; Size VR; P. -F. -T.; CE	1	7	
019-21602-002	Spring; Elevator	2	5	
019-21716-008	Guide Plate (Upper)	1	13	
019-21717-004	Guide Plate (Lower)	1	13	
019-21802-109	Bracket; Feed Tray Safety SW; CE	1	5	
019-21805-108	Shaft; Pickup Roller	1	5	
019-22101-104	Drum Body Support (Right); A3	1	23	
019-22102-305	Screen Ass'y; A3	1	23	
019-22106-106	Screen Hanger(Lower)	1	23	
019-22107-102	Spring; Screen	2	23	
019-22108-206	Clamp Plate Base	1	23	
019-22111-002	Clamp Magnet A; A3	1	23	
019-22112-106	Light Absorber Strip; A3	1	23	
019-22113-102	Anti-Wrinkle Strip; Drum	1	23	
019-22203-209	Bracket; Bottle SW	1	20	
019-22206-003	Reverse Rotation Stopper B	2	15,19	
019-23204-004	Bracket F; Suction; A3	1	3	
019-23205-108	Bracket R; Suction; A3	1	3	
019-23301-107	Shaft; Separator II; A3; CE	1	29	
019-23401-209	Set Plate F; P. -Rcv.-T.; A3	1	3	
019-23403-201	Set Plate R; P. -Rcv.-T.; A3	1	3	
019-23601-208	Bracket; Suction Drive; A3	1	27	
019-23604-304	Shaft; Clutch; A3	1	27	
019-23605-505	Clutch Cover; A3	1	27	

Part No.	Part Name	Q'ty	Page	Unit Value
019-24101-004	Stay A; M. -Rmv.	1	51	
019-24104-208	Guide Plate; M. -Rmv.; A3; CE	1	51	
019-24105-000	Vertical Transport Roller (Down); A3	1	51	
019-24107-002	Shaft; M. -Rmv. Hook; A3	1	51	
019-24110-100	Master Guide; M. -Rmv.; A3	1	51	
019-24111-000	Guide Plate; M. -Rmv.; A3	1	51	
019-24119-108	Vertical Transport Roller (UP); A3	1	51	
019-24126-104	Bracket; Aero Guide Sheet; CE	1	45	
019-24127-100	Aero Guide Sheet; A3	1	45	
019-24132-104	Disposal Box Cover; A3	1	53	
019-24133-003	Disposal Box Cover B; A3	1	53	
019-24134-000	Guide Plate; Disposal Box; A3	1	53	
019-24135-006	Lever Frame; Disposal Box; A3	1	53	
019-24137-009	Guide Shaft; Disposal Box; A3	1	53	
019-24138-005	Shaft; Compression Plate; A3	1	53	
019-25006-307	Bracket; Wire Harness; CE	1	3	
019-25007-001	Shaft; Load Roller	1	47	
019-25101-105	De-electricity Brush	1	45	
019-25103-000	Protection Sheet; De-electricity Brush	1	45	
019-25111-003	Stocker	1	45	
019-25112-107	Stocker Cover	1	45	
019-25115-009	Set Sheet Plate; A3	1	49	
019-25116-005	Set Sheet	2	49	
019-25301-309	Cutter Cover	1	49	
019-25305-002	Master Guide Stopper Plate	1	49	
019-25306-009	Master Guide Stopper Cushion	1	49	
019-25307-102	Cutter Guide	1	49	
019-25309-008	Gear; Cutter Motor	1	49	
019-25311-100	Cutter Guide Sheet (A3)	2	49	
019-25312-300	Cutter Center Guide Sheet	1	49	
019-25511-001	Spring; TPH Pressure	2	47	
019-25516-100	Set Guide Shaft	1	45	
019-25517-000	Stay R; Set Guide Plate	1	45	
019-25518-006	Stay L; Set Guide Plate	1	45	
019-25519-002	Set Guide Plate; A3	1	45	
019-25527-200	Bracket; Micro-SW; M.-M.	1	45	
019-25531-002	Spring (Left); M. -M.	1	47	
019-25532-009	Spring (Right); M. -M.	1	47	
019-25533-005	Actuator Plate; Micro-SW	1	45	
019-25602-007	Base Plate F; Tension Roller	1	45	
019-25603-003	Base Plate R; Tension Roller	1	45	
019-25604-000	Torque Limiter; Tension Roller	1	45	
019-25605-006	Copy Guide Plate (Lower)	1	47	
019-25608-005	Base A; Nip Roller	1	47	
019-25609-001	Base B; Nip Roller	1	47	

Part No.	Part Name	Q'ty	Page	Unit Value
019-25610-000	Nip Roller	1	47	
019-25612-002	Bracket; Micro-SW	1	47	
019-26201-006	Fulcrum Shaft; FB	1	3	
019-26202-800	Bottom Plate; FB-Scanner; CE	1	41	
019-26214-000	Hook Shaft; FB; A3	1	41	
019-26217-000	Bracket; Back Cover; CE	1	3	
019-26218-103	Upper Rear Frame; FB; CE	1	3	
019-27231-006	Mole; 3770	1	59	
019-27240-102	Shaft; Damper	1	41	
019-27301-004	Protection Plate; Motor Con.	1	57	
019-32201-000	Spring; Bottle SW	1	16	
019-32202-103	Bracket; Bottle SW	1	16	
019-32203-207	Holder; Bottle SW	1	16	
019-32206-001	Elbow; Ink Distributor	2	16	
019-32302-000	Drum Cover (Upper)	1	16	
019-32303-007	Drum Cover (Lower)	1	16	
019-32401-009	Spring A; Clamp	1	27	
019-32402-102	Spring B; Clamp	2	27	
019-32403-001	Base Plate; Clamp	1	27	
019-32404-105	Cam; Clamp	1	27	
019-32405-101	Drive Gear; Clamp	1	27	
019-32406-000	Shaft; Clamp	1	27	
019-32407-201	Guide Plate; Clamp Cam	1	27	
019-32410-008	Frame; Clamp	1	27	
019-32411-004	Compensator Plate	1	27	
019-32412-000	Stopper Plate; Clamp	1	27	
019-32416-006	Plate Spring; Clamp	1	27	
019-32417-304	Clamp Plate Ass'y; II	1	23	
019-35002-105	Frame A; M. -M.	1	47	
019-35006-003	Bracket; TPH; A3	1	47	
019-35007-000	Cover A; M. -M.	1	47	
019-35008-006	Bracket; De-electricity Brush	1	45	
019-35015-100	Bracket; Pressure Assist Plate; CE	2	47	
019-35016-009	Pressure Assist Plate	2	47	
019-35020-006	Pulley; Write Pulse Motor	1	27	
019-35021-002	Pulley G; 600	1	45	
019-35022-009	Inner Cover A	1	59	
019-35024-109	Master Guide Plate; A3	1	45	
019-35028-007	Master Roll Holder	1	45	
019-35032-004	Guide Holder D; Master Holder	1	45	
019-35033-000	Cover; Master Roll Holder	1	45	
019-35035-003	Flange F; Master Roll	1	45	
019-35036-000	Flange R; Master Roll	1	45	
019-35037-006	Actuator Plate; Micro-SW; M. -M.	1	47	
019-36001-005	Slide Guide; FB-Scanner	1	43	

Part No.	Part Name	Q'ty	Page	Unit Value
019-36002-109	Main Frame; FB-Scanner	1	41	
019-36006-104	Stage Glass	1	41	
019-36007-003	Glass Plate; Scanner	1	41	
019-36008-000	Original Stopper	1	41	
019-36009-006	Glass Holder F; Scanner	1	41	
019-36010-004	Glass Holder R; Scanner	1	41	
019-36011-000	Drive Pulley Holder; FB-Scanner	1	43	
019-36013-003	Slide Shaft; FB-Scanner	2	43	
019-36014-000	Adj. Plate; FB-Slide Shaft	2	43	
019-36015-006	Hinge Bracket; FB-Scanner; CE	2	41	
019-36016-200	Wire Stand; FB-Image	1	43	
019-36017-009	Core Holder	1	43	
019-36018-102	Image Scanner Cover B	1	43	
019-36019-109	Image Scanner Cover S	1	43	
019-36020-000	Bracket; Stage Cover Sensor	1	41	
019-36022-002	Bracket; R Pulse Motor	1	41	
019-36023-009	Hook Plate; Scanner	1	41	
019-36025-109	Back Frame; FB-Scanner	1	41	
019-36026-008	Set Sheet A; Stage Glass	1	41	
019-36027-004	Set Sheet B; Stage Glass	1	41	
019-36028-000	Core Holder CE	1	43	
019-36029-007	Core Cover	1	43	
019-36201-004	Open Lever; Hook Shaft	1	41	
019-36202-108	Bracket (F); Hook Shaft	1	41	
019-36203-007	Fulcrum Plate; FB-Hook Shaft	1	41	
019-36206-006	Link Plate; FB-Hook Shaft	1	41	
019-36207-002	Bracket; Open Lever	1	41	
019-36301-106	Scanner Cover (F); FB	1	59	
019-36302-005	Scanner Cover (R); FB	1	59	
019-36303-001	Scanner Cover (Left); FB	1	59	
019-36304-008	Scanner Cover (Right); FB	1	59	
019-36305-004	Scanner Cover (LR)	1	59	
019-36306-000	ADF Cover (F); FB	1	59	
019-36307-007	ADF Cover (R); FB	1	59	
019-36308-003	ADF Cover (Right); FB	1	59	
019-36501-000	Pickup Roller Frame; FB-ADF	1	37	
019-36502-004	Bracket; Pickup Solenoid	1	38	
019-36503-000	Lever Shutter R	1	38	
019-36504-007	Lever Shutter L	1	38	
019-36505-003	Claw L; FB-ADF	1	38	
019-36506-000	Claw R; FB-ADF	1	38	
019-36507-006	Lever; Pickup	1	38	
019-36509-009	Shaft; Stripper Roller	1	35	
019-36510-007	Link; Pickup Solenoid	1	38	
019-36511-003	Lever; Hook Plate	1	37	

Part No.	Part Name	Q'ty	Page	Unit Value
019-36512-000	Plate; Hook Plate	1	37	
019-36514-002	Spring; Pickup Solenoid	1	38	
019-36515-009	Guide; Belt	1	35	
019-36516-005	Sheet; Original Guide Base	1	35	
019-36517-001	Spring Plate; FB-ADF	1	35	
019-36518-008	Stripper Tray; FB-ADF	1	35	
019-36519-004	Tray Spring; FB-ADF	1	35	
019-36520-002	Stripper Pad; FB-ADF	1	35	
019-36521-009	Sheet Guide; FB-ADF	3	37	
019-36522-005	Spacer; Transfer Roller	1	37	
019-36523-001	Collar; Transfer Roller	1	38	
019-36524-008	Tray Push; FB-ADF	1	35	
019-36526-000	Original Guide Base (F); FB-ADF	1	35	
019-36527-007	Original Guide (F); FB-ADF	1	37	
019-36528-003	Hook Plate; FB-ADF	1	37	
019-36529-000	Upper Frame; FB-ADF	1	37	
019-36530-008	Side Frame R; FB-ADF	1	35	
019-36531-004	Pickup Roller (Upper); FB-ADF	1	37	
019-36532-000	Shaft; Stripper Roller; FB-ADF	1	37	
019-36533-007	Frame B; FB-Original Guide	1	35	
019-36534-003	Stripper Arm; FB-ADF	1	35	
019-36535-000	Spring; Stripper Arm	1	35	
019-36536-006	Stripper Roller; FB-ADF	1	35,37	
019-36537-002	Stripper Shaft; FB-ADF	1	35	
019-36538-009	Pickup Solenoid; FB-ADF	1	38	
019-36539-005	Pulley; Transfer Roller	1	37	
019-36540-003	Spring; Open Lever	2	37	
019-37209-203	Bracket; Counter; En; CE	1	55	
019-37210-201	Bracket; Counter; Pic.; CE	1	55	
019-37212-000	Bracket; Hinge; CE	1	3	
019-38101-007	Bracket (R); System PCB	1	57	
019-38102-003	Bracket (L); System PCB	1	57	
019-38103-000	Cover (U); PCB	1	57	
019-38104-006	Cover (L); PCB	1	57	
019-38107-005	Bracket; Image PCB	1	57	
019-41502-209	Paper Feed Tray; CE	1	7	
019-41503-205	Paper Feed Tray; US; CE	1	7	
019-41517-001	Bracket; P. -F. -T.; CE	1	7	
019-41519-004	Feed Board; CE	1	7	
019-41801-109	Cover; Pickup Roller; CE	1	5	
019-43201-206	Cover Plate II; Suction; CE	1	31	
019-44102-007	Stay B; M. -Rmv.; CE	1	51	
019-44103-003	Base Plate; M. -Rmv; A3; CE	1	51	
019-44108-102	Upper Stay; M. -Rmv.; CE	1	51	
019-44112-002	Upper Holder B; V. - Transport Roller; A3; CE	1	51	

Part No.	Part Name	Q'ty	Page	Unit Value
019-44116-105	Upper Holder A; V. - Transport Roller; A3; CE	1	51	
019-44131-007	Disposal Box; A3; CE	1	53	
019-46205-008	Fulcrum Support Plate; FB; CE	1	3	
019-51000-503	System PCB 2	1	57	
019-51002-107	LCD CTL PCB	1	55	
019-51003-103	Main SW PCB; Panel	1	55	
019-51005-106	Drum Control PCB2	2	15,19	
019-51030-003	De-electricity PCB	1	57	
019-51040-106	Motor Control PCB2	1	57	
019-51041-102	Power Supply PCB VIII H100	1	55	
019-51042-001	Power Supply PCB VIII H200	1	55	
019-51043-059	Sub-Power Supply PCB	1	47	
019-51044-101	Image Processing PCB; IPIF	1	57	
019-51047-003	Option PCB A III	1	57	
019-55004-104	Wire Harness; Master Loading Unit SW	1	45	
019-55005-003	Wire Harness; M. -Rmv.	1	51	
019-55010-104	Wire Harness; Drum Inner	2	15,19	
019-55014-509	Wire Harness; CN9	1	57	
019-55015-009	Wire Harness J; Guide Plate	1	13	
019-55016-307	Wire Harness II; P. -F. -T.	1	7	
019-55024-105	Wire Harness; Disposal Box Master Sensor	1	41	
019-55025-004	Inlet Terminal; 100V	2	55,57	
019-55028-003	Wire Harness; CN15	2	25,57	
019-55032-000	Wire Harness; Feed Tray Safety SW	1	5	
019-55036-103	Wire Harness; Suction	1	31	
019-55037-002	Wire Harness; Removal Guide	1	41	
019-55066-100	Wire Harness; CN7; CE	1	57	
019-55074-102	Wire Harness II; Counter III; CE	1	65	
019-55077-004	Wire Harness; Panel-System; CE	1	57	
019-55078-000	Wire Harness; CN14; CE	2	55,57	
019-55079-007	Inlet Terminal; 200V; CE	2	55,57	
019-55087-000	Wire Harness; Image-FBI	2	41,57	
019-55088-006	Wire Harness; Image-FBI Power	2	41,57	
019-55089-100	Wire Harness; M. -M. - Image	2	47,57	
019-55090-000	Wire Harness; TPH Power	1	47	
019-55091-104	Wire Harness; Power	2	55,57	
019-55092-100	Wire Harness; TPH Power	2	47,55	
019-55094-006	Wire Harness; ADF (FB)	1	37	
019-55095-002	Wire Harness; CN9; CE	1	57	
019-55096-009	Wire Harness; CN15; CE	2	25,57	
019-55097-105	Wire Harness; Image-FBI Power; CE	2	41,57	
019-55098-001	Wire Harness; M. -M. - Image; CE	1	47,57	
019-55099-105	Wire Harness; Power; CE	2	55,57	
019-60000-001	Disposal Box Master Sensor	1	41	
019-60001-008	Disposal Box Master Sensor (Rcv.)	1	51	

Part No.	Part Name	Q'ty	Page	Unit Value
019-60010-309	Bottle Set SW	2	16,20	
019-60012-204	Paper Receiving Sensor (Send) IV	1	31	
019-60013-200	Paper Receiving Sensor IV (Receive)	1	29	
019-60014-002	Switch A; CE	1	3	
019-60015-106	Master End Sensor (Send)	1	45	
019-60019-101	Master Positioning Sensor II	1	49	
019-60020-002	Micro Sw Ass'y 4 (Stack)	1	13	
019-60022-005	Master End Sensor (Receive)	1	47	
019-60023-001	Bottle Set SW II	1	16	
019-60024-008	Image Scanner 600 CE	1	43	
019-65001-006	P. -F. Clutch	1	9	
019-65003-009	Fan; Power Supply	1	55	
019-65005-001	Master Removal Fan	2	45	
019-65006-008	Separation Fan	1	29	
019-65007-101	Suction Clutch	1	27	
019-65008-205	Cutter Motor Ass'y; CE	1	49	
019-65010-102	Suction Fan Ass'y; CE	1	31	
019-65012-008	Pressure Solenoid	1	9	
019-65014-000	Lock Solenoid	1	25	
019-65015-007	Master Removal Solenoid	1	51	
019-65016-100	Thermal Pressure Motor Ass'y	1	47	
019-65017-107	Write Pulse Motor	1	27	
019-65019-002	Clamp Motor	1	27	
019-80021-	System ROM; GR	1	57	
019-80031-	RPU	1	55	
019-80032-	RPE	1	55	
019-80033-	RPA	1	55	
019-91211-000	Unit/Main Motor; T	1	9	
019-91216-002	Main Motor Ass'y; T	1	9	
019-91220-107	Unit/Drive; CE	1	9	
019-91227-004	Main Shaft Ass'y; A3	1	9	
019-91228-000	Main Pulley; Main Shaft	1	9	
019-91230-102	Pressure Link Ass'y	1	9	
019-91231-001	P Disc Ass'y	1	9	
019-91310-009	Timing Roller Ass'y; A3	1	13	
019-91500-207	Unit/Paper-Feed Tray; A3; CE	1	7	
019-91501-203	Unit/Paper-Feed Tray; A3; US; CE	1	7	.
019-91600-007	Shaft; Elevator	1	5	
019-91712-000	Unit/Stripper (Dial)	1	13	
019-91720-002	Unit/Guide Plate; A3	1	13	
019-91800-103	Feed Tray Safety SW Ass'y; A3; CE	1	5	
019-91811-407	Scraper Ass'y; CE	1	5	
019-91830-002	P.-F. Pressure Adj. Lever Ass'y	1	5	
019-92101-004	Drum Holder Ass'y	1	25	
019-92110-003	Drum Body Ass'y; A3	1	23	

Part No.	Part Name	Q'ty	Page	Unit Value
019-92115-005	Unit/Drum Screen; A4W	1	23	
019-92120-009	Unit/Drum Screen; A3II	1	23	
019-92200-002	Unit/Squeegee; A3	1	15,19	
019-92220-003	Unit/Ink Pump; A3	1	19	
019-92230-203	Bottle Set SW Ass'y	1	20	
019-92231-005	Bottle Set SW Ass'y	1	16	
019-92237-003	Clamp Switch	1	27	
019-92240-004	Unit/Ink Pump; 37	1	15	
019-92320-008	Drum Set SW Ass'y	1	25	
019-92400-001	Unit/Clamp	1	27	
019-92410-007	Clamp Plate Base Ass'y	1	23	
019-93114-053	Unit/Paper Receiving Tray W	1	33	
019-93200-200	Suction Unit W; A3; CE	1	31	
019-93201-207	Paper Receiving Sensor IV (Receive) Ass'y	1	29	
019-93300-108	Separator Ass'y; A3; CE	1	29	
019-93310-006	Separation Fan Ass'y	1	29	
019-93320-109	Air Pump Ass'y	1	29	
019-93602-104	Unit/Clutch; A3	1	27	
019-94100-102	Unit/Master Removal; A3; CE	1	51	
019-94115-207	Holder Ass'y; V. - Transport Roller; A3; CE	1	51	
019-94130-109	Unit/Master Disposal Box; A3; CE	1	53	
019-95001-000	Unit/Master Making; A3	1	47	
019-95002-007	Unit/Master Making; A3 CE	1	47	
019-95037-056	TPH Ass'y; 600A3	1	47	
019-95041-002	Unit/Write Pulse Motor	1	27	
019-95050-052	Copy Guide Plate (Lower) Ass'y	1	47	
019-95070-100	Set Guide Plate Ass'y; A3	1	45	
019-95077-007	Write Roller, A3	1	45	
019-95095-005	Stocker Ass'y; A3	1	45	
019-95100-009	Set Sheet Plate Ass'y; A3	1	49	
019-95204-009	Unit/Master Roll Holder; 377	1	45	
019-95211-005	Guide Flange Ass'y	1	45	
019-95300-202	Unit/Cutter; A3; CE	1	49	
019-95600-001	Tension Roller Ass'y	1	45	
019-96050-005	Flat Bed PCB	1	41	
019-96105-101	Interlock Switch; FB	1	55	
019-96220-008	Ass'y/Digitizer cover; FB	1	63	
019-97008-100	Unit/Operation Panel; 3770 US	1	55	
019-97009-009	Unit/Operation Panel; 3770 Pic.	1	55	
019-97010-007	Unit/Operation Panel; 3770	1	55	
019-97058-000	Sub-Panel Ass'y; 3770 US	1	55	
019-97059-006	Sub-Panel Ass'y, 3770 Pic.	1	55	
019-97060-004	Sub-Panel Ass'y; 3770	1	55	
019-97090-000	LCD; Panel	1	55	
019-97150-003	Key Board Cover; 3770		55	

Part No.	Part Name	Q'ty	Page	Unit Value
019-97200-000	Front Cover Ass'y		59	
019-97220-001	Keyboard Bracket D Ass'y		3	
025-55001-005	Wire Harness; TM-I/F	1	65	
026-55040-008	Wire Harness; GR-TM2500	1	65	
101-55000-002	SCII Cable (Video Cable); 10 m	1	65	
101-55014-003	Parallel Cable IEEE	1	65	
408-02300-001	Battery	1	63	
408-02301-008	Battery; CR-2450	1	57	
435-00018-004	TDK Core; HF70SH40 x 1.3 x 8	1	43	
435-00020-009	Core; TR-23-11-14	1	61	
435-00025-000	Core; SFC-6	2	10,31	
435-00027-003	Ferrite Core; SFC-10	1	63	
443-00120-609	Micro-SW; E21-91N	1	25	
443-00121-109	Micro-SW; 21-52N	1	51	
443-00210-004	Micro-SW; DDIL-AIAA	2	55	
443-02000-708	Micro-SW; AM50630A331	3	5,7	
443-02004-002	Micro-SW: AM50039C331F	1	3	
443-02006-005	Micro-SW; ABV1236413	2	31	
443-02007-001	Micro-SW; AM50036C331	2	47	
443-02008-008	Micro-SW; AM50030C33	1	45	
443-10800-209	Power Switch; AJ921001B3	1	55	
443-30002-007	Sensor K; PS-R11LB	1	7	
443-30003-003	Sensor; LG-203D	7	5,9,41	
443-30005-006	Sensor; GP1A71A	2	9,51	
443-32001-008	Sensor S; GP2A20L	1	7	
480-00033-007	Power Cord; CH	1	57	
481-30004-000	Gasket; 80	2	41	
481-30007-000	Ground Finger	2	3	
481-30009-002	Gasket; PCB1	1	63	
481-30010-000	Gasket; PCB2	2	63	
481-30011-007	Gasket; PCB3	1	63	
481-30012-003	Gasket; LCDF	1	63	
481-30013-000	Gasket; LCDR	1	63	
484-00000-800	Pilot Lamp	2	16,20	
485-00001-804	Fuse 8A 125V 5.2 ULTS C	1	55	
485-00002-401	Fuse 10A 125V 5.2 ULTS C	1	55	
485-00003-203	Fuse 3.15A 250V 5.2 SET	5	55	
485-00003-300	Fuse 5A 250V 5.2 SET	1	55	
485-00003-408	Fuse 3.15A 125V ULTS C	5	55	
485-02520-000	Fuse 6.3A 250V 5.2 SET	1	55	
488-00013-103	Power Cord; 100V	1	57	
488-00014-100	Power Cord; US	1	57	
488-00015-106	Power Cord; 200V	1	57	
488-90009-002	Ground Wire; P. -F. -T.	1	7	
488-90019-105	Ground Wire; R4-440-R4	1	61	

Part No.	Part Name	Q'ty	Page	Unit Value
488-90021-002	Ground Wire; U3-1000-R4	1	3,57	
505-00350-102	Cap Spacer	1	47	
550-20059-108	Seal; P. -F. -T. Down	1	51	
550-20118-104	TPH Seal	1	47	
550-20590-105	Seal; P. -F. -T.	1	7	
550-20671-105	Seal; M. -M.	1	47	
550-20672-101	Seal; M. -M.; Pic.	1	47	
550-20682-107	Seal; Original Size	1	59	
550-20687-001	Seal; P.-Feed Pressure	1	5	
550-20688-008	Seal; P.-Feed Pressure; Pic.	1	5	
550-20690-002	Seal; Master Disposal	1	53	
550-20691-009	Seal; Master Disposal; Pic.	1	53	
550-20693-001	Seal; Set Disposal Box	1	53	
550-20694-008	Seal; Set Disposal Box; Pic.	1	53	
550-20760-000	Seal; Image Scanner	1	35	
550-20764-006	Digitizer Seal; Ja, US	1	63	
550-20861-001	Digitizer Seal; Gr	1	63	
550-20862-008	Digitizer Seal; Fr	1	63	
550-20863-004	Digitizer Seal; It	1	63	
550-20864-000	Digitizer Seal; Sp	1	63	
550-20865-007	Digitizer Seal; In	1	63	
550-20866-003	Digitizer Seal; Ch	1	63	
550-20867-000	Digitizer Seal; Kr	1	63	
550-20981-104	Seal; Ink (Black)	1	20	
550-20982-100	Seal; Ink (Black); Pic.	1	20	
550-20983-000	Seal; Drum Holder	1	25	
550-20984-006	Seal; Drum Holder; Pic.	1	25	
550-20987-005	Seal; Setting Master	1	45	
550-20988-001	Seal; Setting Master, Pic.	1	45	
550-20998-007	Seal; Manual Pocket	1	59	
550-21073-007	Seal; P -Rcv. -T.; Caution	1	45	
550-21121-001	Seal; P. -F. -T.; US	1	7	
550-21141-002	Seal; Paper Guide Set	1	45	
550-21142-009	Seal; Paper Guide Set; Pic.	1	45	
550-21292-108	Seal; Paper Side Guide	1	7	
550-21293-007	Color Seal Set		16,20	
550-21296-103	Seal; P. -Rcv. -T.; US		33	
550-21298-106	Seal; P. -Rcv. -T.; Pic.		33	
550-21299-102	Seal; P. -Rcv. -T.		33	
550-21301-000	Seal; Master Cut	1	3	
550-21302-006	Seal; Master Cut; Pic.	1	3	
550-21399-000	Seal; Ink (HD Black)	1	16	
550-21502-005	Seal; Ink (HD Black); CH	1	16	
552-21400-105	Seal; Ink (HD Black); Pic.	1	16	
600-06105-001	Bearing; DDLF - 1060ZZH	2	45	

Part No.	Part Name	Q'ty	Page	Unit Value
600-06172-108	Bearing; DDR-1760 x 2 ZZR	1	43	
600-08168-000	Bearing NMB; LNR-1680HH	2	31	
600-08168-108	Bearing; SC866ZZNR/1K	2	27	
600-08242-006	Bearing; 628ZZ	6	9	
600-20061-009	Bearing; 608ZZ	1	9	
600-50046-004	Bearing; FLAWBC6-12ZZA	4	31,43	
600-50059-017	Bearing; FLW688ZZ	1	13	
601-10192-005	Bearing; 6800ZZ	4	15,19	
601-10228-000	Bearing; 0900ZZNR	2	45	
607-03000-005	Metal; S4 x 8 x 3	2	27	
607-05001-009	Metal; S6 x 10 x 6	1	45	
607-09001-003	Metal; S14 x 18 x 4.5	2	3	
607-10000-010	Metal; F3 x 5 x 3; 8 x 1.4	2	15,19	
607-11000-200	Metal; F4 x 7 x 6; 10 x 1.5	2	47	
607-11001-002	Metal; F4 x 6 x 2.2; 8 x 1	1	9	
607-11003-005	Metal; F4 x 6/5.6 x 5.9; 9 x 1	2	31	
607-12001-006	Metal; F5 x 10/9 x 4; 12 x 1.5	1	5	
607-13000-003	Metal; F6 x 10/9 x 4; 12 x 1.5	6	9,31,51	
607-13000-402	Metal; F6 x 10/9 x 6; 12 x 1.5	4	13,51	
607-13000-607	Metal; F6 x 9 x 7; 11 x 1	2	47	
607-13003-002	Metal; F6 x 8 x 3; 10 x 1	2	47	
607-13004-009	Metal; F6 x 8 x 7; 10 x 1	1	27	
607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	4	5,13,29	
607-15000-809	Metal; F8 x 16 x 6; 18 x 2	2	45	
607-15002-003	Metal; F8 x 12 x 5; 16 x 2	2	9	
607-15006-009	Metal; F8 x 16 x5; 18 x 1.1	2	7	
607-16000-403	Metal; F10 x 15/14 x 5.5; 20 x 2.5	1	5	
607-16000-802	Metal; F10 x 18/16 x 5; 22 x 1.5	2	5	
607-17000-105	Metal; F12 x 18 x 10; 24 x 2.5	2	13	
607-70815-005	Washer; UH3000	1	9	
610-00002-207	Damper; FB	2	41	
610-00007-004	HG Damper, 2G50-E	1	45	
611-01420-000	Pulley; ϕ 14 x 8	1	43	
611-30090-000	Pulley; P63/20-2M-6; HTD	1	43	
611-42100-001	Pulley; P21-3M060 (HTD)	1	5	
611-42600-004	Pulley; P26-3M060 (HTD)	1	5	
612-03103-009	Gear B; 1.25 x 14	2	51	
620-20714-005	Belt; B71M x L4.8	1	27	
620-21209-002	Squeegee Belt; B120M x L-9.5	2	15,19	
620-21869-002	Belt; B186 M x L-9.5	1	27	
620-22394-008	Belt; 239-M x L-4.8	1	31	
620-31776-002	Belt; 177-3M-6	1	5	
620-32916-002	Belt; 291-3M-6	1	51	
620-62256-007	Belt; B60S3M225	1	31	
620-73758-004	Belt; 375-5GT-8	1	29	

Part No.	Part Name	Q'ty	Page	Unit Value
620-78309-003	Belt; 830-5GT-11	1	9	
620-81966-007	Belt; 196-2GT	1	43	
620-89996-100	Belt; 1344-2GT	1	43	
620-97506-006	Belt; 750-3GT-6	2	9,27	
634-05020-000	Collar; ϕ 5.1 x 2.5	1	27	
634-06060-006	Collar; ϕ6 x 6	1	27	
634-06120-009	Collar; ϕ6 x 12	1	27	
635-11307-106	Stepped Screw; 3 x 7	10	61	
635-17523-005	Stepped Screw; ϕ5x2; M3x3	1	13	
635-17613-004	Stepped Screw; M3 x 4	1	5	
635-17614-000	Stepped Screw, M4 x 4.5	2	47	
635-17624-006	Stepped Screw; ϕ6x2.2; M4x2.5	1	13	
635-17814-000	Stepped Screw; M4 x 4.3	1	41	
635-19404-003	Stepped Screw; M4 x 4.5	1	55	
638-90000-012	Washer; 18 x 10.4 x 0.4	1	5	
638-90000-020	Washer; 18 x 10.2 x 0.2	6	15,19	
638-90616-005	Washer; 6.1 x 12 x 1.6	3	7,9	
638-90804-006	Washer; 8 x 15 x 0.4	1	9	
639-00405-008	Washer; 4 x 6.5 x 0.5	1	35	
640-60080-001	O Ring; P8-1.9	4	15,19	
640-60100-118	O Ring; P10A-2.4	2	16,20	
640-60140-012	O Ring; P14-2.4	6	15,19	
640-60220-024	O Ring; P22-2.4	2	16,20	
640-67340-009	O Ring; P34-3.6	1	29	
640-70030-100	V Ring; VRY2.7 x 3.5 x 4.1	2	15,19	
660-01000-200	Rubber Foot K-45	4	3	
660-05000-018	Magnet Catch SM50P	2	3	
660-05000-301	Magnet Catch; SM-41	1	5	
665-02025-504	Wire Saddle; WS-4W	3	55	
665-02031-008	Clamp; CP2311	2	31	
665-02040-007	Wire Saddle; LWS-2N-VO-MB6	2	57	
665-02901-002	Power Band T10	2	29	
665-04014-003	Snap Bushing; SB-2000-26	3	47,57	
665-04037-003	Free Bushing; NJ-23	1	57	
665-04950-205	Nut; E-632	4	27	
665-04951-104	Clip; Stylus Pen Holder	1	63	
665-09004-006	Stylus Pen Holder	1	63	

Part No.	Part Name	Q'ty	Page	Unit Value
X-500	Pin; ϕ 2 x 8	10		
X-510	Pin; ϕ 2 x 10	10		
X-520	Pin; ϕ 2 x 12	10		
X-530	Pin; ϕ 2 x 14	10		
X-540	Pin; ϕ 2.5 x 8	10		
X-600	Junction Connector; 2P	5		
X-610	Junction Connector; 3P	5		
X-620	Junction Connector; 4P	5		
X-630	Junction Connector; 5P	5		
X-640	Junction Connector; 6P	5		
X-650	Plastic E Ring	10		
The orders for the above (X-000) numbered Parts are available only by quantities of tens or fives as indicated.				