Part No.	Part Name	Q'ty	Page	Unit Value
000-01169-106	Support Roller; Drum	3	23	
000-01327-003	Adj. Plate; Guide Roller	1	21	
000-01328-000	Adj. Eccentric; Guide Roller	1	21	
000-01515-004	Collar; Separator	1	33, 65	
000-02211-009	Spring; Squeegee Gap	2	23	
000-02254-506	Ink Blocking Plate (Front)	1	23	
000-02255-502	Ink Blocking Plate (Back)	1	23	
000-06123-007	Stopper; Paper Guide Roller	6	7	
000-07119-100	Coil Spring; Inking Pump	1	24	
000-10126-002	Pulley G; Original Feed Roller	1	59	
000-10148-030	Spring B	1	67	
002-11210-109	Load Spring; Guide Roller	1	21	
002-11220-007	Cam; Guide Roller	1	13, 17	
002-11225-009	Support Block; Slide Plate	2	13, 17	
002-11227-001	Spacer; Slide Plate	3	13, 17	
002-11242-000	Idler	3	13, 17	
002-11244-003	Idler Pulley	4	13, 17	
002-11247-100	Pressure Link; Top	1	13	
002-11250-100	Stopper Shaft	1	13	
002-11251-204	Spring Hanger Shaft	1	13	
002-11255-013	Linking Plate; Drive Base	1	13	
002-11259-108	Connecting Shaft; Link	1	13	
002-11291-109	Sector Gear	1	13, 17	
002-11303-000	Spring B; Pressure Link	1	13, 17, 18	
002-11304-103	Spring; Hook Lever	1	13, 17	
002-11402-008	Adjuster; Press. -Roll. Support	2	21	
002-11404-108	Roller Holder; Pressure	4	21	
002-11405-007	Center Shaft; Pressure	1	21	
002-11412-003	Shaft Catch; Guide Roller	1	21	
002-11421-002	Adj. Plate; Timing Lever	1	31	
002-11509-104	Joint A	1	65	
002-11542-004	Housing; Stripper	1	21	
002-11543-000	Spring; Stripper	1	21	
002-11544-007	Sliding Plate; Stripper	1	21	
002-11546-000	Bracket; Stack Paper Feeding SW	1	21	
002-11548-002	Adjuster; Stripper	1	21	
002-11549-009	Adj. Shaft; Stripper	1	21	
002-11550-007	Stopper Washer; Stripper	1	21	
002-11557-001	Stripper Pad; SU	1	21	
002-11717-009	Collar; Elevator	2	7	
002-11719-206	Rack; Elevator	2	7	
002-12110-108	Clamp Magnet A; B4	1	27	
002-12134-104	Sticker Sheet; Drum	1	27	
002-12201-308	Squeegee Roller	1	23	
002-12205-001	Doctor Roller	1	23	

Part No.	Part Name	Q'ty	Page	Unit Value
002-12208-000	Adj. Plate (Front); Squeegee	1	23	
002-12209-007	Adj. Collar A; Squeegee	1	23	
002-12210-005	Adj. Collar B; Squeegee	1	23	
002-12213-101	Sector Adjustor; Squeegee	1	23	
002-12216-100	Adj. Shaft; Squeegee	1	23	
002-12218-006	Reverse Rotation Stopper B	1	23	
002-12219-002	Adj. Boss; Ink Blocking	2	23	
002-12222-003	Pulley; Squeegee Roller	1	23	
002-12223-107	Pulley; Main Shaft	1	23	
002-12229-105	Tensioner; Squeegee	1	23	
002-12233-005	Spring; Tensioner; Squeegee	1	23	
002-12234-001	Spring; Adj. Plate (Front)	2	23	
002-12237-000	Adj. Plate (Back); Squeegee	1	23	
002-12238-104	Axis; Drive Shaft; Squeegee	1	23	
002-12240-001	Shaft Catch; Drive; Squeegee	1	23	
002-12303-305	Bracket; Inking Motor	1	24	
002-12304-107	Piston; Inking Pump	1	24	
002-12307-203	Linking Disc; Inking Pump	1	24	
002-12308-013	Linking Plate; Inking Pump	1	24	
002-12309-001	Collar; Inking Pump	2	24	
002-12310-107	Collar Holder; Inking Pump	2	24	
002-12407-003	Boss A; Drum Lever	2	23	
002-12409-006	Support Shaft; Support Roller	2	23	
002-12410-004	Adj. Plate; Support Roller	1	23	
002-12414-000	Shaft; Locking Plate; Drum	1	23	
002-12418-102	Spacer; Drum Lever	2	23	
002-12537-209	Protection Sheet	1	31	
002-13252-003	Gear Pulley B; Suction	1	35, 37	
002-13352-105	Spring; Separator	1	33	
002-14517-000	Pulley; Duct	1	67	
002-17006-007	Shaft Catch; Front Cover	2	77, 79	
002-17016-002	Cover Catch A; Front	1	77, 79	
002-17017-203	Cover Catch B; Front	1	3, 5	
005-24114-003	Shaft Gear; Original Holder	1	77, 79	
006-11216-009	Bearing House A; Main Shaft	1	13, 17	
006-11222-009	Slide Plate (Base)	1	13, 17	
006-11224-109	Slide Plate (Front)	1	13, 17	
006-11301-308	Timing Roller	1	21	
006-11303-009	Gear; Guide Roller	1	21	
006-11304-005	Guide Shaft	1	21	
006-11305-109	One-Way Spring	1	21	
006-11306-008	Gear A; Guide Roller	1	21	
006-11307-004	Gear B; Timing Roller	1	21	
006-11308-000	Timing Lever	1	31	
006-11311-109	Spring; Timing Lever; R3	1	31	

Part No.	Part Name	Q'ty	Page	Unit Value
006-11312-008	Support Collar; R3	2	21	
006-11332-009	Core; Pickup Roller	2	7	
006-11518-013	Stripper Fixing Spring	1	21	
006-91440-001	Unit/Adj. Plate; Timing Lever	1	31	
007-13121-100	Spring; Release Lever	1	33	
007-13124-109	Base Block; Paper Guide; Rcv.	3	39	
007-14113-100	Spring; Vertical Transport	3	67	
009-35214-009	Pulley PM (16); Exit Roller	2	31, 59	
011-11111-002	Bracket F; Suction	1	3, 5	
011-11112-009	Bracket R; Suction	1	3, 5	
011-11113-102	Bottom Cover	1	3, 5	
011-11201-109	Unit/P. -F. Clutch	1	13, 17	
011-11204-000	Base Plate; P. -F. Clutch	1	13, 17	
011-11208-006	Base Shaft Plate; Slide Plate	1	13, 17	
011-11220-006	Shaft Base Block; Slide Plate	1	13, 17	
011-11222-106	Base Shaft Plate; Pressure	1	14	
011-11227-000	Reinforce Plate; Slide Plate	1	13, 17	
011-11229-003	Bracket; Print Positioning Motor	1	31	
011-11230-001	Shaft; Slide Plate	1	13, 17	
011-11231-008	Shaft Block; Slide Plate	1	13, 17	
011-11232-004	Gear; Slide Plate	1	13, 17	
011-11234-007	Main Bracket; Face Plate	2	14, 18	
011-11235-003	P Disc	1	13, 17	
011-11238-002	Disc Plate; Main Shaft	2	13, 17	
011-11240-309	Cam; Timing Roller	1	13, 17	
011-11241-100	Pressure Link; Bottom	1	13	
011-11244-002	Gear; Pressure Control Motor	1	31	
011-11245-009	Gear; Pressure Adj. Screw	1	13, 17	
011-11249-403	Face Plate; Main Shaft	1	13	
011-11251-106	Bracket; Tension Pulley	1	14, 18	
011-11254-105	Tension Pulley	1	14, 18	
011-11255-004	Pressure Sensor Disc	1	13, 17	
011-11257-007	Cam; Pressure Roller; A4	1	13	
011-11258-003	Cam; Pressure Roller; B4	1	13	
011-11270-003	Shaft; Hook Lever	1	13, 17	
011-11276-206	Hook Lever	1	13, 17	
011-11280-009	Pressure Hook	1	13, 17	
011-11284-209	Pressure Lever	1	13, 18	
011-11289-006	Bracket; Hook Lever Spring	1	13, 17	
011-11296-002	Spring; Sector Gear	1	13, 17	
011-11301-006	Guide Roller	1	21	
011-11403-208	Pressure Roller Support	1	21	
011-11404-107	De-electricity Brush; B4	1	21	
011-11409-109	Guide Cover; Pressure; B4	1	21	
011-11502-001	Shaft A; P. -F. -T.	1	9, 11	

Part No.	Part Name	Q'ty	Page	Unit Value
011-11503-109	Shaft B; P. -F. -T.	1	9, 11	
011-11509-103	Side Guide R; P. -F. -T.	1	9, 11	
011-11510-101	Side Guide L; P. -F. -T.	1	9, 11	
011-11512-104	Link Plate; Side Guide; P. -F. -T.	2	9, 11	
011-11513-104	Collar; Slide Rack; P. -F. -T	4	9, 11	
011-11514-000	Gear; Slide Rack; P. -F. -T.	1	9, 11	
011-11515-006	Slide Sheet; P. -F. -T.	4	9, 11	
011-11516-002	L. O. Sheet	1	9, 11	
011-11522-002	Paper Guide Roller	6	7	
011-11523-106	Adj. Nut; P. -F. -T.	1	9, 11	
011-11524-005	Adj. Dial	1	9, 11	
011-11526-008	Support Plate R; Feed Board	1	9, 11	
011-11527-004	Support Plate L; Feed Board	1	9, 11	
011-11528-000	Feed Board	1	9	
011-11529-104	Feed Board Cover	1	9, 11	
011-11708-106	Angular Adj. Plate; Stripper	1	21	
011-11709-102	Stripper Pad Cover	1	21	
011-11710-003	Base Plate; Stripper	1	21	
011-11711-107	Fulcrum Screw; Stripper	2	21	
011-11712-006	Actuator Plate; Stack P. -F. SW	1	21	
011-11713-002	L Plate; Guide Plate	2	21	
011-11720-009	Stripper Noise Reduction Sheet	1	21	
011-11810-008	P. -F. Pressure Adj. Lever	1	7	
011-11815-000	Spring; P. -F. Pressure Adj. Lever	1	7	
011-11817-002	Pickup Roller Ass'y	2	7	
011-11818-009	Rubber Roller; Pickup	2	7	
011-12101-205	Drum Body; B4	1	27	
011-12104-000	Seal Tape	1	27	
011-12105-200	Screen A	1	27	
011-12107-009	Screen B	1	27	
011-12110-409	Clamp Plate Ass'y	1	27	
011-12114-005	Shaft; Clamp Plate	1	27	
011-12116-202	Drum Cover R	1	27	
011-12120-102	Clamp Plate Base	1	27	
011-12123-705	Drum Body Support (Left)	1	27	
011-12124-108	Compensator	1	27	
011-12129-100	Clamp Sub-Plate	1	27	
011-12130-000	Clamp Magnet B	1	27	
011-12131-007	Hanger Plate	2	27	
011-12132-402	Sheet; Clamp Plate	1	27	
011-12136-009	Spring; Screen	2	27	
011-12139-008	Drum Seal	2	27	
011-12140-006	Ink Blocking Sheet; B4	1	27	
011-12141-100	Screw; Spring Hanger	2	27	
011-12142-009	Ink Blocking Sheet; A4	1	27	

Part No.	Part Name	Q'ty	Page	Unit Value
011-12143-005	Clamp Magnet A; A4	1	27	
011-12147-108	Coil Spring; Inking Pump; RC	1	24	
011-12151-008	Valve; Inking Pump	2	24	
011-12153-000	Ink Distributor II	1	24	
011-12154-104	Plate II; Angular Magnet	1	27	
011-12155-003	Screw; Angular Magnet	1	27	
011-12156-000	Drive Shaft II; Squeegee	1	23	
011-12201-200	Inking Pump Body	1	24	
011-12204-101	Squeegee Stay	1	23	
011-12206-104	Ass'y; Shaft Joint	1	23	
011-12208-000	Bottle Guide (Over)	1	23	
011-12211-205	Side Frame; Squeegee	1	23	
011-12213-100	Drum Cover F (Upper)	1	23	
011-12216-002	Bracket; Bottle SW	1	23	
011-12217-009	Adj.Plate; Bottle SW	1	23	
011-12218-005	Boss; Bottle Set SW	1	23	
011-12219-001	Spring; Bottle SW	1	23	
011-12220-107	Drum Cover F (Lower)	1	23	
011-12221-006	Fulcrum; Tensioner; Squeegee	1	23	
011-12222-002	Bracket R; Drum Cover F	1	23	
011-12223-009	Bracket L; Drum Cover F	1	23	
011-12241-007	Shaft Support II; Squeegee	1	23	
011-12304-009	Bracket A; Connector; Drum	1	29	
011-12305-005	Spring; Locking Plate; Drum	1	23	
011-12306-109	Rail; Drum	3	29	
011-12311-005	Drum Catch (L)	1	29	
011-12317-003	Drum Catch (R)	1	29	
011-12402-108	Spring; Clamp Solenoid	1	31	
011-12405-107	Bracket; Compensator Plate	1	31	
011-12409-200	Compensator Plate	1	31	
011-12410-003	Plunger Pin; Clamp Solenoid	1	31	
011-12411-000	Gear; Clamp Motor	1	31	
011-12412-006	Spacer; Compensator Plate	2	31	
011-13106-006	Frame B; Paper Receiving Tray	1	39	
011-13107-002	Catch Plate; P. -Rcv. -T.	1	39	
011-13108-106	Slide Rail A; P. -Rcv. -T.	1	39	
011-13109-102	Slide Rail B; P. -Rcv. -T.	1	39	
011-13110-208	Paper Guide; P. -Rcv. -T.	2	39	
011-13112-103	Shaft; Paper Receiving Tray	1	39	
011-13115-102	Receiving Tray Plate II	1	39	
011-13122-001	Bracket; Magnet Catch; P. -Rcv. -T.	1	5	
011-13134-000	Damper; Cover Plate; Suction	1	35, 37	
011-13135-006	Pin; Paper Guide	2	39	
011-13141-006	Spring; Paper Guide; P. -Rcv. -T.	2	39	
011-13142-002	Paper Guiding Arm F; P. -Rcv. -T.	1	39	

Part No.	Part Name	Q'ty	Page	Unit Value
011-13143-009	Paper Guiding Arm R; P. -Rcv. -T.	1	39	
011-13144-005	Set Plate F; P.-Rcv. T.	1	3, 5	
011-13146-008	Set Plate R; P.-Rcv. T.	1	3, 5	
011-13201-106	Suction Cover (Upper)	1	35	
011-13204-008	Pulley; Suction Motor	1	35, 37	
011-13205-101	Cover Plate; Suction	1	35	
011-13206-205	Suction Fan Cover	1	35, 37	
011-13212-000	Fulcrum Plate; Gear Pulley; Suction	1	35	
011-13220-003	Transfer Belt	3	35	
011-13224-106	Bracket; De-electricity Brush; Suction	1	35, 37	
011-13225-102	De-electricity Brush	1	35, 37	
011-13231-005	De-electricity Brush; P. -Rcv.	1	35	
011-13232-109	Suction Cover (Lower)	1	35	
011-13233-008	Dust-proof Cover 1; Rcv.	1	35	
011-13234-004	Dust-proof Cover 2; Rcv.	1	35	
011-13236-007	Dust-proof Sponge 2; Rcv.	1	35	
011-13237-003	Dust-proof Tape 1; Rcv.	1	35	
011-13238-000	Dust-proof Tape 2; Rcv.	1	35	
011-13301-100	Lever; Separator	1	33	
011-13304-002	Shaft; Separator	1	33	
011-13306-005	Collar A; Separator	2	33	
011-13307-109	Adj. Stopper; Separator	1	33	
011-13310-002	Hook Plate	2	33	
011-13311-009	Release Lever	1	33	
011-13312-005	Separator	1	33	
011-13916-008	Boss; JS Bracket	2	85	
011-14115-009	Linking Plate; M. -Rmv. Hook	1	67	
011-14120-207	Front Cover; M.-Rmv.	1	3, 5	
011-14121-009	Pulley B; M. -Rmv.	1	67	
011-14170-000	Master Removal Hook	2	67	
011-14408-006	Bracket; Disposal Box SW	1	67	
011-14421-207	Guide Cam; Disposal Box	2	69	
011-14422-203	Guide Spring; Disposal Box	1	69	
011-14427-000	Lock Shaft; Disposal Box	1	69	
011-14428-007	Lock Spring (Right)	1	69	
011-14429-003	Lock Spring (Left)	1	69	
011-14502-002	Inner Cover	1	3, 5	
011-15001-007	Support Shaft	2	59	
011-15004-006	Fulcrum; TPH	2	63	
011-15009-105	Catch Roller (Lower); M. -M.	1	59	
011-15010-006	Shaft; Open/Close Hook	1	63	
011-15013-005	Open/Close Hook	1	63	
011-15018-007	Pulley; Write Pulse motor	1	31	
011-15034-002	Bracket; De-electricity Brush; T-TPH	1	63	
011-15035-009	Protection Sheet A; TPH	1	63	

Part No.	Part Name	Q'ty	Page	Unit Value
011-15036-005	De-electricity Brush; TPH	1	63	
011-15037-001	Bracket; Loading Pulse Motor	1	31	
011-15039-101	Bracket; Cutter SW	1	65	
011-15041-009	De-electricity Brush	1	59, 63	
011-15043-109	Cutter Guide Sheet (Right)	1	65	
011-15044-105	Cutter Guide Sheet (Left)	1	65	
011-15047-104	Cutter Cover A	1	65	
011-15048-003	Set Sheet A	2	65	
011-15049-000	Set Sheet B	2	65	
011-15051-004	De-electricity Bar; M. -M.	2	63	
011-15055-000	Spring (Left); M. -M.	1	63	
011-15056-006	Spring (Right); M. -M.	1	63	
011-15098-000	Hook Spring	2	63	
011-15102-202	Cutter Body	1	65	
011-15106-003	Cutter Joint A	1	65	
011-15107-000	Cutter Joint B	1	65	
011-15110-000	Pulley; Loading Roller (Lower)	1	59	
011-15113-000	Bracket; Micro-SW; M. -M.	1	60	
011-15117-005	Cam; Thermal Pressure Motor	1	63	
011-15120-006	Pulley A; Write Roller	1	59	
011-15162-000	Sheet; Master Guide Plate; M. -M.	2	59	
011-15169-102	Cutter Guide Sheet III	1	65	
011-15176-001	Cutter Guide IV	1	65	
011-15177-008	Master Guide III	2	65	
011-15179-000	Bracket; Cutter Motor	1	65	
011-15181-005	Brake Spring; Cutter	1	65	
011-15182-001	Cam II; Cutter SW	1	65	
011-15183-008	Support Bracket; Cutter Roller	1	65	
011-15542-008	Write Pulse Motor	1	31	
011-15704-105	Bracket; TPH	1	63	
011-15708-100	Switch Cam	1	63	
011-15710-008	Bracket; Micro-SW	1	63	
011-15716-006	Pressure Assist Plate	2	63	
011-15717-002	Bracket; Pressure Assist Plate; K-TPH	2	63	
011-15718-106	Spring; TPH Pressure	2	63	
011-15722-006	Fulcrum II; M. -M.	2	63	
011-15733-008	De-electricity Brush; K-TPH	1	63	
011-15734-004	Bracket; De-electricity Brush; K-TPH	1	63	
011-15751-006	Bracket; Pressure Assist Plate; T-TPH	2	63	
011-17046-105	Reinforce Plate; Panel	1	71	
011-17101-009	Front Cover	1	77, 79	
011-17102-005	Magnet Catch Plate; Front	1	77, 79	
011-17105-004	Front Left Cover	1	77, 79	
011-17204-002	Bracket C; Keyboard	1	3, 5	
011-17205-106	Bracket D; Keyboard	1	3, 5	

Part No.	Part Name	Q'ty	Page	Unit Value
011-17206-005	Bracket E; Keyboard	1	3, 5	
011-17209-004	Set Plate; Front Right Cover	2	3, 5	
011-17211-009	Switch Box	1	77, 79	
011-17212-200	Inner Cover A	1	77, 79	
011-17220-008	Blind Plate B; Connector	1	3, 5	
011-41404-004	De-electricity Brush; A4	1	21	
011-41409-006	Guide Cover; Pressure; A4	1	21	
011-41528-005	Feed Board; US	1	9	
011-42101-200	Drum Body; 100US	1	27	
011-42102-206	Drum Body; A4	1	27	
011-43102-102	Receiving Tray Plate II; 100US	1	39	
011-47103-103	Front Right Cover	1	77, 79	
011-47557-007	Back Cover	1	77	
011-60007-008	Rotation SW; A Position	1	77, 79	
011-60020-004	Front Cover Set SW	1	77, 79	
011-60027-106	Photoelectron Disc.	1	13, 17	
011-65004-309	Clamp Solenoid	1	31	
011-65005-100	Lock Solenoid	1	29	
011-65014-002	Cutter Motor	1	65	
011-65018-300	Master Removal Solenoid	1	67	
011-65022-200	Counter	1	72	
011-70022-102	Edging; Face Plate	1	14	
011-70508-005	LCD; DMF5005N	1	83	
011-91222-004	Clutch Base Ass'y		13, 17	
011-91225-100	Main Shaft Ass'y; B4		13	
011-91226-000	Main Shaft Ass'y; A4		13	
011-91227-006	Main Pulley; Main Shaft	2	13, 17	
011-91230-007	Unit/Drive Gear; Transfer Belt	1	31	
011-91245-004	Pressure Solenoid Ass'y	1	13, 17	
011-91320-103	Guide Roller Ass'y		21	
011-91410-200	Pressure Shaft Ass'y; B4		21	
011-91411-001	Pressure Shaft Ass'y; A4		21	
011-91412-008	Pressure Shaft	1	21	
011-91420-000	Pressure Roller Ass'y; B4	1	21	
011-91421-007	Pressure Roller Ass'y; A4	1	21	
011-92106-008	Ass'y; Angular Magnet Plate		27	
011-92320-000	Drum Set SW Ass'y		29	
011-93110-009	Magnet Catch Ass'y; P.-Rcv.-T.		3, 5	
011-93230-004	De-electricity Brush Ass'y		35, 37	
011-93300-002	Separator Ass'y		33	
011-95037-007	K-TPH Ass'y		63	
011-95041-004	Unit/Write Pulse Motor	1	31	
011-95045-212	Unit/Cutter Motor		65	
011-95077-009	Write Roller; 40	1	59	
011-95111-002	Cutter Cover A Ass'y		65	

Part No.	Part Name	Q'ty	Page	Unit Value
011-97210-008	Inner Cover A Ass'y		77, 79	
011-97220-011	Keyboard Bracket D Ass'y		3, 5	
012-17001-109	Back Cover; FB	1	79	
014-11204-002	Spring II; Pressure Link	1	13	
014-11205-009	Pressure Adj. Screw II	1	13	
014-11533-006	Spring; Slide Rack	1	9, 11	
014-12216-101	Bottle Guide II Ass'y	1	23	
014-12217-000	Bottle Guide II (Base)	1	23	
014-12227-103	Reverse Rotation Stopper A II	1	23	
014-12295-001	Lever; Bottle Stopper	1	23	
014-12297-004	Spring; Stopper Lever	1	23	
014-12310-108	Rail Bracket; Drum	1	29	
014-12311-007	Shaft; Lock	1	29	
014-12312-100	Lock Hook; Drum Lock	1	29	
014-12315-100	Bracket; Drum Lock	1	29	
014-12318-001	Spring; Lock	1	29	
014-12401-006	Base Plate; Clamp Solenoid	1	31	
014-12402-100	Bracket; Clamp Solenoid	1	31	
014-13101-006	Frame A; Paper Receiving Tray; A3	1	39	
014-13105-109	Back Stop II; P. -Rcv. -T.	1	39	
014-13106-008	Damper; Back Stop; P. -Rcv. -T.	1	39	
014-13110-005	Slide Guide; Paper Guide; Rcv. ; A3	3	39	
014-13113-004	Slide Frame; Paper Guide; Rcv. ; A3	3	39	
014-14469-007	Shaft; Disposal Box Cover; A3	1	69	
014-15013-007	Sheet; Light Absorber; M. -M.	1	63	
014-15144-101	Spring Hanger L; Master Guide Plate	1	59	
014-15145-108	Spring Hanger R; Master Guide Plate	1	59	
014-15146-007	Spring; Master Guide Plate	2	59	
014-15155-006	Mount; Loading Pulse Motor	1	31	
014-17203-008	Cover; Drum Lock	1	29	
014-17205-108	Bracket; Counter; 63 En	1	72	
014-17206-104	Bracket; Counter; 63 Pic.	1	72	
014-17207-003	Back Cover; Counter	1	72	
014-91220-003	Unit/Drive		13, 17	
014-91230-009	Pressure Link Ass'y		13	
014-92350-008	Unit/Drum Lock		29	
014-93100-102	Unit/Paper Receiving Tray; A3		39	
014-93105-200	Unit/Paper Receiving Tray; A3; 100US		39	
017-11111-006	Bracket; P. -Rcv. Sensor 1 (Receive)	1	33	
017-11201-102	Bracket A; Sensor	1	13, 17	
017-11202-001	Bracket B; Sensor	1	13, 17	
017-11204-004	Guide Plate; Face Plate	1	14	
017-11208-000	Base Shaft Plate; Pressure	1	18	
017-11209-103	Face Plate; Main Shaft	1	17	
017-11214-000	Pressure Link; Top	1	17	

Part No.	Part Name	Q'ty	Page	Unit Value
017-11215-006	Pressure Link; Bottom	1	17	
017-11216-002	Link Boss A	1	17	
017-11217-009	Link Boss B	1	17	
017-11223-009	Linking Plate; Drive Base	1	17	
017-11224-005	Link Spacer	1	17	
017-11225-001	Spring; Pressure Link	1	17	
017-11226-008	Spring B; Pressure Link	1	17	
017-11227-004	Pressure Adj. Screw	1	17	
017-11229-007	Bracket; Pressure Control Motor	1	31	
017-11231-001	Bracket A; Pressure Control	1	17	
017-11232-105	Bracket B; Pressure Control	1	18	
017-11234-000	Spring; Linking Plate	1	17	
017-11237-000	Cam; Pressure Roller; B4	1	17	
017-11238-006	Cam; Pressure Roller; A4	1	17	
017-11240-000	Print Positioning Motor	1	31	
017-11301-107	Shaft; Timing Roller	1	21	
017-11302-006	Bracket; Timing Roller	1	21	
017-11503-001	Bracket; P. -F. -T.	1	9, 11	
017-11504-008	Paper Feed Tray	1	9, 11	
017-11511-004	Slide Rack F; P. -F. -T.	1	11	
017-11512-000	Slide Rack; P. -F. -T.	2	9, 11	
017-11513-007	Actuater Plate; P. -F. -T.	1	11	
017-11516-006	Size Gear; P. -F. -T.	1	11	
017-11517-002	Feed Board II	1	11	
017-11518-203	Bracket; Size VR; P. -F. -T.	1	11	
017-11519-005	Lead SW Cover; P. -F. -T.	1	11	
017-11530-009	Feed Board II; US	1	11	
017-11548-005	Connector Cover	1	9, 11	
017-11553-009	Nut Holder	1	9	
017-11602-107	Link Plate; Elevator	1	7	
017-11640-009	Bracket; Elevator Spring	1	7	
017-11641-005	Spring; Elevator	2	7	
017-11648-000	Bracket; Lower Limit Sensor	1	7	
017-11649-006	Gear; Elevator	1	7	
017-11704-007	Guide Plate (Upper)	1	21	
017-11706-000	Sheet; Guide Plate	1	21	
017-11707-006	Bracket; Stripper Unit	1	21	
017-11710-007	Guide Plate (Lower); 49	1	21	
017-11801-002	Cover; Pickup Roller	1	7	
017-11802-009	Bracket; Feed Tray Safety SW	1	7	
017-11805-008	Bracket; P. -F. Pressure Adj. Lever	1	7	
017-11808-007	Hook; P. -F. Pressure Adj.	1	7	
017-11809-305	Spring B; P. -F Pressure Adj.	1	7	
017-11810-206	Bracket; Upper Limit Sensor	1	7	
017-11811-008	Shaft; Pickup Roller	1	7	

Part No.	Part Name	Q'ty	Page	Unit Value
017-11812-004	Shaft; Scraper	1	7	
017-11813-108	Holder Plate; Scraper	1	7	
017-11817-006	Lock Ring	4	7	
017-11818-002	Collar; Scraper	1	7	
017-11819-009	Spring F; Safety SW	1	7	
017-11820-007	Spring B; Safety SW	1	7	
017-12001-107	Drum Body Support (Right)	1	27	
017-12201-203	Frame; Drum	1	23	
017-12203-001	Bracket B; Connector; Drum	1	29	
017-12204-008	Bracket; Drum Control PCB	1	23	
017-12205-101	Position A Plate	1	27	
017-12206-000	Position C2 Plate	1	27	
017-12207-007	Locking Plate; Drum	1	23	
017-12209-107	Drum Cover (Upper)	1	24	
017-12210-300	Drum Cover (Lower)	1	24	
017-12211-004	Bracket; Stopper Lever	1	23	
017-12213-007	Inner Cover; Drum	1	23	
017-12215-000	PCB Cover; Drum	1	23	
017-12216-103	Drum Lever	1	23	
017-12219-102	Separate Sheet; A4	2	27	
017-12220-003	Position C1 Plate	1	27	
017-12225-005	Sponge; Separator Guide Plate	1	27	
017-12226-001	Separator Guide Plate II	1	27	
017-12409-009	Bracket; Angular Sensors	1	31	
017-12601-104	Drum Holder	1	29	
017-12604-006	Lever; Drum Holder	1	29	
017-12605-100	Lever Base; Drum Holder	1	29	
017-12606-009	Shaft; Drum Holder	1	29	
017-12607-005	Spring; Drum Holder	1	29	
017-13201-207	Face Cover W; Suction	1	37	
017-13205-008	Shaft; Jump Wing	2	37	
017-13206-004	Jump Wing (F); Suction	1	37	
017-13207-000	Jump Wing (R); Suction	1	37	
017-13208-007	Wing Plate; Suction	2	37	
017-13210-001	Spring; Belt Roller; Suction	1	37	
017-13211-008	Shaft Plate; Belt Roller; Suction	1	37	
017-13216-000	Belt Roller; Suction	1	37	
017-13219-009	Suction Cover W (Upper)	1	37	
017-13220-007	Cover; Paper Rcv. Sensor 1	1	37	
017-13221-003	Cover; Paper Rcv. Sensor 2	1	37	
017-13222-107	Shaft; Wing Cam; Suction	1	37	
017-13223-006	Cam Gear; Suction	1	37	
017-13224-207	Wing Cam (F); Suction	1	37	
017-13225-106	Roller Cam; Suction	1	37	
017-13226-102	Wing Cam (R); Suction	1	37	

Part No.	Part Name	Q'ty	Page	Unit Value
017-13228-008	SW Cam; Suction	1	37	
017-13229-101	Adj. SW Plate; Suction	1	37	
017-13232-005	Bracket; Suction Fan	1	37	
017-13233-001	Seal	1	35, 37	
017-13235-004	Idler Shaft; Suction	1	37	
017-13236-108	Belt Idler; Suction	1	37	
017-13237-007	Fulcrum Plate II; Gear Pulley; Suction	1	37	
017-13239-000	Spring; Jump Wing (F)	1	37	
017-13240-008	Stay; Suction	1	37	
017-13241-004	Spring; Jump Wing (R)	1	37	
017-13242-000	Shaft Plate; Wing Gear	1	37	
017-13246-006	Wing Gear; Suction	1	37	
017-13247-002	Drive Shaft; Suction	1	37	
017-13248-009	Pulley; Wing Motor	1	37	
017-13249-200	Transfer Belt	3	37	
017-13250-003	Cover Plate W; Suction	1	37	
017-13251-000	Brush; Suction	1	37	
017-13252-006	Side Flap (F); Suction	1	37	
017-13255-005	Side Flap (R); Suction	1	37	
017-13257-008	Spring; Side Flap; Suction	2	37	
017-13271-108	Face Cover; Suction	1	35	
017-13275-006	Dust-proof Sponge; Rcv.	1	35	
017-13276-002	Dust-proof Sponge (Lower); Rcv.	1	35	
017-13277-009	Suction Fan	1	35	
017-13278-005	Transfer Shaft; Suction	2	35	
017-13301-007	Release Lever; Separator	1	33	
017-13311-002	Nozzle; Separation Fan	1	59	
017-13312-009	Cover Sheet; Separation Fan	1	59	
017-13901-004	Positioning Bracket; JS III	1	85	
017-13902-000	Bracket; JS III	1	85	
017-14101-109	Right-Side Frame; M. -Rmv.	1	67	
017-14102-300	Left-Side Frame; M. -Rmv.	1	67	
017-14103-004	Stay A; M. -Rmv.	1	67	
017-14104-000	Stay B; M. -Rmv.	1	67	
017-14105-104	Base Plate; M. -Rmv.; B4	1	67	
017-14106-100	Guide Plate; M. -Rmv.; B4	1	67	
017-14107-107	Vertical Transport Roller (Down)	1	67	
017-14108-006	Shaft; M. -Rmv. Hook; B4	1	67	
017-14111-104	Sensor Bracket; M. -Rmv.	1	67	
017-14114-006	Set Collar; M. -Rmv.	2	67	
017-14115-002	Screw; M. -Rmv.	2	67	
017-14116-009	Fulcrum; Master Guide; M. -Rmv.	2	67	
017-14117-005	Box Guide	2	67	
017-14120-103	Master Guide; M. -Rmv.	1	67	
017-14121-002	Spring; Master Guide; M. -Rmv.	1	67	

Part No.	Part Name	Q'ty	Page	Unit Value
017-14122-009	Bracket; M. -Rmv. Solenoid	1	67	
017-14124-109	Upper Stay; M. -Rmv.	1	67	
017-14125-008	Guide Boss; M. -Rmv.	2	67	
017-14126-101	Base Plate; M. -Rmv.; A4	1	67	
017-14127-108	Guide Plate; M. -Rmv.; A4	1	67	
017-14128-104	Vertical Transport Roller (Down); A4	1	67	
017-14129-003	Shaft; M. -Rmv. Hook; A4	1	67	
017-14131-105	Upper Holder B; V. -Transport Roller	1	67	
017-14135-003	Upper Holder A; V. -Transport Roller	1	67	
017-14138-100	Vertical Transport Roller (Up); B4	1	67	
017-14141-100	Vertical Transport Roller (UP); A4	1	67	
017-14142-000	Set Plate F; M. -Rmv.	1	67	
017-14143-006	Set Plate R; M. -Rmv.	1	67	
017-14144-002	Fixing Plate F; M. -Rmv.	1	67	
017-14145-009	Fixing Plate R; M. -Rmv.	1	67	
017-14146-005	Bracket; Aero Guide Sheet	1	59	
017-14147-001	Aero Guide Sheet	1	59	
017-14148-008	Hook Spring F; M. -Rmv.	1	67	
017-14149-004	Hook Spring R; M. -Rmv.	1	67	
017-14151-203	Disposal Box	1	69	
017-14152-102	Disposal Box Cover	1	69	
017-14153-109	Disposal Box Cover B	1	69	
017-14154-008	Guide Plate; Disposal Box; B4	1	69	
017-14155-004	Lever Frame; Disposal Box	1	69	
017-14159-107	H. -Lever (F); Disposal Box	1	69	
017-14161-101	H. -Lever (R); Disposal Box	1	69	
017-14162-000	Guide Shaft; Disposal Box	1	69	
017-14163-007	Disposal Shaft	1	69	
017-14165-107	Shaft; Compression Plate	1	69	
017-14166-103	Compression Plate; Disposal Box	1	69	
017-14167-002	Guide Spring B; Disposal Box	1	69	
017-14171-000	Guide Plate; Disposal Box; A4	1	69	
017-15005-006	Frame A; M. -M.	1	63	
017-15006-002	Bracket; De-electricity Brush	1	63	
017-15007-106	Catch Roller (Upper)	1	63	
017-15008-005	Shaft; Load Roller	1	63	
017-15009-001	Load Roller	3	63	
017-15010-000	Cover A; M. -M.	1	63	
017-15011-006	Copy Guide Plate (Lower); B4	1	63	
017-15014-005	Copy Guide Plate (Lower); A4	1	63	
017-15015-001	Open/Close Hook II	1	63	
017-15017-004	Plate A; Stocker	1	59	
017-15018-000	Plate B; Stocker	1	59	
017-15101-005	Load Roller (Lower); M. -M.	1	59	
017-15102-001	Master Guide Plate	1	59	

Part No.	Part Name	Q'ty	Page	Unit Value
017-15103-008	Guide Plate; Load	1	59	
017-15104-004	Bracket; De-electricity Brush	1	59	
017-15107-003	Metal Fixing Plate	1	59	
017-15108-000	Fixing Plate; Bearing	1	59	
017-15111-000	Bracket; Master Sensor	1	59	
017-15113-003	Bracket; Wire Harness	1	3, 5	
017-15120-000	Set Guide Plate; B4	1	59	
017-15121-006	Set Guide Plate; A4	1	59	
017-15124-005	Stay; Set Guide Plate	2	59	
017-15213-008	Holder Stay R	1	59	
017-15214-004	Holder Stay F	1	59	
017-15217-003	Cover; Master Roll Holder	1	59	
017-15229-001	Flange R; Master Roll	1	60	
017-15234-005	Set Plate; Master Holder Cover	1	59	
017-15261-002	Master Roll Holder II; B4	1	59	
017-15265-008	Guide Flange B II; Master Holder	1	59	
017-15266-004	Guide Flange A II; Master Holder	1	59	
017-15269-003	Flange; Master Holder	1	59	
017-15270-001	Spring Holder; Guide Flange II	1	59	
017-15271-008	Master Roll Holder II; A4	1	59	
017-15273-000	Spring; Guide Flange II	1	59	
017-15274-104	Shaft; Guide Flange II	1	59	
017-15281-003	Guide Holder D; Master Holder	1	59	
017-15291-009	Tension Plate; Master Holder	1	59	
017-15292-005	Bracket; Tension Plate	1	59	
017-15293-001	Shaft; Tension Plate	1	59	
017-15294-008	Spring; Tension Plate	1	59	
017-15295-004	Tension Sheet; Master Holder	1	59	
017-15296-000	Flange F II; Master Roll	1	60	
017-15303-007	Cutter Cover	1	65	
017-15306-006	Bracket; Master Positioning Sensor	1	65	
017-15310-003	Master Guide Stopper Plate	1	65	
017-15311-000	Master Guide Stopper Cushion	1	65	
017-16001-209	ADF Base Frame	1	3	
017-16006-103	Bottom Blind Plate; ADF	1	3	
017-16007-002	Bracket B; Back Cover	1	3	
017-16008-009	Bracket A; Back Cover	1	3	
017-16009-005	Shaft; Original Tray	2	77	
017-16021-005	Rack Cover; ADF Cover	1	77, 79	
017-16101-009	Lift Base (F); Upper Cover	1	41	
017-16103-001	Lift Base (R); Upper Cover	1	41	
017-16107-007	Shaft Base; Upper Cover	2	41	
017-16121-000	Bracket; Upper Cover Set SW	1	3, 5	
017-16122-006	Shaft A; Upper Cover Set SW	1	3, 5	
017-16123-002	Shaft B; Upper Cover Set SW	1	3, 5	

Part No.	Part Name	Q'ty	Page	Unit Value
017-16124-106	Spring; Upper Cover Set SW	1	3, 5	
017-16201-208	Upper Rear Frame	1	3	
017-16206-005	PCB Bracket	1	3	
017-16211-106	Fulcrum; Hook Catch	2	3	
017-16244-101	Plate Spring; Interlock Switch	1	72	
017-16245-000	Shaft; Interlock Switch	2	72	
017-16250-004	Cover; Interlock Switch	1	41	
017-16253-100	Bracket; Interlock Switch	1	72	
017-16256-100	Lever; Interlock Switch	1	41	
017-16259-001	Fulcrum; Interlock Switch	1	41	
017-16321-106	Lift Arm (F); Upper Cover	1	41	
017-16322-102	Lift Arm (R); Upper Cover	1	41	
017-16325-101	Lift Spring (F); Upper Cover	1	41	
017-16326-108	Lift Spring (R); Upper Cover	1	41	
017-16328-003	Lift Collar; Upper Cover	2	41	
017-16331-101	Hook; Upper Cover	1	41	
017-16332-108	Lever; Upper Cover	1	41	
017-16333-007	Hook Spring; Upper Cover	1	41	
017-16334-003	Back Plate; Upper Cover	1	41	
017-16340-003	Frame; Upper Cover	1	41	
017-16348-004	Hook Shaft (R); Upper Cover	1	41	
017-16501-007	Original Guide Base (F); ADF	1	43, 45	
017-16502-003	Read Roller; ADF	1	47, 49	
017-16503-000	Frame; Shading	1	47, 49	
017-16504-006	Hook Plate; ADF	1	47, 49	
017-16505-002	Rib; Shading	1	47, 49	
017-16506-009	Original Guide Base (R); ADF	1	43, 45	
017-16507-307	Original Guide (F); ADF	1	47, 49	
017-16508-001	Frame B; Original Guide	1	43, 45	
017-16509-008	Bracket; De-electricity Brush; ADF	1	47, 49	
017-16510-006	Transfer Roller; ADF	1	47, 49	
017-16511-002	Pickup Arm; ADF	1	43, 45	
017-16512-009	Stripper Arm; ADF	1	43, 45	
017-16513-005	Exit Roller (Upper); ADF	1	47, 49	
017-16514-001	Open Lever; ADF	1	47, 49	
017-16516-004	Plate Cover R; ADF	1	43, 45	
017-16517-000	Sheet; Shading	1	47, 49	
017-16518-007	Bracket; ADF PCB	1	43, 45	
017-16519-003	Bracket; ADF Sensor	1	47, 49	
017-16520-001	Adj. Plate R; Scanner	1	43	
017-16521-008	Adj. Plate L; Scanner	1	43	
017-16522-004	Exit Pulley; ADF	1	47, 49	
017-16523-000	Main Gear; ADF	1	47, 49	
017-16524-007	Motor Cover; ADF	1	47, 49	
017-16525-003	Metal; 8M	2	43, 45	

Part No.	Part Name	Q'ty	Page	Unit Value
017-16526-000	Housing; 8P	4	47, 49	
017-16527-006	Stripper Collar; ADF	1	47, 49	
017-16528-002	Transfer Pulley; ADF	1	47, 49	
017-16529-009	Housing; Read Roller	2	47	
017-16530-007	Pulley A; ADF	4	47, 49, 53	
017-16531-003	Tension Pulley; ADF	1	47, 49	
017-16532-000	Shaft; Stripper Roller; ADF	1	47, 49	
017-16533-006	Pickup Roller (Upper); ADF	1	47, 49	
017-16534-002	Pulley; Read Roller	1	47	
017-16534-100	Pulley; Read Roller	1	49	
017-16535-009	Stripper Roller; ADF	1	47, 49, 53	
017-16537-001	Arm; Original Feed Solenoid	1	43, 45	
017-16538-008	Gear; ADF	1	47, 49, 53	
017-16539-004	Original Stripper Pad	1	43, 45	
017-16540-002	Metal; 6	3	43,45,47,49	
017-16542-005	Roller (Lower); ADF	3	43, 45, 51	
017-16543-001	Pickup Shaft; ADF	1	43, 45	
017-16544-008	Shaft; Stripper Arm	1	43, 45	
017-16545-004	De-electricity Brush A; ADF	2	47, 49	
017-16546-000	De-electricity Brush B; ADF	1	47, 49, 53	
017-16547-007	Spring; ADF Lever	1	47, 49	
017-16548-003	Spring; Stripper Arm	2	43, 45	
017-16549-000	Spring; Original Feed Solenoid	1	43, 45	
017-16550-105	Spring; Shading	1	47, 49	
017-16551-004	Cover; Original Feed Solenoid	1	43, 45	
017-16553-007	Spring R; ADF Hinge	1	43, 45	
017-16554-003	Spring L; ADF Hinge	1	43, 45	
017-16555-000	Roller Spring; ADF	5	43, 45, 51	
017-16557-002	Link Joint; Shading	1	47, 49	
017-16558-009	Link Plate; Shading	1	47, 49	
017-16559-005	Gear Cover; ADF	1	43, 45	
017-16560-003	Actuator; ADF SW	1	43, 45, 51	
017-16561-000	Metal; 8M (2)	4	47, 49	
017-16562-006	Spring; Read Roller	2	47, 49, 53	
017-16563-002	Spacer; ADF Hinge R	1	43, 45	
017-16564-009	Spacer; ADF Hinge L	1	43, 45	
017-16565-005	Upper Frame; ADF	1	47	
017-16565-102	Upper Frame; ADF	1	49	
017-16566-001	Bracket; ADF SW	1	43, 45	
017-16567-008	Tension Plate; ADF	1	47, 49	
017-16568-004	Fulcrum; Shading	1	47, 49	
017-16569-000	Side Frame L; Scanner	1	43	
017-16569-108	Side Frame (II) L; Scanner	1	45	
017-16570-009	Side Frame R; Scanner	1	43	
017-16570-106	Side Frame (II) R; Scanner	1	45	

Part No.	Part Name	Q'ty	Page	Unit Value
017-16571-005	ADF Motor	1	47, 49	
017-16572-001	Read Pulse Motor	1	47, 49	
017-16573-008	Original Feed Solenoid	1	43, 45	
017-16574-004	Shading Solenoid	1	47, 49	
017-16575-000	Original Det. Sensor	1	47, 49	
017-16576-007	Original Regist. Sensor	1	47, 49	
017-16577-003	Original Out Sensor	1	43	
017-16579-006	Original IN Sensor (Send)	1	47, 49	
017-16580-209	Original IN Sensor (Receive)	1	43, 45	
017-16581-000	ADF SW	1	43, 45	
017-16582-007	Wire Harness; ADF	1	43, 45	
017-16586-002	Link Plate; ADF	1	47, 49	
017-16587-009	Spacer; Exit Pulley	1	47, 49	
017-16588-005	Belt; 44	1	47, 49, 53	
017-16589-001	Belt; 120	1	47, 49	
017-16590-000	Belt; 56	1	47, 49	
017-16591-006	Fulcrum R; Hook Plate	1	47, 49	
017-16592-002	Spacer; Scanner Adj. Plate	4	43	
017-16593-009	Spacer; Shaft Hinge	2	43, 45	
017-16594-005	Sheet; Sensor	1	47, 49	
017-16595-001	Mount; Read Pulse Motor	1	47, 49, 53	
017-16596-008	Spring; Scanner Adj. Plate	2	43	
017-16597-004	Sheet F; Sensor	1	47, 49	
017-16598-000	Damper Plate; Pickup; ADF	1	43, 45, 51	
017-16599-007	Damper Plate; Shading	1	47, 49	
017-16600-005	Pickup Pad Holder; ADF	1	43, 45	
017-16601-001	Pickup Pad; ADF	1	43, 45	
017-16602-008	Sheet Guide (A); ADF	1	47, 49	
017-16603-004	Sheet Guide (B); ADF	1	47, 49	
017-16604-108	Original Out Sensor	1	45	
017-16605-007	Exit Wheel; ADF	4	43, 45, 51	
017-16606-003	Housing (A); Read Roller	1	49	
017-16607-000	Housing (B); Read Roller	1	49	
017-17007-006	Mylar Sheet; Panel SW	1	71	
017-17008-002	Sheet B; Panel	1	71	
017-17009-009	Sheet A; Panel	2	71	
017-17050-009	Bracket A; Keyboard	1	71	
017-17051-005	Bracket B; Keyboard	1	71	
017-17060-101	Key Board Cover	1	71	
017-17101-100	ADF Cover	1	77	
017-17102-106	Cover B; ADF	1	43, 45	
017-17103-005	Original Side Guide (R)	1	77	
017-17104-001	Original Side Guide (L)	1	77	
017-17105-008	Slide Rack; Original Holder	2	77, 79	
017-17111-008	Upper Cover	1	41	

Part No.	Part Name	Q'ty	Page	Unit Value
017-17121-100	Original Tray	1	77	
017-17200-000	Upper Hinge	1	3, 5	
017-17210-006	Bottom Plate (Right)	1	3, 5	
017-17211-002	Bracket; Hinge	1	3, 5	
017-17214-001	Lower Hinge; Front	1	77, 79	
017-17217-000	Bottom Plate (Left)	1	3, 5	
017-17220-109	Carrying Grasp	4	3, 5	
017-17221-008	Mount; Connector	1	3, 5	
017-17222-004	Blind Plate C; Connector	2	3, 5	
017-17223-000	Blind Plate D; Connector	3	3, 5	
017-17224-007	Mount II; Connector	1	3, 5	
017-17230-007	Bracket B; Back Cover	1	3, 5	
017-17232-107	Side Cover; Power Supply	1	71	
017-17233-103	Cover Plate; Power Supply	1	72	
017-17242-005	Bracket (L); Option PCB	1	75	
017-17243-001	Bracket (Upper); Option PCB	1	75	
017-17244-008	Bracket (Lower); Option PCB	1	75	
017-17245-004	Bracket (R); Option PCB	1	75	
017-18100-204	Bracket (R); System PCB	1	75	
017-18101-103	Bracket (L); System PCB	1	75	
017-18102-100	Reinforce Plate; Image PCB	1	75	
017-18103-106	Reinforce Plate; System PCB	1	75	
017-18130-103	Bracket; Motor Control PCB	1	75	
017-51000-100	ADF PCB	1	43, 45, 53	
017-51003-109	Image Processing PCB	1	75	
017-51004-300	Image Processing PCB S	1	75	
017-51006-205	Motor Control PCB	1	75	
017-51008-003	Power Supply PCB IV H100	1	71	
017-51009-000	Power Supply PCB IV H200	1	71	
017-51010-008	Sub-Power Supply PCB	1	63	
017-51011-500	System PCB	1	75	
017-51012-000	Option PCB A	1	75	
017-51013-007	Panel Control PCB	1	71	
017-51014-208	Panel Display PCB	1	71	
017-51015-000	Panel SW PCB	1	71	
017-51016-006	Panel Control PCB II	1	71	
017-51017-100	Panel Display PCB II	1	71	
017-51018-009	Panel SW PCB II	1	71	
017-51020-305	Drum Control PCB	1	23	
017-51022-006	Option PCB B	1	75	
017-55000-007	Wire Harness; S. Image Scanner	2	43, 45, 63, 75	
017-55003-006	Wire Harness; S. ADF	2	43, 45, 75	
017-55007-303	Inlet Terminal; 100V	1	72, 75	
017-55008-407	Wire Harness; CN7	1	75	
017-55009-004	Wire Harness; CN8	2	29, 72, 75	

Part No.	Part Name	Q'ty	Page	Unit Value
017-55010-304	Wire Harness; CN9	1	75	
017-55011-106	Wire Harness; S. Power	1	63	
017-55012-005	Wire Harness; System-Power	1	71, 75	
017-55013-001	Wire Harness; Image-Power	1	71, 75	
017-55014-105	Wire Harness; Panel-Power	1	71	
017-55015-004	Wire Harness; Motor Con. -Power	1	71, 75	
017-55016-000	Wire Harness; Panel-System	1	71, 75	
017-55017-007	Wire Harness; Motor Con. -System	1	75	
017-55018-100	Wire Harness; CN9; 49	1	75	
017-55019-000	Wire Harness II; Motor Con. -Power	1	71, 75	
017-55020-008	Wire Harness; TPH-Power	1	63	
017-55023-104	Wire Harness; M. -M. -Image	1	63, 75	
017-55025-107	Wire Harness; M. -M. -Image; T40	1	63, 75	
017-55028-106	Wire Harness; Drum (R)	1	23	
017-55029-005	Wire Harness; Drum (L)	1	23	
017-55031-000	Wire Harness; Elevator Motor	1	75	
017-55032-006	Wire Harness; Feed Tray Safety SW	1	7	
017-55033-207	Wire Harness; P. -F. -T.	1	9	
017-55035-102	Wire Harness; M. -Rmv.	1	67	
017-55036-001	Wire Harness; Suction	1	37	
017-55037-300	Inlet Terminal; 200V	1	72, 75	
017-55038-209	Wire Harness II; P. -F. -T.	1	11	
017-55039-108	Wire Harness; Guide Plate; 49	1	21	
017-55042-001	Flexible Flat Wire; Panel	1	71	
017-55043-008	Flexible Flat Wire 14P; Panel	1	71	
017-55048-000	Wire Harness; RA-TM2400	1	85	
017-55049-006	Wire Harness; RA-RC Sorter Inner	1	85	
017-55052-007	Wire Harness; Counter III	1	85	
017-60000-007	Master Positioning Sensor	1	65	
017-60001-003	Master Removal Sensor	1	67	
017-60003-006	Paper Sensor	1	21	
017-60005-009	Cassette Det. Sensor; P. -F. -T.	1	11	
017-60006-200	Sensor; KR820	2	59, 67	
017-60007-001	Upper Limit Sensor	1	7	
017-60010-002	Switch A	2	3, 5, 67	
017-60011-009	Clamp Safety Switch	1	31	
017-60012-005	Paper Receiving Sensor (Send)	1	35, 37	
017-60013-001	Paper Receiving Sensor (Receive)	1	33	
017-60014-105	Master End Sensor (Send)	2	59	
017-60015-004	Master End Sensor (Receive)	1	63	
017-60016-000	Angular Sensor	1	31	
017-60018-003	Stack Paper Feeding SW	1	21	
017-60019-107	Bottle Set SW II	1	23	
017-60020-300	Drum PCB	1	24	
017-60021-101	Image Scanner	1	43, 45	

Part No.	Part Name	Q'ty	Page	Unit Value
017-60022-108	Image Scanner; 49	1	43, 45	
017-60025-000	Micro-SW Ass'y 3	1	7	
017-60031-000	Encoder Sensor	1	13, 17	
017-65000-005	Thermal Pressure Motor III Ass'y	1	63	
017-65002-008	Elevator Motor	1	7	
017-65003-004	M. -Rmv. Vertical Transport Motor	1	67	
017-65004-205	Clamp Motor	1	31	
017-65005-309	Pressure Control Motor	1	31	
017-65006-003	Wing Motor; Suction	1	37	
017-65008-006	Suction Motor	1	35	
017-65010-108	Separation Fan	1	59	
017-65011-007	Loading Fan; Stocker	1	59	
017-65015-002	Loading Pulse Motor	1	31	
017-65016-009	Inking Motor	1	24	
017-70003-	Motor-CTL ROM	1	75	
017-80002-	System ROM; RA	1	75	
017-91206-002	Pressure Det. Ass'y		17	
017-91211-103	Unit/Main Motor; T		13, 17	
017-91216-105	Main Motor Ass'y; T	1	13, 17	
017-91225-007	Main Shaft Ass'y; B4		17	
017-91226-003	Main Shaft Ass'y; A4		17	
017-91230-000	Pressure Link Ass'y		17	
017-91235-002	Face Plate; Pressure Shaft	1	13, 17	
017-91240-006	Unit/Print Positioning Motor		31	
017-91266-005	Pressure Control Motor Ass'y		31	
017-91310-101	Timing Roller Ass'y		21	
017-91500-105	Unit/Paper-Feed Tray		9	
017-91501-101	Unit/Paper-Feed Tray; US		9	
017-91502-108	Unit/Paper-Feed Tray II		11	
017-91503-007	Unit/Paper-Feed Tray II; US		11	
017-91610-008	Shaft; Elevator	1	7	
017-91620-003	Unit/Elevator Motor		7	
017-91701-003	Unit/Guide Plate; 49		21	
017-91702-000	Unit/Stripper		21	
017-91800-001	Feed Tray Safety SW Ass'y		7	
017-91810-007	Scraper Ass'y		7	
017-91831-004	P. -F. Pressure Adj. Lever Ass'y		7	
017-92100-003	Drum Holder IV Ass'y		29	
017-92101-000	Unit/Drum Screen; B4		27	
017-92102-006	Unit/Drum Screen; US		27	
017-92103-002	Unit/Drum Screen; A4		27	
017-92106-001	Ass'y; Separator Guide Plate II		27	
017-92110-009	Drum Body Ass'y; B4	1	27	
017-92111-005	Drum Body Ass'y; US	1	27	
017-92112-001	Drum Body Ass'y; A4	1	27	

Part No.	Part Name	Q'ty	Page	Unit Value
017-92210-003	Unit/Squeegee		23	
017-92220-009	Unit/Ink Pump		24	
017-92300-002	Unit/Drum Frame		23	
017-92400-007	Unit/Clamp		31	
017-93200-109	Suction Unit		35	
017-93201-008	Suction Unit W		37	
017-93215-009	Paper Receiving Sensor (Receive) Ass'y	1	33	
017-93220-002	Angular Sensor Ass'y		31	
017-93225-004	Suction Fan Ass'y	1	37	
017-93300-006	Separation Fan Ass'y		59	
017-94100-019	Unit/Master Removal; B4		67	
017-94101-015	Unit/Master Removal; A4		67	
017-94110-014	Holder Ass'y; V. -Transport Roller; B4		67	
017-94111-010	Holder Ass'y; V. -Transport Roller; A4		67	
017-94130-104	Unit/Master Disposal Box; B4		69	
017-94135-106	Unit/Master Disposal Box; A4		69	
017-95000-107	Unit/Master Making		63	
017-95001-103	Unit/Master Making; 49		63	
017-95002-100	Unit/Master Making; 59		63	
017-95010-005	Master Loading Unit SW Ass'y		59	
017-95035-008	T-TPH Ass'y (400)		63	
017-95036-004	T-TPH Ass'y (300)		63	
017-95037-000	K-TPH Ass'y (400)		63	
017-95050-007	Unit/Loading Pulse Motor	1	31	
017-95070-008	Set Guide Plate Ass'y; B4		59	
017-95071-004	Set Guide Plate Ass'y; A4		59	
017-95095-000	Stocker Ass'y	1	59	
017-95100-004	Master Sensor Ass'y		59	
017-95240-000	Unit/Master Roll Holder II; B4		59	
017-95241-007	Unit/Master Roll Holder II; A4		59	
017-95245-002	Guide Flange II Ass'y	1	59	
017-95250-006	Damper Gear Ass'y	1	59	
017-95255-008	Tension Ass'y; Master Holder	1	59	
017-95300-100	Unit/Cutter; B4		65	
017-95301-107	Unit/Cutter; A4		65	
017-96000-100	Unit/ADF		45, 49	
017-96100-105	Unit/Upper Rear Frame		3	
017-96110-100	Upper Cover Set SW Ass'y		3	
017-96200-002	Interlock Switch		72	
017-97005-009	Unit/Operation Panel; 42 US		71	
017-97006-005	Unit/Operation Panel; 42 Pic.		71	
017-97007-001	Unit/Operation Panel; 42		71	
017-97015-004	Unit/Operation Panel; 49 US		71	
017-97016-000	Unit/Operation Panel; 49 Pic.		71	
017-97017-007	Unit/Operation Panel; 49		71	

Part No.	Part Name	Q'ty	Page	Unit Value
017-97025-000	Unit/Operation Panel; 4050 US		71	
017-97026-006	Unit/Operation Panel; 4050 Pic.		71	
017-97027-002	Unit/Operation Panel; 4050		71	
017-97052-007	Sub-Panel; 42 US	1	71	
017-97053-003	Sub-Panel; 42 Pic.	1	71	
017-97054-000	Sub-Panel; 42	1	71	
017-97055-006	Sub-Panel Ass'y; 42 US	1	71	
017-97056-002	Sub-Panel Ass'y; 42 Pic.	1	71	
017-97057-009	Sub-Panel Ass'y; 42	1	71	
017-97062-002	Sub-Panel; 49 US	1	71	
017-97063-009	Sub-Panel; 49 Pic.	1	71	
017-97064-005	Sub-Panel; 49	1	71	
017-97065-001	Sub-Panel Ass'y; 49 US	1	71	
017-97066-008	Sub-Panel Ass'y; 49 Pic.	1	71	
017-97067-004	Sub-Panel Ass'y; 49	1	71	
017-97070-005	Sub-Panel Ass'y; 4050 US	1	71	
017-97071-001	Sub-Panel Ass'y; 4050 Pic.	1	71	
017-97072-008	Sub-Panel Ass'y; 4050	1	71	
017-97073-004	Sub-Panel; 4050 US	1	71	
017-97074-000	Sub-Panel; 4050 Pic.	1	71	
017-97075-007	Sub-Panel; 4050	1	71	
017-97100-001	Unit/ADF Cover		77	
017-97110-007	Unit/Upper Cover		41	
017-97300-000	Wire Harness; JS III	1	85	
018-16001-206	Slide Guide; FB-Scanner	1	55	
018-16002-008	Scanner Holder (F)	1	55	
018-16003-101	Scanner Holder (R)	1	55	
018-16004-000	Adj. Pin; Scanner Holder	2	55	
018-16005-007	Guide Wheel; Carriage	2	55	
018-16006-003	Arm (L); Carriage	1	55	
018-16009-002	Arm (R); Carriage	1	55	
018-16011-007	Boss; Carriage	1	55	
018-16012-003	Arm Spring; Carriage	1	55	
018-16013-204	Carriage; Image Scanner	1	55	
018-16017-005	Drive Pulley Shaft; FB-Scanner	1	55	
018-16018-001	Drive Pulley Holder; FB-Scanner	1	55	
018-16019-008	Belt Stand Plate; FB-Scanner	1	55	
018-16020-006	Belt Holder Plate; FB-Scanner	1	55	
018-16022-009	Tension Shaft; FB-Scanner	1	55	
018-16023-005	Tension Holder; FB-Scanner	1	55	
018-16024-001	Tension Plate; FB-Scanner	1	55	
018-16027-000	Tension Spring; FB-Scanner	1	55	
018-16028-007	Bracket; R Pulse Motor	1	56	
018-16029-003	Shock-Absorbent Rubber; R Pulse M.	1	56	
018-16030-001	Wire Stand; FB-Image	1	55	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16031-105	Bracket; FB-Pos. Sensor	2	55	
018-16032-004	Actuator; Stage Cover Sensor	1	55	
018-16035-003	Actuator Spring; Stage Cover Sensor	1	55	
018-16036-107	Slide Shaft; FB-Scanner	2	55	
018-16037-006	Adj. Plate; FB-Slide Shaft	2	55	
018-16038-002	Glass Holder (L)	1	55	
018-16039-009	Glass Holder (R)	1	56	
018-16040-104	Stage Glass	1	55	
018-16042-107	Original Stopper	1	55	
018-16043-006	Cover Plate; Image Flexible Wire	1	55	
018-16044-002	Ground Plate; FB-Scanner	1	55	
018-16045-009	Core Holder	1	55	
018-16047-109	Bracket; Stage Cover Sensor	1	55	
018-16050-304	Main Frame; FB-Scanner	1	55	
018-16060-105	Back Frame; FB-Scanner	1	55	
018-16064-003	Blind Plate; FB-Back Frame	1	55	
018-16065-000	Wire Harness Tubing	1	56	
018-16066-006	Shading Plate (L)	1	55	
018-16067-002	Shading Plate (R)	1	55	
018-16068-106	Carriage Weight (Lower)	1	55	
018-16069-102	Carriage Weight (Upper)	2	55	
018-16201-000	Fulcrum Shaft; FB	1	5	
018-16202-007	Stepped Screw; M6 x 10	2	5	
018-16203-100	Bottom Plate; FB-Scanner	1	55	
018-16207-009	Fulcrum Support Plate; FB	1	5	
018-16210-000	Damper Bottom Bracket (F)	1	56	
018-16212-002	Damper Bottom Bracket (R)	1	56	
018-16214-102	Support Shaft Lock	1	56	
018-16215-001	Support Shaft Holder; FB-Scanner	1	55	
018-16216-008	Lock Plate; Support Shaft	2	5	
018-16217-004	Hook Shaft; FB	1	55	
018-16218-000	Shaft; Hook Base	2	55	
018-16220-005	Hook Base (F); FB-Hook Shaft	1	55	
018-16222-008	Hook Base (R); FB-Hook Shaft	1	55	
018-16223-004	Spring; Hook Shaft	2	55	
018-16224-000	Open Lever; Hook Shaft	1	55	
018-16225-104	Bracket (F); Hook Shaft	1	55	
018-16227-000	Bracket (R); Hook Shaft	1	55	
018-16229-002	Hook Plate (F); FB	1	5	
018-16230-000	Hook Plate (R); FB	1	5	
018-16231-104	Upper Rear Frame; FB	1	5	
018-16235-002	Bracket; Back Cover	1	5	
018-16236-106	Bracket; Interlock Switch FB	1	72	
018-16239-105	Bracket B; Interlock Switch FB	1	72	
018-16241-002	Bracket; Damper Stopper	1	5	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16242-009	Spring; Damper Stopper	1	5	
018-16243-102	Cap; Damper Stopper	1	5	
018-16244-001	Bracket; PI	1	5	
018-16245-008	Blind Plate; Upper Rear Frame	1	5	
018-16249-003	Boss; Interlock Switch FB	1	72	
018-16250-001	Damper Hook; FB-Scanner	2	55	
018-16253-000	Hinge Bracket; FB-Scanner	2	55	
018-16254-007	Plate Spring; Interlock Switch FB	1	72	
018-16255-003	Balance Weight; FB	8	55	
018-16301-200	Scanner Cover (F); FB	1	79	
018-16302-303	Scanner Cover (R); FB	1	79	
018-16303-300	Scanner Cover (Left); FB	1	79	
018-16304-209	Scanner Cover (Right); FB	1	79	
018-16305-205	Cover B; FB-ADF	1	51	
018-16306-007	ADF Cover (F); FB	1	79	
018-16307-003	ADF Cover (R); FB	1	79	
018-16308-000	ADF Cover (Right); FB	1	79	
018-16309-200	Original Tray; FB	1	79	
018-16310-004	Original Side Guide	2	79	
018-16401-107	Stage Cover; FB	1	81	
018-16403-002	LCD Cover; Digitizer	1	83	
018-16406-206	PCB Cover; Stage Cover	1	81, 83	
018-16411-102	Original Holder Cover (Upper); Stage Cover	1	81	
018-16412-303	Original Holder Cover (Lower); Stage Cover	1	81	
018-16413-008	Cover B; Stage Cover	1	81	
018-16415-108	Balance Weight A; Stage Cover	1	81	
018-16416-104	Balance Weight B; Stage Cover	1	81	
018-16417-100	Balance Weight C; Stage Cover	1	81	
018-16418-000	Cord Cap; Stage Cover	1	81	
018-16420-004	Actuator Plate; Stage Cover	1	81, 83	
018-16425-006	Stage Pad (W); Stage Cover	1	81, 83	
018-16427-009	Stylus Pen III	1	83	
018-16431-006	LCD Filter; Digitizer	1	83	
018-16501-004	Stripper Pad; FB-ADF	1	51	
018-16502-000	Glass Plate; Image Scanner	1	51	
018-16503-007	Main Gear; FB-ADF	1	53	
018-16504-003	Stepped Screw; M4 x 13	1	53	
018-16506-006	Stopper Plate; FB-ADF	1	53	
018-16507-100	Tension Plate; FB-ADF	1	53	
018-16508-009	Side Frame L; FB-ADF	1	51	
018-16509-005	Side Frame R; FB-ADF	1	51	
018-16510-003	Tension Pulley B; FB-ADF	1	53	
018-16512-006	Upper Frame; FB-ADF	1	53	
018-16513-002	Transfer Roller; FB-ADF	1	53	
018-16514-009	Exit Roller (Upper); FB-ADF	1	53	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16515-005	Original Guide Base (R); FB-ADF	1	51	
018-16516-109	Read Roller	1	53	
018-16517-008	Bracket; ADF SW	1	51	
018-16518-101	Motor Cover; FB-ADF	1	53	
018-16519-000	Original Guide (F); FB-ADF	1	53	
018-16520-009	Original Guide Base (F); FB-ADF	1	51	
018-16521-005	Guide Plate; FB-ADF	1	53	
018-16522-001	Bracket; ADF Motor	1	53	
018-16523-008	Hook Plate; FB-ADF	1	53	
018-16526-007	Spacer; WHG	1	53	
018-16527-003	Arm; Pickup Solenoid	1	51	
018-16528-000	Frame B; FB-Original Guide	1	51	
018-16529-006	Stripper Arm; FB-ADF	1	51	
018-16530-004	Pickup Arm; FB-ADF	1	51	
018-16531-000	Pickup Pad Holder; FB-ADF	1	51	
018-16532-007	Open Lever; FB-ADF	1	53	
018-16533-003	Glass Holder R; Image Scanner	1	51	
018-16534-000	Glass Holder L; Image Scanner	1	51	
018-16535-006	Bracket; Original Out Sensor	1	53	
018-16536-002	Bracket; Original Det. Sensor	1	53	
018-16537-009	Bracket; Original Regist. Sensor	1	53	
018-16538-005	Pickup Shaft; FB-ADF	1	51	
018-16539-001	Shaft; Stripper Roller; FB-ADF	1	53	
018-16540-000	Pickup Roller (Upper); FB-ADF	1	53	
018-16541-006	Collar; Stripper Roller	1	53	
018-16542-100	Pulley; Transfer Roller	1	53	
018-16543-009	Tension Pulley A; FB-ADF	2	53	
018-16544-005	Pulley; Read Roller	1	53	
018-16545-001	Exit Pulley; FB-ADF	1	53	
018-16546-008	Spacer; Main Gear; FB-ADF	1	53	
018-16547-004	Metal; 8P	2	53	
018-16548-000	Metal; 8M	5	51, 53	
018-16549-007	Housing; Exit Roller	2	53	
018-16550-005	Housing; Read Roller	2	53	
018-16551-001	Metal; 6	2	51	
018-16552-008	Spacer; Exit Roller	1	51, 53	
018-16553-004	Spring; Stripper Arm	1	51	
018-16554-000	Metal; Exit Roller	1	51	
018-16555-007	De-electricity Brush A; FB-ADF	2	53	
018-16556-003	Spring; Open Lever	2	53	
018-16557-000	Spring; Pickup Solenoid	1	51	
018-16558-006	Spring R; FB-ADF	1	53	
018-16559-002	Spring L; FB-ADF	1	53	
018-16560-000	Pickup Shaft; FB-ADF	1	51	
018-16561-007	ADF Motor; FB	1	53	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16562-003	Pickup Solenoid; FB-ADF	1	51	
018-16563-000	Read Pulse Motor; FB-ADF	1	53	
018-16564-006	Original Det. Sensor	1	53	
018-16565-002	Original Regist. Sensor	1	53	
018-16566-009	Original Out Sensor	1	53	
018-16567-005	Original IN Sensor (Send)	1	53	
018-16568-001	Original IN Sensor (Receive); FB-ADF	1	51	
018-16569-008	Wire Harness; Original IN Sensor	1	51	
018-16570-006	ADF SW; FB	1	51	
018-16571-002	Wire Harness; FB-ADF SW	1	51	
018-16572-009	Belt B; 56	1	53	
018-16574-001	Pickup Pad; FB-ADF	1	51	
018-16575-008	Collar; Pickup Roller; FB-ADF	1	53	
018-16576-004	Sheet Guide; FB-ADF	2	53	
018-16577-000	Bushing; FB-ADF	3	53	
018-16578-007	Free Bushing	1	51	
018-16579-003	Sheet; Pickup; FB-ADF	2	51	
018-16580-001	Spacer; Stripper; FB-ADF	1	51	
018-16581-008	Bushing (1); ADF Motor	1	53	
018-16582-004	Bushing (2); ADF Motor	1	53	
018-16583-000	Bushing (3); ADF Motor	1	53	
018-16584-007	Sheet; Original Guide Base (F)	2	51	
018-16585-003	Belt; 118	1	53	
018-18107-001	Bracket; Trimming PCB II	2	75	
018-51000-107	Trimming PCB II	1	75	
018-51004-005	Digitizer PCB III	1	83	
018-51005-206	Image Processing PCB F	1	75	
018-51006-008	Digitizer Power PCB	1	83	
018-55000-101	Image Flexible Wire	1	55	
018-55001-108	Wire Harness; FB	1	55	
018-55002-007	Wire Harness; Image (FB)	1	56, 75	
018-55003-003	Wire Harness; ADF (FB)	1	53, 56, 75	
018-55006-002	Wire Harness; FB	1	56, 75	
018-55007-009	Wire Harness; Digitizer III	1	83, 85	
018-55008-005	Wire Harness; Image-Digitizer	1	85	
018-55013-009	Ground Wire II; Digitizer	1	83	
018-55014-005	Wire Harness; Digitizer Power	1	83	
018-60000-004	Original Det. Sensor; FB	1	55	
018-60021-206	Image Scanner; CIPSMA301	1	55	
018-60022-202	Image Scanner; CIPSMA401	1	55	
018-65000-002	R Pulse Motor; FB	1	56	
018-70010-008	LCD ROM; Digitizer	1	83	
018-70011-004	DGT ROM; Digitizer	1	83	
018-70013-104	INF ROM (ST); Digitizer	1	83	
018-70014-003	INF ROM (OP1); Digitizer	1	83	

Part No.	Part Name	Q'ty	Page	Unit Value
018-70015-000	INF ROM (OP2); Digitizer	1	83	
018-70016-006	INF ROM (OP3); Digitizer	1	83	
018-70017-002	INF ROM (OP4); Digitizer	1	83	
018-80000-	System ROM; RA (FB)	1	75	
018-96040-053	Unit/Scanner; FB		55	
018-96050-008	Flat Bed PCB	1	55	
018-96075-000	Image Flexible Wire Ass'y		55	
018-96085-006	Ass'y/Hook Shaft; FB		55	
018-96100-102	Unit/Upper Rear Frame; FB		5	
018-96105-104	Interlock Switch; FB		72	
018-96200-018	Unit/Stage Cover		81	
018-96210-005	Stage Cover Hinge Ass'y	2	81	
018-96220-000	Ass'y/Digitizer Stage Cover; FB		83	
018-96600-008	Original Tray Ass'y; FB		79	
018-97005-006	Unit/Operation Panel; 59 US		71	
018-97006-002	Unit/Operation Panel; 59 Pic.		71	
018-97007-009	Unit/Operation Panel; 59		71	
018-97010-000	Unit/Operation Panel; 43 US		71	
018-97011-006	Unit/Operation Panel; 43 Pic.		71	
018-97012-002	Unit/Operation Panel; 43		71	
018-97055-003	Sub-Panel Ass'y; 59 US	1	71	
018-97056-000	Sub-Panel Ass'y; 59 Pic.	1	71	
018-97057-006	Sub-Panel Ass'y; 59	1	71	
018-97060-007	Sub-Panel Ass'y; 43 US	1	71	
018-97061-003	Sub-Panel Ass'y; 43 Pic.	1	71	
018-97062-000	Sub-Panel Ass'y; 43	1	71	
018-97065-009	Sub-Panel; 59 US	1	71	
018-97066-005	Sub-Panel; 59 Pic.	1	71	
018-97067-001	Sub-Panel; 59	1	71	
018-97070-002	Sub-Panel; 43 US	1	71	
018-97071-009	Sub-Panel; 43 Pic.	1	71	
018-97072-005	Sub-Panel; 43	1	71	
204-03310-019	Spacer; Paper Feed Clutch	2	13	
408-02300-001	Battery	1	83	
408-02301-008	Battery; CR-2450	1	75	
435-00018-004	TDK Core; HF70SH40 x 1.3 x 8	1	55	
443-00120-501	Micro-SW; E21-51N	1	60	
443-00120-609	Micro-SW; E21-91N	5	29, 37, 63	
443-00120-900	Micro-SW; E23-91	1	65	
443-00121-109	Micro-SW; 21-52N	1	67	
443-00121-400	Micro-SW; E21-51H-009	1	3, 5	
443-00210-004	Micro-SW; DDIL-AIAA	4	72	
443-02000-600	Micro-SW; AM50630C331	2	7, 11	
443-12000-005	Power Switch; JWZ2120-2001	1	72	
443-30002-007	Sensor K; PS-R11LB	1	9, 11	

Part No.	Part Name	Q'ty	Page	Unit Value
443-30003-003	Sensor; LG-203D	3	7, 13, 17	
443-30003-003	Sensor K; LG-203D	3	55	
443-30005-006	Sensor; GP1A71A	1	18	
479-10002-003	ROM Cover A	1	83	
479-10003-000	ROM Cover B	2	83	
484-00000-800	Pilot Lamp	1	24	
485-00001-804	Fuse 8A 125V 5.2 ULTSC	1	72	
485-00002-401	Fuse 10A 125V 5.2 ULTSC	1	72	
485-00003-203	Fuse 3.15A 250V 5.2 SET	6	72	
485-00003-300	Fuse 5A 250V 5.2 SET	1	72	
485-00003-408	Fuse 3.15A 125V ULTSC	6	72	
485-01420-002	Fuse 1A 250V 5.2SD6	2	72	
485-01421-009	Fuse 1A 250V 5.2 ET	2	72	
485-02520-000	Fuse 6.3A 250V 5.2 ET	1	72	
488-00013-103	Power Cord; 100V	1	75	
488-00014-100	Power Cord; US	1	75	
488-00015-106	Power Cord; 200V	1	75	
488-90003-101	Ground Wire; U3-100-R3	1	63	
488-90008-103	Ground Wire; R3-400-R4	1	81	
488-90009-002	Ground Wire; P. -F. -T.	1	9, 11	
550-20059-108	Seal; P. -F. -T. Down	1	67	
550-20087-004	Seal; Paper Guiding Arm	1	39	
550-20118-104	TPH Seal	1	63	
550-20226-004	Seal; Paper Guiding Arm; Pic.	1	39	
550-20584-008	Seal; P. -Rcv. -T. Pos.	1	35, 37	
550-20590-105	Seal; P. -F. -T.	1	9, 11	
550-20652-208	Emblem; RA4200	1	77	
550-20662-203	Seal; Ink (Black)	1	24	
550-20663-200	Seal; Ink (Black); Pic.	1	24	
550-20665-105	Cover; Drum Holder	1	29	
550-20666-101	Cover; Drum Holder; Pic.	1	29	
550-20669-003	Seal; Setting Master	1	60	
550-20671-105	Seal; M. -M.	1	63	
550-20672-101	Seal; M. -M; Pic.	1	63	
550-20677-103	Seal; Image Scanner	1	43, 45	
550-20678-100	Seal; Image Scanner; Pic.	1	43, 45	
550-20682-107	Seal; Original Size	1	41, 79	
550-20687-001	Seal; P. -Feed Pressure	1	7	
550-20688-008	Seal; P. -Feed Pressure; Pic.	1	7	
550-20690-002	Seal; Master Disposal	1	69	
550-20691-009	Seal; Master Disposal; Pic.	1	69	
550-20693-001	Seal; Set Disposal Box	1	69	
550-20694-008	Seal; Set Disposal Box; Pic.	1	69	
550-20711-107	Seal; Master Cut	1	3, 5	
550-20712-103	Seal; Master Cut; Pic.	1	3, 5	

Part No.	Part Name	Q'ty	Page	Unit Value
550-20716-001	Emblem; RA4900	1	77	
550-20750-005	Emblem; RA5900	1	79	
550-20760-000	Seal; Image Scanner	1	51	
550-20764-006	Digitizer Seal; Ja • US	1	83	
550-20768-001	Emblem; RA4300	1	79	
550-20770-006	Emblem; RA4050	1	77	
550-20861-001	Digitizer Seal; Gr	1	83	
550-20862-008	Digitizer Seal; Fr	1	83	
550-20863-004	Digitizer Seal; It	1	83	
550-20864-000	Digitizer Seal; Sp	1	83	
550-20865-007	Digitizer Seal; In	1	83	
550-20866-003	Digitizer Seal; Ch	1	83	
550-20867-000	Digitizer Seal; Kr	1	83	
600-20049-009	Bearing; 606ZZ	1	55	
600-50046-004	Bearing; FLAWBC6-12ZZA	2	37, 55	
600-50059-017	Bearing; FLW688ZZ	9	9,11,21,35,37,59	
600-50061-003	Bearing; FL608ZZ	1	13	
607-09001-003	Metal; S14 x 18 x 4.5	2	5	
607-10000-010	Metal; F3 x 5 x 3; 8 x 1.4	1	23	
607-11000-200	Metal; F4 x 7 x 6; 10 x 1.5	4	63	
607-11001-002	Metal; F4 x 6 x 2.2; 8 x 1	3	18, 37	
607-12001-006	Metal; F5 x 10/9 x 4; 12 x 1.5	1	7	
607-13000-003	Metal; F6 x 10/9 x 4; 12 x 1.5	4	13, 17, 37, 67	
607-13000-402	Metal; F6 x 10/9 x 6; 12 x 1.5	2	21, 67	
607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	1	7, 21, 33	
607-15000-809	Metal; F8 x 16 x 6; 18 x 2	4	59	
607-15002-003	Metal; F8 x 12 x 5; 16 x 2	2	17	
607-16000-403	Metal; F10 x 15/14 x 5.5; 20 x 2.5	1	7	
607-16000-802	Metal; F10 x 18/16 x 5; 22 x 1.5	2	7	
607-16000-900	Metal; F10 x 16 x 6; 19 x 2; 14.5 x 1	2	23	
607-17000-105	Metal; F12 x 18 x 10; 24 x 2.5	2	21	
607-50800-109	Washer; TW0815	1	17	
607-50806-301	Liner; R-ML0806	2	59	
607-70815-005	Washer; R-WAS8399H	1	13	
610-00002-002	Damper; FB	2	56	
611-01420-000	Pulley; f14 x 8	1	55	
611-30090-000	Pulley; P63/20-2M-6; HTD	1	55	
611-42100-001	Pulley; P21-3M060 (HTD)	1	7	
611-42600-004	Pulley; P26-3M060 (HTD)	1	7	
612-03103-009	Gear B; 1.25 x 14	2	67	
620-20503-004	Belt; B50M x L3.2	1	59	
620-20714-005	Belt; B71M x L4.8	1	31	
620-21309-104	Squeegee Belt; B130/65M x L9.5	1	23	
620-21559-003	Belt; B115M x L9.5	1	31	
620-22364-001	Belt; B236M x L-4.8	1	35, 37	

Part No.	Part Name	Q'ty	Page	Unit Value
620-31776-002	Belt; 177-3M-6	1	7	
620-32916-002	Belt; 291-3M-6	1	67	
620-37506-007	Belt; 750-3M-6	1	13, 17	
620-48309-009	Belt; 830-5M-15	1	13, 17	
620-62256-007	Belt; B60S3M225	1	37	
620-82006-007	Belt; 106100 x 6 HTD	1	55	
620-89996-002	Belt; 106614 x 6 HTD	1	55	
634-08100-005	Collar; f8.2 x 10	2	56	
635-11307-009	Stepped Screw; 3 x 7	10	81	
638-80801-009	Ring Washer; 8.2 x 10.2 x 1	1	13, 17	
638-90000-020	Washer; 18 x 10.2 x 0.2	1	23	
638-90616-005	Washer; 6.1 x 12 x 1.6	1	13, 17	
640-60080-001	O Ring; P8-1.9	2	23	
640-60100-118	O Ring; P10A-2.4	1	24	
640-60140-012	O Ring; P14-2.4	3	23, 24	
640-60220-024	O Ring; P22-2.4	1	24	
640-70030-100	V Ring; VRY2.7 x 3.5 x 4.1	1	23	
660-01000-200	Rubber Foot K-45	4	3, 5	
660-05000-018	Magnet Catch SM50P	1	3, 5	
660-05000-301	Magnet Catch; SM-41	1	7	
660-05500-100	Magnet TDK REC 18 D5 x 2	1	27	
665-02010-000	Clamp DKN-16	2	3, 5	
665-02020-502	Clamp DKN-10	2	35, 37	
665-02021-401	Clamp DKN-20	2	60	
665-02025-504	Wire Saddle; WS-4W	3	71	
665-02025-601	Wire Saddle; LWS-2N	1	63	
665-04012-000	Snap Bushing; SB-1500-21	1	75	
665-04014-003	Snap Bushing; SB-2000-26	3	72, 75	
665-04037-003	Free Bushing; NJ-23	1	75	
665-09002-003	Shaft Keeper Lock; FB-Scanner	1	55	

Part No.	Part Name	Q'ty	Page	Unit Value
X-500	Pin; ϕ2 x 8	10		
X-510	Pin; ϕ2 x 10	10		
X-520	Pin; ϕ2 x 12	10		
X-530	Pin; ϕ2 x 14	10		
X-540	Pin; ϕ2.5 x 8	10		
X-600	Junction Connector; 2P	5		
X-610	Junction Connector; 3P	5		
X-620	Junction Connector; 4P	5		
X-630	Junction Connector; 5P	5		
X-640	Junction Connector; 6P	5		
X-650	Plastic E Ring	10		
The orders for the above (X-000) numbered Parts are available only by quantities of tens or fives as indicated.				

II. INDEX


[NOTICE]

★ When you order spare parts, please never fail to order the parts listed in this Index after making sure of what is the spare parts you want.

★ For modified or added parts, please refer to the technical information issued by our technical department.

★ What the part No. means;

Ex.)



● When you order spare parts, please never fail to inform us all of this part No. (the number of eleven figures).