Part No.	Part Name	Q'ty	Page	Unit Value
000-01138-006	L Plate; Guide Plate	4	65	
000-01169-106	Support Roller; Drum	3	21	
000-01326-007	Timing Roller Supporter	2	17,19	
000-01327-003	Adj. Plate; Guide Roller	1	17,19	
000-01328-000	Adj. Eccentric; Guide Roller	1	17,19	
000-01515-004	Collar; Separator	1	33	
000-02211-009	Spring; Squeegee Gap	2	21	
000-02254-506	Ink Blocking Plate (Front)	1	21	
000-02255-502	Ink Blocking Plate (Back)	1	21	
000-04123-000	Slide Frame; Paper Guide; Rcv.	3	39	
000-06123-007	Stopper; Paper Guide Roller	6	9	
000-07119-100	Coil Spring; Inking Pump	1	22	
000-10126-002	Pulley G; Original Feed Roller	1	65,71	
000-10142-016	Bracket; M.-Rmv. Solenoid	1	79,81	
000-10148-030	Spring B	1	79,81	
002-11131-004	Lower Hinge; Front	1	97,99	
002-11210-109	Load Spring; Guide Roller	2	17,19	
002-11220-007	Cam; Guide Roller	1	13	
002-11225-009	Support Block; Slide Plate	2	13	
002-11227-001	Spacer; Slide Plate	3	13	
002-11242-000	Idler	3	13	
002-11244-003	Idler Pulley	4	13	
002-11247-100	Pressure Link; Top	1	13	
002-11250-100	Stopper Shaft	1	13	
002-11251-204	Spring Hanger Shaft	1	13	
002-11255-013	Linking Plate; Drive Base	1	13	
002-11259-108	Connecting Shaft; Link	1	13	
002-11291-109	Sector Gear	1	13	
002-11303-000	Spring B; Pressure Link	2	13,14	
002-11304-006	Spring; Hook Lever	1	13	
002-11402-008	Adjuster; Press.-Roll. Support	2	17,19	
002-11404-108	Roller Holder; Pressure	4	17,19	
002-11405-007	Center Shaft; Pressure	1	17,19	
002-11412-003	Shaft Catch; Guide Roller	1	17,19	
002-11421-002	Adj. Plate; Timing Lever	1	31	
002-11424-206	Spring A; M.-M.	1	69	
002-11428-007	Roller Stopper A; Timing	2	17,19	
002-11429-003	Roller Stopper B; Timing	1	17,19	
002-11509-104	Joint A	1	75	
002-11542-004	Housing; Stripper	1	17,19	
002-11543-000	Spring; Stripper	1	17,19	
002-11544-007	Sliding Plate; Stripper	1	17,19	
002-11546-000	Bracket; Stack Paper Feeding SW	1	17,19	
002-11548-002	Adjuster; Stripper	1	17,19	
002-11549-009	Adj. Shaft; Stripper	1	17,19	

Part No.	Part Name	Q'ty	Page	Unit Value
002-11550-007	Stopper Washer; Stripper	1	17,19	
002-11557-001	Stripper Pad; SU	1	17,19	
002-11715-006	Bevel Gear; Elevator	2	9	
002-11717-009	Collar; Elevator	2	9	
002-11719-206	Rack; Elevator	2	9	
002-12110-108	Clamp Magnet A; B4	1	25	
002-12134-104	Sticker Sheet; Drum	1	25	
002-12201-219	Squeegee Roller	1	21	
002-12205-001	Doctor Roller	1	21	
002-12208-000	Adj. Plate (Front); Squeegee	1	21	
002-12209-007	Adj. Collar A; Squeegee	1	21	
002-12210-005	Adj. Collar B; Squeegee	1	21	
002-12213-101	Sector Adjustor; Squeegee	1	21	
002-12216-100	Adj. Shaft; Squeegee	1	21	
002-12217-000	Reverse Rotation Stopper A	1	21	
002-12218-006	Reverse Rotation Stopper B	1	21	
002-12219-002	Adj. Boss; Ink Blocking	2	21	
002-12222-003	Pulley; Squeegee Roller	1	21	
002-12223-107	Pulley; Main Shaft	1	21	
002-12227-005	Bearing Holder A; Squeegee	1	21	
002-12229-105	Tensioner; Squeegee	1	21	
002-12233-005	Spring; Tensioner; Squeegee	1	21	
002-12234-001	Spring; Adj. Plate (Front)	2	21	
002-12237-000	Adj. Plate (Back); Squeegee	1	21	
002-12238-104	Axis; Drive Shaft; Squeegee	1	21	
002-12239-305	Drive Shaft; Squeegee	1	21	
002-12240-001	Shaft Catch; Drive; Squeegee	1	21	
002-12303-305	Bracket; Inking Motor	1	22	
002-12304-107	Piston; Inking Pump	1	22	
002-12307-203	Linking Disc; Inking Pump	1	22	
002-12308-013	Linking Plate; Inking Pump	1	22	
002-12309-001	Collar; Inking Pump	2	22	
002-12310-107	Collar Holder; Inking Pump	1	22	
002-12407-003	Boss A; Drum Lever	2	21	
002-12409-006	Support Shaft; Support Roller	2	21	
002-12410-004	Adj. Plate; Support Roller	1	21	
002-12413-003	Locking Plate; Drum	1	21	
002-12414-000	Shaft; Locking Plate; Drum	1	21	
002-12418-005	Spacer; Drum Lever	2	21	
002-12537-209	Protection Sheet	1	31	
002-12542-300	Cushion; Ink Bottle	1	97,99	
002-13252-003	Gear Pulley B; Suction	1	35,37	
002-13352-105	Spring; Separator	1	33	
002-14130-009	Gear; Vertical Transport	2	81	
002-14143-011	Master Removal Hook	2	81	

Part No.	Part Name	Q'ty	Page	Unit Value
002-14517-000	Pulley; Duct	1	79,81	
002-17006-007	Shaft Catch; Front Cover	2	97,99	
002-17016-002	Cover Catch A; Front	2	97,99	
002-17017-203	Cover Catch B; Front	1	97,99	
002-68470-204	Stack Paper Feeding SW	1	17,19	
005-24114-003	Shaft Gear; Original Holder	1	97	
006-11216-009	Bearing House A; Main Shaft	1	13	
006-11222-009	Slide Plate (Base)	1	13	
006-11224-109	Slide Plate (Front)	1	13	
006-11301-006	Timing Roller	1	17	
006-11303-009	Gear; Guide Roller	1	17,19	
006-11304-005	Guide Shaft	1	17,19	
006-11305-109	One-Way Spring	1	17,19	
006-11306-008	Gear A; Guide Roller	1	17,19	
006-11307-004	Gear B; Timing Roller	1	17,19	
006-11308-000	Timing Lever	1	31	
006-11311-109	Spring; Timing Lever; R3	1	31	
006-11312-008	Support Collar; R3	2	17	
006-11332-009	Core; Pickup Roller	2	9	
006-11518-013	Stripper Fixing Spring	1	17,19	
006-11714-203	Back Stop A; P.-Rcv.-T. ; 100US	1	39	
006-11715-102	Back Stop B; P.-Rcv.-T. ; 100US	1	39	
006-11716-109	Hinge; Back Stop; Rcv.; 100US	1	39	
006-11717-008	Spring; Back Stop; Rcv.; 100US	1	39	
006-11719-000	Vibration Stopper; Back Stop; 100US	1	39	
006-91440-001	Unit; Adj. Plate; Timing Lever	1	31	
007-11305-009	Spring; Lock	1	27,29	
007-13101-001	Slide Guide; Paper Guide; Rcv.	3	39	
007-13121-100	Spring; Release Lever	1	33	
007-13124-109	Base Block; Paper Guide; Rcv.	3	39	
007-14113-100	Spring; Vertical Transport	3	79,81	
008-24108-005	Vertical Transport Roller S (Down)	1	79	
009-35214-009	Pulley PM (16); Exit Roller	2	31,65	
009-35406-005	Slide Rack; Original Holder (A3)	2	97	
011-11110-006	Bracket; P.-Rcv. Sensor 1 (Receive)	1	33	
011-11111-002	Bracket F; Suction	1	3,5	
011-11112-009	Bracket R; Suction	1	3,5	
011-11113-102	Bottom Cover	1	3,5	
011-11201-001	Unit/P.-F. Clutch	1	13	
011-11204-000	Base Plate; P.-F. Clutch	1	13	
011-11208-006	Base Shaft Plate; Slide Plate	1	13	
011-11212-003	Main Pulley; Main Shaft	3	13	
011-11220-006	Shaft Base Block; Slide Plate	1	13	
011-11222-106	Base Shaft Plate; Pressure	1	14	
011-11227-000	Reinforce Plate; Slide Plate	1	13	

Part No.	Part Name	Q'ty	Page	Unit Value
011-11229-003	Bracket; Print Positioning Motor	1	31	
011-11230-001	Shaft; Slide Plate	1	13	
011-11231-008	Shaft Block; Slide Plate	1	13	
011-11232-004	Gear; Slide Plate	1	13	
011-11234-007	Main Bracket; Face Plate	2	14	
011-11235-003	P Disc	1	13	
011-11238-002	Disc Plate; Main Shaft	3	13	
011-11239-009	Bracket; Pressure Det. Sensor	1	13	
011-11240-309	Cam; Timing Roller	1	13	
011-11241-100	Pressure Link; Bottom	1	13	
011-11243-006	Bracket; P Disc Sensor	1	13	
011-11244-002	Gear; Pressure Control Motor	1	31	
011-11245-009	Gear; Pressure Adj. Screw	1	13	
011-11247-001	Linking Plate; Pressure Control	1	14	
011-11248-105	Bracket; Pressure Control	1	13	
011-11249-209	Face Plate; Main Shaft	1	13	
011-11251-106	Bracket; Tension Pulley	1	14	
011-11254-008	Tension Pulley	1	14	
011-11255-004	Pressure Sensor Disc.	1	14	
011-11257-007	Cam; Pressure Roller; A4	1	13	
011-11258-003	Cam; Pressure Roller; B4	1	13	
011-11259-000	Spring; Pressure Det.	1	14	
011-11270-003	Shaft; Hook Lever	1	13	
011-11276-206	Hook Lever	1	13	
011-11280-009	Pressure Hook	1	13	
011-11284-209	Pressure Lever	1	14	
011-11289-006	Bracket; Hook Lever Spring	1	13	
011-11293-003	Bracket; Pressure Control Motor	1	31	
011-11294-107	Print Positioning Motor	1	31	
011-11296-002	Spring; Sector Gear	1	13	
011-11301-006	Guide Roller	1	17	
011-11302-002	Shaft; Timing Roller	1	17	
011-11403-208	Pressure Roller Support	1	17	
011-11404-000	De-electricity Brush; B4	1	17,65	
011-11409-001	Guide Cover; Pressure; B4	1	17	
011-11501-102	Bracket; P.-F.-T.	1	11	
011-11502-001	Shaft A; P.-F.-T.	1	11	
011-11503-008	Shaft B; P.-F.-T.	1	11	
011-11504-101	Paper Feed Tray	1	11	
011-11509-006	Side Guide R; P.-F.-T.	1	11	
011-11510-004	Side Guide L; P.-F.-T.	1	11	
011-11511-000	Slide Rack; P.-F.-T.	2	11	
011-11512-104	Link Plate; Side Guide; P.-F.-T.	2	11	
011-11513-003	Collar; Slide Rack; P.-F.-T.	4	11	
011-11514-000	Gear; Slide Rack; P.-F.-T.	1	11	

Part No.	Part Name	Q'ty	Page	Unit Value
011-11515-006	Slide Sheet; P.-F.-T.	4	11	
011-11516-002	L.O. Sheet	1	11	
011-11517-009	Spring; Slide Rack	2	11	
011-11522-002	Paper Guide Roller	6	9	
011-11523-106	Adj. Nut; P.-F.-T.	1	11	
011-11524-005	Adj. Dial	1	11	
011-11526-008	Support Plate R; Feed Board	1	11	
011-11527-004	Support Plate L; Feed Board	1	11	
011-11528-000	Feed Board	1	11	
011-11529-007	Feed Board Cover	1	11	
011-11532-105	Nut Holder	1	11	
011-11602-006	Link Plate; Elevator	1	9	
011-11606-001	Bracket; Elevator Motor	1	9	
011-11610-009	Bracket; Lower Limit SW	1	9	
011-11701-306	Guide Plate (Lower)	1	17	
011-11704-003	Bracket; Stripper Unit	1	17,19	
011-11708-009	Angular Adj. Plate; Stripper	1	17,19	
011-11709-102	Stripper Pad Cover	1	17,19	
011-11710-003	Base Plate; Stripper	1	17,19	
011-11711-107	Fulcrum Screw; Stripper	2	17,19	
011-11712-006	Actuator Plate; Stack P.-F. SW	1	17,19	
011-11713-002	L Plate; Guide Plate	2	17,19	
011-11714-203	Guide Plate (Upper)	1	17	
011-11717-105	Bracket; Paper Buckle Det. Sensor	1	17,19	
011-11718-101	Sheet; Guide Plate	1	17,19	
011-11720-009	Stripper Noise Reduction Sheet	1	17,19	
011-11805-004	Holder Plate; Scraper	1	9	
011-11806-000	Bracket; Upper Limit Sensor	1	9	
011-11807-007	Bracket; P.-F. Pressure Adj. Lever	1	9	
011-11810-008	P.-F. Pressure Adj. Lever	1	9	
011-11811-209	Spring; P.-F.Pressure	1	9	
011-11812-000	Bracket; Magnet Catch	1	11	
011-11814-003	Bracket; Paper Det. Sensor (Receive)	1	9	
011-11815-000	Spring; P. -F. Pressure Adj. Lever	1	9	
011-11816-103	Collar; Shaft; Pickup Roller	1	9	
011-11817-002	Pickup Roller Ass'y	1	9	
011-11818-009	Rubber Roller; Pickup	2	9	
011-12101-205	Drum Body; B4	1	25	
011-12104-000	Seal Tape	1	25	
011-12105-200	Screen A	1	25	
011-12107-009	Screen B	1	25	
011-12110-301	Clamp Plate Ass'y	1	25	
011-12114-005	Shaft; Clamp Plate	1	25	
011-12116-202	Drum Cover R	1	25	
011-12118-000	Magnet C	3	25	

Part No.	Part Name	Q'ty	Page	Unit Value
011-12120-102	Clamp Plate Base	1	25	
011-12123-705	Drum Body Support (Left)	1	25	
011-12124-108	Compensator	1	25	
011-12129-100	Clamp Sub-Plate	1	25	
011-12130-000	Clamp Magnet B	1	25	
011-12131-007	Hanger Plate	2	25	
011-12132-305	Sheet; Clamp Plate	1	25	
011-12133-204	Drum Body Support (Right)	1	25	
011-12134-006	Sheet; Drum; B4	2	25	
011-12136-009	Spring; Screen	2	25	
011-12139-008	Drum Seal	2	25	
011-12140-006	Ink Blocking Sheet; B4	1	25	
011-12141-100	Screw; Spring Hanger	2	25	
011-12142-009	Ink Blocking Sheet; A4	1	25	
011-12143-005	Clamp Magnet A; A4	1	25	
011-12144-206	Separator Guide Plate	1	25	
011-12145-008	Light Absorber Strip 30; A4	2	25	
011-12146-004	Separate Sheet; B4	2	25	
011-12147-108	Coil Spring; Inking Pump; RC	1	22	
011-12151-008	Valve; Inking Pump	2	22	
011-12153-000	Ink Distributor II	1	22	
011-12154-007	Plate II; Angular Magnet	1	25	
011-12155-003	Screw; Angular Magnet	1	25	
011-12201-200	Inking Pump Body	1	22	
011-12204-101	Squeegee Stay	1	21	
011-12206-007	Ass'y; Shaft Joint	1	21	
011-12207-100	Shaft Joint	1	21	
011-12208-000	Bottle Guide (Over)	1	22	
011-12209-103	PCB Cover; Drum	1	21	
011-12211-205	Side Frame; Squeegee	1	21	
011-12213-100	Drum Cover F (Upper)	1	21	
011-12216-002	Bracket; Bottle SW	1	22	
011-12217-009	Adj. Plate; Bottle SW	1	22	
011-12218-005	Boss; Bottle Set SW	1	22	
011-12219-001	Spring; Bottle SW	1	22	
011-12220-107	Drum Cover F (Lower)	1	21	
011-12221-006	Fulcrum; Tensioner; Squeegee	1	21	
011-12222-002	Bracket R; Drum Cover F	1	21	
011-12223-009	Bracket L; Drum Cover F	1	21	
011-12241-007	Shaft Support II; Squeegee	1	21	
011-12301-000	Frame; Drum	1	21	
011-12302-006	Cover; Drum	1	22	
011-12303-100	Connector Cover; Drum	1	22	
011-12304-009	Bracket A; Connector; Drum	1	27,29	
011-12305-005	Spring; Locking Plate; Drum	1	21	

Part No.	Part Name	Q'ty	Page	Unit Value
011-12306-001	Rail; Drum	2	27	
011-12311-005	Drum Catch (L)	1	27,29	
011-12313-008	Bracket B; Connector; Drum	1	21	
011-12314-101	Drum Holder	1	27	
011-12315-000	Bracket; Magnet C Det. Sensor	1	21	
011-12317-003	Drum Catch (R)	1	27,29	
011-12319-006	Bracket; Magnet A Det. Sensor	1	21	
011-12320-209	Adj. Plate; Magnet A Det. Sensor	1	21	
011-12321-000	Drum Lever	1	21	
011-12332-100	Reinforcing Plate; Drum Holder	1	27	
011-12402-108	Spring; Clamp Solenoid	1	31	
011-12403-309	Base Plate; Clamp Solenoid	1	31	
011-12405-107	Bracket; Compensator Plate	1	31	
011-12406-200	Bracket; Clamp Solenoid	1	31	
011-12409-200	Compensator Plate	1	31	
011-12410-003	Plunger Pin; Clamp Solenoid	1	31	
011-12411-000	Gear; Clamp Motor	1	31	
011-12412-006	Spacer; Compensator Plate	2	31	
011-12413-002	Cushion; Clamp Solenoid	1	5,31	
011-12415-005	Bracket; Angular Sensors	1	31	
011-13102-108	Frame A; Paper Receiving Tray	1	39	
011-13106-006	Frame B; Paper Receiving Tray	1	39	
011-13107-002	Catch Plate; P.-Rcv.-T.	1	39	
011-13108-106	Slide Rail A; P.-Rcv.-T.	1	39	
011-13109-102	Slide Rail B; P.-Rcv.-T.	1	39	
011-13110-208	Paper Guide; P.-Rcv.-T.	2	39	
011-13111-000	Back Stop; P.-Rcv.-T.	1	39	
011-13112-103	Shaft; Paper Receiving Tray	1	39	
011-13115-102	Receiving Tray Plate II	1	39	
011-13122-001	Bracket; Magnet Catch; P.-Rcv.-T.	1	3,5,7	
011-13133-100	Damper; Back Stop; P.-Rcv.-T.	1	39	
011-13134-000	Damper; Cover Plate; Suction	1	35,37	
011-13135-006	Pin; Paper Guide	2	39	
011-13141-006	Spring; Paper Guide; P.-Rcv.-T.	2	39	
011-13142-002	Paper Guiding Arm F; P.-Rcv.-T.	1	39	
011-13143-009	Paper Guiding Arm R; P.-Rcv.-T.	1	39	
011-13144-005	Set Plate F; P.-Rcv.T.	1	3,5	
011-13146-008	Set Plate R; P.-Rcv.T.	1	3,5	
011-13201-106	Suction Cover (Upper)	1	35,37	
011-13203-206	Face Cover; Suction	1	35	
011-13204-008	Pulley; Suction Motor	1	35,37	
011-13205-004	Cover Plate; Suction	1	35	
011-13206-108	Suction Fan Cover	1	35,37	
011-13207-007	Seal	1	35,37	
011-13208-100	Transfer Shaft A; Suction	1	35,37	

Part No.	Part Name	Q'ty	Page	Unit Value
011-13209-107	Transfer Shaft B; Suction	1	35,37	
011-13212-000	Fulcrum Plate; Gear Pulley; Suction	1	35,37	
011-13215-107	Suction Fan	1	35,37	
011-13219-102	Bracket; P.-Rcv. Sensor 1 (Send)	1	35,37	
011-13220-003	Transfer Belt	3	35,37	
011-13224-106	Bracket; De-electricity Brush; Suction	1	35,37	
011-13225-102	De-electricity Brush	1	35,37	
011-13231-005	De-electricity Brush; P.-Rcv.	1	35,37	
011-13232-109	Suction Cover (Lower)	1	35,37	
011-13233-008	Dust-proof Cover 1; Rcv.	1	35,37	
011-13234-004	Dust-proof Cover 2; Rcv.	1	35,37	
011-13235-000	Dust-proof Sponge 1; Rcv.	1	35,37	
011-13236-007	Dust-proof Sponge 2; Rcv.	1	35,37	
011-13237-003	Dust-proof Tape 1; Rcv.	1	35,37	
011-13238-000	Dust-proof Tape 2; Rcv.	1	35,37	
011-13301-100	Lever; Separator	1	33	
011-13304-002	Shaft; Separator	1	33	
011-13305-009	Release Lever; Separator	1	33	
011-13306-005	Collar A; Separator	2	33	
011-13307-109	Adj. Stopper; Separator	1	33	
011-13310-002	Hook Plate	2	33	
011-13311-009	Release Lever	1	33	
011-13312-005	Separator	1	33	
011-14115-009	Linking Plate; M.-Rmv. Hook	1	79,81	
011-14120-002	Front Cover; M.-Rmv.	1	3,5	
011-14121-009	Pulley B; M.-Rmv.	1	79,81	
011-14151-005	Wire Guard	2	69	
011-14168-005	Master Removal Hook (L); B4	1	79	
011-14169-001	Master Removal Hook (R); B4	1	79	
011-14170-000	Master Removal Hook; A4	2	79	
011-14401-001	Right-Side Frame; M.-Rmv.	1	79	
011-14402-008	Left-Side Frame; M.-Rmv.	1	79	
011-14403-004	Stay A; M.-Rmv.	1	79	
011-14404-108	Stay B; M.-Rmv.	1	79	
011-14405-007	Base Plate; M-Rmv.	1	79	
011-14406-100	Guide Plate; M.-Rmv.; B4	1	79	
011-14407-107	Vertical Transport Roller (Up); B4	1	79	
011-14408-006	Bracket; Disposal Box SW	1	79,81	
011-14409-100	Bracket; Master Removal Sensor (Send)	1	79	
011-14417-005	Handle; Disposal Box	1	83	
011-14418-001	H.-Lever (Right); Disposal Box	1	83	
011-14419-008	H.-Lever (Left); Disposal Box	1	83	
011-14420-103	Guide Plate; Disposal Box	1	83	
011-14421-100	Guide Cam; Disposal Box	2	83	
011-14422-106	Guide Spring; Disposal Box	1	83	

Part No.	Part Name	Q'ty	Page	Unit Value
011-14423-200	Guide Shaft; Disposal Box	1	83	
011-14424-001	Boss; Disposal Box	2	83	
011-14425-008	Shaft; Disposal Box Cover	1	83	
011-14426-209	Disposal Shaft; Disposal Box	1	83	
011-14427-000	Lock Shaft; Disposal Box	1	83	
011-14428-007	Lock Spring (Right)	1	83	
011-14429-003	Lock Spring (Left)	1	83	
011-14430-109	Shaft; M.-Rmv.Hook	1	79	
011-14433-000	Base Plate II; M.-Rmv.	1	79	
011-14434-007	Guide Plate II; M.-Rmv.	1	79	
011-14435-003	Vertical Transport Roller II (Up); A4	1	79	
011-14436-000	Vertical Transport Roller II (Down); A4	1	79	
011-14437-006	Holder II; V.-Transport Roller	1	79	
011-14440-007	Guide Plate II; Disposal Box	1	83	
011-14446-005	Bracket II; Master Removal Sensor (Receive)	1	79,81	
011-14502-002	Inner Cover	1	3,5,7	
011-14503-106	Inner Cover B	1	97	
011-14506-105	Master Guide C; M.-Rmv.	2	75,79	
011-15001-007	Support Shaft	2	65,71	
011-15003-107	Shaft; Torsion	2	67,69,73	
011-15004-006	Fulcrum; TPH	2	67,69,73	
011-15007-005	Catch Roller (Upper); M.-M.	1	67,69	
011-15008-001	Load Roller (Upper); M.-M.	1	67,69	
011-15009-105	Catch Roller (Lower); M.-M.	1	65	
011-15010-006	Shaft; Open/Close Hook	1	67,69	
011-15011-207	Bracket B; TPH	1	69	
011-15012-009	Set Plate; M.-M.	2	69	
011-15013-005	Open/Close Hook	2	67,69,73	
011-15014-001	Frame B; M.-M.	1	67,69	
011-15017-000	Plate B; Stocker	1	65	
011-15018-007	Pulley; Write Pulse Motor	1	31	
011-15023-000	Frame A; Stocker	1	65	
011-15025-305	Load Roller (Lower); M.-M.	1	65	
011-15026-107	Bracket A; TPH	1	69	
011-15028-100	Fulcrum; M.-M.	2	65	
011-15029-009	Copy Guide Plate (Lower)	1	69	
011-15030-007	Copy Guide Plate (Upper)	1	69	
011-15034-002	Bracket; De-electricity Brush; T-TPH	1	67,69	
011-15035-009	Protection Sheet A; TPH	1	69	
011-15036-005	De-electricity Brush; TPH	2	67,69	
011-15037-001	Bracket; Loading Pulse Motor	2	31	
011-15038-008	Bracket; Cutter Motor	1	75	
011-15039-004	Bracket; Cutter SW	1	75	
011-15041-009	De-electricity Brush	1	65,67,69	
011-15042-005	Bracket; De-electricity Brush; M.-M.	1	65	

Part No.	Part Name	Q'ty	Page	Unit Value
011-15043-001	Cutter Guide Sheet (Right)	1	75	
011-15044-008	Cutter Guide Sheet (Left)	1	75	
011-15047-104	Cutter Cover A Ass'y	1	75	
011-15048-003	Set Sheet A	2	75	
011-15049-000	Set Sheet B	2	75	
011-15050-008	Bracket; De-electricity Bar	1	69	
011-15051-004	De-electricity Bar; M.-M.	2	67,69	
011-15055-000	Spring (Left); M.-M.	1	67,69,73	
011-15056-006	Spring (Right); M.-M.	1	67,69,73	
011-15057-002	Frame A; M.-M.	1	69	
011-15059-102	Sheet; Master Positioning Sensor	1	75,77	
011-15061-107	Set Guide Sheet; M.-M.	1	65	
011-15073-105	Boss; TPH	1	73	
011-15078-003	Switch Cam	1	67	
011-15080-004	Bracket; Wire Harness	1	3,5	
011-15081-108	Cover A; M.-M.	1	69	
011-15082-007	Cover (Right); M.-M.	1	69	
011-15083-003	Cover (Left); M.-M.	1	69	
011-15087-009	Cover (Right); Wire Harness; M.-M.	1	69	
011-15088-005	Cover (Left); Wire Harness; M.-M.	1	69	
011-15091-006	Sheet; TPH	2	69	
011-15093-009	Cutter Sheet B	1	75	
011-15098-000	Hook Spring	2	67,69,73	
011-15102-202	Cutter Body	1	75	
011-15104-000	Bracket; Roll Fix (Right)	1	69	
011-15105-104	Bracket; Roll Fix (Left)	1	69	
011-15107-000	Cutter Joint B	1	75	
011-15110-000	Pulley; Loading Roller (Lower)	1	65,71	
011-15113-000	Bracket; Micro-SW; M.-M.	1	65	
011-15114-006	Bracket; Thermal Pressure Motor	1	69	
011-15115-304	Thermal Pressure Motor	1	69	
011-15117-005	Cam; Thermal Pressure Motor	1	67,69,73	
011-15118-001	Bracket; Micro-SW; T.-P.-M.	1	69	
011-15120-006	Pulley A; Write Roller	1	65	
011-15126-004	Actuator; Home Position SW; TPH	1	69	
011-15129-208	Actuator; Micro-SW; M.-M.	1	67,69,73	
011-15130-109	Protection Sheet B; TPH	1	69	
011-15139-009	Bracket; Master Sensor II	1	75	
011-15142-000	Bracket; Master Positioning Sensor	1	75,77	
011-15143-006	Bracket II; Master End Sensor	1	65	
011-15145-009	Reflection Sheet; M.-End	1	69	
011-15153-109	Set Guide Plate; M.-M.	1	65	
011-15155-209	Guide Plate; Load	1	65	
011-15156-000	Guide Sheet; Stocker	1	65	
011-15157-007	Stopper	1	75	

Part No.	Part Name	Q'ty	Page	Unit Value
011-15158-003	Bracket; De-electricity Brush	1	67,69	
011-15159-000	Cover; Stocker	1	65	
011-15161-004	Set Sheet II; Copy Guide (Lower)	2	67,69	
011-15162-000	Sheet; Master Guide Plate; M.-M.	1	65	
011-15164-003	Sheet; Capacitor PCB	1	67,73	
011-15169-005	Cutter Guide Sheet III	1	75	
011-15175-005	Cutter Cover D	1	75	
011-15176-001	Cutter Guide IV	1	75	
011-15177-008	Master Guide III	1	75	
011-15250-201	Master Roll Holder	1	65,71	
011-15254-002	Holder; Master Roll	2	65,71	
011-15263-001	Cushion; Master Roll Holder	2	65	
011-15268-100	Holder Spring	1	71	
011-15269-107	Support Pin (Right); Master Holder	1	65	
011-15270-105	Support Pin (Left); Master Holder	1	65	
011-15272-000	Spacer; Magnet Catch	2	3,5	
011-15277-002	Set Guide Cover R	1	65	
011-15278-009	Set Guide Cover F	1	65	
011-15280-003	Cover Plate (Right); Master Holder	1	65	
011-15281-000	Cover Plate (Left); Master Holder	1	65	
011-15293-008	Support Sheet; M.-Rmv.	1	75	
011-15294-004	Tension Plate; Master Roll Holder	2	65	
011-15303-003	Bracket; Damper	1	71	
011-15306-100	Shaft; Master Holder	1	71	
011-15307-106	Damper Gear	1	71	
011-15703-001	Frame A; M.-M.; 40	1	67	
011-15704-008	Bracket; TPH; 40	1	67	
011-15707-201	Thermal Pressure Motor II Ass'y	1	67,73	
011-15708-100	Switch Cam	2	73	
011-15710-008	Bracket; Micro-SW	1	67,73	
011-15711-101	Copy Guide Plate (Lower)	1	67	
011-15712-000	Cover A; M.-M.;40	1	67	
011-15713-007	Bracket; Capacitor PCB	1	67,73	
011-15716-006	Pressure Assist Plate	2	67,73	
011-15717-002	Bracket; Pressure Assist Plate; K-TPH	2	67	
011-15718-106	Spring; TPH Pressure	2	67,73	
011-15721-107	Wire Harness Guide	1	67	
011-15722-006	Fulcrum II; M.-M.	4	73,67	
011-15723-002	Sponge; M.-M. 40	1	67	
011-15733-008	De-electricity Brush; K-TPH	1	67	
011-15734-004	Bracket; De-electricity Brush; K-TPH	1	67	
011-15750-000	T-TPH Set Plate	1	73	
011-15751-006	Bracket; Pressure Assist Plate; T-TPH	2	67,73	
011-16001-108	Set Plate; ADF Cover	1	97	
011-16002-007	Bracket; Top Cover	1	45	

Part No.	Part Name	Q'ty	Page	Unit Value
011-16003-100	Catch Plate; ADF Cover	1	97	
011-16004-107	Boss; Top Cover	3	49	
011-16005-006	Sheet; Image Processing PCB	1	41,45	
011-16007-203	Bottom Plate; Scanner	1	41,45	
011-16008-102	Hinge; ADF Cover	2	41,45	
011-16009-001	Bracket; Handle; Scanner	1	41,45	
011-16010-107	Handle Cover; Scanner	1	41,45	
011-16011-103	Handle; Scanner	1	41,45	
011-16012-002	Link Plate A; Scanner	1	41,45	
011-16013-009	Link Plate B; Scanner	1	41,45	
011-16015-001	Slide Lock; Scanner	1	41,45	
011-16016-008	Bracket; Rail; Scanner	2	41,45	
011-16019-007	Rail; Scanner	4	41,45	
011-16020-102	Bottom Blind Plate; Scanner	1	41,45	
011-16023-004	Wire Harness Stay (Upper); Scanner	1	93	
011-16024-000	Wire Harness Stay (Lower); Scanner	1	93	
011-16026-003	Boss B; Link Plate B; Scanner	1	41,45	
011-16027-000	Spring; Link Plate B; Scanner	1	41,45	
011-16029-002	Bracket; Interlock Switch	2	5,7,41	
011-16030-108	Ground Plate; Scanner	1	93	
011-16031-007	Bracket L; Image Scanner	1	47	
011-16032-100	Actuater Guide	1	41,45	
011-16035-002	Side Blind Plate; Scanner	1	41,45	
011-16037-005	Stopper III; Scanner	1	3,41,45	
011-16039-008	Stopper IV; Scanner	1	41,45	
011-16040-006	Front Ground Plate	1	41,45	
011-16048-104	Bracket L; Image Scanner; 40	1	43	
011-16049-100	Bracket R; Image Scanner; 40	1	43	
011-16050-001	Hinge II; ADF Cover	1	45	
011-16101-102	Rail (Left)	1	3	
011-16102-109	Rail (Right)	1	3	
011-16103-105	Upper Rear Frame	1	3	
011-16107-003	Bracket; Wire Harness	1	93	
011-16109-006	Rail Edge (Left)	1	3	
011-16110-004	Rail Edge L (Right)	1	3	
011-16111-000	Rail Edge S (Right)	1	3	
011-16112-007	Bracket A; Micro-SW	1	3	
011-16118-102	Actuator	1	85,87,89,91	
011-16302-000	Bracket R; Image Scanner	1	47	
011-16308-009	Shaft; Open Lever	2	43,47	
011-16309-005	Open Lever L; ADF	1	43,47	
011-16310-003	Open Lever R; ADF	1	43,47	
011-16315-005	Lever	3	43,47	
011-16321-005	Spacer; 3 x 12	1	43,47	
011-16322-001	Separation Spring; ADF	1	43,47	

Part No.	Part Name	Q'ty	Page	Unit Value
011-16323-008	Release Spring; ADF	1	43,47	
011-16324-004	Registration Spring; ADF	1	43,47	
011-16325-000	Separation Lever; ADF	1	43,47	
011-16326-007	Release Lever; ADF	1	43,47	
011-16327-003	Registration Lever; ADF	1	43,47	
011-16328-000	Belt; B 87M x L3.2	1	43,47	
011-16330-004	Pulley; ADF	2	43,47	
011-16331-000	Pulley I; ADF	2	43,47	
011-16333-003	Belt; 246-3M-4	1	43,47	
011-16334-000	Pulley II; ADF	2	43,47	
011-16335-006	Gear; G40	1	43,47	
011-16336-002	Gear; G28	4	43,47	
011-16339-001	Metal; 6 mm	3	59,61,101	
011-16340-000	Lever; Original Guide 1	1	43,47	
011-16341-006	Shaft; Original Guide 1	1	43,47	
011-16342-002	Registration Stopper	1	43,47	
011-16344-005	Metal; 8 mm	2	61	
011-16345-001	Exit Roller (Upper); Scanner	1	43,47	
011-16346-008	Transfer Roller; Scanner	1	43,47	
011-16347-004	Spring; Transfer Roller	2	43,47	
011-16356-003	Sensor Stay	1	43,47	
011-16357-000	Original Sensor A	1	43,47	
011-16358-006	Sheet; Original Guide 1; Scanner	2	43,47	
011-16359-002	Original Guide 1; Scanner	1	43,47	
011-16360-000	Original Guide 5; Scanner	1	43,47	
011-16361-007	Spring; Exit Roller	2	43,47	
011-16365-002	Upper Original Pickup Roller	1	43,47	
011-16366-009	Original Feed Roller	1	43,47	
011-16371-002	Original Sensor B	1	43,47	
011-16372-009	Sheet; Original Guide 3; Scanner	1	43,47	
011-16373-005	Original Guide 3	1	43,47	
011-16374-001	Sheet; Original Guide 2; Scanner	1	43,47	
011-16377-000	Original Guide 2	1	43,47	
011-16378-007	Side Frame L; Scanner	1	43,47	
011-16379-003	Side Frame R; Scanner	1	43,47	
011-16381-008	Holder; One-Way Spring	1	43,47	
011-16382-004	One-Way Spring; Stripper Roller	1	43,47	
011-16383-000	Stripper Roller; ADF	1	43,47	
011-16449-009	Mylar Sheet; Original Feed (Up)	1	61	
011-17037-009	Door; Sub-Panel	1	85,87,89,91	
011-17039-001	Knob; Pocket Cover	1	85,87,89,91	
011-17040-000	Plate Spring; Knob; Pocket Cover	1	85,87,89,91	
011-17041-006	Shaft; Pocket Cover; Panel	1	85,87,89,91	
011-17046-105	Reinforce Plate; Panel	1	85,87,89,91	
011-17047-004	Bracket A; Panel	1	85,87,89,91	

Part No.	Part Name	Q'ty	Page	Unit Value
011-17048-108	Bracket B; Keyboard	1	85,87,89,91	
011-17049-007	Sponge; Pocket Manual	2	91	
011-17050-005	Sheet; Sub-Panel Base	1	89,91	
011-17101-009	Front Cover	1	97,99	
011-17102-005	Magnet Catch Plate; Front	1	97,99	
011-17105-004	Front Left Cover	1	97,99	
011-17106-000	ADF Cover	1	97	
011-17107-007	Original Side Guide (Right)	1	97	
011-17108-003	Original Side Guide (Left)	1	97	
011-17109-000	Set Plate; Original Holder	1	97	
011-17113-007	Original Tray	1	97	
011-17201-003	Upper Hinge	1	3,5,7	
011-17204-002	Bracket C; Keyboard	2	3,5,7	
011-17205-106	Bracket D; Keyboard	1	3,5,7	
011-17206-005	Bracket E; Keyboard	1	3,5,7	
011-17207-109	Bracket; Hinge	1	3,5,7	
011-17208-202	Bottom Plate (Right)	1	3,5,7	
011-17209-004	Set Plate; Front Right Cover	2	3,5,7	
011-17211-009	Switch Box	1	97,99	
011-17212-102	Inner Cover A	1	97,99	
011-17213-400	Bottom Plate (Left)	1	3,5,7	
011-17217-007	Inner Cover B	1	99	
011-17219-000	Blind Plate A; Connector	4	3,5,7	
011-17220-008	Blind Plate B; Connector	3	3,5,7	
011-17229-102	Mount; Connector; 200 V	1	3,5,7	
011-17230-003	Mount; Connector; 100 V	1	3,5,7	
011-17501-007	Clip A; 56D	1	97	
011-17502-100	Clip B	1	97,103	
011-17503-000	Plate Spring; Clip	1	97,103	
011-17504-006	Rubber; Clip	2	97,103	
011-17505-002	Scroll Arm; 56D	1	97	
011-17506-009	Fulcrum; 56D	2	97	
011-17508-109	Scroll Magnet; 56D	1	97	
011-17514-001	Cable Hold Plate; Stylus Pen; 56D	1	49	
011-17515-008	Spacer; Digitizer; 56D	1	49	
011-17517-108	Tablet	1	103	
011-18101-207	Bracket; Power Supply PCB	1	87	
011-18102-009	Bracket (Right); System PCB	1	93,95	
011-18103-005	Bracket (Left); System PCB	1	93,95	
011-18104-001	Sheet; System PCB	1	93,95	
011-18106-209	Bracket; Power Supply PCB	1	89	
011-18108-104	Side Cover; Power Supply	1	91,97,99	
011-18113-000	Cover Plate Left; Power Supply	1	85,87,89,91	
011-18506-002	Bracket; Pressure Control PCB	1	93,95	
011-41404-004	De-electricity Brush; A4	1	17	

Part No.	Part Name	Q'ty	Page	Unit Value
011-41409-006	Guide Cover; Pressure; A4	1	17	
011-41528-005	Feed Board; 100US	1	11	
011-41813-109	Cover; Pickup Roller	1	9	
011-41814-202	Bracket; Feed Tray Safety SW	1	9	
011-41815-101	Safety Bar	1	9	
011-41816-000	Spring; Safety SW	2	9	
011-41817-007	Cover; Pickup Roller; Pic.	1	9	
011-42101-200	Drum Body; 100US	1	25	
011-42102-206	Drum Body; A4	1	25	
011-42212-001	Bottle Guide	1	22	
011-42316-001	Cover; Drum Holder	1	27,29	
011-42317-008	Cover; Drum Holder; Pic.	1	27,29	
011-43102-102	Receiving Tray Plate II; 100US	1	39	
011-44415-007	Disposal Box	1	83	
011-44416-003	Disposal Box Cover	1	83	
011-44417-000	Disposal Box; Pic.	1	83	
011-44418-006	Disposal Box Cover; Pic.	1	83	
011-45262-000	Sponge S	1	65	
011-45263-006	Sponge; Master Holder	1	65	
011-45264-002	Dustproof Sponge	2	65	
011-45265-009	Dustproof Sponge (Left)	1	65	
011-45266-102	Dustproof Sponge (Right)	1	65	
011-45267-001	Set Guide Sponge R	1	65	
011-45268-008	Set Guide Sponge F	1	65	
011-45270-002	Copy Guide Sponge	1	69	
011-45513-002	Digitizer Sheet	1	103	
011-45514-009	Digitizer Sheet; Pic.	1	103	
011-47103-103	Front Right Cover	1	97,99	
011-47110-207	Top Cover; 100US	1	45	
011-47111-009	Top Cover	1	45	
011-47210-104	Bracket; Counter	1	85,87,89	
011-47211-100	Bracket; Counter; Pic.	1	87,89	
011-47554-105	Pocket Cover	1	85,87	
011-47557-007	Back Cover	1	97	
011-47560-008	Pocket Cover	1	89,91	
011-51004-306	Image Processing PCB A	1	45	
011-51005-302	Image Processing PCB B	1	45	
011-51009-200	Drum PCB	1	22	
011-51011-302	Digitizer PCB	1	49,103	
011-51016-100	Image Processing PCB C; 56D, 56	1	45	
011-51028-000	Image Processing PCB GA	1	45	
011-51031-001	Capacitor PCB	2	67,73	
011-51035-104	Image Processing PCB III GA	1	41	
011-51500-702	System Main PCB II	1	93,95	
011-51501-709	System Drive PCB II	1	93,95	

Part No.	Part Name	Q'ty	Page	Unit Value
011-51502-209	Panel Main PCB	1	91	
011-51503-000	Panel SW PCB	1	85,87,89,91	
011-51505-003	Panel Display PCB	1	85,87,89,91	
011-51511-208	Panel Main PCB	1	85,87	
011-51517-001	P. VR PCB; 56	1	87	
011-51518-008	P. VR PCB	1	85,87	
011-51525-101	Pressure Control PCB II	1	93,95	
011-51526-205	Joint PCB	1	41	
011-55001-204	Wire Harness; CN12; Power	1	93,95	
011-55002-308	Wire Harness; CN2; Image Processing	2	93	
011-55003-100	Wire Harness; CN3; Panel	1	93,95	
011-55004-203	Wire Harness; Image-Power	1	85,87,93	
011-55005-404	Wire Harness; TPH	1	93	
011-55006-109	Wire Harness; Image Scanner	1	47	
011-55007-008	Wire Harness; Digitizer; 56D	1	49	
011-55008-004	Wire Harness; Drum Drawer	1	27,29	
011-55009-205	Wire Harness; Drum	1	21	
011-55010-505	Wire Harness; TPH-Power	1	91	
011-55011-102	Wire Harness; Panel-Power	1	85,87,89,91	
011-55016-309	Wire Harness; CN6	1	93,95	
011-55017-100	Wire Harness; CN7	1	93	
011-55021-302	Wire Harness; CN11	1	93,95	
011-55023-100	Wire Harness; CN13-S7	1	93	
011-55028-102	Wire Harness; Stack Paper SW	1	14	
011-55037-101	Wire Harness; Master Loading Unit	1	65	
011-55041-109	Ground Wire; Image	1	93	
011-55045-104	Wire Harness; TPH Pos. SW	1	69	
011-55054-103	Wire Harness; Main Motor	1	91	
011-55056-203	Wire Harness; M.-Rmv.	1	79,81	
011-55062-009	Wire Harness; Main Motor	1	89	
011-55064-001	Wire Harness; P.-Rcv. Sensor (Send)	1	35,37	
011-55065-008	Wire Harness; P.-Rcv. Sensor	1	33	
011-55070-206	Wire Harness; TPH-Power	1	73,85,87,89	
011-55072-101	Wire Harness; Feed Tray Safety SW	1	9	
011-55087-109	Wire Harness; CN1 & CN8	1	93,95	
011-55090-100	Wire Harness; CN4, CN5,CN9 & CN10	2	93	
011-55095-101	Wire Harness; CN4,CN5,CN9 & CN10; Pressure Det.	1	93,95	
011-55115-102	Inlet Terminal; 200V	1	85,87,89,93,95	
011-55116-001	Inlet Terminal; 100V	1	85,87,89,93,95	
011-55127-208	Wire Harness; Image Scanner; 40	1	43	
011-55134-107	Wire Harness; CN2; Image Processing; 40	2	93	
011-55137-106	Wire Harness; Thermal Pressure Motor	2	67,73	
011-55138-005	Wire Harness; Image-TPH; 40	1	93	
011-60000-003	Scroll Sensor; 56D	1	49	
011-60001-204	Paper Det. Sensor (Send)	1	9	

Part No.	Part Name	Q'ty	Page	Unit Value
011-60002-103	Paper Det. Sensor (Receive)	1	9	
011-60003-207	Paper Sensor	1	17,19	
011-60004-106	Angular Sensor	1	31	
011-60005-307	Master Sensor	1	75,77	
011-60006-109	Master Positioning Sensor	1	75,77	
011-60007-008	Rotation SW; A Position	1	97,99	
011-60008-306	Pressure Det. Potentiometer	1	14	
011-60009-205	ADF Interlock SW	1	41,45	
011-60012-109	Master End Sensor	1	65	
011-60019-200	Bottle Set SW	1	22	
011-60020-004	Front Cover Set SW	1	97,99	
011-60022-007	Switch A	1	3,5,7,79,81	
011-60023-100	Paper Buckle Det. Sensor	1	17,19	
011-60024-000	Magnet C Det. Sensor	1	21	
011-60025-006	Magnet A Det. Sensor	1	21	
011-60026-002	Encoder Sensor	1	13	
011-60027-106	Photoelectron Disc.	1	13	
011-60029-001	Upper Limit Sensor	1	9	
011-60030-107	Clamp Safety Switch	1	31	
011-60033-300	Master Removal Sensor (Send)	1	79,81	
011-60034-307	Master Removal Sensor (Receive)	1	79,81	
011-60035-109	Paper Receiving Sensor (Send)	1	35,37	
011-60036-105	Paper Receiving Sensor (Receive)	1	33	
011-65001-105	Elevator Motor	1	9	
011-65003-108	Clamp Motor	1	31	
011-65004-309	Clamp Solenoid	1	31	
011-65006-301	Suction Motor	1	35,37	
011-65007-103	Inking Motor	1	22	
011-65009-009	Pressure Control Motor	1	31	
011-65012-107	Storage Fan	1	65,71	
011-65013-006	Loading Pulse Motor	1	31	
011-65014-002	Cutter Motor	1	75	
011-65016-307	M.-Rmv. Vertical Transport Motor	1	79,81	
011-65018-300	Master Removal Solenoid	1	79,81	
011-65022-200	Counter	1	85,87,89,91	
011-65025-004	Loading Fan	1	65	
011-70001-300	Image Scanner	1	47	
011-70010-201	Protection Net; Wire Harness	1	93	
011-70019-	System ROM; SP 11	1	93	
011-70022-005	Edging Plate	1	14	
011-70045-	System ROM; SP 11 G	2	93	
011-70053-202	Image Scanner; 40	1	43	
011-70058-000	Glass Plate; Image Scanner	1	47	
011-70500-004	LCD; DMF5005N	1	91	
011-70502-	Panel ROM; 11 En		85,87	

Part No.	Part Name	Q'ty	Page	Unit Value
011-70508-005	LCD; Panel	1	85,87,89	
011-90000-504	Unit/ Power Supply; 100V		87,89	
011-90020-203	Unit/Image Processing PCB; 56D, 56		45	
011-90025-205	Unit/Image Processing PCB; 45	1	45	
011-90050-307	Unit/ Power Supply; 200V		87,89	
011-90100-304	Power Supply PCB III H100	1	91	
011-90105-004	Power Supply PCB III H200	1	91	
011-91200-108	Unit/Main Motor		13	
011-91203-000	Main Motor Ass'y; SU	1	13	
011-91208-109	Pressure Det. Ass'y		13	
011-91211-002	Interlock Switch		85,87	
011-91225-100	Main Shaft Ass'y; B4		13	
011-91226-000	Main Shaft Ass'y; A4		13	
011-91230-007	Unit/Drive Gear; Transfer Belt	1	31	
011-91235-009	Face Plate; Pressure Shaft	1	13	
011-91240-002	Unit/Print Positioning Motor		31	
011-91245-004	Pressure Solenoid Ass'y	1	14	
011-91250-008	Paper Feed Clutch Sensor Ass'y		13	
011-91265-005	Pressure Control Motor Ass'y	1	31	
011-91310-000	Timing Roller Ass'y		17	
011-91320-006	Guide Roller Ass'y		17	
011-91410-102	Pressure Shaft Ass'y; B4		17	
011-91411-001	Pressure Shaft Ass'y; A4		17	
011-91412-008	Pressure Shaft	1	17	
011-91420-000	Pressure Roller Ass'y; B4	1	17	
011-91421-007	Pressure Roller Ass'y; A4	1	17	
011-91500-004	Unit/Paper-Feed Tray		11	
011-91520-005	Unit/Paper-Feed Tray; 100US		11	
011-91530-205	Feed Tray Safety SW Ass'y		9	
011-91610-004	Shaft; Elevator	1	9	
011-91620-107	Unit/Elevator Motor		9	
011-91700-208	Unit/Guide Plate		17	
011-91702-103	Unit/Stripper		17,19	
011-91810-003	Scraper Ass'y		9	
011-91812-006	Shaft; Scraper	1	9	
011-91814-009	Shaft; Pickup Roller	1	9	
011-91820-009	Upper Limit Sensor Ass'y		9	
011-91830-004	P.-F. Pressure Adj. Lever Ass'y		9	
011-91840-000	Magnet Catch Ass'y; P.-F.-T.	1	11	
011-91850-005	Paper Det. Sensor (Receive) Ass'y		9	
011-92100-000	Unit/Drum Screen; B4		25	
011-92101-006	Unit/Drum Screen; 100US		25	
011-92102-002	Unit/Drum Screen; A4		25	
011-92106-008	Ass'y; Angular Magnet Plate		25	
011-92220-005	Unit/Ink Pump		22	

Part No.	Part Name	Q'ty	Page	Unit Value
011-92300-009	Unit/Drum Frame		21	
011-92310-004	Wire Harness Ass'y; Drum Drawer		29	
011-92320-000	Drum Set SW Ass'y		27,29	
011-92350-006	Unit/Drum Lock	1	27,29	
011-92400-003	Unit/Clamp		31	
011-92402-006	Clamp Motor Ass'y	1	31	
011-93100-402	Unit/Paper Receiving Tray II		39	
011-93105-102	Unit/Paper Receiving Tray; 100US		39	
011-93110-009	Magnet Catch Ass'y; P.-Rcv.-T.		3,7	
011-93206-006	Suction Unit		35	
011-93215-005	Paper Receiving Sensor (Receive) Ass'y	1	33	
011-93220-009	Angular Sensor Ass'y		31	
011-93230-004	De-electricity Brush Ass'y		35	
011-93300-002	Separator Ass'y		33	
011-93310-105	Separation Fan	1	33	
011-93315-000	Separation Fan Ass'y II	1	33	
011-94410-308	Unit/Master Removal III; B4		79	
011-94412-203	Unit/Master Removal III; A4		79	
011-94422-004	Holder Ass'y II; V.-Transport Roller	1	79	
011-94431-003	Unit/Master Disposal Box		83	
011-94432-000	Unit/Master Disposal Box; Pic.		83	
011-94433-006	Unit/Master Disposal Box II		83	
011-94434-002	Unit/Master Disposal Box II; Pic.		83	
011-95011-008	Capacitor PCB II Ass'y		67,73	
011-95016-000	Frame B Ass'y; M.-M.		67,69	
011-95017-006	Thermal Pressure Motor Ass'y		69	
011-95018-002	Open/Close Hook Ass'y; M.-M.		67,69	
011-95035-004	TPH Ass'y		69	
011-95037-007	K-TPH Ass'y; 40		67	
011-95038-003	T-TPH Ass'y; 40		67	
011-95041-004	Unit/Write Pulse Motor	1	31	
011-95045-107	Unit/Cutter Motor		75	
011-95046-006	Cutter Joint A	1	75	
011-95050-208	Unit/Loading Pulse Motor	1	31	
011-95070-101	Set Guide Plate Ass'y	1	65	
011-95076-002	Write Roller	1	65	
011-95077-009	Write Roller; 40	1	65	
011-95085-001	De-electricity Brush Ass'y	1	65	
011-95095-007	Stocker Ass'y		65	
011-95100-000	Master Sensor Ass'y	1	75	
011-95111-002	Cutter Cover A Ass'y		75	
011-95121-105	Unit/Cutter II; B4		75	
011-95122-101	Unit/Cutter II; A4		75	
011-95207-107	Unit/Master Roll Holder D; B4		65	
011-95208-103	Unit/Damper; Master Roll Holder; B4	1	65	

Part No.	Part Name	Q'ty	Page	Unit Value
011-95211-104	Unit/Damper; Master Roll Holder; A4	1	65	
011-95212-100	Unit/Master Roll Holder D; A4		65	
011-95360-002	Master Loading Unit SW Ass'y		65	
011-96041-202	Scanner Bottom Plate Ass'y		41,45	
011-96046-000	Unit/ADF II		43,47	
011-96050-104	Wire Harness Ass'y; Image		93	
011-96055-009	Wire Harness Ass'y; Image; 40		93	
011-96065-004	Unit/Top Cover; 100US		49	
011-96067-007	Unit/Top Cover		49	
011-96070-008	Unit/ADF Cover; 56D		97	
011-96075-000	Unit/Clip; 56D		97	
011-96080-003	Unit/ADF Cover; 45, 56		97	
011-96100-209	Original IN Sensor	1	43,47	
011-96101-205	Wire Harness; Original Regist./Det. Sensor	1	43,47	
011-96102-007	Original Guide 4 Ass'y	1	43,47	
011-96104-000	De-electricity Brush Ass'y	1	43,47	
011-96105-103	Original Feed Solenoid	1	43,47	
011-96107-106	Read Pulse Motor	1	43,47	
011-96111-006	Transfer Roller (Lower)	1	43,47	
011-96113-009	Original Guide 1	1	43,47	
011-96115-001	Exit Roller (Lower); Scanner	1	43,47	
011-96116-008	Shaft; Original Feed	1	43,47	
011-96117-004	Original Guide 3 Ass'y	1	43,47	
011-96118-000	Original Guide 2 Ass'y	1	43,47	
011-96501-009	Unit/Digitizer; 56D 100US		49	
011-96502-005	Unit/Digitizer; 56D		49	
011-96511-004	Digitizer; 56D 100US	1	49	
011-96512-000	Digitizer; 56D	1	49	
011-96520-003	Stylus Pen	1	49,103	
011-97200-002	Front Cover Ass'y		99	
011-97210-008	Inner Cover A Ass'y		97,99	
011-97235-000	Unit/Counter		85,87,89	
011-97236-007	Unit/Counter; Pic.		87,89	
011-97241-000	Mount Ass'y; Connector; 100 V		7	
011-97249-001	Mount Ass'y; Connector; 200 V		7	
011-97525-009	Pocket Cover Ass'y; Pic.	1	89,91	
011-97530-509	Unit/Operation Panel; 56/D 100US		87	
011-97531-505	Unit/Operation Panel; 56/D A4		87	
011-97532-404	Unit/Operation Panel; 56/D B4		87	
011-97533-303	Unit/Operation Panel; 56/D Pic.		87	
011-97540-008	Pocket Cover Ass'y	1	85,87	
011-97541-500	Unit/Operation Panel; 45 A4		87	
011-97542-507	Unit/Operation Panel; 45 B4		87	
011-97543-309	Unit/Operation Panel; 45Pic.		87	
011-97550-500	Unit/Operation Panel; 45 100US		87	

Part No.	Part Name	Q'ty	Page	Unit Value
011-97551-204	Unit/Operation Panel; 40US		85	
011-97552-200	Unit/Operation Panel; 40B4		85	
011-97553-207	Unit/Operation Panel; 40Pic		85	
011-97555-005	Key Board Cover Ass'y; 40US	1	85	
011-97556-001	Key Board Cover Ass'y; 40B4	1	85	
011-97557-008	Key Board Cover Ass'y; 40Pic	1	85	
011-97560-009	Key Board Cover Ass'y; 45 US	1	87	
011-97565-009	Key Board Cover Ass'y; 56/D US	1	87	
011-97570-004	Key Board Cover Ass'y; 45 A4	1	87	
011-97571-000	Key Board Cover Ass'y; 45 Pic.	1	87	
011-97575-006	Key Board Cover Ass'y; 56/D A4	1	87	
011-97576-002	Key Board Cover Ass'y; 56/D Pic.	1	87	
011-97580-000	Key Board Cover Ass'y; 45 B4	1	87	
011-97585-001	Key Board Cover Ass'y; 56/D B4	1	87	
011-98120-509	Unit/System PCB II		93,95	
011-98200-200	Unit/Power Supply III-S; 100V		85	
011-98205-105	Unit/Power Supply III-S; 200V		85	
012-16101-401	Upper Rear Frame; 58	1	5	
012-16105-105	Cover Stopper	1	5	
012-16107-108	Edging	1	5,7	
012-16109-100	Rail (Right); 58	1	5,7	
012-16110-109	Rail (Left); 58	1	5,7	
012-16113-000	Bracket C; Micro-SW	2	5	
012-16115-003	Support Cover	2	5,7	
012-16116-107	Stopper A; 58	2	7	
012-16117-006	Stopper B; 58	2	7	
012-16119-009	Spacer; Switch A	1	5	
012-16120-309	Rail Bracket (Right)	2	5,7	
012-16121-003	Rail Bracket (Left)	1	5	
012-16123-006	Flat Cable Clamp Plate A	1	7	
012-16125-106	Sponge; Upper Rear Frame	1	7	
012-16126-005	Bracket II; Interlock Switch	1	85,87,89,91	
012-16127-001	Bracket; Interlock Switch	1	85,87,89,91	
012-16128-008	Spring; Interlock Switch	1	85,87,89,91	
012-16130-002	Shaft; Actuator	1	85,87,89,91	
012-16201-007	Blind Cover	1	55,57	
012-16203-000	Solenoid Cover	1	51	
012-16205-002	Solenoid Holder	1	51	
012-16206-009	Solenoid Pin	1	51	
012-16208-001	Shading Mylar	1	51	
012-16209-008	Shading Plate	1	51	
012-16210-006	Shading Cover	1	51	
012-16211-304	Scanner Bottom Plate	1	55,57	
012-16212-009	Spacer; L4.8	12	55,57	
012-16213-005	Sub-Base Frame	1	55,57	

Part No.	Part Name	Q'ty	Page	Unit Value
012-16214-001	Sheet; Trimming PCB	1	55,57	
012-16215-008	Sheet; Image Processing PCB; 58	1	55,57	
012-16216-004	Sheet; A.C.C. PCB	1	55	
012-16217-000	Bracket; Connector	1	55,57	
012-16218-007	Front Frame	1	52	
012-16219-003	Magnet Plate	1	52	
012-16220-001	Pulley; P2N-20-D	1	51	
012-16221-008	Side Frame (Left)	1	52	
012-16222-101	Side Frame (Right)	1	51	
012-16223-000	Drive Shaft	1	51	
012-16224-007	Pulley; P2M-20/36	1	51	
012-16225-003	Back Frame	1	51	
012-16226-000	Hook	1	51	
012-16227-006	Hook Holder	1	51	
012-16228-002	Crank Arm	1	51	
012-16229-009	Crank Pin	2	51	
012-16230-007	Spring; Hook Holder	1	51	
012-16231-003	Pulley; P2M-20-M	1	51	
012-16232-000	Pulley; P2M-42/24	1	51	
012-16233-006	Pulley Shaft	1	51	
012-16234-002	Bracket; Pulley	1	51	
012-16235-009	Grip Arm	1	51	
012-16236-005	Grip	1	51	
012-16237-001	Grip Holder	1	51	
012-16238-008	Grip Pin	2	51	
012-16240-002	Bracket; Wire Harness	1	95	
012-16241-009	Holder A; Wire Harness	1	95	
012-16242-005	Holder B; Wire Harness	1	95	
012-16243-001	Tension Holder	2	52	
012-16244-008	Tension Pulley	2	52	
012-16245-004	Shaft; Tension Pulley	2	52	
012-16246-000	Tension Pulley Holder	2	52	
012-16247-007	Tension Spring	2	52	
012-16248-003	Reinforce Fitting	3	52	
012-16249-000	Driving Belt Holder Plate (Upper)	2	52	
012-16250-008	Driving Belt Holder Plate (Lower)	2	52	
012-16251-004	Blind Plate C	1	51	
012-16252-000	Edge Fitting; Scanner Bottom Plate	1	55,57	
012-16253-007	Edge Fitting 1		55,57	
012-16254-003	Edge Fitting 2		55	
012-16255-000	Edge Fitting 3		55	
012-16256-103	Upper Back Frame	1	51	
012-16257-002	Spacer Holder	2	51	
012-16258-009	Flat-Head Screw M4 x 6	6	51	
012-16259-005	Sub-Frame	1	51	

Part No.	Part Name	Q'ty	Page	Unit Value
012-16260-003	CCD Fixing Plate	1	51	
012-16261-000	CCD Fixing Screw	2	51	
012-16262-006	Lifting Pin	2	51	
012-16263-002	Lifting Spring	2	51	
012-16264-009	Front Rail	1	52	
012-16265-005	Back Rail	1	52	
012-16266-001	Roller Tension Plate (Right)	1	51	
012-16267-008	Roller Tension Plate (Left)	1	51	
012-16268-004	Roller; CCD	4	51	
012-16269-000	Roller Spring (Right)	1	51	
012-16270-009	Roller Spring (Left)	1	51	
012-16271-005	CCD Holder (Front)	1	51	
012-16272-001	CCD Holder (Rear)	1	51	
012-16273-008	AJ Pin	2	51	
012-16274-101	CCD Cover (Right)	1	51	
012-16275-108	CCD Cover (Left)	1	51	
012-16276-007	Blind Plate A	1	51	
012-16277-003	Blind Plate B	1	51	
012-16278-000	Guide Cover	1	51	
012-16279-103	Stage Glass; US	1	51	
012-16281-000	Scanner Cover	1	51	
012-16287-106	CCD Cover	1	51	
012-16288-005	Stage Glass	1	51	
012-16292-002	Stopper Crank	1	51	
012-16294-005	Stopper Ass'y; US	1	51	
012-16295-001	Stopper Ass'y	1	51	
012-16296-008	Bracket C; Core Set	1	55,57	
012-16298-000	Bracket B; Core Set	1	55,57	
012-16401-103	ADF Rear Frame	1	59	
012-16402-002	Tension Plate (Rear)	1	59	
012-16403-009	Or.-Trans Belt Pulley	1	59	
012-16404-005	Holder Plate; O.T.B. Pulley	2	59	
012-16405-001	Spring; Belt Tension (Back)	1	59	
012-16406-008	ADF Ejection Pulley	1	59	
012-16407-004	Belt Gear	1	59	
012-16408-000	Gear; 28	1	59	
012-16409-007	Damper	1	59	
012-16410-005	Adj. Plate (Rear); Side-shift Prevention	1	59	
012-16411-001	Collar; Side-shift Prevention	2	59	
012-16412-008	DF Spacer	4	59	
012-16413-004	Or.-Trans Belt Roller (Right)	1	59	
012-16414-000	ADF Stay (Right)	1	59	
012-16415-007	ADF Mid Stay (Right)	1	59	
012-16416-003	ADF Mid Stay (Left)	1	59	
012-16417-000	ADF Stay (Left)	1	59	

Part No.	Part Name	Q'ty	Page	Unit Value
012-16418-006	Spring; Holding Roller	16	59	
012-16419-002	Arm; Holding Roller	16	59	
012-16420-000	Holding Roller	16	59	
012-16421-007	Adj. Plate (Front); Side-shift Prevention	1	59	
012-16422-003	ADF Front Frame; 58	1	59	
012-16423-000	Bracket; ADF Magnet Catch	1	59	
012-16424-006	Tension Plate (Front)	1	59	
012-16425-002	Spring; Belt Tension (Front)	1	59	
012-16426-009	Side Frame; ADF Ejection	1	59	
012-16427-005	Or.-Trans Belt Roller (Left)	1	59	
012-16428-001	ADF Ejection Roller	1	59	
012-16429-008	ADF Ejection Plate	1	59	
012-16430-103	ADF Ejection Guide	1	59	
012-16431-002	Mylar Sheet; ADF Ejection	1	59	
012-16432-009	Collar; ADF Ejection	2	59	
012-16433-005	Bracket; ADF Ejection Sensor	1	59	
012-16434-001	Collar; ADF Ejection Sensor	1	59	
012-16435-008	Spring; ADF Ejection Sensor	1	59	
012-16436-004	Actuator; ADF Ejection Sensor	1	59	
012-16437-000	Stopper	1	59	
012-16438-007	Spring; Original Exit Plate	2	59	
012-16439-003	Spring; Original Exit Guide	2	59	
012-16440-109	Hold Plate; Original Loading	3	59	
012-16441-008	Belt; Original Loading	1	59	
012-16442-004	ADF Hinge (Left)	1	61	
012-16443-000	Actuator Plate; ADF SW	1	61	
012-16444-007	ADF Hinge (Right)	1	61	
012-16445-003	ADF Hinge Spacer	2	61	
012-16446-000	Registration Roller	1	61	
012-16447-006	Upper Guide Plate; ADF	1	61	
012-16448-002	Mylar Sheet; Original Feed	2	61	
012-16450-007	Bracket; ADF Original Det. Sensor	1	61	
012-16451-003	Actuator; ADF Original Det. Sensor	1	61	
012-16452-000	Stopper; Original Feed Roller	1	61	
012-16453-006	Lower Guide Plate; ADF	1	61	
012-16454-002	Mylar Sheet; Registration	3	61	
012-16455-009	Mylar Sheet; Separator	1	61	
012-16456-005	Mylar Sheet; Original Feed (Low)	1	61	
012-16457-001	Arbor	2	61	
012-16458-008	Spring; Original Feed (Front)	1	61	
012-16459-004	Link Plate; Original Feed Roller	2	61	
012-16460-002	Joint; Original Feed	1	61	
012-16461-009	Original Pickup Roller (Upper)	1	61	
012-16462-005	Original Feed Roller	1	61	
012-16463-001	Pulley 18	2	61	

Part No.	Part Name	Q'ty	Page	Unit Value
012-16464-008	Spring; Original Feed (Back)	1	61	
012-16465-004	Shaft; Original Pickup Roller	1	61	
012-16466-000	Pulley; Original Pickup	1	61	
012-16467-007	Gear; Original Pickup	1	61	
012-16468-003	Arbor Clutch	1	61	
012-16469-000	Release Spring Clutch	1	61	
012-16470-008	Stopper Release Plate 2	1	61	
012-16471-004	Stopper Shaft; Original Feed	1	61	
012-16472-000	Stopper; Original Feed	2	61	
012-16473-007	Bracket; Original Separation Roller	1	61	
012-16474-003	Side Holder (Rear)	1	61	
012-16475-000	Ground Plate	1	61	
012-16476-006	Center Holder	1	61	
012-16477-002	Shaft; Original Separation Roller	1	61	
012-16478-009	Joint B; Original Sepa. Roller	1	61	
012-16479-005	Spring; Original Sepa. Roller	1	61	
012-16480-003	Spring Cover; Original Sepa. Roller	1	61	
012-16481-000	Joint; Original Sepa. Roller	1	61	
012-16482-006	Original Separation Roller	1	61	
012-16483-002	Side Holder (Front)	1	61	
012-16484-009	Pulley; Original Sepa. Roller	1	61	
012-16485-005	ADF Idler Pulley	1	61	
012-16486-001	Set Plate; Original Tray	2	61	
012-16487-008	Release Lever Ass'y	1	61	
012-16488-004	Release Plate (Front); Registration Collar	1	61	
012-16489-000	Release Spring; Registration Collar	2	61	
012-16490-009	Set Plate; Registration Collar	1	61	
012-16491-005	Side Frame; Registration Collar	1	61	
012-16492-001	Spring; Side Holder	2	61	
012-16493-008	Joint Plate	1	61	
012-16494-004	Shaft; Registration Collar	1	61	
012-16495-000	Release Plate (Rear); Registration Collar	1	61	
012-16496-007	Registration Collar M	1	61	
012-16497-003	Registration Collar L	2	61	
012-16498-000	ADF Base Cover	1	62	
012-16499-006	Gear 18/25	1	62	
012-16500-004	Gear; Registration Collar	1	62	
012-16501-000	Stopper Release Plate 1	1	62	
012-16502-007	Center Arbor; Clock	1	62	
012-16503-003	Center Spring Clutch; Clock	1	62	
012-16504-000	Center Gear; Clock	1	62	
012-16505-006	Clutch Gear; Clock	1	62	
012-16506-002	Center Shaft; Clock	1	62	
012-16507-009	Pulley 60	1	62	
012-16508-005	Spring; Stopper Release	1	62	

Part No.	Part Name	Q'ty	Page	Unit Value
012-16509-001	Clock Disc Pulley	1	62	
012-16510-000	Collar; ADF Motor	2	62	
012-16511-006	Bracket; ADF Motor	1	62	
012-16512-002	Mylar; ADF Motor	1	62	
012-16514-005	Collar; Original Tray	2	101	
012-16515-109	Original Table Support Plate	1	101	
012-16517-004	Original Side Guide	2	101	
012-16518-000	Slide Sheet; Original Tray	4	101	
012-16520-005	Slide Rack; Original Tray	2	101	
012-16521-001	Center Gear; Original Tray	1	101	
012-16522-008	De-electricity Brush	3	59	
012-16525-007	ADF Cover	1	101	
012-16526-003	Original Feed Tray; US	1	101	
012-16527-000	Original Feed Tray; Pic.	1	101	
012-16602-001	Digitizer Cover (Lower)	1	103	
012-16603-008	Lower Clip; 58	1	103	
012-16604-209	Original Slide Plate; Digitizer 58	1	103	
012-16605-108	Holding Plate; Tablet	1	103	
012-16606-007	Frame; Digitizer; 58	1	103	
012-16607-003	Hinge; Digitizer	1	103	
012-16608-000	Digitizer Rail; 58	1	103	
012-16610-004	Bracket; Scroll SW	1	103	
012-16611-000	Protection Sheet; Tablet	1	103	
012-16616-002	Hinge Sponge	1	103	
012-16624-102	Digitizer Cover (Upper); 58US	1	103	
012-16625-001	Digitizer Cover (Upper); 58Eu	1	103	
012-16626-008	Digitizer Cover (Upper); 58Pic.	1	103	
012-17001-109	Back Cover; 58	1	99	
012-17012-003	Pocket Manual; 58	1	89	
012-17014-006	Pocket Manual; 58Pic.	1	89	
012-17032-101	Pocket Cover; Pic.	1	89,91	
012-17052-005	SW Sheet; 58	1	89	
012-17053-001	SW Sheet; 58Pic.	1	89	
012-51007-000	Image Processing PCB (GA); RC5800	1	55	
012-51009-003	Trimming PCB	1	55,57	
012-51016-204	A.C.C. PCB	1	55	
012-51017-103	Original Det. Sensor PCB II	1	55,57	
012-51605-005	P.Main PCB; 58	1	89	
012-51606-001	P.Sub SW PCB	1	89,91	
012-51901-100	ADF Control PCB	1	59	
012-55008-001	Wire Harness; Digitizer (Outer)	1	103	
012-55009-008	Wire Harness; Digitizer (Inner)	1	103	
012-55011-002	Wire Harness; Digitizer	1	55,57	
012-55029-203	Wire Harness; Original Det. Sensor	1	55,57	
012-55031-305	Wire Harness; ADF	1	55,57	

Part No.	Part Name	Q'ty	Page	Unit Value
012-55032-204	Wire Harness; Home-Pos. Sensor	1	55,57	
012-55033-103	Wire Harness; A.C.C.	1	55	
012-55039-101	Wire Harness; Power-Image	1	89,91,95	
012-55049-107	Junction Wire; CN2; Image	1	95	
012-55056-103	Junction Wire; Stopper Solenoid	1	55,57	
012-55057-207	Wire Harness; Image Processing; 58	2	57,95	
012-55901-008	Wire Harness; Ori.-Exit Sensor	1	59	
012-55903-000	Wire Harness; Open/Close SW	1	59	
012-55904-007	Wire Harness; ADF Motor	1	59	
012-55905-003	Wire Harness; Original Feed	1	59	
012-55906-204	Ground Wire	1	59	
012-55907-006	Wire Harness; ADF Control	1	59	
012-60001-007	Scroll SW A	1	103	
012-60002-003	Scroll SW B	1	103	
012-60018-201	Original Det. Sensor	1	55,57	
012-60901-008	ADF Registration Sensor (Receive)	1	61	
012-60902-004	ADF Registration Sensor (Send)	1	61	
012-65001-005	Stopper Solenoid	1	51	
012-65002-001	Read Pulse Motor	1	51	
012-65901-006	ADF Motor	1	62	
012-70001-501	CCD; CIPS305MS5A-1	1	51	
012-70004-	System ROM; SP22G		95	
012-70101-	Panel ROM; 22En		89	
012-96011-009	Key Board Cover Ass'y; 58US		89	
012-96012-005	Key Board Cover Ass'y; 58B		89	
012-96013-001	Key Board Cover Ass'y; 58Pic.		89	
012-96031-000	Pocket Cover Ass'y; 58	1	89,91	
012-96041-200	Upper Rear Frame Ass'y; 58		5	
012-96065-001	Rail (Right) Ass'y; 58		5,7	
012-96070-005	Rail (Left) Ass'y; 58		5	
012-96080-000	Interlock Switch		89,91	
012-96110-104	Unit/Scanner; 58US		51	
012-96111-100	Unit/Scanner; 58		51	
012-96201-002	Unit/Side-shift Prevention Collar (Rear)		59	
012-96202-009	Unit/Side-shift Prevention Collar (Front)		59	
012-96204-001	Unit/ADF Ejection Guide		59	
012-96205-008	Unit/Back Frame		51	
012-96206-004	Unit/Original Feed (Lower)		61	
012-96207-000	Unit/Original Stripper		61	
012-96208-007	Unit/Original Registration Collar		61	
012-96209-003	Unit/Clock Sensor Shaft		62	
012-96210-001	Unit/Read Pulse Motor	1	51	
012-96211-008	Unit/Clock Sensor	1	62	
012-96213-000	Unit/Original Feed (Upper)		61	
012-96214-007	Unit/ADF Motor		62	

Part No.	Part Name	Q'ty	Page	Unit Value
012-96215-208	Unit/CCD		51	
012-96216-000	Unit/Original Tray		101	
012-96217-006	Unit/Original Tray; Pic.		101	
012-96218-002	Wire Harness; CCD Ass'y	1	55,57	
012-96500-000	Unit/Stage Cover	1	99	
012-96601-000	Unit/Digitizer; 58US		103	
012-96602-007	Unit/Digitizer; 58Eu		103	
012-96603-003	Unit/Digitizer; 58Pic.		103	
012-96611-006	Digitizer Ass'y; 58US	1	103	
012-96612-002	Digitizer Ass'y; 58Eu	1	103	
012-96613-009	Digitizer Ass'y; 58Pic.	1	103	
012-97102-202	Unit/Operation Panel; 58US		89	
012-97104-205	Unit/Operation Panel; 58B		89	
012-97105-201	Unit/Operation Panel; 58Pic.		89	
014-11111-004	Bracket F; Suction; A3	1	7	
014-11112-000	Bracket R; Suction; A3	1	7	
014-11114-003	Bottom Cover; A3	1	7	
014-11203-006	Bracket; Pressure Det. Sensor; A3	1	13	
014-11204-002	Spring II; Pressure Link	1	13	
014-11205-009	Pressure Adj. Screw II	1	13	
014-11207-001	Cam; Pressure Roller II; A3	1	13	
014-11301-105	Guide Roller; A3	1	19	
014-11302-101	Shaft; Timing Roller; A3	1	19	
014-11303-000	Timing Roller; A3	1	19	
014-11404-001	Guide Cover; Pressure; A3	1	19	
014-11405-008	De-electricity Brush; A3	1	19	
014-11406-101	Pressure Roller Support; A3	1	19	
014-11410-001	Support Collar; A3	2	19	
014-11501-007	Bracket; P.-F.-T.; A3	1	11	
014-11502-003	Shaft A; P.-F.-T.; A3	1	11	
014-11503-000	Shaft B; P.-F.-T.; A3	1	11	
014-11504-103	Paper Feed Tray; A3	1	11	
014-11511-002	Slide Rack; P.-F.-T.; A3	2	11	
014-11528-100	Feed Board; A3	1	11	
014-11529-009	Feed Board Cover; A3	1	11	
014-11533-006	Spring; Slide Rack; A3	1	11	
014-11601-001	Shaft; Elevator; A3	1	9	
014-11701-006	Guide Plate (Lower); A3	1	19	
014-11714-000	Guide Plate (Upper); A3	1	19	
014-11814-102	Sub-Cover; Pickup Roller	2	9	
014-12101-002	Drum Body; A3	1	25	
014-12103-005	Drum Body Support (Left); A3	1	25	
014-12104-001	Clamp Plate Ass'y; A3	1	25	
014-12106-004	Clamp Plate Base; A3	1	25	
014-12109-003	Screen A; A3	1	25	

Part No.	Part Name	Q'ty	Page	Unit Value
014-12114-007	Seal Tape; A3	1	25	
014-12115-003	Clamp Sub-Plate; A3	1	25	
014-12116-204	Ink Blocking Sheet; A3	1	25	
014-12118-100	Sticker Sheet; Drum; A3	1	25	
014-12119-009	Separate Sheet; A3	2	25	
014-12120-104	Clamp Magnet A; A3	1	25	
014-12121-208	Sheet; Clamp Plate; A3	1	25	
014-12122-000	Screen B; A3	1	25	
014-12124-100	Separator Guide Plate; A3	1	25	
014-12125-009	Sheet (Right); Drum; A3	1	25	
014-12126-005	Sheet (Left); Drum; A3	1	25	
014-12201-007	Squeegee Stay; A3	1	21	
014-12211-002	Inking Pump Body; A3	1	22	
014-12213-005	Ink Distributor; A3	1	22	
014-12216-101	Bottle Guide II Ass'y	1	22	
014-12217-000	Bottle Guide II (Base)	1	22	
014-12221-008	Squeegee Roller; A3	1	21	
014-12224-007	Doctor Roller; A3	1	21	
014-12251-004	Adj. Shaft; Squeegee; A3	1	21	
014-12252-000	Drive Shaft; Squeegee; A3	1	21	
014-12281-000	Frame II; Drum	1	21	
014-12291-006	Bracket; Stopper Lever	1	22	
014-12295-001	Lever; Bottle Stopper	1	22	
014-12297-004	Spring; Stopper Lever	1	22	
014-12299-007	Cover; Bottle Stopper	1	22	
014-12301-109	Rail; Drum; A3	3	29	
014-12302-105	Drum Cover II	1	22	
014-12305-007	Bracket (F); Drum Rail	1	29	
014-12306-003	Bracket (R); Drum Rail	1	29	
014-12307-000	Drum Holder III	1	29	
014-12401-006	Base Plate; Clamp Solenoid; A3	1	31	
014-12402-100	Bracket; Clamp Solenoid; A3	1	31	
014-13101-006	Frame A; Paper Receiving Tray; A3	1	39	
014-13110-005	Slide Guide; Paper Guide; Rcv. ; A3	3	39	
014-13113-004	Slide Frame; Paper Guide; Rcv. ; A3	3	39	
014-13201-108	Cover Plate; Suction; A3	1	37	
014-13202-007	Suction Cover F	1	37	
014-13203-003	Suction Cover R	1	37	
014-13210-000	Face Cover II; Suction	1	37	
014-13301-307	Shaft; Separator; A3	1	33	
014-13302-001	Lever; Separator II	1	33	
014-13401-107	Set Plate F; P.-Rcv.-T.; A3	1	7	
014-13403-100	Set Plate R; P.-Rcv.-T.; A3	1	7	
014-13410-009	Bracket B; Magnet Catch; P.-Rcv.-T.	1	7	
014-14110-009	Vertical Transport Roller (Up); A3	1	81	

Part No.	Part Name	Q'ty	Page	Unit Value
014-14111-102	Vertical Transport Roller (Down); A3	1	81	
014-14119-103	Front Cover; M.-Rmv.; A3	1	7	
014-14120-101	Master Guide; M.-Rmv.; A3	1	77,81	
014-14131-103	Aero Guide Sheet; A3	1	71	
014-14402-107	Right-Side Frame; M.-Rmv.;A3	1	81	
014-14404-100	Left-Side Frame; M.-Rmv.; A3	1	81	
014-14405-009	Stay A; M.-Rmv.; A3	1	81	
014-14406-102	Back Plate; M.-Rmv.; A3	1	81	
014-14407-001	Base Plate; M.-Rmv.; A3	1	81	
014-14408-105	Upper Plate; M.-Rmv.; A3	1	81	
014-14411-009	Guide Plate; M.-Rmv.; A3	1	81	
014-14428-203	Upper Holder; V.-Transport Roller; A3	1	81	
014-14431-000	Shaft; M.-Rmv. Hook; A3	1	81	
014-14432-006	Feed Guide Plate; M.-Rmv.; A3	1	81	
014-14441-005	Guide Screw; Feed Guide Plate	2	81	
014-14451-000	Disposal Box; A3	1	83	
014-14454-000	Handle; Disposal Box; A3	1	83	
014-14455-200	H.-Lever (Right); Disposal Box; A3	1	83	
014-14458-200	H.-Lever (Left); Disposal Box; A3	1	83	
014-14460-107	Frame; Disposal Handle	1	83	
014-14461-006	Guide Plate; Disposal Box; A3	1	83	
014-14463-106	Guide Shaft; Disposal Box; A3	1	83	
014-14464-005	Disposal Shaft; Disposal Box; A3	1	83	
014-14465-001	Lock Shaft; Disposal Box; A3	1	83	
014-14469-007	Shaft; Disposal Box Cover; A3	1	83	
014-15003-109	Frame A; M.-M.; A3	1	73	
014-15004-008	Bracket; TPH; A3	1	73	
014-15005-209	Wire Harness Guide; A3	1	73	
014-15007-007	Load Roller	1	73	
014-15008-003	Shaft; Open/Close Hook; A3	1	73	
014-15009-000	Cover A; M.-M.; A3	1	73	
014-15011-004	De-electricity Bar; M.-M.; A3	2	73	
014-15012-000	Shaft; Load Roller	1	73	
014-15013-007	Sheet; Light Absorber; M.-M.	1	73	
014-15014-100	Lower Cover; M.-M.; A3	1	73	
014-15018-009	Catch Roller (Upper); A3	1	73	
014-15031-005	Guide R; TPH; A3	1	73	
014-15032-001	Guide L; TPH; A3	1	73	
014-15033-008	Bracket; De-electricity Brush; TPH; A3	1	73	
014-15034-004	Protection Sheet A; TPH; A3	1	73	
014-15035-000	De-electricity Brush; TPH; A3	1	73	
014-15102-000	Load Roller (Lower); M.-M.; A3	1	71	
014-15106-005	De-electricity Brush; A3	1	71	
014-15111-009	Cutter Cover A; A3	1	77	
014-15112-102	Set Sheet C	2	77	

Part No.	Part Name	Q'ty	Page	Unit Value
014-15116-108	Set Sheet E	2	77	
014-15119-000	Guide Plate; Cutter; A3	1	77	
014-15123-007	Cutter Guide; A3	1	77	
014-15124-003	Cutter Body; A3	1	77	
014-15125-204	Cutter Guide Sheet B	1	77	
014-15126-200	Cutter Guide Sheet C	1	77	
014-15127-207	Cutter Guide Sheet A	1	77	
014-15128-009	Bracket; Master Sensor; A3	1	77	
014-15131-107	Master Guide Plate; A3	1	71	
014-15144-101	Spring Hanger L; Master Guide Plate	1	71	
014-15145-108	Spring Hanger R; Master Guide Plate	1	71	
014-15146-007	Spring; Master Guide Plate	2	71	
014-15151-000	Frame A; Stocker; A3	1	71	
014-15152-104	Plate B; Stocker; A3	1	71	
014-15155-006	Mount; Loading Pulse Motor; A3	1	31	
014-15161-103	Bracket; Wire Harness	1	7	
014-15173-101	Set Guide Plate; A3	1	71	
014-15174-000	Stay R; Set Guide Plate	1	71	
014-15175-007	Stay L; Set Guide Plate	1	71	
014-15178-103	Set Guide Shaft	1	71	
014-15179-002	Bracket; Micro-SW; M.-M.	1	71	
014-15182-003	Fixing Plate; Pulley G	1	71	
014-15191-002	Guide Plate; Load; A3	1	71	
014-15204-309	Master Roll Holder; A3	1	71	
014-15210-104	Cover; Master Roll Holder	1	71	
014-15214-002	Set Plate; Cover	1	71	
014-15250-009	Tension Arm; Master Roll Holder	1	71	
014-15253-008	Tension Stay; Master Roll Holder	1	71	
014-15255-000	Tension Spring	1	71	
014-15256-007	Tension Sheet; Master Roll Holder	1	71	
014-16001-100	Upper Rear Frame; A3	1	7	
014-16006-004	Rail Bracket (Left); A3	1	7	
014-16008-104	Cover Stopper II	1	7	
014-16009-003	Sheet; Cover Stopper II	1	7	
014-17012-008	Sheet; Sub-Panel; 63 US	1	91	
014-17013-004	Sheet; Sub-Panel; 63 Pic.	1	91	
014-17015-007	Key Board Cover; 63		91	
014-17016-003	Key Board Cover; 63 Pic.		91	
014-17052-000	Pocket Manual; 63	1	91	
014-17053-006	Pocket Manual; 63Pic.		91	
014-17101-000	Back Cover; A3	1	99	
014-17205-000	Bracket; Counter; 63En	1	91	
014-17206-007	Bracket; Counter; 63Pic.	1	91	
014-41528-007	Paper Feed Tray; A3; US	1	11	
014-41814-107	Bracket; Feed Tray Safety SW; A3	1	9	

Part No.	Part Name	Q'ty	Page	Unit Value
014-41815-006	Safety Bar; A3	1	9	
014-44451-102	Disposal Box Cover; A3	1	83	
014-44452-109	Disposal Box Cover; A3; Pic.	1	83	
014-44453-105	Disposal Box Cover B; A3	1	83	
014-44454-101	Disposal Box Cover B; A3; Pic.	1	83	
014-50000-104	Image Processing PCB; A3	1	57	
014-50001-003	MTF2 PCB	1	57	
014-51501-000	System Drive PCB III	1	93,95	
014-55001-001	Wire Harness; Drum; A3	1	21	
014-55002-105	Wire Harness; Image-MTF	1	57	
014-55003-004	Wire Harness; Master Loading SW	1	71	
014-55004-000	Wire Harness; TPH Signal	1	73,95	
014-55005-104	Wire Harness; Trimming PCB	1	55,57	
014-55006-003	Wire Harness; TPH; A3	1	73	
014-55007-000	Wire Harness; CN1 & CN8; A3	1	95	
014-55008-006	Inlet Terminal; 100V; A3	2	91,95	
014-55009-002	Inlet Terminal; 200V; A3	2	91,95	
014-60001-001	Cutter SW; A3	1	77	
014-60002-105	Master End Sensor (Send); A3	1	73	
014-60003-209	Master End Sensor; A3	1	71	
014-65000-003	Cutter Motor; A3	1	77	
014-65013-008	Loading Pulse Motor; A3	1	31	
014-80000-	System ROM; SP33G		95	
014-80002-	Panel ROM; 33En		91	
014-91220-003	Unit/Drive		13	
014-91225-005	Main Shaft Ass'y; A3		13	
014-91230-009	Pressure Link Ass'y		13	
014-91235-009	Unit/Drive Gear; Transfer Belt; A3	1	31	
014-91310-002	Timing Roller Ass'y; A3		19	
014-91320-008	Guide Roller Ass'y; A3		19	
014-91410-104	Pressure Shaft Ass'y; A3		19	
014-91412-000	Pressure Shaft; A3	1	19	
014-91420-002	Pressure Roller Ass'y; A3	1	19	
014-91500-006	Unit/Paper-Feed Tray; A3		11	
014-91520-007	Unit/Paper-Feed Tray; A3; US		11	
014-91530-002	Feed Tray Safety SW Ass'y; A3		9	
014-91700-005	Unit/Guide Plate; A3		19	
014-91810-005	Scraper Ass'y; A3		9	
014-91814-000	Shaft; Pickup Roller; A3	1	9	
014-92100-001	Unit/Drum Screen; A3		25	
014-92220-015	Unit/Ink Pump; A3		22	
014-92300-000	Unit/Drum Frame II		21	
014-92400-005	Unit/Clamp; A3		31	
014-93100-005	Unit/Paper Receiving Tray; A3	1	39	
014-93105-007	Unit/Paper Receiving Tray; A3; 100US	1	39	

Part No.	Part Name	Q'ty	Page	Unit Value
014-93110-000	Magnet Catch B Ass'y; P.Rcv.-T.		7	
014-93200-000	Suction Unit III		37	
014-93300-004	Separator Ass'y; A3		33	
014-94400-002	Unit/Master Removal; A3		81	
014-94410-108	Holder Ass'y; V.-Transport Roller; A3		81	
014-94435-000	Unit/Master Disposal Box; A3		83	
014-94436-007	Unit/Master Disposal Box; A3; Pic.		83	
014-95010-003	Unit/Master Marking; A3		73	
014-95036-002	TPH Ass'y; A3		73	
014-95050-005	Unit/Loading Pulse Motor; A3		31	
014-95060-000	Master Loading Unit SW Ass'y		71	
014-95070-006	Set Guide Plate Ass'y; A3		71	
014-95076-004	Write Roller; A3	1	71	
014-95095-009	Stocker Ass'y; A3		71	
014-95111-004	Cutter Cover A Ass'y; A3		77	
014-95115-000	Unit/Cutter; A3		77	
014-95120-003	Master Sensor Ass'y; A3		77	
014-95207-109	Unit/Master Roll Holder; A3		71	
014-95208-008	Unit/Damper; Master Roll Holder; A3		71	
014-96040-003	Upper Rear Frame Ass'y; A3		7	
014-96070-000	Rail (Left) Ass'y; A3		7	
014-96110-109	Unit/Scanner; 63US		51	
014-96111-105	Unit/Scanner; 63		51	
014-97110-005	Unit/Operation Panel; 63 US		91	
014-97111-001	Unit/Operation Panel; 63 Pic.		91	
014-97112-008	Unit/Operation Panel; 63		91	
014-97210-000	Key Board Cover Ass'y; 63 US		91	
014-97211-006	Key Board Cover Ass'y; 63 Pic.		91	
014-97212-002	Key Board Cover Ass'y; 63		91	
014-97232-003	Unit/Counter; 63En		91	
014-97233-000	Unit/Counter; 63Pic.		91	
015-18252-000	Master Holder II	1	71	
015-70100-005	TPH; A3	1	73	
204-03310-019	Spacer; Paper Feed Clutch	2	13	
408-02300-001	Battery	2	85,87	
435-00004-003	Core Set; ESD QR-25	1	55,95	
435-00015-005	Core Set; 2643-164501	1	55,57	
443-00120-501	Micro-SW; E21-51N	1	3,65,71	
443-00120-609	Micro-SW; E21-91N	2	27,29,67,69,73	
443-00120-706	Micro-SW; E21-92N	1	9	
443-00120-900	Micro-SW; E23-91	1	75	
443-00121-109	Micro-SW; 21-52N	1	79,81	
443-00121-206	Micro-SW; E21-51S	3	5,7	
443-00210-004	Micro-SW; DDIL-AIAA	2	85,87,89,91	
443-01000-704	Micro-SW; V62-1A4	1	61	

Part No.	Part Name	Q'ty	Page	Unit Value
443-02000-600	Micro-SW; AH73503608MSW	2	9	
443-10800-101	Power Switch; AJ911001B3	1	87,89	
443-12000-005	Power Switch; JWZ 2120-2001	1	85,91	
443-30000-403	Sensor; OS3705-02	1	13	
443-30000-500	Sensor; OS3701R-03	3	13,51	
443-30000-608	Sensor; TLP1217(C2)	1	59,61	
485-00001-600	Fuse 10A125V6.3 CES6	1	87	
485-00001-804	Fuse 8A125V5.2 ULTSC	1	87,89,91	
485-00002-401	Fuse 10A 125V 5.2ULTSC	1	89,91	
485-00002-509	Fuse 5A125V5.2 ULTSC	2	87,89,91	
485-00003-408	Fuse 3.15A 125V ULTSC	6	87,89,91	
485-00003-505	Fuse 1A125V5.2 ULTSC	1	87,89	
485-01420-002	Fuse 1A 250V 5.2 SD6	1	91	
488-00013-103	Power Cord; 100V	1	93,95	
488-00014-100	Power Cord; US	1	93,95	
488-00015-106	Power Cord; 200V	1	93,95	
488-90003-101	Ground Wire; U3-100-R3	1	73	
488-90004-108	Ground Wire	2	95	
505-00050-109	Spacer; KGLS-5RTVOL	8	55,57	
505-00050-206	Spacer; KGPS-5RT	8	55,57	
505-00310-003	Support Post (R); SP-3-3-01	6	95	
505-00600-001	Board Spacer; SPS-20	2	95	
550-20077-106	Seal; Ink (Black)	1	22	
550-20078-102	Seal; Setting Master	1	65,71	
550-20079-109	Seal; Setting Procedure	1	65,71	
550-20080-000	Seal; Master Loading	1	3	
550-20081-006	Seal; Scanner Cleaning	1	43,47	
550-20082-002	Seal; Open	1	69,73	
550-20087-004	Seal; Guide; P.-Rcv.-T.	1	39	
550-20091-109	Seal; Ink (Blue)	1	22	
550-20092-105	Seal; Ink (Red)	1	22	
550-20093-101	Seal; Ink (Yellow)	1	22	
550-20094-108	Seal; Ink (Brown)	1	22	
550-20095-104	Seal: Ink (Green)	1	22	
550-20096-003	Seal; Remove Master	1	69	
550-20118-007	Seal; TPH	1	73	
550-20119-003	Seal; Ground	1	95	
550-20208-006	Emblem; 4500	1	97	
550-20209-002	Emblem; 5600	1	97	
550-20210-000	Emblem; 5600D	1	97	
550-20215-100	Seal; Ink (Black); Pic.	1	22	
550-20221-100	Seal; Setting Master; Pic.	1	71	
550-20222-009	Seal; Setting Procedure; Pic.	1	71	
550-20225-008	Seal; Open; Pic.	1	73	
550-20228-007	Seal; TPH; Pic.	1	73	

Part No.	Part Name	Q'ty	Page	Unit Value
550-20241-003	Emblem; 5800	1	99	
550-20280-106	Seal; Setting Master; 58	1	5,7	
550-20281-102	Seal; Setting Master; 58Pic.	1	5,7	
550-20362-005	Emblem; 4000	1	97	
550-20584-008	Seal; P.-Rcv.-T. Pos.	1	37	
550-20605-005	Emblem; 6300	1	99	
550-20613-105	Seal; Ink (Black); A3	2	22	
550-20614-101	Seal; Ink (Black); A3; Pic.	1	22	
550-20621-000	Seal; Ink (Blue); A3	1	22	
550-20622-007	Seal; Ink (Red); A3	1	22	
550-20623-003	Seal; Ink (Yellow); A3	1	22	
550-20624-000	Seal; Ink (Brown); A3	1	22	
550-20625-006	Seal; Ink (Green); A3	1	22	
550-20626-002	Seal; Ink (Blue); A3; Pic.	1	22	
550-20627-009	Seal; Ink (Red); A3; Pic.	1	22	
550-20628-005	Seal; Ink (Yellow); A3; Pic.	1	22	
550-20629-001	Seal; Ink (Brown); A3; Pic.	1	22	
550-20630-000	Seal; Ink (Green); A3; Pic.	1	22	
600-06102-002	Bearing; MR 106ZZS	4	52	
600-08125-000	Bearing; MF128ZZS NSK	2	51	
600-08162-002	Bearing; L816ZZ	4	59	
600-50057-006	Bearing; FLAW678ZZA	2	71	
600-50059-017	Bearing; FLW 688ZZ	4	11,17,19,35,37,65,71	
600-50061-003	Bearing; FL608ZZ	1	13	
601-10007-003	Bearing; 6202ZZ	1	21	
607-05000-207	Metal; S6 x 12 x 10M	2	17,19	
607-10000-010	Metal; F3 x 5 x 3; 8x 1.4	1	21	
607-11000-200	Metal; F4 x 7 x 6; 10 x 1.5	4	67,69,73	
607-12000-000	Metal; F5 x 10 x 6; 12 x 1.5	1	69	
607-13000-003	Metal; F6 x 10/9 x 4; 12 x 1.5	2	13	
607-13000-402	Metal; F6 x 10/9 x 6; 12 x 1.5	4	13,79,81	
607-13000-607	Metal; F6 x 9 x 7; 11 x 1	2	73	
607-13000-801	Metal; 6S	1	59	
607-13000-909	Metal; F6 x 10/8 x 6; 12 x 2	1	62	
607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	2	9,17,19,33	
607-15000-809	Metal; F8 x 16 x 6; 18 x 2	4	65,71	
607-16000-403	Metal; F10 x 15/14 x 5.5; 20 x 2.5	1	9	
607-16000-802	Metal; F10 x 18/16 x 5; 22 x 1.5	4	9	
607-16000-900	Metal; F10 x 16 x 6; 19 x 2; 14.5 x 1	2	21	
607-16000-918	Metal; F10 x 16 x 6; 19 x 2; 14.5 x 8	2	21	
607-17000-105	Metal; F12 x 18 x 10; 24 x 2.5	2	17,19	
607-50800-109	Washer; TW0815	1	13	
610-00001-006	Damper 50F; Master Holder	1	71	
612-03101-006	Gear; Vertical Transport	2	79	
620-03066-105	Belt; 264-3M-6	1	79	

Part No.	Part Name	Q'ty	Page	Unit Value
620-20503-004	Belt; B50M x L3.2	1	65	
620-20714-005	Belt; B71 M x L-4.8	1	31	
620-21309-104	Squeegee Belt; B130/65M x L9.5	1	21	
620-21559-003	Belt; B115 M x L-9.5	1	31	
620-22364-001	Belt; B236 M x L-4.8	1	35,37	
620-31776-002	Belt; 177-3M-6	1	9	
620-32916-002	Belt; 291-3M-6	1	81	
620-37506-007	Belt; 750-3M-6	1	13	
620-48309-009	Belt; 830-5M-15	1	13	
620-50504-005	Belt; B4OS2M100	1	61	
620-50634-006	Belt; B4OS2M126	1	62	
620-50716-002	Belt; 142P2M6	1	51	
620-50806-001	Belt; 160P2M6	1	51	
620-50906-006	Belt; B6OS2M180	1	62	
620-55796-004	Belt; 1158P2M6	1	52	
635-00409-004	Plastic Head Screw; M4 x 9	2	81	
635-00416-108	Set Screw; M4 x 16 (Black)	2	79	
638-80801-009	Ring Washer; 8.2 x 10.2 x 1		14	
638-90000-020	Washer; 18 x 10.2 x 0.2	1	21	
638-90304-003	Washer; 3.5 x 24 x 0.4	2	9	
638-90610-007	Washer; 6.5 x 13 x 1	2	61	
638-90616-005	Washer; 6.1 x 12 x 1.6	1	13	
638-92000-001	Plastic Washer; Plastic Head Screw	2	81	
639-00605-007	Washer; 6 x 10 x 0.5	1	61	
639-00805-103	Washer; 8.5 x 17.5 x 0.5; V-Trans.-Roller	16	79,81	
640-60080-001	O Ring; P8-1.9	2	21	
640-60100-118	O Ring; P10A-2.4	1	22	
640-60140-012	O Ring; P14-2.4	3	21,22	
640-60220-024	O Ring; P22-2.4	1	22	
640-63320-003	O Ring; S32 - 1.8	2	59	
640-70030-100	V Ring; VRY2.7 x 3.5 x 4.1	1	21	
660-01000-200	Rubber Foot K-45	4	3,5,7	
660-05000-018	Magnet Catch SM50P	2	3,5,7	
660-05000-026	Magnet Catch; SM-77S	2	49	
660-05000-301	Magnet Catch; SM-41	1	11	
660-05000-603	Magnet Catch; TL-98S-AL-F	2	103	
660-05000-700	Magnet Catch	1	59	
660-05100-004	Roll Fix	2	69	
660-05500-100	Magnet TDK REC 18 D5 x 2	1	25	
665-00300-109	Flat Cable Clamp; FCN-50P	2	5	
665-02010-000	Clamp DKN-16	9	5,7,71	
665-02020-804	Nylon Clip; NK-2N	5	55,57	
665-02020-901	Nylon Clip; NK-6N	3	55,57	
665-02021-002	Nylon Clip; NK-8N	4	55,57	
665-02021-100	Nylon Clip; NK-10N	2	55,57	

Part No.	Part Name	Q'ty	Page	Unit Value
665-02021-207	Nylon Clip; NK-13N	1	55,57	
665-02025-105	Wire Saddle; WS-A-2-02	1	11	
665-04012-000	Snap Bushing; SB-1500-21	1	91,95	
665-04014-003	Snap Bushing; SB-2000-26	3	91,95	
665-04036-007	Free Bushing; KG-024K	1	95	

II. INDEX

[NOTICE]

★ When you order spare parts, please never fail to order the parts listed in this Index after making sure of what is the spare parts you want.

★ For modified or added parts, please refer to the technical information issued by our technical department.

★ What the part No. means;

Ex.)



● When you order spare parts, please never fail to inform us all of this part No. (the number of eleven figures).