
Sharp AR-235 / AR-275

"1st delivery paper unit 1" - схема узла



Sharp AR-235 / AR-275

"1st delivery paper unit 1" - схема узла

No	Partscode	Price	Description
1	NSFTZ0042QSZZ	AF	Delivery sub roller shaft
3	NROLP0049QSZZ	AC	Delivery sub roller
4	NROLP0079QSZZ	AC	Delivery sub roller (Large)
5	LBRC-0003QSZZ	AD	P-OUT bracket
6	PBRSR0019QSZZ	AK	Discharger brush LP
7	NROLM0037QSZZ	AR	Delivery roller C
8	NBRGY2122SCZZ	AB	Transport roller bearing
9	LPLTM0195QSZZ	AC	Delivery earth plate A
10	NBRGM0501FCZZ	AB	Bearing
11	XRESP50-06000	AA	E type ring
12	LHLDZ0058QSZZ	AR	Delivery roller holder
13	LPLTP0185QSZZ	AM	Delivery change gate
14	MSPRD0224QSZZ	AB	Delivery actuator spring
15	MLEVP0055QSZZ	AC	Delivery actuator
16	MSPRT0197QSZZ	AB	Delivery sub spring
17	XEBSD30P08000	AA	Screw (3x8)
18	CPWBF0083QS51	AU	Sensor PWB
19	DHAI-0240QSZZ	AK	1st delivery harness

Sharp AR-235 / AR-275

"1st delivery paper unit 1" - схема узла

No	Partscode	Price	Description
20	PSPO-0021QSZZ	AD	Shifter cution
21	CSFTZ0023QS01	AH	Shifter shaft
22	XRESP40-06000	AA	E type ring
23	LFRM-0038QSZZ	AX	Delivery frame
24	NROLR0051QSZZ	AL	DUP delivery roller
25	LBSHZ0303FCZZ	AC	M bushing C
26	PGIDM0065QSZZ	AX	Delivery upper paper guide
27	NROLP1122FCZZ	AF	PS upper roller
28	MSPRT0229GCAZ	AC	FU spring R
29	XHBSE40P10000	AA	Screw (4x10)
30	PDUC-0003QSZ1	AG	Cooling fan duct
31	NFANP0004QSZZ	BB	Cooling fan
32	PFILZ0004QSZZ	AM	Ozone filter
33	PMLT-0027QSZZ	AC	Cleaning fan cushion
34	XEBSD20P06000	AA	Screw (2x6)
35	LX-BZ0780FCZZ	AC	Screw
36	LPLTM0264QSZZ	AE	Reinforce plate D
37	PMLT-0066QSZZ	AA	Delivery fan cushion


Sharp AR-235 / AR-275

"1st delivery paper unit 1" - схема узла

No	Partscode	Price	Description
38	LPLTM0271QSZZ	AK	Delivery fan plate side B
39	LPLTM0270QSZZ	AK	Delivery fan plate side A
40	LPLTM0268QSZZ	AF	Delivery fan plate upper B
41	LPLTM0267QSZZ	AE	Delivery fan plate upper A
42	LPLTM0274QSZZ	AH	Delivery frame reinforce plate
43	LPLTM0273QSZZ	AS	Delivery PG reinforce plate
44	LPLTM0272QSZZ	AK	Delivery PG reinforce plate R
(Unit)			
901	CFRM-0038QS51	BX	1st delivery unit(Include Block.24, Except No.29, 35)

Sharp AR-235 / AR-275

"1st delivery paper unit 2" - схема узла



Sharp AR-235 / AR-275

"1st delivery paper unit 2" - схема узла

No	Partscode	Price	Description
1	XHBSD30P10000	AA	Screw (3x10)
2	RMOTP0029QSZZ	AT	Shifter motor
3	CPLTM0184QS02	AG	Shifter drive plate
4	XEBSD30P08000	AA	Screw (3x8)
5	MSPRD0225QSZZ	AC	Stopper return spring
6	LSTPP0003QSZZ	AE	Shifter stopper
7	NGERH0068QSZ1	AD	Shifter gear (50T)
8	NGERH0067QSZZ	AD	Shifter gear (24T)
9	VHPGP1A71A1-1	AG	Photo sensor (GP1A71A1)
10	DHAI-0255QSZZ	AE	Shifter HP sensor harness
11	XRESP30-06000	AA	E type ring
12	XRESP40-06000	AA	E type ring
13	MSPRD0216QSZZ	AD	Shifter earth spring
14	MSPRT0217QSZ1	AC	Gate return spring
15	LBRC-0002QSZZ	AD	Gate bracket
16	LBSHZ0303FCZZ	AC	M bushing C
17	NBRGY2122SCZZ	AB	Transport roller bearing
18	NBRGC0019QSZZ	AD	Bearing

Sharp AR-235 / AR-275

"1st delivery paper unit 2" - схема узла

No	Partscode	Price	Description
19	LPINS0258FCZZ	AA	Spring pin (f3-10)
20	NBLTT0024QSZZ	AG	Drive belt 240
21	NGERH0080QSZZ	AE	Delivery drive gear (25/31T)
22	NGERH0082QSZZ	AD	DUP delivery gear (20/31T)
23	MSPRD0198QSZZ	AC	Delivery earth spring B
24	NGERH0113QSZZ	AC	Idle gear B (29T)
25	NGERH0114QSZZ	AC	Idle gear C (29T)
26	MSPRD0196QSZZ	AC	Delivery earth spring A
27	NGERH0155QSZZ	AD	Gear (31/39T)
28	RPLU-0027QSZZ	AU	Change gate solenoid
29	CBRC-0004QS01	AF	DUP motor fixing bracket
30	RMOTP0024QSZZ	AW	DUP motor
31	XHBSD30P08000	AA	Screw (3x8)
32	XBBSD26P03000	AA	Screw (2.6x3)
33	XWHSD30-05070	AA	Washer
34	LHLDW1334FCZZ	AA	Wire holder
35	PSHEZ0316QSZZ	AD	Delivery motor sheet
36	PRDAZ0002QSZZ	AD	Delivery motor radiation plate


Sharp AR-235 / AR-275

"1st delivery paper unit 2" - схема узла

No	Partscode	Price	Description
501	CPLTM0184QS51	BA	Shifter unit
502	CBRC-0004QS51	BA	DUP motor fixing bracket unit
(Unit)			
901	CFRM-0038QS51	BX	1st delivery unit(Include Block.23)

Sharp AR-235 / AR-275

"2nd 550 cassette unit" - схема узла



Sharp AR-235 / AR-275

"2nd 550 cassette unit" - схема узла

No	Partscode	Price	Description
1	LPLTP0159QSZZ	AD	Cassette rear side plate
2	LHLDW1226FCZZ	AB	Turn fastener
3	LPLTM0179QSZZ	AQ	Rotetion plate
4	PSHEZ0274QSZZ	AC	Rotation plate sheet
5	GCASP0005QSZZ	AZ	550 cassette
6	PGIDM0070QSZZ	AA	Guide F
7	PTPE-0021QSZZ	AD	GID tape
8	LPLTM0181QSZZ	AB	Side plate guide
9	PGIDM0071QSZZ	AL	Guide R
10	LX-BZ0884FCZZ	AB	Screw
11	NGERH0193FCZZ	AB	UC manual feed gear
12	MSPRC2631FCZZ	AC	Fusing pressure spring
13	MLEVP0755FCZ1	AE	Side plate F lever
14	LX-BZ0833FCZZ	AC	Screw
15	PSHEZ0244QSZ1	AC	Cassette mylar
16	XRESP70-08000	AA	E type ring
17	NGERH0108QSZZ	AD	Lift gear (22T)
18	MSPRC0210QSZZ	AC	Lift gear spring


Sharp AR-235 / AR-275

"2nd 550 cassette unit" - схема узла

No	Partscode	Price	Description
19	NSFTZ0047QSZZ	AP	Lift shaft
20	LPLTM0180QSZZ	AE	Lift plate
21	NBRGP0041GCZZ	AD	Bearing
22	XEBSE40P10000	AA	Screw (4x10)
23	JHNDP0003QSZZ	AR	Cassette panel
24	XBPSD40P08KS0	AA	Screw (4x8KS)
25	PSHEZ0275QSZZ	AE	Rotation plate assistance sheet
501	CCASP0005QS61	BG	2nd 550 cassette
(Unit)			
901	CCASP0005QS51	BH	2nd 550 cassette unit

Sharp AR-235 / AR-275

"2nd delivery paper unit" - схема узла



Sharp AR-235 / AR-275

"2nd delivery paper unit" - схема узла

No	Partscode	Price	Description
1	XHBSD40P10000	AA	Screw (4x10)
2	CPLTM0216QS01	AH	DID rail assistance plate
3	PBRSR0021QSZ1	AG	Discharger brush S
4	PBRSR0020QSZ1	AH	Discharger brush L
5	LFRM-0047QSZZ	AG	Delivery frame
6	LFRM-0058QSZZ	AG	Delivery frame R
7	MSPRT0229GCAZ	AC	FU spring R
8	NROLP1122FCZZ	AF	PS upper roller
9	NROLR0056QSZZ	AP	Delivery roller
10	DHAI-0242QSZZ	AG	2nd delivery harness
11	MSPRD0218QSZZ	AD	Delivery earth spring
12	VHPGP1S44S/-1	AK	Photo sensor (GP1S44S)
13	VHPGP1S73P+-1	AF	Photo sensor (GP1S73P)
14	NROLP0079QSZZ	AC	Delivery roller
15	QSW-B0003QSZZ	AF	Tray detect switch
16	NBRGM0501FCZZ	AB	Bearing
17	NGERH0111QSZZ	AC	Drive gear A (25T)
18	NGERH0110QSZZ	AE	Idle gear A (29T)


Sharp AR-235 / AR-275

"2nd delivery paper unit" - схема узла

No	Partscode	Price	Description
19	NGERH0112QSZZ	AC	Drive gear B (25T)
20	NBRGY2122SCZZ	AB	Transport roller bearing
21	PGIDM0072QSZ1	AU	Delivery lower paper guide
22	NROLR0051QSZZ	AL	DUP delivery roller
23	LBSHZ0303FCZZ	AC	M bushing C
24	XRESP40-06000	AA	E type ring
25	MLEVP0067QSZZ	AC	Delivery actuator
26	XRESP50-06000	AA	E type ring
27	XHBSD30P08000	AA	Screw (3x8)
28	XHBSE40P10000	AA	Screw (4x10)
501	CGIDM0072QS61	BD	Delivery paper guide unit
502	CFRM-0047QS51	AZ	Delivery frame unit
(Unit)			
901	CGIDM0072QS51	BG	2nd delivery unit(Except No.28)

Sharp AR-235 / AR-275

"2nd drive section" - схема узла



Sharp AR-235 / AR-275

"2nd drive section" - схема узла

No	Partscode	Price	Description
1	PCOVP0084QSZZ	AE	2nd bottom cover
2	CPWBF0082QS51	BB	2nd cassette interface PWB
3	XEBSD30P08000	AA	Screw (3x8)
4	DHAI-0227QSZZ	AV	2nd harness
5	NBRGC0100FCZ1	AC	Bearing 6
6	MARMP0018QSZZ	AD	Body joint arm
7	PCLC-0008QSZZ	AT	2nd paper feed clutch (42T)
8	XRESP40-06000	AA	E type ring
9	XRESP50-06000	AA	E type ring
10	MSPRT0203QSZZ	AC	Joint spring
11	NGERH0119QSZZ	AD	Gear (36T)
12	NGERH1207FCZZ	AF	Joint gear (40T)
13	CDAIU0024QS52	BA	2nd lift up unit
14	XEBSD40P30000	AA	Screw (4x30)
15	XEBSE40P12000	AA	Screw (4x12)
16	RCORF1036ACZZ	AP	Core
17	DHAI-0231QSZZ	AC	Lift up harness
20	LPLTM0203QSZZ	AH	Drive plate


Sharp AR-235 / AR-275

"2nd drive section" - схема узла

No	Partscode	Price	Description
24	NGERH0121QSZZ	AE	Gear (20T/45T/26P)
25	NBLTT0029QSZZ	AG	Vertical delivery belt
26	PCLC-0003QSZZ	AT	Transport clutch
28	NPLYZ0027QSZZ	AD	Vertical transport pulley
29	PSHEZ0250QSZZ	AB	Frange mylar
30	NROLP0008QSZZ	AD	Pulley
31	PSHEZ0249QSZZ	AB	Frange mylar
32	NBRGC0529FCZZ	AD	Bearing
33	LPLTM0176QSZZ	AH	Crutch earth plate

Sharp AR-235 / AR-275

"2nd exteiors" - схема узла




Sharp AR-235 / AR-275

"2nd exteiors" - схема узла

No	Partscode	Price	Description
1	GCAB-0030QSZZ	AP	Left cabinet
2	XEBSE40P12000	AA	Screw (4x12)
3	LPLTM0240QSZZ	AC	2nd joint plate
5	GCOVA0025QSZZ	AR	Rear cover
7	LFRM-0039QSZZ	BC	Frame
8	LPLTM0236QSZZ	AG	2nd reinforce plate R
10	PCOVP0063QSZZ	AD	Front cover
12	NSFTZ0048QSZZ	AG	Cassette collar shaft
13	NKOM-0005QSZZ	AC	Cassette guide collar
14	XBPSD30P08KS0	AA	Screw (3x8KS)
15	GLEGG0064FCZZ	AC	Rubber foot
16	LPLTM0237QSZZ	AH	2nd reinforce plate F
17	PSPO-0025QSZZ	AC	2nd rear cover sponge
18	LPLTP0192QSZZ	AK	Dry heater fixing plate (120V)
19	XEBSD30P08000	AA	Screw (3x8) (120V)
20	RHET-0006QSZZ	AQ	Dry heater (120V)
21	XEBSD30P10000	AA	Screw (3x10) (120V)

Sharp AR-235 / AR-275

"2nd paper feed section" - схема узла



Sharp AR-235 / AR-275

"2nd paper feed section" - схема узла

No	Partscode	Price	Description
1	CPWBF0082QS51	BB	2nd cassette interface PWB
2	PCOVP0070QSZZ	AD	Sensor cover
4	CPWBF0095QS51	AY	2nd cassette sensor PWB
5	MLEVP0063QSZZ	AD	Upper limit detect actuator
6	MLEVP0064QSZZ	AD	Paper detect actuator
7	MLEVP0062QSZZ	AC	P-IN detect actuator
8	PCOVP0064QSZZ	AD	Solenoid cover
9	RPLU-0026QSZZ	AQ	Paper feed solenoid
10	MARMP0026QSZZ	AD	Solenoid arm
11	MSPRC0209QSZZ	AC	Solenoid spring
13	NSFTZ0050QSZ1	AH	2nd paper feed roller shaft
14	QSW-B0003QSZZ	AF	Tray detect switch
17	DHAI-0246QSZZ	AD	Cassette paper feed switch harness
18	NBRGC0100FCZ1	AC	Bearing 6
19	MSPRD0206QSZZ	AC	Pick up roller pressure spring
20	MARMP0021QSZZ	AD	Pick up arm R
21	NGERH0107QSZZ	AD	Paper feed gear
22	LPIN-0026MCZZ	AA	Spring pin (f2-10)


Sharp AR-235 / AR-275

"2nd paper feed section" - схема узла

No	Partscode	Price	Description
23	NROLR0084QSZZ	AS	Paper feed roller
24	MARMP0019QSZZ	AD	Pick up arm F
26	NGERH0990FCZZ	AB	Gear (16T)
27	NROLR0054QSZZ	AP	Pick up roller
29	DHAI-0228QSZZ	AD	Door open/close detect harness
30	MSPRD0204QSZZ	AC	P-IN detect actuator spring
31	DHAI-0230QSZZ	AF	Cassette sensor PWB harness

Sharp AR-235 / AR-275

"2nd paper transfer section" - схема узла



Sharp AR-235 / AR-275

"2nd paper transfer section" - схема узла

No	Partscode	Price	Description
1	MSPRC0141QSZZ	AB	lock spring
2	MLOKZ0001QSZZ	AC	Paper guide lock
3	XEPSD30P08X00	AA	Screw (3x8X)
4	PGIDM0068QSZZ	AP	Transport paper guide
5	MARMP0015QSZZ	AD	Door arm
6	NSFTZ0054QSZZ	AE	Transport paper guide shaft
7	NROLP1060FCZZ	AF	U-turn roller
8	MSPRP0241QSZZ	AC	Transport paper guide spring
9	XEBSD30P08000	AA	Screw (3x8)
10	GCOVA0026QSZZ	AL	Right cover
11	XEBSD30P10000	AA	Screw (3x10)
12	PCOVP0079QSZZ	AE	Plate cover
13	LPLTP0158QSZZ	AE	Separation plate
14	GPAD-0001QSZZ	AG	Separator pad
15	NROLR0052QSZZ	AN	Transport roller
16	MSPRC0207QSZZ	AB	Separator plate spring
17	NBRGZ0503FCZZ	AC	Bearing
18	LSTPP0011QSZZ	AC	E-ring


Sharp AR-235 / AR-275

"2nd paper transfer section" - схема узла

No	Partscode	Price	Description
19	LRALP0009QSZZ	AQ	Cassette rail R
20	XBPSD30P08KS0	AA	Screw (3x8KS)
21	NKOM-0005QSZZ	AC	Cassette guide collar
22	NSFTZ0048QSZZ	AG	Cassette collar shaft
23	PGIDM0074QSZZ	AK	2nd U-turn guide
24	XEBSE40P12000	AA	Screw (4x12)
25	PSHEZ0301QSZZ	AC	Rail R side mylar F
26	PSHEZ0302QSZZ	AC	Rail R side mylar R
501	CCOVP0079QS51	AX	Plate cover unit
502	CGIDM0068QS51	AT	Transport paper guide unit

Sharp AR-235 / AR-275

"550 cassette unit" - схема узла



Sharp AR-235 / AR-275

"550 cassette unit" - схема узла

No	Partscode	Price	Description
1	LPLTP0159QSZZ	AD	Cassette rear side plate
2	LHLDW1226FCZZ	AB	Turn fastener
3	LPLTM0179QSZZ	AQ	Rotetion plate
4	GCASP0004QSZZ	BA	550 cassette
5	PGIDM0070QSZZ	AA	Guide F
6	MLEVP0755FCZ1	AE	Side plate F lever
7	MSPRC2631FCZZ	AC	Fusing pressure spring
8	LX-BZ0833FCZZ	AC	Screw
9	PTPE-0021QSZZ	AD	GID tape
10	LPLTM0181QSZZ	AB	Side plate guide
11	PGIDM0071QSZZ	AL	Guide R
12	NGERH0193FCZZ	AB	UC manual feed gear
13	LX-BZ0884FCZZ	AB	Screw
14	PSHEZ0244QSZ1	AC	Cassette mylar
15	XRESP70-08000	AA	E type ring
16	NGERH0108QSZZ	AD	Lift gear (22T)
17	MSPRC0210QSZZ	AC	Lift gear spring
18	NSFTZ0047QSZZ	AP	Lift shaft


Sharp AR-235 / AR-275

"550 cassette unit" - схема узла

No	Partscode	Price	Description
19	LPLTM0180QSZZ	AE	Lift plate
20	XBPSD40P08KS0	AA	Screw (4x8KS)
21	NBRGP0041GCZZ	AD	Bearing
22	PSHEZ0274QSZZ	AC	Rotation plate sheet
23	PSHEZ0275QSZZ	AE	Rotation plate assistance sheet
(Unit)			
901	CCASP0004QS51	BG	550 cassette unit

Sharp AR-235 / AR-275

"Delivery tray section" - схема узла



Sharp AR-235 / AR-275

"Delivery tray section" - схема узла

No	Partscode	Price	Description
1	XEPSD30P14X00	AA	Screw (3x14)
2	PCOVP0085QSZZ	AP	Exhaust cover
3	PBOX-0013QSZZ	AK	Exhaust fan box
4	XEBSD30P10000	AA	Screw (3x10)
5	NFANP0006QSZZ	AT	Exhaust fan motor
6	PDUC-0004QSZZ	AL	Exhaust fan duct
8	PBOX-0006QSZZ	AF	Delivery sensor BOX
9	VHPGP1S73P+-1	AF	Photo sensor (GP1S73P)
10	MLEVP0068QSZZ	AC	Delivery tray actuator
11	DHAI-0244QSZZ	AD	Delivery paper detect sensor harness
12	XEBSD30P30000	AA	Screw (3x30)
13	PMLT-0043QSZZ	AE	Delivery cushion
14	LSOU-0023QSZZ	BA	Delivery tray
15	LHLDW1098HCZZ	AB	Holder
16	PSHEZ0292QSZZ	AD	Delivery tray mylar
17	PSHEZ0286QSZZ	AE	Exhaust fan mylar
18	PSHEZ0296QSZZ	AA	Ozone duct dumper sheet
19	PSHEZ0282QSZZ	AC	Dumper sheet D


Sharp AR-235 / AR-275

"Delivery tray section" - схема узла

No	Partscode	Price	Description
20	PSHEZ0283QSZZ	AB	Fan motor sheet
21	PMLT-0056QSZZ	AD	Delivery tray back cushion
22	PMLT-0055QSZZ	AH	Delivery tray back cushion A

Sharp AR-235 / AR-275

"Drive unit" - схема узла



Sharp AR-235 / AR-275

"Drive unit" - схема узла

No	Partscode	Price	Description
1	XBPSD40P08K00	AA	Screw (4x8K)
2	RMOTP0025QSZZ	BH	Main motor
3	CPLTM0160QS01	AU	Main drive plate
4	MSPRC0200QSZZ	AB	Ratchet spring
5	NGERH0153QSZZ	AH	Ratchet gear (49T)
6	NGERH0090QSZZ	AE	Ratchet gear (19T)
7	NGERH0084QSZZ	AK	Gear (94/21T)
8	XRESP70-08000	AA	E type ring
9	NGERH0085QSZZ	AE	Gear (46/18T)
10	NGERH0086QSZZ	AD	Gear (39/21T)
11	NGERH0087QSZZ	AE	Gear (28/21T)
12	NGERH0010QSZZ	AD	Gear (28T)
13	NGERH0092QSZZ	AD	Gear (30/16T)
14	NGERH0093QSZZ	AD	Gear (28/16T)
15	XBPSD30P06KS0	AA	Screw (3x6KS)
16	NGERH0095QSZZ	AE	Gear
17	NGERH0011QSZZ	AD	MG gear
18	NGERH0152QSZZ	AH	N gear (59/21T)


Sharp AR-235 / AR-275

"Drive unit" - схема узла

No	Partscode	Price	Description
19	NGERH0096QSZZ	AE	Gear (37/25T)
20	CPLTM0161QS01	AN	Sub drive plate
21	MSPRC0262QSZZ	AC	MG spring
22	NCPL-0009QSZZ	AC	MG cupring
23	NGERH0091QSZZ	AE	Cupring (34T)
24	NGERH0083QSZZ	AH	Drum cupring gear
25	DHAI-0216QSZZ	AD	Main motor harness
(Unit)			
901	CPLTM0160QS51	BQ	Drive unit

Sharp AR-235 / AR-275

"DV unit" - схема узла



Sharp AR-235 / AR-275

"DV unit" - схема узла

No	Partscode	Price	Description
1	PGIDM0085QSZZ	AP	TN guide U
2	PGIDM0086QSZZ	AQ	TN guide D
3	PSEL-0035QSZZ	AE	TG seal
4	XBBSD40P08000	AA	Screw (4x8)
5	PCOVP0072QSZZ	AK	DV cover U
6	PMLT-0002YSZZ	AC	DV-TH cushion
7	PMLT-0006YSZZ	AB	DV side cushion R
8	PMLT-0005YSZZ	AB	DV side cushion F
9	NROLP0072QSZZ	AP	DMX roller
10	NGERH0135QSZZ	AD	DMX gear (28T)
11	NBRGC0020QSZZ	AH	DMX Bearing
12	XEBSF30P08000	AA	Screw (3x8)
13	PSEL-0037QSZ1	AG	TG seal
14	NGERH0001YSZZ	AD	DV idle gear (20T)
15	NBRGC0021QSZZ	AD	DID Bearing
16	NGERH0136QSZZ	AD	MG gear (18T)
17	XBPSD30P06KS0	AA	Screw (3x6KS)
18	PBOX-0001YS11	AP	DV BOX

Sharp AR-235 / AR-275

"DV unit" - схема узла

No	Partscode	Price	Description
19	PSHEP0035YSZZ	AB	DV side seat N
20	LPLTM5422FCZZ	AC	M4 plate
21	PSEL-0025QSZZ	AA	DVC seal
22	NROLM0071QSZZ	AZ	MG roller
23	PSEL-0001YSZ1	AE	DV plate
24	XBPBZ30P03000	AB	Screw (3x3)
25	LPLTM0001YSZZ	AN	Doctor
26	LPLTM0002YSZZ	AS	Doctor reinforce plate
27	PSEN-0001QSZZ	AC	DV cap F
28	RDTCM0011QSZZ	AZ	ATC sensor
29	XUBUZ30P06000	AA	Screw (3x6)
30	XRESP30-06000	AA	E type ring
31	LHLDR0072QSZZ	AC	MG holder
33	MSPRK0001YSZZ	AB	Bias spring
34	PSPAP0023QSZZ	AC	DV spacer F
35	LHLDZ0001YSZZ	AD	Bearing holder
36	LX-BZ0026QSZZ	AD	Screw
37	XEBSF30P10000	AA	Screw (3x10)


Sharp AR-235 / AR-275

"DV unit" - схема узла

No	Partscode	Price	Description
38	PCOVP0073QSZZ	AG	DV cover F
39	PSEL-0114QSZZ	AC	Seal F
40	PSEL-0115QSZZ	AD	Seal F2
41	TCAUH0016QSZZ	AC	Label
501	CBOX-0001YS58	BM	DV box unit
502	CCOVP0072QS51	AY	DV cover unit

Sharp AR-235 / AR-275

"Exteriors 1" - схема узла




Sharp AR-235 / AR-275

"Exteriors 1" - схема узла

No	Partscode	Price	Description
1	GCAB-0035QSZZ	AK	Optical left cabinet upper
2	GCAB-0036QSZZ	AH	Optical left cabinet lower
3	CFIX-0013QS01	AK	Glass fixing plate
4	PSHEZ0220QSZ1	AK	Shadhing sheet
5	LX-BZ0024QSZZ	AA	Screw
6	GCAB-0040QSZZ	AX	Rear cabinet upper
7	CGIDM0077QS01	AL	OR guide
8	LFIX-0011QSZZ	AK	OC glass fixing plate
9	GCAB-0033QSZZ	AK	Optical right cabinet upper
10	GCAB-0034QSZZ	AK	Optical right cabinet lower
11	PGLSP0003QSZZ	BA	Table glass
12	GCAB-0031QSZZ	AS	Optical front cabinet upper
13	GCAB-0032QSZZ	AQ	Optical front cabinet lower
14	CPNLH0020QS01	AK	Model panel (AR-235)
CPNLH0020QS02	AK	Model panel (AR-275)	
15	TLABH0302QSZZ	AG	Operation label

Sharp AR-235 / AR-275

"Exteriors 2" - схема узла



Sharp AR-235 / AR-275

"Exteriors 2" - схема узла

No	Partscode	Price	Description
1	GCAB-0042QSZZ	AP	Rear cabinet left
2	GCOV-0028QSZZ	BA	Power supply cover
3	XHBSE30P08000	AA	Screw (3x8)
4	GCOV-0029QSZZ	AR	Delivery rear cover upper
5	GCOV-0030QSZZ	AT	Delivery rear cover lower
6	GCAB-0043QSZZ	AN	Rear cabinet lower
7	XEBSE40P10000	AA	Screw (4x10)
8	GCAB-0041QSZZ	BA	Rear cabinet right
9	GCOV-0034QSZZ	AK	Rear cabinet memory cover
10	GCOV-0031QSZZ	AK	Delivery dummy cover
11	MSPRD0189QSZZ	AB	Right cabinet spring
12	MLEVP0069QSZZ	AD	Right cabinet lever
13	GDOR-0003QSZ1	AP	Right cabinet door
14	NROLP1060FCZZ	AF	U-turn roller
15	MSPRT0229GCAZ	AC	FU spring R
16	GCAB-0039QSZZ	AR	Right cabinet
17	GCOV-0043QSZ1	AS	OP PWB cover
18	PFILZ0011QSZZ	AS	Ozon filter

Sharp AR-235 / AR-275

"Exteriors 2" - схема узла

No	Partscode	Price	Description
23	GCAB-0037QSZZ	AL	Front right cabinet (U.S.A)
CCAB-0037QS01	AN	Front right cabinet Except(U.S.A)	
24	LSOU-0033QSZZ	AR	Delivery exetension tray
25	CPNLH0016QS51	BD	Operation panel unit (U.S.A, U.Kingdom, Australia, New Zealand, Philippines)
CPNLH0016QS53	CA	Operation panel unit (Canada)	
CPNLH0016QS55	CB	Operation panel unit (Germany, Greece, Cyprus, Turkey, Poland, Hungary, Czechoslovakia, LAG2, LAG4)	
CPNLH0016QS56	CB	Operation panel unit (Sweden, Finland, Norway, Denmark)	
CPNLH0016QS54	CA	Operation panel unit (Other countries)	
26	GCAB-0038QSZZ	AX	Front cabinet
27	GCOV-0032QSZZ	AE	Power supply switch cover (120V)
GCOV-0032QSZ1	AE	Power supply switch cover (Other countries)	
28	CARMM0023QS01	AD	Hinge arm R
29	MARMM0022QSZZ	AC	Hinge arm L
30	LPIN-0277FCZZ	AB	Slide pin
31	CCOV-0027QS01	AU	Front cover (U.S.A)
GCOV-0027QSZZ	AT	Front cover (Except U.S.A)	
32	DHAI-0205QSZZ	AG	Oparation unit harness
33	XEBSE30P08000	AA	Screw (3x8)

Sharp AR-235 / AR-275

"Exteriors 2" - схема узла

No	Partscode	Price	Description
34	XEBSE40P12000	AA	Screw (4x12)
35	XHBSE40P10000	AA	Screw (4x10)
36	XHBSE40P18000	AB	Screw (4x18)
37	LX-BZ0024QSZZ	AA	Screw
38	GCOV-0042QSZZ	AK	Rail dummy cover
40	TLABZ0058QSZZ	AD	Class 1 label [Except U.S.A, Canada, Taiwan, LAG2, Brazil]
41	TLABH0264GCZZ	AC	Service man label [Europe]
42	TCAUA0770FCZZ	AB	Service caution card
43	TLABH0360QSZZ	AD	Power supply label (120V)
44	TLABH0361QSZZ	AD	Warm heater label (120V)
45	PSHEZ0281QSZZ	AC	Damper sheet C
46	PSHEZ0280QSZZ	AE	Damper sheet B
47	PMLT-0057QSZZ	AC	Front cabinet cushion
48	PMLT-0059QSZZ	AC	Front cabinet cushion C
49	PMLT-0046QSZZ	AF	Front cabinet cushion under
50	PMLT-0062QSZZ	AD	Delivery rear cover upper cushion B
51	LPLTM0263QSZZ	AP	Reinforce plate C
52	PMLT-0048QSZZ	AF	Power supply cover cushion F


Sharp AR-235 / AR-275

"Exteriors 2" - схема узла

No	Partscode	Price	Description
53	PMLT-0047QSZZ	AK	Power supply cover cushion UP
54	PMLT-0050QSZZ	AC	Power supply cover cushion L corner B
55	PMLT-0051QSZZ	AF	Power supply cover left cushion A
56	PMLT-0052QSZZ	AD	Power supply cover left cushion B
57	PMLT-0065QSZZ	AD	Rail dummy cover cushion

Sharp AR-235 / AR-275

"Frame section" - схема узла



Sharp AR-235 / AR-275

"Frame section" - схема узла

No	Partscode	Price	Description
1	LPLTM0163QSZZ	AK	Left reinforce plate lower
2	XHBSE30P08000	AA	Screw (3x8)
3	LPLTM0232QSZZ	AU	Frame reinforce plate R
4	CFRM-0043QS02	AX	Corner frame RL
5	XEBSD40P10000	AA	Screw (4x10)
6	CPLTM0168QS01	AK	DUP drive idle plate
7	PSHEZ0065QSZZ	AB	Pully flange sheet
8	NGERH0109QSZZ	AD	DUP gear (17T)
9	NPLYZ0014QSZZ	AC	DUP pulley gear (17/20T)
10	NPLYZ0015QSZZ	AC	Pulley (20T)
11	LDAI-0023QSZZ	BM	Base plate
13	MSPRC1315FCZ1	AD	Manual clutch spring A
14	LHLDW1061FCZZ	AB	Harness holder (HL-18-0)
15	XHBSE40P10000	AA	Screw (4x10)
16	LPLTM0231QSZZ	AX	Frame reinforce plate F
17	NGERH0066QSZZ	AD	Gear (17T)
18	XRESP40-06000	AA	E type ring
19	NBLTT0026QSZZ	AF	DUP drive belt


Sharp AR-235 / AR-275

"Frame section" - схема узла

No	Partscode	Price	Description
20	LPLTM0165QSZZ	AR	Front reinforce plate
21	PCOVP0066QSZZ	AC	Interlock cover
22	LPLTM0166QSZZ	AC	Front support adjusting plate
23	CFRM-0044QS01	BA	Right frame
24	LPLTM0251QSZZ	AE	PS earth plate
25	NSFTZ0048QSZZ	AG	Cassette collar shaft
26	NKOM-0005QSZZ	AC	Cassette guide collar
27	XBPSD30P08KS0	AA	Screw (3x8KS)
28	XHBSE30P06000	AA	Screw (3x6)
31	LPLTM0262QSZZ	AH	Reinforce plate B
32	PSHEZ0319QSZZ	AC	Base plate R sheet A
33	PSHEZ0320QSZZ	AB	Base plate R sheet B
34	PSHEZ0315QSZZ	AB	Stay RR sheet

Sharp AR-235 / AR-275

"Fusing unit 1" - схема узла



Sharp AR-235 / AR-275

"Fusing unit 1" - схема узла

No	Partscode	Price	Description
1	PCOVP0083QSZZ	AW	Fusing cover
2	XBPSD30P06KS0	AA	Screw (3x6KS)
3	RTHM-0003QSZZ	AL	Thermostat
4	XBBSF30P08000	AA	Screw (3x8)
5	LHLDW0086QSZZ	AB	Harness ring
6	CFRM-0059QS02	AZ	Fusing upper frame
7	LHLDZ0082QSZZ	AH	Rump holder
8	RDTCT0010QSZZ	AN	Thermistor
9	XBPSD30P10KS0	AB	Screw (3x10KS)
10	DHAI-0065QSZZ	AF	Fusing harness
11	RLMPU0019QSZZ	BA	Heater lamp (120V)
RLMPU0022QSZZ	BA	Heater lamp (230V)	
RLMPU0021QSZZ	BA	Heater lamp (110V)	
12	DHAI-0221QSZZ	AD	DUP OUT sensor harness
14	LX-WZ0001QSZZ	AC	Washer
15	LSTPF0172FCZ1	AA	Roller stopper
16	NGERH0100QSZ1	AU	Fusing gear (38T)
17	CBRGP0010QS01	AN	FU bearing


Sharp AR-235 / AR-275

"Fusing unit 1" - схема узла

No	Partscode	Price	Description
18	NROLR0053QSZZ	AZ	Upper heat roller
19	MSPRT0257QSZ1	AC	Upper pawl spring
20	PGIDM0091QSZZ	AR	Fusing rear paper guide
21	PTME-0024QSZZ	AN	Upper separator pawl
22	VHPGP1S73P+-1	AF	Photo sensor (GP1S73P)
23	CFRM-0060QS51	BL	Fusing lower frame unit
24	MSPRC0256QSZ1	AE	Pressure spring LP
25	LX-BZ0028QSZZ	AC	Screw
26	LX-WZ7021SCZZ	AA	Washer
27	PSHEZ0266QSZZ	AH	Sheet
28	LX-WZ0007QSZZ	AC	Washer
(Unit)			
901	DUNTW0171QS13	BX	Fusing unit (110V)
DUNTW0171QS12	BW	Fusing unit (230V)	
DUNTW0171QS15	BX	Fusing unit (120V)	

Sharp AR-235 / AR-275

"Fusing unit 2" - схема узла



Sharp AR-235 / AR-275

"Fusing unit 2" - схема узла

No	Partscode	Price	Description
1	CFRM-0059QS51	BQ	Fusing upper frame unit
2	MSPRD0255QSZZ	AC	Lower pawl spring R
3	XEBSD40P10000	AA	Screw (4x10)
4	NBRGY0022QSZZ	AL	FU pressure bearing
5	NROLR0083QSZZ	BF	Pressure roller
6	XEBSD30P08000	AA	Screw (3x8)
7	CLEVF0088QS02	AM	Pressure lever R
8	CLEVF0087QS02	AM	Pressure lever F
9	MLEVP0085QSZZ	AD	Pressure release lever R
10	XRESP50-06000	AA	E type ring
11	MLEVP0084QSZZ	AD	Pressure release lever F
12	PTME-0014QSZZ	AK	Lower separator pawl
13	MSPRD0254QSZZ	AC	Lower pawl spring F
14	LFRM-0060QSZZ	AS	Fusing lower frame
15	LPLTP0243QSZZ	AM	Reverse gate
16	MSPRD0253QSZZ	AC	Reverse gate spring
17	MSPRD0252QSZ1	AC	DMC spring
18	MLEVP0086QSZZ	AD	DMC actuator


Sharp AR-235 / AR-275

"Fusing unit 2" - схема узла

No	Partscode	Price	Description
19	LPLTM0250QSZ1	AC	Shaft support plate
20	XBPSD30P06KS0	AA	Screw (3x6KS)
21	TLABH0289QSZZ	AA	Green label
22	TLABH0308QSZZ	AF	Heater temperature caution label
23	XHBSE30P08000	AA	Screw (3x8)
24	LX-BZ0029QSZZ	AC	Screw
26	LPLTM0266QSZZ	AE	Presure R earth plate
(Unit)			
901	DUNTW0171QS13	BX	Fusing unit(Except No.3, 23, 24) (110V)
DUNTW0171QS12	BW	Fusing unit(Except No.3, 23, 24) (230V)	
DUNTW0171QS15	BX	Fusing unit(Except No.3, 23, 24) (120V)	

Sharp AR-235 / AR-275

"Job seprator unit(Option AR-TR3)" - схема узла




Sharp AR-235 / AR-275

"Job seprator unit(Option AR-TR3)" - схема узла

No	Partscode	Price	Description
1	LSOU-0034QSZZ	AX	Second delivery tray
3	MLEVP0066QSZZ	AD	Actuator
4	XEBSD30P08000	AA	Screw (3x8)
100	SPAKA0316QSZZ	AK	Spacer
101	SPAKC0315QS11	AN	Packing case English(U.S.A)
SPAKC0315QS12	AN	Packing case English(E.kingdom)	
102	SSAK-4271CCZZ	AD	Vinyl bag (420X690)
103	SSAKA2011KCZZ	AA	Vinyl bag (60X100)
104	TCADZ0154QSZZ	AE	Inst.manual
105	TLABH0305QSZZ	AD	JAM release label

Sharp AR-235 / AR-275

"Lump unit" - схема узла




Sharp AR-235 / AR-275

"Lump unit" - схема узла

1	PREFL0004QSZZ	AP	Riflector
2	RLMPU0012QSZZ	BG	Lump
3	LHLDZ0047QSZ2	AW	Base
4	MSLI-0138FCZZ	AC	Slider
5	PCUSU0203FCZZ	AE	Protection cushion
6	MSPRP0145QSZZ	AF	Spring
7	PMIR-0009QSZZ	AS	1st mirror
8	DUNTK0034QSZZ	BC	Inverter unit
9	DHAI-0200QSZZ	AS	CL harness
10	LFIX-0009QSZZ	AF	Harness fixing
11	PCUSF0334FCZZ	AP	Cushion
12	XEPSD30P06000	AA	Screw (3x6)
14	LPLTM4715FCZ1	AF	Wire fixing plate
15	TCAUH0933FCZZ	AB	High temperature caution label
(Unit)			
901	CREFL0004QS33	BL	Copy lamp unit

Sharp AR-235 / AR-275

"Middle frame" - схема узла



Sharp AR-235 / AR-275

"Middle frame" - схема узла

No	Partscode	Price	Description
1	DUNTK0185QSZZ	BW	LSU unit
2	XEPSD30P14X00	AA	Screw (3x14X)
3	PCOVP0077QSZZ	AE	Middle frame cover upper
5	MARMP0025QSZZ	AD	Separator pawl arm
6	XEBSD30P10000	AA	Screw (3x10)
7	CHAI-0213QS51	AQ	MC harness
8	CHAI-0214QS51	AP	GBMCFB harness
9	LHLDZ0057QSZZ	AH	High voltage terminal holder A
10	DHAI-0215QSZZ	AR	DVS harness
11	MSPRD0190QSZZ	AD	High voltage terminal saw teeth
12	MSPRD0191QSZZ	AD	High voltage terminal grid L
13	MSPRD0192QSZZ	AD	High voltage terminal case L
14	DHAI-0235QSZ1	AL	Interlock switch harness
15	LX-BZ0020QSZZ	AB	Screw
16	LPLTM0149QSZZ	AD	Connector fixing plate
18	XRESP50-06000	AA	E type ring
19	PCLC-0006QSZZ	AU	PS clutch
27	XBBSD30P04000	AA	Screw (3x4)

Sharp AR-235 / AR-275

"Middle frame" - схема узла

No	Partscode	Price	Description
28	LHLDZ0085QSZZ	AE	TR terminal holder
29	LPLTM0248QSZZ	AE	TR terminal plate
30	NROLR0050QSZZ	AS	PS roller
31	NBRGC0018QSZZ	AD	Bearing
32	PCOVP0062QSZZ	AD	ILSW cover
33	LSTPP0010QSZZ	AD	Right door stopper
34	MSPRC0220QSZZ	AB	Stopper spring
35	MLEVP0071QSZZ	AD	ILSW lever
36	CSW-M0007QS52	BB	Inter lock switch
37	LHLDZ0065QSZZ	AE	ILSW holder
39	MSPRT0221QSZZ	AB	ILSW spring
40	JKNBZ0006QSZZ	AD	PS knob
41	XBPSD30P08KS0	AA	Screw (3x6KS)
42	XBPSC30P06ES0	AA	Screw (3x6ES)
43	LFRM-0037QSZZ	BD	Middle frame
44	XRESP60-08000	AA	E type ring
45	LPLTM0194QSZZ	AC	DV fixing plate
47	RMOTD0023QSZZ	AZ	Toner motor


Sharp AR-235 / AR-275

"Middle frame" - схема узла

No	Partscode	Price	Description
48	MSPRC0195QSZZ	AB	Hopper spring
49	NCPL-0011QSZZ	AC	Hopper cupring
50	RPLU-0024QSZZ	AM	Pawl solenoid
51	MSPRC1318FCZ1	AA	Spring B
52	LPINS0300FCZZ	AD	DV guide pin (U.S.A Other countries)
LPINS0301FCZZ	AD	DV guide pin (Europe, Australia, New Zealand)	
53	XEBSD40P10000	AA	Screw (3x10)
54	XEBSD30P06000	AA	Screw (3x6)
55	DHAI-0211QSZZ	AG	TC harness
56	DHAI-0212QSZZ	AH	BC harness
57	XEBSD30P10000	AA	Screw (3x10)
58	DHAI-0232QSZZ	AH	LSU interface harness
59	RCORF0002QSZZ	AE	Core
60	PTPE-0016QSZZ	AC	Core fixing tape
61	RCORF0026FCZZ	AL	LSU harness core
63	TCAUH0007QSZZ	AD	Laser causion label
64	XEPSD23P12000	AA	Screw (3x12)
65	MSPRC0217QSZZ	AD	Sub blade earth spring

Sharp AR-235 / AR-275

"Multi manual paper feed tray unit" - схема узла



Sharp AR-235 / AR-275

"Multi manual paper feed tray unit" - схема узла

No	Partscode	Price	Description
1	PGIDM0075QSZZ	AF	MB side guide F
2	PGIDM0076QSZZ	AF	MB side guide R
3	XEBSE30P08000	AA	Screw (3x8)
4	LSOU-0024QSZZ	AR	Manual paper feed tray 1 upper
5	PTME-0271FCZZ	AD	Tray lock pawl
6	MSPRC0250QSZZ	AC	Tray lock spring
7	NGERR0140QSZZ	AD	Width detect rack
8	XEPSD30P06X00	AA	Screw (3x6X)
9	NGERP1385FCZZ	AF	Width detect pinion
10	LHLDZ0066QSZZ	AD	Harness holder
11	LSOU-0026QSZZ	AR	Manual paper feed tray 2 upper
12	QSW-B0003QSZZ	AF	Tray detect switch
13	DHAI-0236QSZZ	AN	Manual paper feeding unit harness
14	MSPRP2830FCZZ	AA	Width detect spring
15	LPLTP0234QSZZ	AE	Width detect plate
16	MLEVP0035QSE1	AC	Original detect actuator
17	CPWBF0106QS51	AX	Manual paper feeding VR PWB unit
18	LSOU-0025QSZZ	AS	Manual paper feed tray 1 lower


Sharp AR-235 / AR-275

"Multi manual paper feed tray unit" - схема узла

No	Partscode	Price	Description
19	VHPGP1S73P+-1	AF	Photo sensor (GP1S73P)
20	LSOU-0027QSZZ	AQ	Manual paper feed tray 2 lower
(Unit)			
901	CSOU-0024QS51	BK	Manual paper feeding tray unit

Sharp AR-235 / AR-275

"Multi manual paper feed unit" - схема узла



Sharp AR-235 / AR-275

"Multi manual paper feed unit" - схема узла

No	Partscode	Price	Description
1	PCOVP0055QSZZ	AL	Multi frame cover
2	XEBSE30P10000	AA	Screw (3x10)
3	PSHEZ0099QSZZ	AC	Protect sheet
4	NROLR1051FCZZ	AT	Manual feed roller A9
5	NGERH0495FCZZ	AC	Gear (20T)
6	XPSSJ20-07000	AA	Spring pin
7	NGERH0061QSZZ	AD	Gear (24T)
8	MARMP0009QSZZ	AF	Roller arm
9	MSPRT0264QSZZ	AC	Roller arm spring
10	CROLP1115FC02	AN	Paper feeding rolor
11	NSFTZ0018QSZ1	AL	Roller shaft
12	XRESP40-06000	AA	E type ring
13	LBSHZ0303FCZZ	AC	M bushing C
14	LBOSZ1508FCZZ	AG	Cam boss A2
15	MSPRC1315FCZ1	AD	Manual clutch spring A
16	PPIPP0109FCZZ	AB	Manual clutch sleeve pipe A
17	LBOSZ1510FCZZ	AF	Cam boss A1
18	MARMP0041QSZZ	AE	Cam transmission arm

Sharp AR-235 / AR-275

"Multi manual paper feed unit" - схема узла

No	Partscode	Price	Description
19	MARMP0006QSZZ	AD	Arm
20	MSPRT0147QSZZ	AC	Stopper arm spring
21	MCAMP0003QSZZ	AD	Drive cam
22	MSPRC1316FCZ1	AE	MF clutch spring B
23	PPIPP0014QSZZ	AC	Cam clutch sleeve
25	NSFTZ0017QSZZ	AG	Manual feed cam shaft
26	NGERH0972FCZZ	AB	Gear (27T)
27	CPLTM0242QS01	AF	Paper feed plate
28	MSPRD0092QSZZ	AE	MF earth spring
29	XEBSD30P08000	AA	Screw (3x8)
30	PTME-0178FCZZ	AC	Manual paper feeding pawl A
31	MSPRC2175FCZZ	AA	Pawl A spring
32	RPLU-0028QSZZ	AM	Solenoid
33	MSPRC1318FCZ1	AA	Spring B
34	PTME-0179FCZZ	AC	Manual paper feeding pawl B
35	XBBSD30P10000	AA	Screw (3x10)
36	MARMP0027QSZ1	AE	Manual paper feed tray arm
37	LFRM-0048QSZZ	AT	Multi frame


Sharp AR-235 / AR-275

"Multi manual paper feed unit" - схема узла

No	Partscode	Price	Description
38	MARMP0008QSZZ	AH	Stopper arm
39	LPLTP0056QSZ1	AD	Stopper plate
40	XEPSD30P06X00	AA	Screw (3x6X)
41	XEBSD30P10000	AA	Screw (3x10)
42	PSHEZ0241QSZZ	AB	Manual feed protection sheet
43	LBNDJ0013FCZ1	AA	Wire band
(Unit)			
901	CFRM-0048QS51	BG	Multi manual paper feeding unit(Except No.36, 40, 41, 43)

Sharp AR-235 / AR-275

"OC cover unit(Option AR-VR3)" - схема узла



FCP04718


Sharp AR-235 / AR-275

"OC cover unit(Option AR-VR3)" - схема узла

No	Partscode	Price	Description
1	GCOVH0010QSE3	BC	OC cover
2	PMLT-0039QSZZ	AC	OC cushion
3	PCUSS0023QSZZ	AV	OC mat
4	MHNG-0015QSZZ	AS	OC hinge
5	XWVSD40-05000	AA	Washer
6	XEBSE40P12000	AA	Screw (4x12)

Sharp AR-235 / AR-275

"Operation panel unit" - схема узла



Sharp AR-235 / AR-275

"Operation panel unit" - схема узла

1	CPNLH0017QS01	AP	FAX dummy panel
2	GCAB-0050QSZZ	AG	FAX cabinet
7	LPINS0014QSZZ	AC	Fixing pin A
8	CPNLH0016QS01	AZ	Main panel (U.S.A, U.Kingdom, Australia, New Zealand, Pilippines)
CPNLH0016QS04	AZ	Main panel (Germany, Greece, Cyprus, Turkey, Poland, Hungary, Czechoslovakia, LAG2, LAG4)	
CPNLH0016QS03	BA	Main panel (Other countries)	
9	GCAB-0049QSZZ	AQ	Operation panel cabinet
10	LPINS0015QSZZ	AC	Fixing pin B
11	CBTN-0047QS31	AQ	Mode key (U.S.A, Canada, U.kingdom, Australia, New Zealand, Germany, Greece, Cyprus, Turkey, Poland, Hungary, Czcho, LAG2, 4, Philippins)
CBTN-0047QS32	AL	Mode key (Other countries)	
12	JBTN-0046QSZZ	AE	Operation key
13	CBTN-0043QS01	AL	Ten key
14	CBTN-0044QS01	AG	Information key
15	CPLTP0190QS01	AG	Interrupt ring
16	CPLTP0189QS01	AG	Start ring
17	CBTN-0042QS01	AN	Start key
18	CBTN-0045QS01	AL	Cross key
20	XEBSD30P08000	AA	Screw (3x8)
21	CPWBF0077QS51	BB	KEY/LED R PWB


Sharp AR-235 / AR-275

"Operation panel unit" - схема узла

1	CPNLH0017QS01	AP	FAX dummy panel
22	LBOSZ0061QSZZ	AC	Cross key boss
25	DHAI-0206QSZZ	AE	KEY/LED harness A
26	DHAI-0233QSZZ	AC	KEY/LED harness B
27	CPWBF0077QS52	BB	KEY/LED L PWB
28	DHAI-0234QSZZ	AC	FAX/KEY harness
29	RCORF0002QSZZ	AE	Core
30	PSHEZ0293QSZZ	AD	Key panel mylar A
31	PSHEZ0294QSZZ	AD	Key panel mylar B
501	CBOX-0007QS51	BZ	LCD box unit (U.S.A, U.Kingdom, Canada, Australia, New Zealand, Philippines)
CBOX-0007QS54	BZ	LCD box unit (Germany, Greece, Cyprus, Turkey, Poland, Hungary, Czechoslovakia, LAG2, LAG4)	
CBOX-0007QS55	BZ	LCD box unit (Sweden, Finland, Norway, Denmark)	
CBOX-0007QS53	BZ	LCD box unit (Other countries)	
(Unit)			
901	CPNLH0016QS51	BD	Operation panel unit (U.S.A, U.Kingdom, Australia, New Zealand, Philippines)
CPNLH0016QS53	CA	Operation panel unit (Canada)	
CPNLH0016QS55	CB	Operation panel unit (Germany, Greece, Cyprus, Turkey, Poland, Hungary, Czechoslovakia, LAG2, LAG4)	
CPNLH0016QS56	CB	Operation panel unit (Sweden, Finland, Norway, Denmark)	
CPNLH0016QS54	CA	Operation panel unit (Other countries)	

Sharp AR-235 / AR-275

"Optical frame 1" - схема узла



Sharp AR-235 / AR-275

"Optical frame 1" - схема узла

No	Partscode	Price	Description
1	PWIR-0006QSZZ	AQ	MB wire F
2	CDAIU0012QS08	BM	Optical frame
3	NPLYZ0016QSZZ	AF	Pulley
4	NPLYZ0006QSZZ	AD	L pulley
5	XRESP40-05000	AA	E type ring
6	PWIR-0005QSZ1	AQ	MB wire R
7	CMIR-0008QS33	BC	2/3 mirror unit
8	CREFL0004QS33	BL	Copy lamp unit
9	XBPSD40P06K00	AA	Screw (4x6K)
10	LHLDZ0056QSZZ	AC	Wire holder
11	LX-BZ0004QSZZ	AB	Screw
12	LRALM0007QSZZ	AG	MB-B rail R
13	LRALM0006QSZZ	AG	MB-B rail F
14	XBPSD30P05K00	AA	Screw (3x5K)
15	RMOTP0027QSZZ	BG	Mirror motor
16	MSPRC0040QSZZ	AB	MB drive spring
17	CPLTM0084QS02	AK	Mirror motor fixing plate
18	PGUMS0002QSZZ	AL	Protection rubber

Sharp AR-235 / AR-275

"Optical frame 1" - схема узла

No	Partscode	Price	Description
19	XBPSD40P16KS0	AA	Screw (4x16KS)
20	PCUSG0190FCZ1	AB	Table glass cushion
21	XRESP50-06000	AA	E type ring
22	NBRGP0012QSZZ	AC	Winder bearing F
23	NPLYZ0004QSZZ	AG	Winder drive shaft pulley
24	NPLYZ0003QSZZ	AM	Winder pulley
25	LX-BZ0049FCZZ	AB	Screw
26	XPSSJ30-12000	AB	Spring pin (f3-12)
27	NSFTZ0028QSZZ	AM	Winder drive shaft
28	LX-BZ0324FCZZ	AA	Screw
29	NBLTT0002QSZZ	AH	Winder drive belt
30	NGERH0027QSZZ	AH	Mirror motor idle gear
31	LX-WZ0119FCZZ	AA	Washer
32	XRESP70-08000	AA	E type ring
33	NBRGP0011QSZZ	AC	Winder bearing F
34	LX-BZ0024QSZZ	AA	Screw
35	PGIDM0054QSEZ	AG	Hinge guide L
36	XHBSE30P08000	AA	Screw (3x8)


Sharp AR-235 / AR-275

"Optical frame 1" - схема узла

No	Partscode	Price	Description
37	PGIDM0055QSEZ	AG	Hinge guide R

Sharp AR-235 / AR-275

"Optical frame 2" - схема узла



Sharp AR-235 / AR-275

"Optical frame 2" - схема узла

No	Partscode	Price	Description
1	PCOVP0075QSZZ	AE	Harness cover
2	XNESD30-24000	AA	Nut (M3)
3	VHPGP2D03//-1	BA	Photo sensor (GP2D03) (Inch Series)
VHPGP2D07//-1	BA	Photo sensor (GP2D07) (AB Series)	
4	DHAI-0202QSZZ	AN	Optical sensor harness (AB Series)
DHAI-0203QSZZ	AL	Optical sensor harness (Inch Series)	
5	LHLDW1009ACZZ	AA	Clamp
6	XBBSF30P08000	AA	Screw (3x8)
7	CPWBF0083QS51	AU	Sensor PWB
8	CDAIU0012QS08	BM	Optical frame
9	PCUSG0190FCZ1	AB	Table glass cushion
10	XHBSD30P06000	AA	Screw (3x6)
11	VHPGP2D032/-1	BA	Photo sensor (GP2D032) (Inch Series)
RSNSZ0001QSZZ	BA	Photo sensor (GP2D071) (AB Series)	
12	XBPSD30P08X00	AA	Screw (3x8)
13	LPLTP0230QSZZ	AF	Open/close sensor fixing plate
14	VHPGP1S73P+-1	AF	Photo sensor (GP1S73P)
15	MSPRD0232QSZZ	AB	Return spring


Sharp AR-235 / AR-275

"Optical frame 2" - схема узла

No	Partscode	Price	Description
16	MLEVP0077QSZZ	AC	Open/Close actuator
17	LCRA-0002QSZZ	AC	Mini clump
19	LHLDZ0043QSZZ	AE	CL lead holder
20	PSHEZ0218QSZZ	AC	Edge protect mylar A
21	PSHEZ0217QSZZ	AC	CCD harness protect mylar B
22	PSHEZ0109QSZZ	AC	Optical base plate bottom myler B
24	PCASZ0010QSZZ	AL	Durk box
25	LHLDZ7021XCZZ	AD	Holder (FRH-12)
26	RCORF0002QSZZ	AE	Core (HF57SH35*1)
28	CLNS-0003QS52	BP	Lens unit
29	LX-BZ0004QSZZ	AB	Screw
30	DHAI-0201QSZZ	AH	CCD harness
31	PSHEZ0108QSZZ	AC	Optical base plate bottom myler A
32	PSHEZ0219QSZZ	AC	Edge protect mylar B
33	LX-BZ0031GCZZ	AB	Screw
34	PSHEZ0254QSZZ	AC	Optical bottom mylar
38	PSHEZ0273QSZZ	AB	CCD harness protect mylar A
39	PGSK-0008QSZZ	AF	Gasket

Sharp AR-235 / AR-275

"Packing material & accessories" - схема узла



Sharp AR-235 / AR-275

"Packing material & accessories" - схема узла

No	Partscode	Price	Description
1	SPAKC0288QS11	BA	Packing case (AR-235)[U.S.A]
SPAKC0288QSZZ	BA	Packing case (AR-235)Except[U.S.A]	
SPAKC0288QS13	BA	Packing case (AR-275)[U.S.A]	
SPAKC0288QS12	BA	Packing case (AR-275)Except[U.S.A]	
2	CINSE0540QS51	AZ	Operation manual (Copy) [English] (U.S.A)
CINSE0542QS51	BE	Operation manual (Copy) [English](U.Kingdom)	
CINSE0642QS51	BC	Operation manual (Copy) [English](Hong Kong)	
CINSE0541QS51	BE	Operation manual (Copy) [English](Other countries)	
CINSF0543QS51	BC	Operation manual (Copy) [French]	
CINSG0544QS51	BE	Operation manual (Copy) [German]	
CINSS0545QS51	BC	Operation manual (Copy) [Spanish]	
CINSA0549QS51	BC	Operation manual (Copy) [Arabic]	
CINSE0563QS51	AP	Operation manual (Key) (U.S.A)	
TCADZ0049QSZZ	AH	Inst.manual (Germany, Greece, Cyprus, Turkey, Poland, Hungary, Czecho, Sweden, Finland, Norway, Denmark, France, Italy, Holland, Spain)	
TCADZ2001QCZA	AE	Inst.manual (Australia, New Zealand)	
TCADZ0098QSZZ	AF	Warranty resistration card (U.Kingdom)	
TCADZ0015QSZZ	AD	ECP card (Canada)	
PSHEZ1394FCZZ	AC	Vinyl sheet	

Sharp AR-235 / AR-275

"Packing material & accessories" - схема узла

No	Partscode	Price	Description
TLABH0287QSZZ	AK	Label (AB Series)	
TLABH0269QSZZ	AK	Label (Inch Series)	
UKOGZ0002FCZZ	AD	Vinyl gloves	
UYOK-0011FCZZ	AA	Vinyl bag	
3	SPAKA0291QSZZ	AU	Top packing L
4	SPAKA0292QSZZ	AU	Top packing R
5	SSAKZ0019FCZZ	AM	Vinyl bag
6	SPAKA0295QSZ1	AN	Reinforce packing
7	SPAKA0290QSZZ	BD	Bottom packing case
8	LX-BZ0015QSZZ	AF	2/3 fixing screw
9	TCADZ0010QSZZ	AC	Fixing screw caution card
10	LHLDW1226FCZZ	AB	Turn fastener
11	TCADZ1275FCZZ	AB	Cassett rotation tag
12	SSAKA3001CCZZ	AA	Vinyl bag (140X360)
13	SSAKA2343QCZZ	AA	Vinyl bag (260X380)
101	CSHEZ0245QS01	AW	Key sheet (French)
CSHEZ0245QS02	AW	Key sheet (English)	
CSHEZ0245QS04	AW	Key sheet (Spanish)	


Sharp AR-235 / AR-275

"Packing material & accessories" - схема узла

No	Partscode	Price	Description
CSHEZ0245QS07	AW	Key sheet FAX (French)	
102	CCASZ0067FC01	AD	Maintenance case

Sharp AR-235 / AR-275

"Paper feed section" - схема узла



Sharp AR-235 / AR-275

"Paper feed section" - схема узла

No	Partscode	Price	Description
1	XEBSD30P10000	AA	Screw (3x10)
2	CPWBF0081QS51	AU	Cassette sensor PWB
3	MLEVP0064QSZZ	AD	Paper detect actuator
4	MLEVP0063QSZZ	AD	Upper limit detect actuator
5	MLEVP0056QSZZ	AC	P-IN actuator
6	MSPRD0201QSZZ	AC	P-IN actuator spring
7	PCOVP0064QSZZ	AD	Solenoid cover
8	RPLU-0026QSZZ	AQ	Paper feed solenoid
9	MARMP0026QSZZ	AD	Solenoid arm
10	NROLR0054QSZZ	AP	Pick up roller
11	MARMP0019QSZZ	AD	Pick up arm F
13	NGERH0990FCZZ	AB	Gear (16T)
14	NROLR0055QSZ1	AR	Paper feed roller
15	MARMP0021QSZZ	AD	Pick up arm R
16	LPIN-0026MCZZ	AA	Spring pin (f2-10)
17	NGERH0107QSZZ	AD	Paper feed gear (20T)
18	MSPRD0206QSZZ	AC	Pick up roller pressure spring
19	NBRGC0100FCZ1	AC	Bearing 6


Sharp AR-235 / AR-275

"Paper feed section" - схема узла

No	Partscode	Price	Description
20	NGERH0097QSZZ	AF	2nd joint gear
21	DHAI-0238QSZZ	AH	Cassette sensor PWB harness
22	QSW-B0003QSZZ	AF	Tray detect switch
23	NGERH0156QSZZ	AD	Paper feed clutch gear (42T)
24	MSPRC0209QSZZ	AC	Solenoid spring
25	XRESP40-06000	AA	E type ring
27	XRESP50-06000	AA	E type ring
28	PCLC-0004QSZZ	AT	Paper feed clutch (42T)
29	NSFTZ0043QSZ1	AH	Paper feed roller shaft
30	VHPGP1S73P+-1	AF	Photo sensor (GP1S73P)
31	DHAI-0209QSZZ	AG	Manual paper feeding empty harness
32	DHAI-0210QSZZ	AD	Cassette detect sensor harness

Sharp AR-235 / AR-275

"Paper transfer section" - схема узла



Sharp AR-235 / AR-275

"Paper transfer section" - схема узла

No	Partscode	Price	Description
1	XEBSD40P12000	AA	Screw (4x12)
2	PCOVP0053QSZZ	AP	Middle frame cover
3	MSPRD0194QSZZ	AE	PS earth spring LP
4	MSPRC0193QSZZ	AB	PS pressure spring
5	NSFTZ0058QSZZ	AG	PS sub roller shaft
6	NKOM-0003QSZZ	AC	PS collar
7	PSHEZ0133QSZZ	AD	Paper feeding sheet
8	XEBSE40P10000	AA	Screw (4x10)
9	PGIDM0067QSZZ	AR	Base plate paper feed guide
10	MSPRD0233QSZ1	AC	MF actuator spring
11	MLEVP0023QSZZ	AE	MF sensor actuator
12	MLEVP0044QSZZ	AE	MF sensor actuator 2
13	LHLDZ0017QSZZ	AD	Pressure plate holder
14	MSPRC0243QSZZ	AC	Pressure plate spring
15	PCOVP0076QSZZ	AC	Pressure plate cover
16	XEBSD30P10000	AA	Screw (3x10)
17	PSHEZ0242QSZZ	AK	Pressure sheet
18	LRALP0008QSZZ	AS	Base plate rail

Sharp AR-235 / AR-275

"Paper transfer section" - схема узла

No	Partscode	Price	Description
19	VHPGP1S73P+-1	AF	Photo sensor (GP1S73P)
20	DHAI-0208QSZZ	AF	Manual paper feeding PIN harness
21	MSPRD0202QSZZ	AB	Manual P-IN actuator spring
22	MLEVP0057QSZZ	AC	Manual paper feed P-IN actuator
23	GPAD-0001QSZZ	AG	Separator pad
24	LPLTP0158QSZZ	AE	Separation plate
25	PCOVP0060QSZZ	AF	Plate cover
26	MSPRC0207QSZZ	AB	Separator plate spring
27	NKOM-0005QSZZ	AC	Cassette guide collar
28	NSFTZ0048QSZZ	AG	Cassette collar shaft
29	XBPSD30P08KS0	AA	Screw (3x8KS)
30	PSHEZ0243QSZ1	AE	Rail R mylar
31	XEBSD40P10000	AA	Screw (4x10)
32	XPLUZ20-14000	AB	Pin
33	PSHEZ0301QSZZ	AC	Rail R side mylar F
34	PSHEZ0302QSZZ	AC	Rail R side mylar R
35	PSPO-0026QSZZ	AA	MF ACT cushion
36	LPLTM0276QSZZ	AE	Manual feed damper plate


Sharp AR-235 / AR-275

"Paper transfer section" - схема узла

No	Partscode	Price	Description
37	PSHEZ0322QSZZ	AD	Front separator sheet
501	CGIDM0067QS51	AY	Base plate paper feed guide unit
502	CCOVP0053QS51	AW	Middle frame cover unit
503	CCOVP0060QS51	AY	Plate cover unit

Sharp AR-235 / AR-275

"Pick up motor unit" - схема узла




Sharp AR-235 / AR-275

"Pick up motor unit" - схема узла

No	Partscode	Price	Description
1	CMOTV0778FC52	AW	Lift up motor unit
2	NGERH0158QSZZ	AE	Gear (29T/11T)
3	LDAIU0024QSZZ	AH	Lift up base
4	NGERH0102QSZZ	AD	Gear (53T/14T)
5	NSFTZ0045QSZZ	AC	Shaft
6	NGERH0103QSZZ	AE	Gear (54T/13T)
7	NSFTZ0044QSZZ	AC	Shaft
8	NSFTZ0060QSZZ	AC	Shaft
9	NGERH0104QSZZ	AE	Gear (13T/42T)
10	NGERH0105QSZZ	AD	Gear (19T)
11	PCOVP0061QSZZ	AH	Lift up cover
12	MSPRD0208QSZZ	AC	1st cassette earth spring
MSPRD0251QSZZ	AD	2nd cassette earth spring	
13	MSPRC0263QSZZ	AC	Lift up spring
(Unit)			
901	CDAIU0024QS51	BA	1st lift up unit
CDAIU0024QS52	BA	2nd lift up unit	

Sharp AR-235 / AR-275

"Process unit" - схема узла



Sharp AR-235 / AR-275

"Process unit" - схема узла

No	Partscode	Price	Description
1	XEBSD30P08000	AA	Screw (3x8)
2	PCAPH0009QSZZ	AC	Toner pipe cap
3	NSRW-0002QSZZ	AE	Transport pipe screw
4	LPLTM0241QSZZ	AF	Process reinforce plate
5	MLEVP0065QSZZ	AE	Separator pawl lever
6	CFRM-0049QS61	BP	Process frame
7	NCPL-0003QSZZ	AC	Screw cupring
10	PSEL-0071QSZZ	AF	Seal R
11	PSEL-0070QSZZ	AF	Seal F
12	PSHT-0004QSZ1	AC	Toner pipp shuter
13	PPIPP0015QSZZ	AG	Toner pipe
14	MSPRC0045QSZZ	AA	Toner pipe spring
15	PSPAZ0696FCZZ	AC	P cap spacer
16	NGERH0036QSZZ	AC	Transport screw gear (30T)
17	PCOVP0057QSZZ	AG	Drum cover
18	NGERH0039QSZZ	AE	Transport pipe gear (14T)
19	LFIX-0014QSZZ	AE	Drum fixing plate A (U.S.A Other countries)
LFIX-0015QSZZ	AE	Drum fixing plate B (Europe, Australia, New Zealand)	


Sharp AR-235 / AR-275

"Process unit" - схема узла

No	Partscode	Price	Description
20	NGERH0037QSZZ	AC	Idle gear (26T)
21	NGERH0038QSZZ	AC	Transport pipe gear (15T)
22	NSFTZ0020QSZZ	AL	Transport screw
23	NBRGP0299FCZZ	AC	DV bearing
24	PMLT-0018QSZ1	AC	Transport screw cushion
25	PTME-0021QSZZ	AK	Separator pawl
26	LX-WZ0329FCZZ	AB	Washer
27	LX-RZ0001QSZZ	AB	Starling
28	MSPRT0214QSZZ	AB	Lever spring
29	XHBS230P08000	AA	Screw (2.3x8)
30	MSPRC0213QSZZ	AB	Separator pawl spring
31	CHLDZ0035QS53	AZ	MC holder unit
32	UCLEZ0011QSZZ	AT	Cleaning blade
33	XEBSE30P10000	AA	Screw (3x10)
501	CPIPP0015QS51	AU	Toner pipe unit
(Unit)			
901	CFRM-0049QS51	BM	Process unit(Except No.19)

Sharp AR-235 / AR-275

"PWB section" - схема узла



Sharp AR-235 / AR-275

"PWB section" - схема узла

No	Partscode	Price	Description
1	CPWBX0074QS31	BN	IMC PWB
2	PSPAN0025QSZZ	AE	Support post 16
3	PSPAF0030QSZZ	AG	Spacer
4	CPWBF0080QS51	BG	Option connector PWB
5	XBBSF30P08000	AA	Screw (3x8)
6	DHAI-0219QSZZ	AF	OP interface PWB harness
7	LHLDZ0062QSZ1	AP	MCU PWB holder
8	LSTYM5022BCZZ	AD	Screw
9	LHLDW0086QSZZ	AB	Harness ring
10	CPWBX0073QS31	BN	MCU PWB (AR-235)
CPWBX0073QS32	BN	MCU PWB (AR-275)	
12	LHLDZ0071QSZZ	AG	Mother bord holder
13	CPWBX0090QS51	BB	Mother bord
14	XHBSE30P08000	AA	Screw (3x8)
15	LX-BZ0024QSZZ	AA	Screw
16	LHLDZ0070QSZ1	AW	OP PWB holder
17	XHBSE30P08000	AA	Screw (3x8)
18	XEBSE40P10000	AA	Screw (4x10)


Sharp AR-235 / AR-275

"PWB section" - схема узла

No	Partscode	Price	Description
19	XBPSD30P08KS0	AA	Screw (3x8KS)
20	PSHEZ0269QSZZ	AC	CCD harness sheet
21	RCORF0002QSZZ	AE	Core
22	CPWBX0099QS33	CE	Code Dimm PWB
23	PCAPH1005ACZZ	AC	9P protect cap
24	PCAPH1003ACZZ	AC	25P protect cap
25	PCAPH0023FCZZ	AC	15P protect cap

Sharp AR-235 / AR-275

"Rear frame section" - схема узла



Sharp AR-235 / AR-275

"Rear frame section" - схема узла

No	Partscode	Price	Description
1	XBPSN40P06K00	AA	Screw (4x6K)
2	DHAI-0220QSZZ	AK	HL interface harness
3	DHAI-0222QSZZ	AR	PS harness
4	XHBSE30P06000	AA	Screw (3x6)
5	LPLTM0162QSZZ	AC	Drive earth plate
6	LPLTM0252QSZZ	AD	Paper feed earth plate LP
7	DHAI-0237QSZZ	AR	Drive/Manual paper feeding harness
8	DHAI-0256QSZZ	AC	Cassette earth harness
9	XHBSE30P08000	AA	Screw (3x8)
10	XEBSD40P30000	AA	Screw (4x30)
11	PGIDM0066QSZZ	AK	Harness guide
12	XEBSD40P30000	AA	Screw (4x30)
13	CDAIU0024QS51	BA	1st lift up unit
14	DHAI-0218QSZZ	AD	LUM harness
15	LPLTM0249QSZZ	AC	2nd earth plate
19	QACCD741BQCZZ	AS	AC cord (U.S.A, Canada, LAG2, Brazil)
QACCB7421QCZZ	AS	AC cord (U.Kingdom, Yemen, Suudi Arabia, Oman, Qutar, Bahrain, Kuwait, UAE)	
QACCL7426QCZZ	AT	AC cord (Australia, New Zealand)	

Sharp AR-235 / AR-275

"Rear frame section" - схема узла

No	Partscode	Price	Description
QACCJ6411QCZZ	AS	AC cord (Philippines, Taiwan)	
QACCE7423QCZZ	AP	AC cord (Other countries)	
DHAI-0151QSZZ	AU	AC cord (SRH, South Africa, India, SRS, SRSSC, Indonesia, Special countries)	
QPLGA0005QCZZ	AN	AC plug (SRH, South Africa, India)	
DHAI-0167QSZZ	BA	AC cord (Saudi Arabia)	
QPLGA0002QCZZ	AN	AC plug (Saudi Arabia)	
QPLGA0001QCZZ	AN	AC plug (Special countries)	
QPLGA0003QCZZ	AN	AC plug (SRS, SRSSC, Indonesia)	
20	QSW-C9292QCZZ	AN	Power supply switch (AJ8W200B)
21	DHAI-0225QSZZ	AG	3P terminal stand harness (200V Series)
22	PSHEZ0140QSZZ	AE	3P terminal stand sheet (200V Series)
23	QTANN0015FCZZ	AG	3P terminal stand (200V Series)
24	XEBSD30P18000	AA	Screw (3x18)
25	XWHSD30-05080	AA	Washer
26	XWSSD30-07000	AA	Washer
27	RCILZ0012QSZZ	BE	Reactle (200V Series)
28	RDENU0003QS11	BY	Power supply unit (120V)
RDENU0003QS12	CA	Power supply unit (230V)	


Sharp AR-235 / AR-275

"Rear frame section" - схема узла

No	Partscode	Price	Description
RDENU0003QSZZ	BZ	Power supply unit (100V)	
30	LHLDW1057FCZZ	AB	Wire holder (LWS-3S)
31	DHAI-0223QSZZ	AN	AC switch harness
32	LFIX-0016FCZZ	AD	AC cord fixer
33	XEBSD40P30000	AA	Screw (4x30)
34	XEBSE40P12000	AA	Screw (4x12)
35	XWHSD40-08100	AA	Washer
36	XWSSD40-10000	AA	Washer
37	QSW-C9293QCZZ	AG	Dry heater switch (120V)
38	DHAI-0224QSZZ	AK	Dry heater switch harness (120V)
39	DHAI-0258QSZZ	AH	Dry heater separete harness (120V)

Sharp AR-235 / AR-275

"Side door unit" - схема узла



Sharp AR-235 / AR-275

"Side door unit" - схема узла

No	Partscode	Price	Description
1	MLEVP0058QSZZ	AE	Lock lever
2	GDOR-0002QSZZ	AU	Right door
3	XRESP40-06000	AA	E type ring
4	LBSHZ0303FCZZ	AC	M bushing C
5	NGERH0074QSZZ	AD	DUP roller driving gear
6	LPINS0133FCZZ	AA	Pin (2x10)
7	PTME-0020QSZZ	AC	Lock pawl
8	MSPRD0222QSZZ	AC	Lock pawl spring
9	MARMP0043QSZZ	AC	Lock pawl arm
10	NSFTZ0055QSZ1	AN	Lock pawl shaft
11	XRESP30-06000	AA	E type ring
12	NROLP0036QSZZ	AP	DUP transport roller
13	XPSSJ20-07000	AA	Spring pin
14	MSPRT0141GCA1	AB	FU PSV spring
15	NROLP1122FCZZ	AF	PS upper roller
16	LFRM-0040QSZZ	AV	Right door inner
17	MSPRC0249QSZ1	AE	High voltage spring B
18	MSPRC0248QSZ1	AE	High voltage spring A


Sharp AR-235 / AR-275

"Side door unit" - схема узла

No	Partscode	Price	Description
19	LPLTM0102QSZZ	AD	DUP roller eatrh plate
20	LHLDZ0084QSZZ	AF	TR terminal interface holder
21	XEBSE30P08000	AA	Screw (3x8)
22	MSPRC0247QSZ2	AE	TR pressure spring R
23	MSPRC0246QSZ2	AE	TR pressure spring F
24	XHBSD30P10000	AA	Screw (3x10)
25	XHBSD30P16000	AA	Screw (3x16)
26	XHBSD30P14000	AA	Screw (3x14)
27	XEBSD30P10000	AA	Screw (3x10)
28	LPLTM0090QSZZ	AE	Inner reinforce plate F
29	LPLTM0091QSZZ	AE	Inner reinforce plate R
30	MSPRD0205QSZZ	AE	TC grand spring
31	LRALP0004QSZZ	AL	Right door rail
32	LPLTM0092QSZZ	AF	Rail reinforce plate
33	CHLDR0083QS51	BG	TC unit
34	PSHEZ0307QSZZ	AB	Right door mylar
(Unit)			
901	CDOR-0002QS51	BH	Side door unit(Except No.33)

Sharp AR-235 / AR-275

"TC unit" - схема узла



Sharp AR-235 / AR-275

"TC unit" - схема узла

No	Partscode	Price	Description
1	PSHEZ0246QSZ1	AF	Sheet
2	PCLR-0008QSZZ	AD	Roller collar
3	NBRGP0023QSZZ	AD	Roller bearing
4	NROLR0078QSZZ	AZ	TC roller
5	LHLDR0083QSZ1	AK	TC holder N
6	MSPRC0245QSZ1	AC	TR roller spring
7	NGERH0151QSZZ	AH	TR gear
8	LPLTM0247QSZZ	AC	Separator electrode plate
9	LPLTM0246QSZZ	AC	TR electrode plate
10	LPLTM0245QSZ1	AT	TR reinforce plate
11	XBPSC30P06K00	AA	Screw (3x6K)
12	XEBSE30P06000	AA	Screw (3x6)
13	PGIDH0093QSZ1	AN	TR front paper guide N
14	DUNTK0233QSZZ	CA	Resistor unit
15	PMLT-0044QSZZ	AA	TR cushin
16	PSHEZ0305QSZZ	AD	Discharger plate sheet upper
17	CSPAZ0031QS01	AF	Discharger spacer
18	CHLDZ0089QS01	AP	Separetor holder

Sharp AR-235 / AR-275

"TC unit" - схема узла

No	Partscode	Price	Description
19	PRNGF0107FCZZ	AC	TC rear starring
20	UCLEZ0015QSZZ	AL	Cleaner mocket
(Unit)			
901	CHLDR0083QS51	BG	TC unit