Savin SC106 (A109)
(RICOH NC5006)
PARTS CATALOG

First Edition January 1996

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

SC106	**(A109)**
DF60	**(A376)**
CS210	**(A511)**
Sorter Adapter Type J	**(A527)**
RE8	**(A997)**
SPU2	**(A998)**
Holder Type A	**(A702)**

Savin SC106 (A109)
(RICOH NC5006)

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG


Location of Unit 3
1.Exterior 1 (A109) 12
2.Exterior 2 (A109) 14
3.Operation Panel (A109) 16
4.Optics Section 1 (A109) 18
5.Optics Section 2 (A109) 20
6.Optics Section 3 (A109) 22
7.Optics Section 4 (A109) 24
8.Printer Section 1 (A109) 26
9.Printer Section 2 (A109) 28
10.1st Paper Feed Tray (A109) 30
11.2nd And 3rd Paper Feed Tray (A109) 32
12.Paper Supply Unit 1 (A109) 34
13.Paper Supply Unit 2 (A109) 36
14.Paper Supply Unit 3 (A109) 38
15.Paper Feed Section 1 (A109) 40
16.Paper Feed Section 2 (A109) 42
17.By-pass Feed Table (A109) 44
18.Paper Registration (A109) 46
19.Around The Drum (A109) 48
20.Drum Unit 1 (A109) 50
21.Drum Unit 2 (A109) 52
22.Toner Tank Unit 1 (A109) 54
23.Toner Tank Unit 2 (A109) 56
24.Development Unit - Black (A109) 58
25.Development Unit - Cyan (A109) 60
26.Development Unit - Magenta (A109) 62
27.Development Unit - Yellow (A109) 64
28.Transfer Belt Unit 1 (A109) 66
29.Transfer Belt Unit 2 (A109) 68
30.Transfer Roller Unit (A109) 70
31.Transport Unit (A109) 72

Janualy ,15 ’96

32.Belt Cleaning Unit (A109) 74
33.Toner Collection Section (A109) 76
34.Fusing Unit 1 (A109) 78
35.Fusing Unit 2 (A109) 80
36.Fusing Unit 3 (A109) 82
37.Fusing Unit 4 (A109) 84
38.Drive Section 1 (A109) 86
39.Drive Section 2 (A109) 88
40.Drive Section 3 (A109) 90
41.Drive Section 4 (A109) 92
42.Electrical Section 1 (A109) 94
43.Electrical Section 2 (A109) 96
44.Electrical Section 3 (A109) 98
45.Electrical Section 4 (A109) 100
46.Frame Section 1 (A109) 102
47.Frame Section 2 (A109) 104
48.Frame Section 3 (A109) 106
49.Frame Section 4 (A109) 108
50.Main Control Board (A109) 110
51.IPU Board (A109) 114
52.AC Main Harness (A109) 120
53.Decal And Document (A109) 122
54.Special Tools (A109) 126
Parts index 129


Location of unit

1. EXTERIOR 1 (A109)




See Page 12

2. EXTERIOR 2 (A109)




See Page 14

3. OPERATION PANEL (A109)




See Page 16

4. OPTICS SECTION 1 (A109)




See Page 18

5. OPTICS SECTION 2 (A109)



See Page 20


6. OPTICS SECTION 3 (A109)



See Page 22


Location of unit

7. OPTICS SECTION 4 (A109)




See Page 24

8. PRINTER SECTION 1 (A109)




See Page 26

9. PRINTER SECTION 2 (A109)




See Page 28

10. 1ST PAPER FEED TRAY (A109)




See Page 30

11. 2ND AND 3RD PAPER FEED TRAY (A109)



See Page 32


12. PAPER SUPPLY UNIT 1 (A109)



See Page 34


Location of unit

13. PAPER SUPPLY UNIT 2 (A109)




See Page 36

14. PAPER SUPPLY UNIT 3 (A109)




See Page 38

15. PAPER FEED SECTION 1 (A109)




See Page 40

16. PAPER FEED SECTION 2 (A109)




See Page 42

17. BY-PASS FEED TABLE (A109)



See Page 44


18. PAPER REGISTRATION (A109)



See Page 46


Location of unit

19. AROUND THE DRUM (A109)




See Page 48

20. DRUM UNIT 1 (A109)




See Page 50

21. DRUM UNIT 2 (A109)




See Page 52

22. TONER TANK UNIT 1 (A109)




See Page 54

23. TONER TANK UNIT 2 (A109)



See Page 56


24. DEVELOPMENT UNIT - BLACK (A109)



See Page 58


Location of unit

25. DEVELOPMENT UNIT - CYAN (A109)




See Page 60

26. DEVELOPMENT UNIT - MAGENTA (A109)




See Page 62

27. DEVELOPMENT UNIT - YELLOW (A109)




See Page 64

28. TRANSFER BELT UNIT 1 (A109)




See Page 66

29. TRANSFER BELT UNIT 2 (A109)



See Page 68


30. TRANSFER ROLLER UNIT (A109)



See Page 70


Location of unit

31. TRANSPORT UNIT (A109)




See Page 72

32. BELT CLEANING UNIT (A109)




See Page 74

33. TONER COLLECTION SECTION (A109)




See Page 76

34. FUSING UNIT 1 (A109)




See Page 78

35. FUSING UNIT 2 (A109)



See Page 80


36. FUSING UNIT 3 (A109)



See Page 82


Location of unit

37. FUSING UNIT 4 (A109)




See Page 84

38. DRIVE SECTION 1 (A109)




See Page 86

39. DRIVE SECTION 2 (A109)




See Page 88

40. DRIVE SECTION 3 (A109)




See Page 90

41. DRIVE SECTION 4 (A109)



See Page 92


42. ELECTRICAL SECTION 1 (A109)



See Page 94


Location of unit

43. ELECTRICAL SECTION 2 (A109)




See Page 96

44. ELECTRICAL SECTION 3 (A109)




See Page 98

45. ELECTRICAL SECTION 4 (A109)




See Page100

46. FRAME SECTION 1 (A109)




See Page102

47. FRAME SECTION 2 (A109)




See Page104

48. FRAME SECTION 3 (A109)




See Page106

Location of unit

49. FRAME SECTION 4 (A109)  See Page108		

1. Exterior 1 (A109)




1. Exterior 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 1265	Right Cover	1
2	A109 1267	Right Cover Cap	2
3	A109 7065	Operation Panel Ass'y - LT	1
4	AW03 0034	Optics Fiber Cable - 1400mm	1
5	A109 7001	Top Cover	1
6	A109 1273	Left Cover	1
7	A109 1276	Left Cover Bracket	2
8	A024 1368	Sorter Cap - Left Cover	1
9	A006 1329	Cap Left Cover	2
10	A006 1328	Small Cap	2
11	A109 4300	Copy Tray	1
12	A109 4775	Stepped Screw - M5	1
13	A049 1964	Cap - Scale	5
14	AC04 2098	Left Scale - LT	1
15	A109 1911	Exposure Glass Ass'y	1
17	A109 7821	Rear Scale - LT	1
18	AA14 0065	Stepped Screw - M3x6	5
19	A109 1320	Rear Cover	1
20	A109 1322	DF Connector Cap	1
21	A109 1256	Upper Right Cover	1
22	A109 1277	Left Cover Louver	1
23	A109 5560	IC - AM27C4096 - 150DC (English - LT)	1
24	A109 5559	IC - AM27C4096 - 150DC (English - LT)	1
25	A109 5558	IC - AM27C4096 - 150DC (English - LT)	1
26	A109 5557	IC - AM27C4096 - 150DC (English - LT)	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0344 0060F	Philips Truss Head Screw - M4x6	
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0344 0080F	Philips Truss Head Screw - M4x8	
103	1607 0623	Ferrite Core - Small	

2. Exterior 2 (A109)




2. Exterior 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A100 1330	Platen Cover	1
2	A406 9505	Platen Cover Sheet - 10 Sheet/1 Set	1
3	AA16 2053	Platen Cover Pad	1
4	A100 1321	Front Platen Cover	1
5	A053 1957	Flex Hinge - Platen Cover	2
6	A100 1322	Rear Platen Cover	1
7	A100 1323	Original Holder	1
8	A100 1324	Positioning Sensor Shutter	1
9	A100 1310	Platen Cover Hinge Ass'y	1
10	A100 1325	Hinge Spacer	1
11	A095 1394	Mounting Bracket - Platen Cover	1
12	5215 1667	Platen Cover Stud	2
13	A109 7362	Right Door	1
14	A109 1290	Right Upper Door Hinge	1
15	A109 1291	Right Lower Door Hinge	1
16	A109 1374	Right Inner Cover	1
17	A109 1553	Decal - Misfeed Removal B	1
18	A109 1552	Decal - Misfeed Removal A	1
19	A109 7526	Left Door	1
20	AG07 0004	Magnetic Catch	2
21	A109 1307	Left Upper Door Hinge	1
22	AA14 5180	Pin - Hinge	2
23	A109 1306	Left Door Hinge Plate	1
24	A109 4776	Hinge Support Plate	1
25	A109 1308	Left Lower Door Hinge	1
26	A109 1309	Transport Lever Stopper	1
27	A109 1554	Decal - Misfeed Removal D	1
28	A109 1135	Safety Switch Actuator	1
29	A109 1310	Fusing Lever Stopper	1
30	5215 2843	Left Spring - Platen Cover	1
31	5215 2842	Right Spring - Platen Cover	1
32	5215 2844	Slide Supporter	2
33	5215 2840	Pin - 4 x 115 mm	3
34	5215 2838	Rubber Magnet	1
35	5215 2845	Plate - Magnet	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	5215 2846	Platen Base	1
37	5215 2847	Base Holder	1
38	A069 1972	Arm Holder	1
39	5215 2837	Shaft 7 x 40 mm	1
40	5215 2836	Sleeve - 8 X 34 Mm	1
41	A100 1311	Balancer Spring	1
100	0414 0142W	Tapping Screw - M4x14	
101	0344 0060F	Philips Truss Head Screw - M4x6	
102	0434 0102W	Tapping Screw - M4x10	
103	0344 0080F	Philips Truss Head Screw - M4x8	
104	0354 0100W	Philips Pan Head Screw - M4x10	
105	0720 0030E	Retaining Ring - M3	
106	0314 0050W	Philips Pan Head Screw - M4x5	
107	0805 0083	Retaing Ring - M4	


3. Operation Panel (A109)



3. Operation Panel (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 7065	Operation Panel Ass'y - LT	1
1	A109 5553	Operation Panel Board - LT	1
2	A109 1487	Operation Panel Hook	3
3	AY20 0001	IC - C5C202	1
4	A109 5558	IC - AM27C4096 - 150DC (English - LT)	1
5	A109 5559	IC - AM27C4096 - 150DC (English - LT)	1
6	A109 5560	IC - AM27C4096 - 150DC (English - LT)	1
7	A109 5557	IC - AM27C4096 - 150DC (English - LT)	1
8	AW50 0016	Touch Panel	1
9	AX30 0002	LCD Display	1
10	A096 1492	Keytop - C/S	1
11	A096 1493	Keytop - Set12	1
12	A096 1494	Keytop - Interrupt	1
13	A096 1497	LCD Display Dial	1
14	A096 1509	Cushion - 1	2
15	A096 1510	Cushion - 2	2
16	A096 1512	Grounding Harness - 2	1
18	A109 1455	Key Top - Start	1
19	A109 1456	Key Top - Clear Modes	1
20	A109 1457	Key Top - Memory Call	1
21	A109 1458	Key Top - Color Adjust/memory	1
22	A109 1459	Key Top - User Color - LT	3
23	A109 1460	Key Top - White	2
24	A109 1461	Key Top - Black	2
25	A109 1462	Key Top - Red	2
26	A109 1463	Key Top - Magenta	2
27	A109 1464	Key Top - Blue	2
28	A109 1465	Key Top - Cyan	2
29	A109 1466	Key Top - Green	2
30	A109 1467	Key Top - Light Green	1
31	A109 1468	Key Top - Yellow	2
32	A109 1469	Key Top - Orange	1
33	A109 1488	Key Top - Program	1
34	A109 1472	Key Top - Option	1
35	A109 1473	Key Top - Area Marker	1
36	A109 1474	Lens Ass'y	2
37	A109 1480	Grounding Wire	2
38	A109 1481	Large Shielding Sheet	1
39	A109 1482	Small Shielding Sheet	1
41	A109 1484	Grounding Plate - LCD	1
42	A109 1486	Operation Panel Bracket	2
101	0433 0082B	Tapping Screw - M3x8	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0344 0060F	Philips Truss Head Screw - M4x6	

4. Optics Section 1 (A109)




4. Optics Section 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 1879	Scale Bracket	1
2	A109 1886	Right Stay	1
3	A109 3461	Stopper Lever - Toner Tank	1
4	A069 1882	Exposure Glass Holder	4
5	AW02 0067	Photointerruptor - EE-SX4119-P15	1
6	A048 1870	Scanner Motor Pulley	1
7	A109 1833	Upper Cover - Scanner Drive	1
8	AA14 0526	Drive Shaft	1
9	AA04 3360	Timing Belt - 200	1
10	AB03 0453	Timing Pulley - 48Z	1
11	AA16 1100	Stopper Cushion - 5.4x8.5x18	1
12	A069 5352	Harness - Ground Wire - Scanner	1
13	A109 1842	Scanner Drive Motor - DC24V	1
14	A134 1724	Cushion - Stepper Motor	1
15	AB03 0452	Timing Pulley - 24Z	1
16	H081 2118	Pressure Spring	1
17	A109 1832	Scanner Drive Bracket	1
18	AA05 0082	Scanner Drive Wier - Rear Right	1
19	A109 1835	Lower Cover - Scanner Drive	1
20	AA05 1019	Wire Stopper	1
21	AA05 0081	Scanner Drive Wire - Front Right	1
22	5361 2080	Plate : Wire Clamp	2
23	AA05 0080	Scanner Drive Wire - Rear Left	1
24	AA06 0083	Tension Wire Spring	1
25	AA05 0079	Scanner Drive Wire - Front Left	1
26	AA15 0266	Seal - 0.1x29x100	1
27	A109 1129	Left Bracket	1
28	A109 3460	Toner Hopper Stopper	1
29	A109 1331	Operation Panel Holder	2
30	A109 1332	Middle Bracket - Operation Panel	1
31	A109 1124	Right Bracket - Operation Panel	1
32	AA14 3431	Stepped Screw - M4	1
33	AA06 6233	Stopper Spring	1
34	5215 1924	Cushion	2

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0060B	Philips Tapping Screw - M4x6	
101	0313 0050B	Philips Pan Head Screw - M3x5	
102	0314 0120B	Philips Pan Head Screw - M4x12	
103	0574 0060E	Hexagon Headless Set Screw - M4x6	
104	0807 4076	Washer - 8.2x6.1x0.3mm	
105	0805 3145	Ball Bearing - 6x12x4mm	
106	0807 4047	Wave Washer - 6mm	
107	0720 0040B	Retaining Ring - M4	
108	0951 4008B	Philips Screw With Washer - M4x8	
109	0314 0080B	Philips Pan Head Screw - M4x8	
110	0344 0060F	Philips Truss Head Screw - M4x6	
111	0951 4006B	Philips Screw With Washer - M4x6	

5. Optics Section 2 (A109)




5. Optics Section 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 1922	Second Mirror Assy	2
2	A006 1721	Front Spring Plate	2
3	AC03 5051	Spring Plate - 2nd Mirror	2
4	A069 1883	Shoe - Scanner	8
5	AB03 2041	Pulley - 26Z	2
6	A109 1741	2nd Scanner Ass'y	1
7	A109 5378	Exposure Lamp Harness - 120V	1
8	A109 1920	1st Mirror	1
9	AW11 0017	Thermostat 140°C AC120V 15A	1
10	A109 1731	1st Scanner Ass'y	1
11	A109 1715	Front Terminal Holder	1
12	A109 1717	Front Terminal - Exposure Lamp	1
13	AX52 0017	Exposure Lamp - 7.5V 200W	1
14	A109 1711	Rear Terminal Holder	1
15	A109 1713	Rear Terminal - Exposure Lamp	1
16	A109 1700	Reflector	1
17	A109 1707	Reflector Cover	1
18	AA14 3025	Stepped Screw - M3	1
19	A109 1708	Reflector Bracket	1
20	A109 5377	Exposure Lamp Relay Harness	1
21	A048 1721	Spring Plate A	2
22	A096 1873	Scanner Shoe Pin	8

Index No.	Part No.	Description	Q'ty Per Assembly
100	0720 0050B	Retaining Ring - M5	
101	0952 3008B	Screw - M3X8	
102	0951 3006B	Philips Screw With Flat Washer-M3x6	
103	0313 0060B	Philips Pan Head Screw - M3x6	
104	0952 3012B	Screw - M5X12	
105	AA14 3025	Stepped Screw - M3	3
106	0807 3109	Spring Washer - M4	

6. Optics Section 3 (A109)




6. Optics Section 3 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 1806	Original Sensor Cover	1
2	AX40 0021	Anti-condensation Heater - 115V 18W	1
3	AW01 0034	Original Width Sensor	1
4	AW01 0037	Original Length Sensor	1
5	A109 1882	Original Sensor Bracket	1
6	AW01 0033	Original Sensor Ass'y - H=3-50	1
7	A109 1636	Lens Unit	1
8	AA01 1039	Correction Filter	1
9	A109 1789	Spring Plate	2
10	A109 1853	Scanner Control Board Bracket	1
11	A109 1884	Optics Exhaust Bracket	1
12	AX64 0045	Cooling Fan Motor - DC24V 2.40W	1
13	A109 5291	Scanner Control Board	1
14	A109 5378	Exposure Lamp Harness - 120V	1
15	A109 1785	Spacer - 9.5x9.5x72	5
16	A109 5341	Scanner Interface Harness	1
17	A109 5336	CCD Harness - 2	1
18	A109 5335	CCD Harness - 1	1
19	A109 5344	Ccd Harness 3 - Exp	1
20	A109 1805	Scanner Control Board Cover	1
21	A109 5146	IC - 512KX8120NS	1
22	A109 5145	IC - uPD78P312ACW	1
23	A109 5338	IPU Harness	1
24	AW03 0035	Optics Fiber Cable - 900mm	1
25	A109 1782	CCD Grounding Plate	2

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0060B	Philips Tapping Screw - M4x6	
101	0952 3012B	Screw - M5X12	
102	0957 4008B	Philips Screw W/F Washer - M4x8	
103	0951 3008B	Philips Screw With Flat Washer - M3x8	
104	0313 0050B	Philips Pan Head Screw - M3x5	
105	0951 3006B	Philips Screw With Flat Washer - M3x6	
106	0433 0050B	Tapping Screw - M3x5	
107	0951 4014B	Philips Screw With Washer - M4x14	
108	0951 4010B	Philips Screw With Washer - M4x10	
109	0413 0062W	Tapping Screw - M3x6	

7. Optics Section 4 (A109)




7. Optics Section 4 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A012 1752	Lens Bracket Block	2
2	AW02 0065	Photointerruptor	1
3	A109 1867	Pin Guide	4
4	A109 1869	Front Slide Rail	1
5	A109 5376	Scanner AC Harness	1
6	A109 1831	Scanner Drive Board Bracket	1
7	A060 1822	Scanner Wire Pulley	4
8	A109 1818	Wire Adjuster	1
9	AW03 0034	Optics Fiber Cable - 1400mm	1
10	A109 5370	Operation Panel Relay Harness	1
11	A109 1868	Rear Slide Rail	1
12	A060 1824	Scanner Wire Pulley	2
13	A109 5341	Scanner Interface Harness	1
14	A109 1844	Dust Filter Front Guide	1
15	A060 1812	Sensor Bracket	1
16	AA01 2066	Optics Cooling Fan Filter	1
17	A109 1845	Dust Filter Rear Guide	1
18	AX64 0048	Dev. Exhaust Fan Motor - DC24V 2.88W	1
19	AX64 0047	Dev. Exhaust Fan Motor - DC24V 3.36W	1
20	A109 1854	Scanner Louver	1
21	A109 5340	Scanner DC Harness	1
22	A109 5711	IPU Unit Position Plate	1
23	AZ23 0037	Lamp Regulator - 115V	1
24	AA14 3419	Support Stud	1
25	A109 5342	Scanner Drive Harness	1
26	AW02 0061	Photointerruptor - EE-SX4019-P1	1
27	A109 1881	H.P Sensor Bracket	1
28	A109 1885	Support Plate	2
29	A109 5151	Scanner Motor Drive Board	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0314 0080B	Philips Pan Head Screw - M4x8	
101	0951 3006B	Philips Screw With Flat Washer - M3x6	
102	0951 4008B	Philips Screw With Washer - M4x8	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0314 0300B	Philips Pan Head Screw - M4x30	
105	0313 0060B	Philips Pan Head Screw - M3x6	
106	1105 0199	Clamp	
107	1105 0310	Wire Clamp	
108	1105 0113	Edge - P108	
109	1105 0292	Wire Saddle	
110	1105 0193	Nylon Stud	
111	0314 0200B	Philips Pan Head Screw - M4x20	
112	0314 0120B	Philips Pan Head Screw - M4x12	
113	1106 0310	Bushing	

8. Printer Section 1 (A109)




8. Printer Section 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 5722	Front Guide Plate - IPU	1
2	A109 5724	IPU Fixing Bracket	1
3	A109 5723	Rear Guide Plate - IPU	1
4	A109 5701	IPU Unit Base	1
5	A109 5705	IPU Cooling Fan Louver	1
6	A109 5707	IPU Board Cover	1
7	A109 5519	IPU Board	1
8	A109 5236	IPU Interface Board	1
9	A109 5731	IPU Cover Seal	3
10	AW03 0029	Fiber Cable - 800	1
11	AA15 1866	Seal - 3x7x30	2
12	AA15 1867	Seal - 3x7x23.5	2
13	A109 2080	Optics Cooling Fan Duct	1
14	A109 5373	Front AC Harness	1
15	A109 5471	AC Drive Board - 100/115V	1
19	A109 5745	AC Drive Board Bracket	1
20	AZ02 0006	Coil - 4.6mm 5A	1
21	A109 5720	Seal - 9.5x9.5x125	2
22	AA15 1868	Seal - 3x7x64	2
23	AA15 1869	Seal - 3x7x17.3	1
24	A109 5721	Seal - 9.5x9.5x66	1
25	A109 5729	IPU Cooling Fan Bracket	1
26	AX64 0041	Cooling Fan Motor - DC24 7.64W	2
27	A109 5730	Polygon Motor Fan Bracket	1
28	A109 5528	IC - 128K 8BIT120NS	1
29	A109 5529	IC - 128K 8BIT120NS	1
30	A109 5338	IPU Harness	1
31	AA15 1870	Seal - 3x20x76	1
32	A109 5309	IPU Board Relay Harness - 120V	1
33	A109 5326	IPU Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0080B	Philips Tapping Screw - M4x8	
101	0314 0300B	Philips Pan Head Screw - M4x30	
102	0314 0080M	Philips Pan Head Screw - M4x8	
103	0354 0060B	Screw - M4X6	
104	1105 0193	Nylon Stud	
105	1105 0409	Spacer	
106	1105 0246	Spacer	

9. Printer Section 2 (A109)




9. Printer Section 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA15 2094	Seal - 22x38x2	1
2	A109 2066	Right Rail	1
3	A109 2065	Left Rail	1
4	A109 2136	Mirror Cover	1
5	AA15 1855	Mirror Seal 5	1
6	AA15 1852	Mirror Seal 2	1
7	AA15 1854	Mirror Seal 4	1
8	AA15 1853	Mirror Seal 3	1
9	AA15 1856	Mirror Seal 6	1
10	AA15 1851	Mirror Seal 1	1
11	AC03 5021	Front Spring Plate	1
12	A109 2132	Drum Mirror Ass'y	1
13	AC03 5020	Rear Spring Plate	1
14	A109 2069	Mirror - Synchronizing	1
15	AA15 0347	Shielding Sheet - 21.5x41	1
16	A109 2128	Diode Bracket	1
17	AA15 1858	Seal - 5x18x40	1
18	A109 5171	Laser Synchronizing Detector Board	1
19	AX64 0045	Cooling Fan Motor - DC24V 2.40W	1
20	A109 2072	LD Cooling Fan Bracket	1
21	A109 2070	Synchronizing Harness Bracket	1
22	A109 5333	Synchronizing Detector Harness	1
23	A109 5332	LD Unit Harness	1
24	A109 5718	IPU Lower Harness Cover	1
25	A109 5719	IPU Upper Harness Cover	1
26	AY10 0002	Polygon Motor Board	1
27	A109 2159	Optical Housing Unit	1
28	A060 5547	Polygon Motor Harness	1
29	AX06 0094	Polygon Motor - DC24V	1
30	A037 2113	Optical Housing Spacer	1
31	A109 5312	Relay Harness - Polygon Motor	1
32	A109 2160	LD Unit	1
33	5203 2679	Pinion Tightening Screw - M4x5	1
35	AA15 2061	O-ring 83	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0354 0060B	Screw - M4X6	
101	0593 0060E	Bolt - M3x6	
102	0953 4008M	Screw - M4X8	
103	0951 3014B	Philips Screw With Washer - M3x14	
104	0951 3020B	Philips Screw With Flat Washer - 3x8	
105	0354 0100B	Screw - M4x10	
106	0960 4008B	Philips Flange Screw - M4x8	
107	0803 0020	Positioning Pin	

10. 1st Paper Feed Tray (A109)




10. 1st Paper Feed Tray (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A513 2829	Cover - Paper Tray	1
2	AA00 0143	Decal - Cover - Paper Tray - No.1	1
3	AA00 2177	Decal - Side Fence - LT	1
4	AA00 0134	Dacal - Universal Tray	1
5	A096 6537	Stopper Lever	2
6	A096 6563	End Fence Cover	1
7	AA06 6551	Stopper Spring - 22mm	2
8	A096 6562	End Fence	1
9	A096 6564	End Fence Plate	1
10	AA00 2179	Decal - End Fence LT	1
11	AA15 1804	Lever Cushion	1
12	A096 6536	Side Fence Cover	1
13	AA15 1805	Bottom Plate Cushion	2
14	A096 6534	Front Side Fence	1
15	A096 6553	Side Fence Pad	2
16	A048 2838	Nylon Rivet	2
17	A096 6556	Tray Bottom Plate	1
18	AF01 3002	Bottom Plate Pad	1
19	A096 6541	Gear Side Fence	1
20	A096 6520	Paper Tray	1
21	AA00 2010	Decal - Paper Level	1
22	A096 6545	Side Fence Plate - LT	1
23	A096 6539	Side Fence Gear	2
24	AB01 3492	Gear - 16Z	1
25	AA00 2181	Decal - LT	1
26	A096 6577	Size Sensor Slider	1
27	A096 6578	Size Sensor Plate	1
28	A096 6527	Paper Guide Feeler	1
29	A096 6524	Lift Shaft	1
30	A096 6526	Lift Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0082F	Philips Truss Head Screw - M4x8	
102	0413 0082B	Tapping Screw - M3x8	
103	0965 4008B	Tapping Screw - M4 x 8	
104	0354 0050F	Philips Pan Head Bind Screw - M4x5	
105	0951 3008B	Philips Screw With Flat Washer - M3x8	
106	0805 0073	Retaining Ring - M5	
107	0433 0082B	Tapping Screw - M3x8	
108	0313 0060B	Philips Pan Head Screw - M3x6	
109	0314 0080B	Philips Pan Head Screw - M4x8	
110	0720 0060B	Retaining Ring - M6	

11. 2nd And 3rd Paper Feed Tray (A109)




11. 2nd And 3rd Paper Feed Tray (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A513 2829	Cover - Paper Tray	2
2	AA00 0138	Decal - Cover - Paper Tray - No.2	1
2	AA00 0139	Decal - Cover - Paper Tray - No.3	1
3	A096 6549	Front Side Fence	2
4	A029 7904	Pad - CFF	4
5	A096 6568	Position Plate - End Fence	2
6	AF01 7010	End Fence	2
7	A048 2838	Nylon Rivet	4
8	A096 6556	Tray Bottom Plate	2
9	AF01 3002	Bottom Plate Pad	2
10	A096 6550	Rear Side Fence	2
11	AA00 2010	Decal - Paper Level	2
12	AA15 1804	Lever Cushion	1
13	A096 6551	Position Plate - Side Fence	2
14	A096 6527	Paper Guide Feeler	2
15	A096 6524	Lift Shaft	2
16	A096 6526	Lift Lever	2
17	A096 6520	Paper Tray	2
18	AA15 1805	Bottom Plate Cushion	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0082F	Philips Truss Head Screw - M4x8	
102	0965 4008B	Tapping Screw - M4 x 8	
103	0952 3008B	Screw - M3X8	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	0314 0080B	Philips Pan Head Screw - M4x8	
106	0720 0060B	Retaining Ring - M6	
107	0354 0050F	Philips Pan Head Bind Screw-M4x5	

12. Paper Supply Unit 1 (A109)




12. Paper Supply Unit 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 1591	Operating Instructions Holder	1
2	A513 1335	Left Cover - Paper Feed Unit	1
3	A109 7347	Cap Left Cover	2
4	A513 1338	Left Cover Bracket	2
5	A513 1341	Rear Left Cover - Paper Feed Unit	1
6	A027 1673	Spring Plate	6
7	A109 7042	Rear Lower Cover	1
8	A513 1356	Front Cover - Paper Feed Unit	1
9	AA06 3492	Spring	1
10	A513 6600	Toner Collection Bottle	1
11	AA03 6013	Toner Collection Cap	1
12	A007 3763	Adhesive Tape - Sensor Holder	1
13	A007 3762	Sensor Holder	1
14	A513 5403	Toner Overflow Sensor	1
15	A060 3826	Toner Collection Bottle Roller	6
16	A060 3827	Roller Holder	6
17	A513 6643	Collection Bottle Guide Plate	1
18	A513 6642	Right Side Plate	1
19	A513 6644	Right Lower Hinge - Tray Unit	1
20	A513 1349	Right Cover - Paper Feed Unit	1
21	A513 6152	Humidity Sensor Holder	1
22	A109 5196	Humidity Sensor	1
23	A109 5362	Humidity Sensor Harness	1
24	A513 5364	Relay Harness - Humidity Sensor	1
25	A513 5351	Front Harness - Paper Feed Unit	1
26	A513 6603	Seal - Toner Overflow Sensor	1
27	A513 1180	Upper Stay - Rear Cover	1
28	A513 1181	Lower Stay - Rear Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0354 0060B	Screw - M4X6	
101	0965 3006W	Tapping Screw With Flat Washer - M3x6	
102	0353 0050B	Philips Truss Head Screw - M3x5	
103	0344 0060F	Philips Truss Head Screw - M4x6	
104	0414 0082B	Binding Self Tapping Screw - M4x8	
105	0433 0060B	Philips Tapping Screw - M3x6	

13. Paper Supply Unit 2 (A109)




13. Paper Supply Unit 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A513 6622	Tray Unit Gear Holder	1
2	AA14 8403	Shaft	1
3	AB01 3856	Gear - 31Z	1
4	AB01 7325	Gear - 35Z	1
5	AB01 7324	Gear - 26Z/70Z	1
6	AB01 3855	Gear - 68Z	1
7	A513 1173	Upper Hinge - Paper Feed Unit	1
8	AB01 3781	Gear - 30Z	3
9	A513 5353	Relay Harness - Lift Motor	3
10	A513 2840	Paper Lift Motor	3
11	AA14 5223	Drive Shaft	2
12	AB03 0456	Timing Pulley - 30Z	3
13	A027 1673	Spring Plate	2
14	AB03 3058	Timing Pulley - 22Z	1
15	A513 1175	Lower Hinge - Paper Feed Unit	1
16	5053 0447	Bushing - 6mm	2
17	AA14 5224	Drive Shaft	1
18	AA06 0560	Release Spring	2
19	A513 2820	Belt Tightner	2
20	AB03 0449	Timing Pulley - 23Z	1
21	A513 2846	Paper Feed Motor Bracket	1
22	A513 5358	Relay Harness - Paper Feed Motor	1
23	AX06 0087	Papaer Feed Motor - DC22W	1
24	AA04 3239	Timing Belt - P3M6 486mm	2

Index No.	Part No.	Description	Q'ty Per Assembly
100	0720 0040B	Retaining Ring - M4	
101	1105 0199	Clamp	
102	0434 0080B	Philips Tapping Screw - M4x8	
103	0720 0050E	Retaining Ring - M5	
104	0964 4008B	Tapping Screw With Flat Washer - M4x8	
105	0720 0060B	Retaining Ring - M6	
106	0720 0040B	Retaining Ring - M4	
107	0740 3008	Ball Bearing - 8x22x7	
108	0433 0060B	Philips Tapping Screw - M3x6	
109	0574 0060B	Hexagon Headless Set Screw - M4	
110	0951 4008B	Philips Screw With Washer - M4x8	

14. Paper Supply Unit 3 (A109)




14. Paper Supply Unit 3 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX40 0021	Heater - 115V 18W	2
2	A513 2870	Upper Tray Heater Bracket	1
3	A513 2861	Left Rail - Paper Tray	3
4	AA06 0534	Tray Lock Spring - 19mm	3
5	A096 6266	Tray Lock Arm	3
6	A513 6612	Joint Case Bracket	1
7	A513 6614	Upper Shielding Seal	1
8	A513 6613	Collection Joint Case	1
9	A513 6615	Lower Shielding Seal	1
10	A096 6100	Lower Heater Sink	1
11	A513 5383	Heater Harness	1
12	A513 2809	Rear Cover - Vertical Transport	1
13	A513 6652	Collection Bottle Stopper	1
14	A513 6653	Collection Bottle Cushion	1
15	A513 2760	Vertical Transport Guide Bracket	1
16	A513 2785	Guide Plate Rear Holder	2
17	5424 1064	Screw Stand	4
18	A513 2775	Guide Plate Front Holder	1
19	AA14 3074	Stepped Screw - M4x5	2
20	A513 2776	Guide Plate Stopper	1
21	A513 2782	Cover Release Plate	1
22	A513 2783	Spring Plate	2
23	AF02 0295	Vertical Driven Roller	4
24	AA08 0156	Bushing - M4	8
25	AA06 3487	Spring - 10mm	8
26	A513 2762	Pressure Plate	4
27	A513 2771	Switch Bracket - Vertical Transport	1
28	A109 5365	Harness - Paper Feed Door Switch	1
29	A513 2752	Vertical Transport Guide	1
30	5447 2681	Snap Ring	5
31	A513 2780	Vertical Transport Guide Cover	1
32	AG07 0004	Magnetic Catch	2
33	5415 1053	Caster	4
34	A513 6661	Cover Support Plate	1
35	A513 2801	Front Side Frame	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A513 1036	Lower Front Right Bracket	1
37	A513 2850	Right Rail - Paper Tray	3
38	A513 1177	Lower Cover Bracket	1
39	A513 1366	Front Lower Cover	1
40	AA14 7674	Pin - 6x12.7	1
41	A513 2786	Support Cover	1
42	AA00 1330	Decal - Misfeed Removal A	1
43	5301 1662	Hexagon Bolt	12
44	AH01 3008	Leveling Foot Guide	4
45	A513 1034	Lower Rear Right Bracket	1
46	A513 1035	Lower Rear Left Bracket	1
100	0950 4010B	Sem,s Screw M4 x 10	
101	0434 0080B	Philips Tapping Screw - M4x8	
102	1105 0310	Wire Clamp	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	1204 2356	Microswitch - AH51612A531	
105	0434 0082F	Tapping Screw - M3x10	
106	0720 0040B	Retaining Ring - M4	
107	0353 0050B	Philips Truss Head Screw - M3x5	
108	1204 2376	Microswitch - V-162-3C25	

15. Paper Feed Section 1 (A109)




15. Paper Feed Section 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 5411	Upper Feed Unit Harness	3
2	A096 6344	Paper End Actuater	3
3	A096 6345	End Sensor Bracket	3
4	AW02 0056	Photointerruptor - EE-SX4235A-P1	6
5	5447 2681	Snap Ring	12
6	A096 6358	Photointerrupter Bracket	3
7	A096 6355	Pick-up Solenoid	3
8	A096 6346	Paper Feed Stay	3
9	A096 6362	Paper End Feeler	3
10	AA06 0523	Pick-up Pressure Sping	3
11	AA14 0498	Feed Roller Shaft	3
12	A096 6353	Feed Roller Lever	3
13	AA06 0522	Stopper Spring	3
14	A096 6337	Paper Feed Guide	3
15	A096 6351	Pick-up Arm	3
16	A096 6352	Feed Roller Bracket	3
17	AA08 2070	Bushing - 8x16x7	6
18	AF03 1022	Paper Feed Roller	3
19	AF03 0020	Pick-up Roller	3
20	5447 2706	Gear - 15T	3
21	A096 6335	Front Side Plate	3
22	A096 6330	Rear Side Plate	3
23	A096 6360	Paper Flattener	6
24	AX21 0037	Magnetic Clutch	3
25	AB01 3775	Gear - 33Z	3
26	AB01 3774	Gear - 18Z	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0720 0060B	Retaining Ring - M6	
103	1105 0087	Clamp	
104	0720 0040B	Retaining Ring - M4	
105	0573 0040B	Hexagon Headless Set Screw - M3x4	

16. Paper Feed Section 2 (A109)




16. Paper Feed Section 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 6375	Unit Fixing Plate	3
2	AF02 0289	Grip Drive Roller	3
3	A096 6338	Separation Guide	3
4	A096 6366	Clutch Stopper Arm	3
5	AB01 3777	Gear - 32Z	3
6	AB01 3776	Gear - 30Z	3
7	A096 5412	Lower Feed Unit Harness	3
8	AA08 2046	Bushing - 6x12x6	9
9	AB01 3773	Gear - 18Z	3
10	A096 6306	Separation Drive Shaft	3
11	A096 6315	Release Solenoid	3
12	A096 6311	Release Lever	3
13	AA06 6553	Spring - Pressure Release - Reverse	3
14	AF02 0280	Driven Roller	3
15	AA08 0156	Bushing - M4	6
16	A096 6369	Vertical Transport Guide	3
17	AA06 3487	Spring - 10mm	6
18	A096 6308	Separation Pressure Lever	3
19	AA06 0520	Lever Spring - 24.4mm	3
20	A096 6303	Separation Roller Stay	3
21	AB01 3729	Gear - 18Z	3
22	AA06 6189	Feed Sensor Spring	3
23	A096 6307	Separation Driver Shaft	3
24	A097 6000	Separation Torque Limiter	3
25	AF03 2023	Separation Roller	3
26	5447 2681	Snap Ring	3
27	A096 6321	Position Sensor Bracket	3
28	A096 6322	Position Sensor Feeler	3
29	AW02 0061	Photointerruptor - EE-SX4019-P1	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0720 0060B	Retaining Ring - M6	
103	0742 3808	Ball Bearing - 8x16x5	
104	1102 6265	Connector - Red 8P	
105	1102 6250	Connector - 7P	
106	0720 0040B	Retaining Ring - M4	
107	0805 3145	Ball Bearing - 6x12x4mm	
108	0574 0040E	Hexagon Headless Set Screw - M4x4	
109	1105 0087	Clamp	
110	0314 0120B	Philips Pan Head Screw - M4x12	
111	0720 0030B	Retaining Ring - M3	
112	1102 6245	Connector - 2P	

17. By-pass Feed Table (A109)




17. By-pass Feed Table (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 2721	Upper Stay Vertical Transport	1
2	A109 2691	Oil Damper - GF.cm	1
3	A109 2693	By-pass Feed Shaft	1
4	AA06 2272	Release Spring	1
5	A109 2653	Pressure Arm - By-pass	1
6	AA06 2283	Spring	1
7	AW02 0066	Photointerruptor	1
8	A109 2642	Paper End Sensor Bracket	1
9	A109 2680	By-pass Pick-up Solenoid	1
10	5447 2927	Friction Pad - B	1
11	AA06 2271	Release Spring	1
12	A109 5322	By-pass Feed Harness - 1	1
13	A109 2665	Feed Roller Shaft - By-pass	1
14	AA08 3003	Bushing - 6x18x5mm	1
15	AX20 0096	Magnetic Clutch	1
16	A109 2670	Housing - Manual Feed	1
17	A109 2621	Manual Feed Table	1
18	A109 5361	By-pass Feed Harness - 3	1
19	AB01 3846	Gear - 28Z	1
20	AA14 3074	Stepped Screw - M4x5	2
21	A109 2675	Cover - Housing	1
22	5447 2683	Gear - 18T	1
23	AA14 0522	Drive Shaft	1
24	5447 2684	Gear - 18T	1
25	A109 2652	Separation Roller Shaft - By-pass	1
26	A097 6000	Separation Torque Limitter	1
27	AF03 2021	Separation Roller	1
28	5447 2681	Snap Ring	2
29	AF03 0021	Pick-up Roller	1
30	5353 3710	Gear - 18Z	1
31	A109 2666	Pick-up Arm Holder	1
32	A109 2661	Arm - Pick Up - Manual Feed	1
33	5447 2706	Gear - 15T	1
34	AF03 1023	Paper Feed Roller	1
35	A109 2662	Cover - Pick Up	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A109 2630	Cover - Manual Feed	1
37	AB01 3866	Front Side Fence Rack	1
38	A109 2638	Rear Side Fence Rack	1
39	G011 3305	Gear - 16T	1
40	A109 5526	By-pass Feed Table Sensor - 115V	1
41	A010 5700	Sensor	1
42	AA00 2192	Decal - Paper Size - LT	1
43	A109 5323	By-pass Feed Harness - 2	1
44	A109 2627	Arm - Auxiliary - Manual Feed Table	1
45	A109 2635	Side Fence - Rear	1
46	A109 2633	Side Fence - Front	1
100	0413 0082B	Tapping Screw - M3x8	
101	0805 3385	Bushing - 6mm	
102	0720 0040B	Retaining Ring - M4	
103	0965 3006B	Tapping Screw With Flat Washer M3x6	
104	0414 0082B	Binding Self Tapping Screw - M4x8	
105	0720 0040E	Retaining Ring - M4	

18. Paper Registration (A109)




18. Paper Registration (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB01 3852	Gear - 21Z	1
2	5053 0447	Bushing - 6mm	3
3	A109 6502	Drive Gear Bracket	1
4	AA14 8402	Drive Shaft	1
5	A010 5700	Sensor	2
6	AB01 6001	Gear - 14Z	2
7	A109 2594	Registration Sensor Holder	1
8	AA08 0037	Bushing - 6 mm	2
9	5442 2754	Spring - Registration Roller	2
10	5447 3922	Gear - 16T	1
11	AG05 0069	Registration Knob	1
12	AB01 3601	Gear - 20Z	1
13	AA08 2021	Bushing - 8x12x10mm	2
14	A109 6285	Transfer Cam Positioning Plate	1
15	AA14 5217	Cam Shaft	1
16	A109 6097	Release Cam	1
17	A109 6286	Paper Transfer Unit Rail	1
18	AF02 0311	Upper Registration Roller	1
19	A109 2588	Upper Guide - Registration	2
20	A109 2582	Upper Guide Plate - Registration	1
21	A109 2589	Large Guide - Registration	1
22	AF02 1049	Lower Registration Roller	1
23	AG07 0008	Magnet Catch	2
24	A109 2610	Gear Holder	1
25	A109 2575	Lower Guide Plate - Registration	1
26	AA06 2288	Spring - Toner End Lever	2
27	A109 2571	Registration Guide Plate	1
28	AF02 0312	Relay Roller	1
29	A109 2574	Relay Guide Plate	1
30	AB01 3844	Gear - 30Z	1
31	AB01 7322	Gear - 34Z/41Z	1
32	A109 2711	Sensor Bracket - Registration Guide	1
33	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
34	A109 5311	Sensor Relay Harness	1
35	AB01 3843	Gear - 12Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AX21 0040	Magnetic Clutch	1
37	AX21 0041	Spring Clutch	1
38	A109 6298	Sensor Feeler - Transfer Roller	1
39	AW02 0062	Photointerruptor - EE-SX4019-P15	1
40	A109 4714	Position Sensor Bracket	1
41	A109 6284	Heat Sink	1
42	AX40 0008	Heater - 115V 18W	1
43	AA08 0166	Bushing - 8mm	1
44	AA08 2058	Bushing - 6x10x9mm	2
100	0434 0080B	Philips Tapping Screw - M4x8	
101	0720 0040B	Retaining Ring - M4	
102	0354 0060B	Screw - M4X6	
103	0951 4008B	Philips Screw With Washer - M4x8	
104	0720 0060B	Retaining Ring - M6	
105	0951 3006B	Philips Screw With Flat Washer - M3x6	
106	0314 0060B	Philips Pan Head Screw - M4x6	
107	0354 0100B	Screw - M4X10	
108	0720 0050B	Retaining Ring - M5	
109	0313 0100B	Philips Pan Head Screw - M3x10	

19. Around The Drum (A109)




19. Around The Drum (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AD00 4071	Pre - Cleaning Corona Unit	1
2	AD02 2293	Front End Block Cover - Pre Cleaning	1
3	A109 2369	Grounding Plate - Pre - Cleaning	1
4	AD02 2291	Front End Block - Pre Cleaning	1
5	AD02 3086	Corona Casing - Pre Cleaning	1
6	AD02 0056	PCC Wire	1
7	5442 2108	Spring - Corona Wire	1
8	AD02 2294	Rear End Block Cover - Pre Cleaning	1
9	AD02 2292	Rear End Block	1
10	AD02 4025	Corona Wire Terminal	2
11	AD00 4082	Charge Corona Unit	1
12	AD02 3085	Right Casing - Charge	1
13	AD02 2329	Front End Block - Charge	1
14	G004 3762	Corona Wire Spring	1
15	AD02 2289	Front End Block Cover - Charge	1
16	A109 2351	Spring Plate - Grid	1
17	AD02 0055	Charge Corona Grid	1
18	AD02 0054	Charge Corona Wire	1
19	AD02 3084	Left Casing - Charge	1
20	AD02 2290	Rear End Block Cover - Charge	1
21	AD02 2330	Rear End Block - Charge	1
22	A109 2287	Drum Flange Knob	1
23	A109 2381	Quenching Lamp	1
24	A109 5192	ID Sensor Board	1
25	A109 2371	ID Sensor Stay	1
26	AA15 0360	Seal - 13x20	1
27	A109 2291	Knob Screw	1
28	A109 2281	Drum Flange	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0433 0062B	Tapping Screw - M3 x 6 mm	
101	0314 0080B	Philips Pan Head Screw - M4x8	
102	0313 0060B	Philips Pan Head Screw - M3x6	

20. Drum Unit 1 (A109)




20. Drum Unit 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 3635	Gear - 18Z	1
2	A109 3631	Gear - 18Z/20Z	1
3	A109 3629	Toner Collection Joint	1
4	A109 3632	Toner Collection Auger	1
5	A109 3645	Toner Collection Tube	1
6	A109 3637	Toner Collection Pipe	1
7	A109 3642	Pressure Spring	1
8	A109 3643	Joint Shutter - Toner Collection	1
9	A109 3639	Right Shutter - Toner Collection	1
10	A109 3641	Left Shutter - Toner Collection	1
11	A109 3644	Shutter Stopper	1
12	A109 3615	Bushing - Cleaning Brush	3
13	A109 3605	Front Side Holder - Cleaning Brush	1
14	A109 3603	Cleaning Brush	1
15	A109 3610	Rear Side Holder - Cleaning Brush	1
16	A172 9510	OPC Drum	1
17	A109 3616	Gear - 16Z	2
18	A109 3652	Front Drum Flange	1
19	A109 3651	Gear - 20Z	1
20	A109 3650	Knob Screw	1
21	A109 3601	Blade Stopper Lever	1
22	A109 3574	Pressure Plate - Cleaning Brush	1
23	A109 3577	Pressure Spring - Cleaning Brush	1
24	A109 3626	Blade Holder - Bias Roller	1
25	A109 3623	Bias Roller Blade	1
26	A109 3653	Rear Drum Flange	1
27	A109 3618	Toner Collection Coil	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0314 0060B	Philips Pan Head Screw - M4x6	
101	0951 4006B	Philips Screw With Washer - M4x6	
102	0720 0040B	Retaining Ring - M4	

21. Drum Unit 2 (A109)




21. Drum Unit 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 3570	Lower Louver	1
2	A109 3571	Middle Louver	1
3	A109 3572	Upper Louver	1
4	A109 3569	Charge Corona Housing	1
5	A109 3573	Guide Rail - Charge Corona	2
6	A109 3553	Front Side Plate - Drum	1
7	A109 3558	Drum Grounding Plate	1
8	A109 3615	Bushing - Cleaning Brush	2
9	A109 3557	Seal - 5x14x14	1
10	A109 3556	Seal - 4x5x10	1
11	A109 3598	Cleaning Blade	1
12	A109 3596	Seal - 16x323	1
13	A109 3595	Cleaning Blade Holder	1
14	A109 3597	Stepped Screw - M4	1
15	A109 3589	Cleaning Bracket	1
16	A109 3648	Spacer - 6x8x14	2
17	A109 3585	Front Side Seal - Cleaning Brush Cover	1
18	A109 3586	Rear Seal - Cleaning Brush Cover	1
19	A109 3584	Cleaning Brush Cover	1
20	A109 3617	Cleaning Brush Bias Roller	1
21	A109 3579	Right Side Stay - Drum Cleaning	1
22	A109 3565	Seal - 3x4x5	1
23	A109 3647	Gear - 16/17Z	1
24	A109 3582	Pre-cleaning Corona Rail	1
25	A109 3593	Seal - 21x323	1
26	A109 3566	Seal - 5x10x14	1
27	A109 3560	Rear Side Plate - Drum	1
28	A109 3567	Duct Seal - 3x22x27	1
29	A109 3646	Gear - 16Z	1
30	A109 3616	Gear - 16Z	1
31	A109 3659	Seal - 3x9x9	2
32	A109 3660	Seal - 3x8x18	2
33	A109 3661	Cover Bracket - Cleaning Brush	1
34	A109 9501	Drum Cleaning Entrance Seal	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0972 4006A	Philips Polycarbonate Screw - M4x6	
101	0314 0200B	Philips Pan Head Screw - M4x20	
102	0314 0160B	Philips Pan Head Screw - M4x16	
103	0313 0060B	Philips Pan Head Screw - M3x6	
104	0313 0120B	Philips Pan Head Screw - M3x12	
105	0720 0040B	Retaining Ring - M4	

22. Toner Tank Unit 1 (A109)




22. Toner Tank Unit 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 3420	Left Side Plate - Toner Tank	1
2	A109 5306	Toner Tank Unit Harness	1
3	A109 3406	Top Cover Bottle - Black	1
4	AA15 1875	Seal - 20x40	4
5	A109 3401	Toner Bottle Guide - Black	1
6	AA15 1829	Seal - 72	4
7	A109 3407	Top Cover Bottle - Cyan	1
8	A109 3404	Toner Bottle Guide - Cyan	1
9	A109 3408	Top Cover Bottle - Magenta	1
10	A109 3402	Toner Bottle Guide - Magenta	1
11	A109 3409	Top Cover Bottle - Yellow	1
12	A109 3403	Toner Bottle Guide - Yellow	1
13	A109 3428	Right Side Plate - Toner Tank	1
14	A049 3292	Tank Unit Stopper	1
15	A109 3427	Rear Side Plate - Toner Tank	1
16	A109 5401	Toner Supply Motor	4
17	A109 3395	Toner Supply Motor Bracket	4
18	AA15 0351	Sheet - 25x57	2
19	A109 3410	Toner Tank Cover	1
20	A092 1393	Decal - Adding Toner	1
21	A109 1550	Decal - Adding Toner	1
22	A109 1551	Decal - Misfeed Removal C	1
23	A109 3112	Development Support Cam	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0951 3006B	Philips Screw With Flat Washer-M3x6	
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0952 3008B	Screw - M3X8	
103	0414 0082B	Binding Self Tapping Screw - M4x8	
104	0314 0080B	Philips Pan Head Screw - M4x8	
105	0951 3005B	Philips Screw With Flat Washer M3x5	

23. Toner Tank Unit 2 (A109)




23. Toner Tank Unit 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB01 3810	Gear - 52Z	4
2	5447 3200	Bushing - 6mm	14
3	AB01 7306	Gear - 18Z/40Z	4
4	AB01 3811	Gear - 40Z	1
5	AA15 0351	Sheet - 25x57	1
6	AB01 3355	Gear - 18Z	4
7	5205 2612	Gear - 19T	4
8	A109 3355	Front Casing - Toner Tank	1
9	AD03 9045	Large Agitator - BK	1
10	AA14 0510	Drive Shaft	5
11	AD03 9048	Small Agitator - BK	1
12	AA06 3363	Spring	4
13	A109 3393	Spacer - Toner Supply Coil	2
14	AD03 9042	Agitator - Collor	3
15	A109 3352	Rear Casing - Toner Tank	1
16	A109 3383	Toner Vibrating Mylar - Yellow	1
17	A109 3382	Toner Vibrating Mylar - Magenta	1
18	A109 3381	Toner Vibrating Mylar - Cyan	1
19	A109 3380	Toner Vibrating Mylar - Black	1
20	AA15 0343	Toner Entrance Seal	4
21	AD03 7036	Toner Supply Coil - Color	3
22	AA06 3361	Spring	4
23	A109 3390	Toner Supply Cap	4
24	AD03 7039	Toner Supply Coil - Black	1
25	AA15 2232	Packing - 18	4

Index No.	Part No.	Description	Q'ty Per Assembly
100	0720 0040B	Retaining Ring - M4	
101	0951 3008B	Philips Screw With Flat Washer - M3x8	
102	0313 0080B	Philips Pan Head Screw - M3x8	
103	0720 0030E	Retaining Ring - M3	


24. Development Unit - Black (A109)



24. Development Unit - Black (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	AD00 1045	Development Unit - B/C	1
1	5205 1336	Front Cover Chain	1
2	A109 3089	Development Unit Guide - Black	1
3	AA15 1849	Seal - 5x8x342	1
4	A109 3065	Spacer - Toner Density Sensor	1
5	AW23 0007	Toner Density Sensor	1
6	6803 2273	Stepped Screw - M4	1
7	A109 3059	Development Casing - Black	1
8	A109 3096	Black Development Seal	1
9	A109 3066	Mixing Paddle Roller - B/C	1
10	A109 3086	Development Casing Seal	2
11	A109 3054	Rear Side Plate - B/C	1
12	A109 5305	Development Unit Harness	1
13	AB01 3814	Gear - 40Z	1
14	AA15 1842	Seal - 1x5x55.5	2
15	A109 3073	Development Sleeve Ass'y - Black	1
16	AB01 1342	Gear - 30Z	1
17	A109 3102	Toner Collection Cover	1
18	AA15 2320	Seal - 16x36	1
19	A109 3082	Development Sleeve Cover	1
20	A109 3108	Development Support Lever	1
21	AB01 1149	Gear - 14Z	1
22	AA15 2319	Seal - 16x36	1
23	AB01 1148	Gear - 28Z	1
24	A109 3085	Positioning Adjuster	1
25	5403 6246	Stepped Screw - Cleaning	1
26	A109 3051	Front Side Plate - B/C	1
27	A109 3100	Toner Supply Receptacle	1
28	AA15 1846	Seal - 2x27x36	1
29	AA15 1847	Seal - 4x47	1
30	A109 3068	Paddle Flange	1
31	AB01 7330	Gear - 20Z/34Z	1
32	A109 3070	Paddle Flange Stopper	1
33	AA14 3358	Stepped Screw - M4x3	1
34	A109 3107	Development Support Shaft	1
35	A109 3109	Lock - Spring	1
36	A109 3106	Development Support Plate	1
37	A109 3111	Spring Plate	1
38	A109 3064	Black Development Seal-rear	1
100	0354 0060B	Screw - M4X6	
101	0313 0060B	Philips Pan Head Screw - M3x6	
102	0952 4014B	Screw - M4X14	
103	0805 3449	Ball Bearing - M12x24x6	
104	0725 0120E	Retaining Ring C - M12	
105	0952 4010B	Screw - M4X10	
106	0413 0102B	Tapping Screw - M3x10	
107	0720 0040B	Retaining Ring - M4	
108	0313 0040B	Philips Pan Head Screw - M3x4	

25. Development Unit - Cyan (A109)




25. Development Unit - Cyan (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 3095	Development Unit Cover - B/C	1
2	AA15 1845	Seal - 4x8x333.5	1
3	A172 3074	Development Sleeve Assy - Cyan	1
4	A109 3086	Development Casing Seal	2
5	A109 3082	Development Sleeve Cover	1
6	A109 3070	Paddle Flange Stopper	1
7	A109 3085	Positioning Adjuster	1
8	AA14 3285	Shoulder Screw - M4	1
9	AA15 2319	Seal - 16x36	1
10	AB01 7330	Gear - 20Z/34Z	1
11	A109 3051	Front Side Plate - B/C	1
12	AA15 2320	Seal - 16x36	1
13	AB01 1342	Gear - 30Z	1
14	AA15 1843	Seal - 4x7x59.5	2
15	AA15 1842	Seal - 1x5x55.5	2
16	AB01 3814	Gear - 40Z	1
17	A109 3066	Mixing Paddle Roller - B/C	1
18	A109 3054	Rear Side Plate - B/C	1
19	AA15 1849	Seal - 5x8x342	1
20	A109 3062	Development Casing - Cyan	1
21	A109 3065	Spacer - Toner Density Sensor	1
22	AW23 0007	Toner Density Sensor	1
23	A109 3100	Toner Supply Receptacle	1
24	AA15 1846	Seal - 2x27x36	1
25	AA15 1847	Seal - 4x47	1
26	A109 3068	Paddle Flange	1
27	AB01 1148	Gear - 28Z	1
28	AB01 1149	Gear - 14Z	1
29	A109 3102	Toner Collection Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0354 0060B	Screw - M4X6	
101	0720 0040B	Retaining Ring - M4	
102	0313 0060B	Philips Pan Head Screw - M3x6	
103	0805 3449	Ball Bearing - M12x24x6	
104	0725 0120E	Retaining Ring C - M12	
105	0952 4014B	Screw - M4X14	
106	0952 4010B	Screw - M4X10	

26. Development Unit - Magenta (A109)




26. Development Unit - Magenta (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	AD00 1041	Development Unit - M/Y	1
1	A172 3214	Development Sleeve - M/Y	1
2	A109 3082	Development Sleeve Cover	1
3	AB01 1149	Gear - 14Z	1
4	A109 3086	Development Casing Seal	2
5	A109 3085	Positioning Adjuster	1
6	AB01 1148	Gear - 28Z	1
7	AA15 2319	Seal - 16x36	1
8	AB01 7330	Gear - 20Z/34Z	1
9	AA14 3285	Shoulder Screw - M4	1
10	AA15 2320	Seal - 16x36	1
11	AB01 1342	Gear - 30Z	1
12	A109 3204	Rear Side Plate - M/Y	1
13	A109 5305	Development Unit Harness	1
14	AA15 1842	Seal - 1x5x55.5	3
15	AB01 3814	Gear - 40Z	1
16	A109 3067	Mixing Paddle Roller	1
17	A109 3070	Paddle Flange Stopper	1
18	AA15 1849	Seal - 5x8x342	1
19	6803 2273	Stepped Screw - M4	1
20	A109 3209	Development Casing - Magenta	1
21	A109 3065	Spacer - Toner Density Sensor	1
22	AW23 0007	Toner Density Sensor	1
23	A109 3201	Front Side Plate - M/Y	1
24	A109 3100	Toner Supply Receptacle	1
25	AA15 1846	Seal - 2x27x36	1
26	AA14 3418	Positioning Pin	1
27	A109 3102	Toner Collection Cover	1
28	AA15 1847	Seal - 4x47	1
29	A109 3068	Paddle Flange	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0313 0040B	Philips Pan Head Screw - M3x4	
102	0725 0120E	Retaining Ring C - M12	
103	0413 0102B	Tapping Screw - M3x10	
104	0952 4014B	Screw - M4X14	
105	0805 3449	Ball Bearing - M12x24x6	
106	0313 0060B	Philips Pan Head Screw - M3x6	
107	0952 4010B	Screw - M4X10	
108	0720 0040B	Retaining Ring - M4	

27. Development Unit - Yellow (A109)




27. Development Unit - Yellow (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A172 3214	Development Sleeve - M/Y	1
2	A109 3082	Development Sleeve Cover	1
3	A109 3102	Toner Collection Cover	1
4	A109 3086	Development Casing Seal	2
5	A109 3085	Positioning Adjuster	1
6	AB01 1149	Gear - 14Z	1
7	AA15 2319	Seal - 16x36	1
8	AB01 1148	Gear - 28Z	1
9	AB01 7330	Gear - 20Z/34Z	1
10	AA15 2320	Seal - 16x36	1
11	AB01 1342	Gear - 30Z	1
12	A109 3204	Rear Side Plate - M/Y	1
13	AA15 1842	Seal - 1x5x55.5	3
14	AB01 3815	Gear - 30Z	1
15	AB01 3814	Gear - 40Z	1
16	A109 3067	Mixing Paddle Roller	1
17	AA14 3285	Shoulder Screw - M4	1
18	AA15 1849	Seal - 5x8x342	1
19	A109 3212	Development Casing - Yellow	1
20	A109 3226	ID Sensor Rail	1
21	AA15 0345	Seal - 19.5x170	1
22	AA14 3358	Stepped Screw - M4x3	1
23	A109 3219	Development Unit Stopper - M/Y	1
24	A109 3216	Base Plate - M/Y	1
25	A109 3222	Development Unit Cover - M/Y	1
26	A109 3065	Spacer - Toner Density Sensor	1
27	AW23 0007	Toner Density Sensor	1
28	A109 3100	Toner Supply Receptacle	1
29	AA15 1846	Seal - 2x27x36	1
30	A109 3201	Front Side Plate - M/Y	1
31	5350 1754	Stud - M5x4	2
32	AA15 1847	Seal - 4x47	1
33	A109 3068	Paddle Flange	1
34	A109 3070	Paddle Flange Stopper	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0725 0120E	Retaining Ring C - M12	
103	0952 4014B	Screw - M4X14	
104	0720 0060B	Retaining Ring - M6	
105	0952 4010B	Screw - M4X10	
106	0313 0060B	Philips Pan Head Screw - M3x6	
107	0354 0060B	Screw - M4X6	
108	0805 3449	Ball Bearing - M12x24x6	
109	0313 0040B	Philips Pan Head Screw - M3x4	

28. Transfer Belt Unit 1 (A109)




28. Transfer Belt Unit 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5919 2201	Shoulder Screw - M4	1
2	AG05 1106	Transfer Belt Unit Band	1
3	A109 6124	Transfer Unit Grip Plate	1
4	AA14 3709	Stepped Screw - M4	1
5	A109 6069	Belt Cleaning Roller	1
6	A109 6055	Front Side Plate - Transfer	1
7	C201 5125	Shoulder Screw - M4	2
8	A109 6126	Transfer Unit Position Shaft	1
9	AA16 1097	Cushion - 6.5x14	1
10	A109 6087	Spring Holder Cover - Transfer	1
11	AA06 3493	Pressure Spring	1
12	A109 6089	Spring Holder - Transfer	1
13	A109 6060	Transfer Unit Stay	1
14	A109 6063	Belt Drive Roller	1
15	A109 6130	Transfer Belt	1
16	A109 6058	Rear Side Plate - Transfer	1
17	AA13 2167	Spacer	1
18	A109 6082	Transfer Roller Joint	1
19	AG05 1100	Transfer Belt Unit Handle	1
20	A109 6155	Cleaning Roller Front Bracket	1
21	A109 6156	Cleaning Roller Rear Bracket	1
22	A109 6157	Belt Support Roller	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0354 0060B	Screw - M4X6	
101	0951 4008B	Philips Screw With Washer - M4x8	
102	0720 0060B	Retaining Ring - M6	
103	0805 3482	Ball Bearing - 8x14x3.5	

29. Transfer Belt Unit 2 (A109)




29. Transfer Belt Unit 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 6000	Transfer Belt Unit	1
1	A109 6105	Belt Bias Roller	1
2	A109 6110	Transfer Idle Roller	1
3	AA08 4045	Bearing Holder	2
4	AA13 2172	Spacer	4
5	5409 1855	Mounting Pin	1
6	A109 6101	Bias Roller Bracket	1
7	AA14 8391	Pin - 4x36	4
8	AA13 2166	Roller	4
9	AA14 1081	Support Stay	2
10	A109 6096	Cam Shaft	1
11	A109 6097	Release Cam	2
12	A109 6098	Tention Cam	2
13	5206 2686	Snap Ring	4
14	AA08 1003	Bushing - 5x7x3.8mm	4
15	A109 6091	Transfer Unit Frame	1
16	A109 6121	Tension Roller Bracket	1
17	A109 6099	Cam Lever	1
18	AA14 1082	Support Stay	1
19	A109 6122	Tension Support Roller Holder	2
20	AA08 4044	Bearing Holder	2
21	AA06 3491	Pressure Spring	2
22	A109 6118	Belt Tension Roller	1
23	5875 2088	Shoulder Screw - M4	1
24	A109 6117	Base - Spring	2

Index No.	Part No.	Description	Q'ty Per Assembly
100	0720 0060B	Retaining Ring - M6	
101	0805 3482	Ball Bearing - 8x14x3.5	
102	0720 0030B	Retaining Ring - M3	
103	0951 3006B	Philips Screw With Flat Washer - M3x6	
104	0354 0060B	Screw - M4x6	
105	0805 3385	Bushing - 6mm	
106	0727 0080E	Retaining Ring - M8	
107	0324 0060B	Philips Sunken Head Screw - M4x6	

30. Transfer Roller Unit (A109)




30. Transfer Roller Unit (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 6256	Paper Discharge Support Plate	1
2	A109 6251	Paper Discharge Plate	1
3	A109 6243	Entrance Seal Ass'y - Transfer	1
4	AA15 1821	Seal - 5.5x356	1
5	A109 6248	Upper Guide Plate - Transfer	1
6	A109 6247	Transfer Guide Plate Knob	1
7	A109 6200	Transfer Roller	1
8	AD04 1026	Transfer Roller Blade	1
9	A109 6222	Transfer Roller Blade Bracket	1
10	AA08 0162	Bushing - 8mm	2
11	AB01 3847	Gear - 30Z	1
12	5400 3404	Stepped Screw	2
13	AA02 0018	Magnet	2
14	A109 6235	Lower Guide Plate - Transfer	1
15	AA06 3353	Pressure Spring	2
16	AA08 0163	Bushing - 8mm	2
17	A109 6258	Roller	1
18	AA14 5216	Pin - 6x54.9	1
19	A109 6270	Right Positioning Plate	1
20	A109 6260	Toner Catch Pan	1
21	AA15 1822	Seal - 3x4x47	2
22	AA15 1860	Seal - 2x5.5x347.8	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0720 0060B	Retaining Ring - M6	
101	0354 0060B	Screw - M4X6	
102	0720 0040B	Retaining Ring - M4	

31. Transport Unit (A109)




31. Transport Unit (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AG05 1098	Transport Lever	1
2	AA00 0537	Decal - High Voltage	1
3	5053 0447	Bushing - 6mm	1
4	AF02 2069	Left Transport Roller	1
5	AB01 3835	Gear - 20Z	1
6	AA04 0023	Transfer Belt	2
7	A109 5310	Relay Harness - Transport Fan	1
8	A172 3851	Transport Tank	1
9	AF02 2070	Right Transport Roller	2
10	AX64 0042	Transport Fan Motor - DC24V 3.12W	2
11	A109 3859	Transport Fan Bracket	1
12	A109 3853	Rear Lift Arm - Transport	1
13	A109 3852	Front Lift Arm - Transport	1
14	A109 3857	Support Roller - Lift Arm	2
15	AA14 0517	Drive Shaft	1
16	A109 3858	Lift Arm Stay	1
17	5447 2681	Snap Ring	1
18	AA14 0518	Drive Shaft	2
19	AA06 2268	Spring	1
20	AA06 2267	Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0080B	Philips Tapping Screw - M4x8	
101	0720 0040B	Retaining Ring - M4	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	1105 0199	Clamp	
104	0414 0082B	Binding Self Tapping Screw - M4x8	
105	0805 3366	Bushing - 6mm	

32. Belt Cleaning Unit (A109)




32. Belt Cleaning Unit (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 6367	Front Holder - Entrance Seal	1
2	A109 6310	Toner Collection Cap	1
3	A109 6311	Toner Collection Spring	1
4	A109 6354	Cleaning Entrance Seal Solenoid	1
5	A172 6318	Cleaning Left Stay	1
6	A109 6344	Cleaning Blade Solenoid	1
7	A109 6305	Front Side Plate - Belt Cleaning	1
8	A109 6309	Front - Seal - 10x20	1
9	A109 6338	Cleaning Blade Lever	1
10	A109 6342	Cleaning Blade Roller	1
11	A109 6350	Cleaning Blade Lever Spring	1
12	A109 3598	Cleaning Blade	1
13	A109 6349	Cleaning Blade Spring	1
14	A109 6336	Belt Cleaning Casing	1
15	A109 6351	Spring Stopper Seal	1
16	AA14 3733	Stepped Screw M4	1
17	A109 9502	Seal - Cleaning Blade	1
18	A109 9504	Entrance Seal - Belt Cleaning Unit	1
19	A109 6303	Blade Holder	1
20	AB01 3848	Gear - 12Z	1
21	A109 6317	Toner Collection Auger	1
22	A109 6370	Entrance Seal Bracket	1
23	A109 6372	Entrance Seal Bracket Sheet	1
24	A109 6369	Entrance Seal Collar	2
25	A109 6352	Entrance Seal Spring	1
26	A109 6364	Cleaning Blade Bracket	1
27	A109 9503	Entrance Seal - Belt Cleaning	1
28	A109 6314	Rear Side Plate - Belt Cleaning	1
29	A109 6316	Rear Seal - 10x30	1
30	A109 6360	Release Spring	1
31	A109 6377	Front Side Plate Cushion	1
32	A109 6373	Base Plate - Belt Cleaning	1
33	A109 6375	Base Plate Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0314 0080B	Philips Pan Head Screw - M4x8	
101	0313 0060B	Philips Pan Head Screw - M3x6	
102	0952 4014B	Screw - M4X14	
103	0324 0080B	Philips Sunken Head Screw - M4x8	
104	0720 0030B	Retaining Ring - M3	
105	1102 6246	Connector - 3P	
106	1102 6260	Connector - Red 3P	
107	0720 0040B	Retaining Ring - M4	
108	0951 3006B	Philips Screw With Flat Washer - M3x6	

33. Toner Collection Section (A109)




33. Toner Collection Section (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5447 2681	Snap Ring	2
2	AB01 3849	Gear - 14Z	1
3	AB01 3850	Gear - 21Z	1
4	A109 1384	Lower Inner Cover	1
5	A109 6335	Seal - 8x327	1
6	A109 6418	Brush Roller Holder	1
7	A109 6430	Lubricant Bar	1
8	A109 6425	Brush Roller Spacer	2
9	A109 6424	Shaft Roller	2
10	A109 6422	Lubricant Brush	1
12	A109 6426	Front Holder	1
13	A109 6427	Release Spring	1
14	A109 6140	Transfer Unit Cover Plate	1
15	A109 6541	Joint Fixing Band	1
16	A109 6523	Lower Collection Joint	1
17	A109 6547	Seal - 18mm	1
18	A109 6548	Small Duct Upper Seal	1
19	A109 6545	Collection Pipe Support Plate	1
20	A109 6546	Seal - 12mm	2
21	A109 6543	Toner Collection Duct	1
22	A109 6544	Collection Pipe - Transfer Belt	1
23	A109 6555	Lower Collection Tube	1
24	A109 6531	Lower Collection Coil	1
25	A109 6551	Joint Duct - Collection Bottle	1
26	AB01 3853	Gear - 18Z	1
27	AB01 3854	Gear - 36Z	1
28	A109 6561	Toner Collection Duct	1
29	A109 6564	Lower Seal - 8x13x7	2
30	A109 6563	Upper Seal - 3x10x36	2
31	5413 2298	Screw - M4	1
32	AG07 0004	Magnetic Catch	1
33	A109 1366	Magnet Catch Bracket	1
34	A109 3335	Developer Supply Funnel	1
35	A109 1397	Inner Cover - Transfer Unit	1
36	AA01 2068	Inner Cooling Fan Filter	1

Index No.	Part No.	Description	Q'ty Per Assembly
37	A109 6435	Grounding Plate	1
38	A109 1136	Flange Bracket	1
100	0720 0060B	Retaining Ring - M6	
101	0805 3385	Bushing - 6mm	
102	0354 0060B	Screw - M4X6	
103	0344 0060F	Philips Truss Head Screw - M4x6	
104	0964 4008B	Tapping Screw With Flat Washer - M4x8	
105	0720 0040B	Retaining Ring - M4	
106	1105 0310	Wire Clamp	

34. Fusing Unit 1 (A109)




34. Fusing Unit 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 7702	Fusing Unit - 115V	1
1	A109 4217	Cover - Exit	1
2	5840 1632	Stepped Screw	3
3	5215 4497	Exit Antistatic Brush	1
4	A109 4208	Upper Exit Guide Plate	1
5	A109 4204	Slider - Hot Roller Stripper	1
6	AA06 0189	Spring - Stripper Pawl Plate	1
7	A109 4201	Hot Roller Stripper Bracket	1
8	A109 4207	Exit Roller Guide	1
9	AE04 4016	Hot Roller Stripper	6
10	5208 6136	Spring - Hot Roller Stripper	6
11	A109 4212	Exit Roller Holder	2
12	AF04 0031	Upper Exit Roller	2
13	AG05 1105	Rear Release Lever - Exit	1
14	5215 4444	Pin	2
15	AA06 6063	Spring - Rear Release Lever	1
16	AB01 3320	Gear - 19Z	1
17	5442 4495	Slip Clutch	1
18	AB01 3819	Gear - 22Z	1
19	A109 4250	Front Fusing Cover	1
20	A109 4251	Upper Fusing Cover	1
21	A109 4253	Fusing Cover - Right	1
22	A109 5324	Exit Unit Relay Harness	1
23	AF02 0310	Exit Roller	1
24	A109 4210	Exit Sensor Bracket	1
25	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
26	AA06 6226	Spring	1
27	A109 4215	Exit Sensor Feeler	1
28	AA11 1020	Sensor Feeler	1
29	A109 4205	Paper Exit Frame	1
30	AG05 1104	Front Release Lever - Exit	1
31	AA00 0339	Decal - Silicone Oil	1
32	AA06 6062	Spring - Front Release Lever	1
33	5447 2681	Snap Ring	1
34	A109 4209	Lower Exit Guide Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	A109 4213	Exit Roller Front Guide	1
100	0720 0040E	Retaining Ring - M4	
101	0805 3385	Bushing - 6mm	
102	0951 4008B	Philips Screw With Washer - M4x8	
103	0951 4006B	Philips Screw With Washer - M4x6	
104	0314 0060B	Philips Pan Head Screw - M4x6	
105	0952 4014B	Screw - M4X14	

35. Fusing Unit 2 (A109)




35. Fusing Unit 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 7702	Fusing Unit - 115V	1
1	AA18 0008	Oil Tube - 320mm	1
2	5447 4241	Tube Clamp	2
3	A109 4230	Oil Supply Bracket	1
4	AA13 2025	Spacer - 1x8x12	1
5	AA06 6079	Spring - Oil Pump Lever	1
6	A030 4133	Oil Pump Lever	1
7	AA18 0035	Sleeve - Oil Pump	1
8	AA18 0009	Oil Tube - 120mm	1
9	AA03 6007	Oil Tank Cap	1
10	AA03 1008	Oil Tank	1
11	AG05 0070	Fusing Knob	1
12	AB01 7038	Gear - 32T	1
13	A109 4161	Spring Plate - Oil Supply Pad	1
14	A109 5406	Fusing Thermofuse - 150°C 15A	1
15	A109 4162	Oil Supply Bracket	1
16	A109 5408	Pressure Roller Thermofuse - 150°C 15A	1
17	AE04 5015	Oil Supply Pad	1
18	AW10 0023	Fusing Thermistor	1
19	AA06 0340	Spring - Thermistor	1
20	A072 4115	Upper Entrance Guide Plate	1
21	A109 4167	Lower Entrance Guide Plate	1
22	A109 5327	Relay Harness - Oil End Sensor	1
23	5209 5320	Oil End Sensor	1
24	5215 4411	Spring Plate	1
25	5415 4310	Valve - Oil Pump	2

Index No.	Part No.	Description	Q'ty Per Assembly
100	0313 0060B	Philips Pan Head Screw - M3x6	
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0414 0082B	Binding Self Tapping Screw - M4x8	
103	0720 0060B	Retaining Ring - M6	

36. Fusing Unit 3 (A109)




36. Fusing Unit 3 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 7702	Fusing Unit - 115V	1
1	A109 5324	Exit Unit Relay Harness	1
2	A109 5405	Pressure Roller Thermistor	1
3	A109 4182	Left Lower Stay - Fusing	1
4	A109 4153	Oil Guide	1
5	A109 4110	Oil Supply Stopper	1
6	A109 4107	Fusing Lamp Holder - Front	1
7	A109 4072	Pressure Roller Lamp Holder	2
8	AB01 3363	Gear - 16Z	1
9	AE03 1005	Bushing	1
10	AA15 2233	Gasket - 10x36	1
11	AX44 0073	Fusing Lamp - 115V 650W	1
12	AX43 0016	Pressure Roller Lamp - 115V 400W	1
13	AA14 0512	Drive Shaft	1
14	AA06 2275	Release Spring	2
15	A109 4141	Fusing Harness Bracket	1
16	AE04 1002	Oil Blade	1
17	5215 4116	Oil Blade Holder	1
18	AE03 0013	Ball Bearing - 8x15.6x4mm	1
19	AA06 3097	Spring - Fusing Drive	1
20	AB01 3817	Gear - 30Z	1
21	A109 5304	Fusing Unit Harness	1
22	A109 4137	Fusing Lamp Holder - Rear	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0314 0060B	Philips Pan Head Screw - M4x6	
101	0720 0060B	Retaining Ring - M6	
102	0314 0080B	Philips Pan Head Screw - M4x8	
103	0952 4014B	Screw - M4X14	
104	0952 3008B	Screw - M3X8	
105	1105 0292	Wire Saddle	
106	1101 0474	Connector - 4P	
107	1105 0230	Clamp	
108	0951 4008B	Philips Screw With Washer - M4x8	

37. Fusing Unit 4 (A109)




37. Fusing Unit 4 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 7702	Fusing Unit - 115V	1
1	A109 4192	Blade Bracket	1
2	A109 4194	Cleaning Roller Scraper	1
3	A109 4190	Cleaning Roller Bracket	1
4	AE03 1013	Bushing - 6mm	2
5	AB01 3820	Gear - 17Z	1
6	AE04 2004	Fusing Cleaning Roller	1
7	A109 4159	Upper Fusing Rail	1
8	AE01 0006	Hot Roller	1
9	AE02 0035	Pressure Roller	1
10	A109 4180	Right Lower Stay - Fusing	1
11	A109 4169	Oil Pan	1
12	5840 1632	Stepped Screw	1
13	A109 4100	Front Side Plate - Fusing	1
14	AE03 0015	Ball Bearing - 35x47x7	2
15	AE03 2017	Bushing - 30x40x14.5	2
16	AE03 0019	Ball Bearing - 7x20x32	2
17	AA14 3707	Stepped Screw - M5	2
18	AA13 2094	Spacer - Mounting Arm	2
19	A109 4063	Upper Pressure Lever	2
20	A030 4145	Pressure Spring Holder	2
21	AA06 3355	Pressure Spring	2
22	A109 4064	Lower Pressure Lever	2
23	A109 4130	Rear Side Plate - Fusing	1
24	AB01 3318	Gear - 17Z	1
25	AB01 3818	Gear - 61Z	1
26	A172 4171	Right Stay - Fusing	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0314 0060B	Philips Pan Head Screw - M4x6	
101	0720 0040E	Retaining Ring - M4	
102	0720 0060B	Retaining Ring - M6	
103	0725 0300E	Retaining Ring C - M30	
104	0585 0161B	Hexagon Bolt - M5x16	
105	0720 0080B	Retaining Ring - M8	
106	0951 4008B	Philips Screw With Washer - M4x8	

38. Drive Section 1 (A109)




38. Drive Section 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB03 0442	Timing Pulley	1
2	AB01 3827	Gear - 20Z	1
3	AB01 3828	Gear - 20Z	1
4	A109 5762	Support Bracket - E	1
5	AX06 0093	Lubricant Brush Motor - DC36W	1
6	AB01 7311	Gear - 30Z/34Z	1
7	A109 4621	Lubricant Motor Bracket	1
8	AA13 2129	Spacer - 8x12x4.5	1
9	A109 4812	Tightener	1
10	5418 2859	Spring - Regist Roller (Front)	1
11	AB03 0266	Pulley - 28Z	2
12	AB01 7310	Gear - 26Z/89Z	1
13	AA04 3410	Timing Belt - 699 - S3MV	1
14	5053 0447	Bushing - 6mm	2
15	A109 4642	Clutch Bracket - Lubricant Brush	1
16	AX20 0097	Magnetic Spring Clutch	1
17	AA14 5219	Drive Shaft	1
18	AB01 3826	Gear - 21Z	1
19	AW02 0062	Photointerruptor - EE-SX4019-P15	1
20	AB01 7312	Gear - 19Z/26Z	1
21	A109 4630	Joint - Clutch	1
22	AA06 3358	Pressure Spring	1
23	A109 4628	Clutch Holder	1
24	AA14 5248	Clutch Shaft	1
25	A109 4627	Clutch Holder Bracket	1
26	C105 2065	Bushing - 6mm	2
27	AX21 0055	Spring Clutch	1
28	AA04 3408	Timing Belt - 453 - S3MV	1
29	AB01 7309	Gear - 28Z/62Z	1
30	A109 5316	Relay Harness - Development Motor	1
31	A172 4754	Belt Tightener	1
32	AA06 0064	Tension Spring	1
33	A109 4752	Drive Motor Bracket	1
34	AX06 0085	Color Development Drive - DC26W	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0720 0060B	Retaining Ring - M6	
101	0354 0060B	Screw - M4X6	
102	0434 0080B	Philips Tapping Screw - M4x8	
103	0951 4008B	Philips Screw With Washer - M4x8	
104	0720 0040B	Retaining Ring - M4	
105	0951 4006B	Philips Screw With Washer - M4x6	
106	0314 0160B	Philips Pan Head Screw - M4x16	
107	0727 0080E	Retaining Ring - M8	
108	0950 4008B	Philips Screw With Spring Washer	
109	0807 7049	Spacer - 12.3x18mmx0.2T	

39. Drive Section 2 (A109)




39. Drive Section 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX05 0067	Color Sleeve Motor - DC9.3W	3
2	AB03 0440	Timing Pulley - 28Z	1
3	5053 0223	Bushing - 8mm	2
4	A109 4723	Support Plate	1
5	A109 4725	Sleeve Motor Bracket	1
6	AA06 3357	Pressure Spring	4
7	AB01 7307	Gear - 20Z/50Z	4
8	AA06 3356	Pressure Spring	2
9	AB01 3864	Gear - 30Z	2
10	AB01 3865	Gear - 26Z	2
11	AA14 0515	Drive Shaft	1
12	AB01 3823	Gear - 31Z	1
13	A109 4652	Fly Wheel - 190	1
14	A109 4651	Fly Wheel - 195	1
15	A109 4656	Drum Motor	1
16	AX05 0070	Black Sleeve Motor - DC9.3W	1
17	AX05 0066	Black Dev.Drive Motor - DC7.2W	1
18	AB01 7313	Gear - 20Z/132Z	1
19	AB01 3830	Gear - 40Z	1
20	A109 4742	Drum Drive Motor Bracket	1
21	AB01 7308	Gear - 25Z/56Z	1
22	AA13 2133	Spacer	2
23	A109 4727	Collar - 10x17x18mm	2
24	AA13 2094	Spacer - Mounting Arm	4

Index No.	Part No.	Description	Q'ty Per Assembly
100	0354 0060B	Screw - M4X6	
101	0950 3010B	Philips Screw With Spring Washer	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	
104	0807 7049	Spacer - 12.3x18mmx0.2T	
105	1105 0231	Clamp	
106	0951 5040B	Screw - M5X40	
107	0951 4008B	Philips Screw With Washer - M4x8	
108	1105 0349	Edge Saddle	
109	1105 0310	Wire Clamp	

40. Drive Section 3 (A109)




40. Drive Section 3 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 4674	Front Joint - Transfer Belt	1
2	A109 4675	Rear Joint - Transfer Belt	1
3	AA06 3359	Pressure Spring	1
4	A109 4679	Transfer Belt Drive Shaft	1
5	AX06 0088	Transport Belt Motor - DC24V 2A	1
6	AB03 0444	Timing Pulley - 66Z	1
7	A109 4670	Motor Cushion	1
8	A109 4671	Transfer Belt Motor Bracket	1
9	5432 3265	Spring Lock Lever	1
10	A109 4676	Belt Tightner	1
11	AB03 0445	Timing Pulley - 44Z	1
12	AA14 3708	Stepped Screw - M4	2
13	AD02 1095	Transfer Roller Receptacle	1
14	5919 2201	Shoulder Screw - M4	1
15	AA06 6231	Receptacle Spring	1
16	A109 1132	Drum Flange Cover	1
17	AA04 3234	Timing Belt - 200 TN15 10.0	1
18	A109 4673	Pulley Cover	1
19	AB03 0443	Timing Pulley - 88Z	1
20	A100 5378	Grounding Wire	1
21	A109 5390	Drum Bias Cable	1
22	A109 4655	Drum Shaft Terminal	1
23	A109 4653	Drum Shaft Holder	1
24	A109 2270	Drum Shaft	1
25	A109 2380	ID Sensor Duct	1
26	A109 2385	Duct Tube Ass'y	1
27	AB01 3912	Gear - 80Z	1
28	A109 1131	Drum Gear Cover	1
29	A109 4650	Fly-wheel Support Plate	1
30	A109 6150	Positioning Screw	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0725 0120E	Retaining Ring C - M12	
101	0807 7049	Spacer - 12.3x18mmx0.2T	
102	0741 3808	Ball Bearing - 8x16x5mm	
103	0807 5053	Washer	
104	0354 0100B	Screw - M4X10	
105	0574 0060E	Hexagon Headless Set Screw - M4x6	
106	0951 4006B	Philips Screw With Washer - M4x6	
107	0354 0060B	Screw - M4X6	
108	0951 4008B	Philips Screw With Washer - M4x8	
109	0414 0082B	Binding Self Tapping Screw - M4x8	
110	0575 0050E	Hexagon Headless Set Screw - M5x5	
111	0720 0060E	Retaining Ring - M6	
112	1105 0310	Wire Clamp	
113	0710 0100B	Hexagonal Nut - M10	
114	0701 0100B	Flat Washer - 10	

41. Drive Section 4 (A109)




41. Drive Section 4 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A033 7558	Grounding Plate	2
2	A109 5751	Main Control Board Hinge	2
3	AB01 7320	Gear - 29Z/44Z	1
4	AB01 3837	Gear - 42Z	1
5	AB01 3838	Gear - 17Z	1
6	AB01 7318	Gear - 29Z/33Z	1
7	AB01 3836	Gear - 46Z	1
8	AB03 0446	Timing Pulley	2
9	AB01 7321	Gear - 20Z/30Z	1
10	A109 4712	Belt Tightner	1
11	AA06 0559	Release Spring	1
12	AB01 7316	Gear - 20Z/43Z	1
13	AA04 3409	Timing Belt - 600 - S3MV	1
14	AX06 0084	Transport Motor - DC36W	1
15	A109 4692	Transport Motor Bracket	1
16	AB01 3870	Gear - 22Z	1
17	A109 4697	Idle Gear Bracket - Rear	1
18	AB01 7314	Gear - 20Z/33Z	1
19	A109 4695	Idle Gear Bracket - Front	1
20	AB01 3832	Gear - 28Z	1
21	5447 2743	Lever Spring	1
22	AA14 5220	Drive Shaft	1
23	AB01 3834	Gear - 30Z	1
24	A109 4694	Fusing Drive Gear Bracket	1
25	AB01 3835	Gear - 20Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0720 0060B	Retaining Ring - M6	
101	0575 0050E	Hexagon Headless Set Screw - M5x5	
102	0354 0060B	Screw - M4x6	
103	0354 0100B	Screw - M4x10	
104	0314 0060B	Philips Pan Head Screw - M4x6	
105	0720 0040E	Retaining Ring - M4	
106	0740 3008	Ball Bearing - 8x22x7	

42. Electrical Section 1 (A109)




42. Electrical Section 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A006 1352	Key Counter Cover	1
2	A060 1325	Right Hinge Pin	2
3	A109 1101	Front Right Frame	1
4	5420 1515	Plate - Key Counter	1
5	A109 1086	Upper Paper Feed Stay	1
6	AA17 4018	Sheet - 45x45	1
7	A109 2697	Front Holder - By-pass Feed Table	1
8	A109 5755	Front Holder - Interface 1	2
9	AZ31 0017	High Voltage Supply Board - D	1
10	A109 5391	High Voltage Harness	1
11	A109 5184	IC - UPD78P312ACW	1
12	A109 5758	Rear Holder - Interface 1	1
13	A109 1092	Right Upper Stay	1
14	A109 5312	Relay Harness - Polygon Motor	1
15	A109 5747	Interface Board 1 Bracket	1
16	A109 2722	Stay Angle	1
17	A109 1109	Frame Bracket - Rear Upper Right	1
18	A109 1107	Rear Right Frame	1
19	A109 5182	Transfer Belt Drive Board	1
20	A109 5329	Polygon Motor Relay Harness	1
21	A109 5330	AC Power Pack Relay Harness	1
22	A109 5315	Relay Harness - Brush Motor	1
23	A109 5111	Interface Board 1	1
24	A109 5301	Front DC Harness	1
25	A109 2696	Latch Bracket - By-pass	1
26	AW02 0065	Photointerruptor	1
27	A109 2703	Sensor Feeler Holder	1
28	A109 2701	Sensor Feeler - By-pass Feed Table	1
29	AA15 2234	Seal - 6x10x11	1
30	A109 2707	Right Upper Stay	1
31	AG07 1007	Latch - By Pass Feed Table	1
32	A109 5317	Key Counter Relay Harness	1
33	A109 5156	IC - MB7111LM	1
34	A109 5155	IC - MB7111LM	1
35	5922 2642	Edging	2

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0080B	Philips Tapping Screw - M4x8	
101	0964 4008B	Tapping Screw With Flat Washer - M4x8	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0354 0060B	Screw - M4X6	
104	1105 0292	Wire Saddle	
105	0323 0060B	Philips Sunk Screw - M3x6	
106	1105 0409	Spacer	
107	1105 0193	Nylon Stud	
108	1105 0413	Harness Clamp	

43. Electrical Section 2 (A109)




43. Electrical Section 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 5302	Rear Upper DC Harness	1
2	AA14 3301	Stepped Screw - M3x4	4
3	A109 5320	Development Relay Harness - 1	1
4	A172 3608	Cleaning Receptacle	1
5	A109 5318	Erase Lamp Relay Harness	1
7	A109 5386	Transfer Belt Heater Hanrness	1
8	A109 2300	Charge Corona Receptacle	1
9	A109 5798	Harness Clamp Plate	1
10	AA14 3708	Stepped Screw - M4	2
11	AD02 1103	Transfer Belt Receptacle	1
12	5919 2201	Shoulder Screw - M4	1
13	A109 5303	Rear Lower DC Harness	1
14	5446 5832	Connector Guide Pin	2
15	AA06 3068	Spring Connector	2
16	A109 3315	Development Bias - Terminal - Y	1
17	A109 5314	Relay Harness - Transport Unit	1
18	A109 5321	Development Relay Harness - 2	1
19	A109 3314	Development Bias Retminal - M	1
20	A109 3313	Development Bias - Terminal - C	1
21	A109 3312	Development Bias Terminal - B	1
22	A109 1115	Fusing Connector Bracket	1
23	A109 5372	AC Main Harness - 120V	1
24	AA06 6227	Receptacle Spring	1
25	AA06 3026	Terminal - Spring	1
26	A109 2321	Pre Cleaning Corona Receptacle	1
27	A172 3606	Cleaning Bias Receptacle	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0354 0060B	Screw - M4X6	
101	0434 0080B	Philips Tapping Screw - M4x8	
102	0433 0102B	Tapping Screw - M3x10	
103	1105 0316	Clamp	
104	1105 0413	Harness Clamp	
105	1105 0291	Wire Saddle	
106	1106 0459	Bushing - 20.2mm	
107	1105 0199	Clamp	

44. Electrical Section 3 (A109)




44. Electrical Section 3 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 5761	Support Bracket - T	1
2	AZ32 0068	High Vol. Supply Board - T1,PCC,BR	1
3	A109 1119	Rear Support Stay	1
4	A109 5106	IC - 4MX8120SN	1
5	A033 7558	Spring Plate - Grounding	4
6	A109 5741	Main Control Board Bracket	1
7	AW03 0036	Optics Fiber Cable - 1000mm	1
8	A109 5101	Main Control Board	1
9	A100 5125	RAM Board	1
10	A109 5119	Interface Board 2	1
11	A172 5743	Interface Board 2 Bracket	1
12	AZ31 0016	High Voltage Supply Board - B	1
13	A109 5765	Board Bracket - B	1
14	AX64 0041	Cooling Fan Motor - DC24 7.64W	2
15	A109 5771	Fusing Exhaust Fan Bracket	1
16	AA01 0081	Fusing Exhaust Ozone Filter	1
17	AZ30 0038	High Voltage Supply Board - T2	1
18	A109 5234	Display Editor Interface Board	1
19	A109 5742	Editor Interface Board Bracket	1
20	A109 5760	Support Bracket - C	1
21	AZ30 0037	High Voltage Supply Board - C.G	1
22	A109 2390	Charge Corona Duct - Large	1
23	AA15 1841	Duct Seal - 2x5x84.5	1
24	AA15 1840	Duct Seal - 2x5x34.5	1
25	A109 2410	Charge Inlet Fan Filter	1
26	A109 2403	Charge Corona Duct - Small	1
28	A109 5104	IC - 4MX8150SN	1
29	A096 7636	DF Harness - 115V	1
30	A109 5331	Editor Relay Harness - 120V	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0080B	Philips Tapping Screw - M4x8	
101	0354 0060B	Screw - M4x6	
102	0314 0300B	Philips Pan Head Screw - M4x30	
103	1102 5981	Fiber Connector	
104	1107 0750	Fuse - 3.15A 250V	
105	0413 0302B	Tapping Screw - M3x10	
106	0314 0120B	Philips Pan Head Screw - M4x12	
107	1105 0291	Wire Saddle	
108	1105 0349	Edge Saddle	
109	1105 0278	Harness Clamp	
110	1105 0193	Nylon Stud	
111	1105 0409	Spacer	
112	1105 0199	Clamp	
113	0800 0072	Philips Pan Head Screw - M2.6x4	
114	0353 0060F	Philips Truss Head Screw - M3x6	
115	0950 4008M	Screw - M4X8	

45. Electrical Section 4 (A109)




45. Electrical Section 4 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A513 5351	Front Harness - Paper Feed Unit	1
2	A513 5350	Rear Harness - Paper Feed Unit	1
3	A109 5355	Relay Harness - Paper Tray Unit	1
4	A513 5121	Paper Feed Interface Board	1
5	A513 1172	Interface Board Bracket	1
6	AW50 0010	Push Switch	1
7	A513 5354	Relay Harness - Paper Size Sensor	1
8	A513 2832	Paper Size Sensor Bracket	1
9	A513 2836	Tray Set Sensor Bracket	2
10	AW50 0012	Push Switch	2
11	A513 5357	Relay Harness - Tray Set Sensor	1
12	A513 5356	DC Relay Harness	1
13	AZ24 0020	DC Power Supply Unit - 100/120V	1
14	A085 5571	Power Supply Cord - 115V	1
15	A513 1178	Power Supply Cord Bracket	1
16	AA00 1190	Decal - Ground	1
17	A513 1179	Noise Filter Bracket	1
18	A513 1033	Left Middle Frame	1
19	A513 5431	Noise Filter Board - 100/115V	1
20	A513 5380	AC Harness - Noise Filter Board (IN)	1
21	A513 5381	Relay Harness	1
22	A513 5383	Heater Harness	1
23	A513 5384	AC Harness - Noise Filter Board (OUT)	1
24	A513 5542	Noise Filter - 115V	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	1107 0391	Fuse - 5A, 125V	
101	1107 0392	Fuse (glass Case) - 6.3A - 125V	
102	1107 0629	Fuse (ceramic Case) - 15A - 125V	
103	1107 0693	Circuit Breaker - 18A 250V	
104	0434 0080B	Philips Tapping Screw - M4x8	
105	1105 0193	Nylon Stud	
106	1105 0409	Spacer	
107	0964 4008B	Tapping Screw With Flat Washer - M4x8	
108	0951 3008B	Philips Screw With Flat Washer - M3x8	
109	1105 0310	Wire Clamp	
110	1105 0413	Harness Clamp	
111	0314 0080M	Philips Pan Head Screw - M4x8	
112	0801 0142	Screw - Spring Washer - M5x8	
113	0954 4008B	Philips Screw - M4x8	

46. Frame Section 1 (A109)




46. Frame Section 1 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 5726	Scanner Stopper Rod	1
2	A109 3437	Latch Bracket - Toner Tank	1
3	A049 3282	Latch	1
4	A109 1387	Inner Cover - Main Switch	1
5	A109 2077	Toner Shielding Grass	1
6	A109 1104	Front Upper Left Frame	1
7	A109 5781	Total Counter Bracket	1
8	AX31 0017	Black Total Counter	1
9	AX31 0019	Color Total Counter	1
10	A109 1393	Inner Cover - Total Counter	1
11	A109 1555	Decal - Total Counter	1
12	A109 1102	Front Upper Right Bracket	1
13	A109 5782	Counter Bracket Hinge	1
14	AA01 0080	Development Ozone Filter	1
15	AA01 2084	Development Filter	1
16	A109 3307	Filter Holder	1
17	A109 5786	Safety Switch Lever	1
18	AA14 5525	Pin - 4x66.2	1
19	A109 5792	Safety Switch Link	1
20	AA14 5526	Pin - 5x63	1
21	A109 5789	Safety Switch Bracket	1
22	C202 3102	Collar - 6.35x10x4mm	1
23	AA06 0308	Spring	1
24	A109 5794	Safety Switch Holder	1
25	A109 1311	Left Door Stopper	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0080B	Philips Tapping Screw - M4x8	
101	1204 2414	Main Switch	
102	0344 0060F	Philips Truss Head Screw - M4x6	
103	0801 1007	Philips Pan Head Screw - M10x7	
104	1204 2356	Microswitch - AM51612A 531	
105	1204 2376	Microswitch - V-162-3C25	
106	0720 0030B	Retaining Ring - M3	
107	1105 0349	Edge Saddle	
108	1105 0292	Wire Saddle	
109	1105 0200	Clamp	
110	1204 2355	Microswitch - AM51632A 531	

47. Frame Section 2 (A109)




47. Frame Section 2 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA01 2069	Development Exhaust Fan Filter	2
2	AA15 1779	Seal - 99x105.5	2
3	A109 3302	Development Exhaust Fan Bracket	1
4	AX64 0043	Optics Cooling Fan Motor - DC24V 2.88	2
5	A109 5319	Separation Corona Cable	1
6	A109 3303	Shielding Plate - Development Duct	1
7	A109 3301	Development Exhaust Fan Duct	1
8	AA15 1827	Seal - 12x12x97	2
9	AA01 2070	Development Duct Lower Filter	1
10	AA15 1828	Seal - 12x12x304	2
11	A109 1111	Rear Left Frame	1
12	A109 1113	Frame Bracket - Rear Upper Left	1
13	A109 1089	Left Upper Tray	1
14	A109 1096	Left Middle Stay	1
15	A109 3330	Lower Left Development Cover	1
16	A172 3325	Development Unit Base	1
17	A109 4270	Fusing Unit Rail	1
18	A172 3881	Transport Sensor Bracket	1
19	AW01 0069	Photo Sensor Assy	1
20	A109 5313	Relay Harness - Transport Sensor	1
21	AG05 1099	Fusing Release Lever	1
22	A109 1105	Front Lower Left Frame	1
23	A109 4273	Fusing Unit Stopper	1
24	A109 4271	Heat Insulating Plate	1
25	AA06 0244	Spring	1
26	AA14 3733	Stepped Screw M4	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0354 0060B	Screw - M4X6	
101	0414 0102B	Tapping Screw M4x10	
102	1105 0199	Clamp	
103	1105 0310	Wire Clamp	
104	0314 0300B	Philips Pan Head Screw - M4x30	
105	0434 0080B	Philips Tapping Screw - M4x8	
106	0414 0102B	Tapping Screw M4x10	
107	0314 0060B	Philips Pan Head Screw - M4x6	
108	1106 0193	Bushing - 7.9mm	
109	0314 0050B	Philips Pan Head Screw - M4x5	
110	0313 0100B	Philips Pan Head Screw - M3x10	
111	1105 0200	Clamp	

48. Frame Section 3 (A109)




48. Frame Section 3 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 3441	Right Slide Rail Stay	1
2	AA07 0022	Slide Rail	2
3	A109 3446	Right Stay - Toner Tank	1
4	AA14 3301	Stepped Screw - M3x4	2
5	A109 5307	Toner Tank Relay Harness - 1	1
6	A109 3455	Left Stay - Toner Tank	1
7	A109 3459	Connector Cover - Hopper Harness	1
8	A109 6403	Solenoid Bracket	1
9	A109 3440	Left Slide Rail Stay	1
10	AA14 3358	Stepped Screw - M4x3	1
11	A109 3332	Development Unit Stopper - B.C	1
12	A109 1094	Left Side Stay	1
13	A109 3438	Connector Bracket	1
14	A109 5308	Toner Tank Relay Harness - 2	1
15	AA06 3068	Spring Connector	1
16	5446 5832	Connector Guide Pin	1
17	AX40 0057	Heater - 115V 9W	1
18	A109 2421	Drum Heater Bracket	1
19	A109 3322	Development Unit Rail	1
20	A109 2426	Drum Potential Sensor Bracket	1
21	AW33 0004	Drum Potential Sensor	1
22	A109 6131	Transfer Unit Rail	1
23	A109 6401	Lubricant Brush Roller Stay	1
24	A109 6414	Roller	1
25	A109 6415	Lever Spring	1
26	A109 6406	Lubricant Brush Solenoid	1
27	A109 6416	Release Spring	1
28	AA13 2178	Spacer - Drum Potential Sensor	2
29	A109 5328	Solenoid Relay Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0080B	Philips Tapping Screw - M4x8	
101	1102 6265	Connector - Red 8P	
102	0314 0050B	Philips Pan Head Screw - M4x5	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	0720 0040B	Retaining Ring - M4	
106	0720 0030B	Retaining Ring - M3	
107	0957 4008B	Philips Screw W/F Washer - M4x8	
108	0952 3008B	Screw - M3x8	

49. Frame Section 4 (A109)



49. Frame Section 4 (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A109 5756	Front Holder - AC Drive	1
2	A109 4274	Copy Tray Holder	2
3	A109 2430	Connector Bracket	1
4	A030 3403	Bracket	2
5	A109 3872	Front Left Positioning Plate	1
6	A109 3871	Front Right Positioning Plate	1
7	A109 4771	Gear Release Arm	1
8	A109 3874	Rear Left Positioning Plate	1
9	A109 5310	Relay Harness - Transport Fan	1
10	A109 5313	Relay Harness - Transport Sensor	1
11	A109 3873	Rear Right Positioning Plate	1
12	A109 1032	Rear Fixing Plate	2
13	A109 4775	Stepped Screw - M5	1
14	A109 4772	Arm Bracket - Gear Release	1
15	A109 1031	Front Fixing Plate	2
16	A109 4774	Gear Release Wire	1
17	A109 4773	Wire Holder - Gear Release	1
18	A109 4910	Lower Left Hinge	1
19	A096 1094	Grip Base	4
20	A109 1057	Grip Plate	4
21	A109 1123	Inner Cooling Fan Bracket	1
22	AX64 0041	Cooling Fan Motor - DC24 7.64W	1
23	A172 3870	Spring Plate - Transport	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	0434 0080B	Philips Tapping Screw - M4x8	
101	0720 0040E	Retaining Ring - M4	
102	0314 0300B	Philips Pan Head Screw - M4x30	
103	1106 0193	Bushing - 7.9mm	
104	1105 0113	Edge - P108	
105	1105 0278	Harness Clamp	
106	1105 0199	Clamp	
107	1105 0352	Clamp	
108	1106 0430	Bushing - 13mm	
109	1105 0334	Edge - 17	

50. Main Control Board (A109)

CAPACITOR

SYMBOL NO.	INDEX NO.
C502	177
C503	178
C504	177
C505	181
C506	181
C507	181
C508	181
C509	181
C510	181
C511	176

SYMBOL NO.	INDEX NO.
C512	178
C513	175
C514	180
C515	183
C516	183
C517	183
C518	183
C519	183
C520	183
C521	183

SYMBOL NO.	INDEX NO.
C522	183
C523	183
C524	183
C525	183
C526	183
C527	183
C528	183
C529	181
C530	183
C531	183

SYMBOL NO.	INDEX NO.
C532	184
C533	176
C534	180
C535	183
C536	184
C537	180
C538	183
C539	180
C540	186
C541	186

SYMBOL NO.	INDEX NO.
C542	183
C543	184
C544	180
C545	180
C546	183
C547	183
C548	180
C549	183
C550	180
C551	183

SYMBOL NO.	INDEX NO.
C552	183
C553	183
C554	180
C555	183
C556	183
C557	183
C558	180
C559	183
C560	183
C561	183

SYMBOL NO.	INDEX NO.
C562	183
C563	183
C564	183
C565	180
C566	183
C567	183
C568	183
C569	183
C570	180
C571	180

SYMBOL NO.	INDEX NO.
C572	183
C573	180
C574	180
C575	180
C576	183
C577	183
C578	183
C579	183
C580	180
C581	180

SYMBOL NO.	INDEX NO.
C582	183
C583	183
C584	183
C585	183
C586	183
C587	183
C588	180
C589	180
C591	183
C592	183

SYMBOL NO.	INDEX NO.
C593	183
C594	183
C595	183
C596	183
C597	183
C598	183
C599	183
C600	183
C601	183
C602	183

SYMBOL NO.	INDEX NO.
C603	180
C604	180
C605	180
C606	180
C607	180
C608	183
C609	183
C610	182
C611	182
C612	183

SYMBOL NO.	INDEX NO.
C613	183
C614	183
C615	183
C616	183
C617	181
C618	183
C619	181
C620	180
C621	180
C622	180

SYMBOL NO.	INDEX NO.
C623	180
C624	183
C625	183
C626	180
C627	180
C629	183
C630	183
C631	183
C632	183
C633	183

SYMBOL NO.	INDEX NO.
C634	183
C635	183
C636	183
C637	183
C638	183
C639	180
C640	183
C641	183
C642	180
C643	183

50. Main Control Board (A109)

SYMBOL NO.	INDEX NO.
C644	179
C645	179
C646	183
C647	180
C648	180
C649	180
C650	180
C651	181
C652	183
C653	183
C654	180

CONNECTOR

SYMBOL NO.	INDEX NO.
CN501	118
CN502	126
CN503	125
CN504	129
CN505	130
CN506	126
CN507	127
CN508	128
CN509	124
CN510	117

SYMBOL NO.	INDEX NO.
CN511	119
CN512	120
CN513	121
CN514	122
CN515	119
CN517	132
CN518	131

DIODE

SYMBOL NO.	INDEX NO.
D502	138
D504	138
D505	138
D506	138
D509	138

DPS

SYMBOL NO.	INDEX NO.
DPS501	134

FIB

SYMBOL NO.	INDEX NO.
FIB501	185
FIB502	185
FIB503	185
FIB504	185
FIB505	185
FIB506	185
FIB507	185
FIB508	185
FIB509	185
FIB510	185

SYMBOL NO.	INDEX NO.
FIB511	185
FIB512	185
FIB513	185
FIB514	185
FIB515	185
FIB516	185
FIB517	185

IC

SYMBOL NO.	INDEX NO.
IC501	170
IC502	168
IC503	168
IC504	164
IC505	169
IC506	149
IC507	156
IC508	161
IC509	2
(socket)	133

SYMBOL NO.	INDEX NO.
IC511	163
IC512	149
IC513	148
IC514	145
IC515	142
IC516	155
IC517	154
IC518	156
IC519	141
IC520	167

SYMBOL NO.	INDEX NO.
IC521	149
IC522	3
(socket)	133
IC523	122
IC524	160
IC525	160
IC526	157
IC527	157
IC528	145
IC529	141
IC530	146

SYMBOL NO.	INDEX NO.
IC531	157
IC532	142
IC533	142
IC534	142
IC535	152
IC536	165
IC537	1
IC538	165
IC539	160
IC540	157

SYMBOL NO.	INDEX NO.
IC541	149
IC542	149
IC543	158
IC544	152
IC545	150
IC546	150
IC547	153
IC548	166
IC549	151
IC550	145

SYMBOL NO.	INDEX NO.
IC551	141
IC552	142
IC553	152
IC554	143
IC555	147
IC556	144
IC557	144
IC558	159
IC559	163
IC560	159

LED

SYMBOL NO.	INDEX NO.
LED502	140

NF

SYMBOL NO.	INDEX NO.
NF501	174

OSC

SYMBOL NO.	INDEX NO.
OSC501	173
OSC502	171
OSC503	172

RESISTOR

SYMBOL NO.	INDEX NO.
R501	190
R502	204
R503	203
R504	189
R505	199
R506	187
R507	190
R508	190
R509	199
R510	199

SYMBOL NO.	INDEX NO.
R511	190
R512	190
R513	190
R514	190
R515	190
R516	190
R517	201
R518	201
R519	200
R520	201

SYMBOL NO.	INDEX NO.
R521	201
R522	201
R523	201
R524	201
R525	201
R526	201
R527	198
R528	190
R529	202
R530	190

SYMBOL NO.	INDEX NO.
R531	201
R532	201
R533	201
R534	198
R535	198
R536	198
R537	190
R538	190
R539	201
R540	198

SYMBOL NO.	INDEX NO.
R541	190
R542	190
R543	190
R544	190
R545	201
R546	201
R547	201
R548	201
R549	201
R550	201

SYMBOL NO.	INDEX NO.
R551	201
R552	201
R553	190
R554	190
R555	190
R556	190
R557	197
R558	201
R559	198
R560	190

SYMBOL NO.	INDEX NO.
R562	201
R563	201
R564	201
R565	190
R566	190
R567	193
R568	198
R569	201
R570	203
R571	189

SYMBOL NO.	INDEX NO.
R572	204
R573	199
R574	201
R575	201
R576	201
R577	201
R578	201
R579	201
R580	203
R581	204

SYMBOL NO.	INDEX NO.
R582	193
R583	197
R584	201
R585	201
R586	201
R587	201
R588	201
R589	198
R590	198
R591	198

SYMBOL NO.	INDEX NO.
R592	198
R593	198
R594	198
R595	198
R596	198
R597	190
R598	190
R599	201
R600	198
R601	198

SYMBOL NO.	INDEX NO.
R602	198
R603	198
R604	192
R605	203
R606	204
R607	199
R608	199
R609	190
R610	203
R611	204

SYMBOL NO.	INDEX NO.
R612	188
R613	188
R614	188
R615	188
R616	188
R617	188
R618	188
R619	188
R620	193
R621	197

SYMBOL NO.	INDEX NO.
R622	193
R623	193
R624	201
R625	201
R626	201
R627	198
R628	198
R629	189
R630	189
R631	189

50. Main Control Board (A109)

SYMBOL NO.	INDEX NO.
R632	189
R633	189
R634	197
R635	193
R636	197
R637	193
R638	190
R639	190
R640	190
R641	190

SYMBOL NO.	INDEX NO.
R642	190
R643	201
R644	198
R645	198
R646	201
R647	201
R648	201
R649	189
R650	197
R651	193

SYMBOL NO.	INDEX NO.
R652	190
R653	190
R654	190
R655	190
R656	201
R657	201
R658	201
R659	201
R660	201
R661	196

SYMBOL NO.	INDEX NO.
R662	196
R663	201
R664	201
R665	190
R666	201
R667	201
R668	201
R669	196
R670	190
R671	189

SYMBOL NO.	INDEX NO.
R674	189
R675	189
R676	190
R677	189
R678	205
R679	189
R680	189
R681	189
R682	194
R683	199

SYMBOL NO.	INDEX NO.
R684	189
R685	189
R686	191
R687	191
R688	190
R689	195
R690	201
R691	201
R692	189
R693	189

SYMBOL NO.	INDEX NO.
R694	190
R695	205
R696	202
R697	189
R698	189
R699	190
R700	202
R701	190
R702	190
R703	190

SYMBOL NO.	INDEX NO.
R704	190
R705	190
R706	190
R707	189
R708	201
R709	201
R710	198
R711	198
R712	189
R713	202

SYMBOL NO.	INDEX NO.
R714	201
R715	201

SW

SYMBOL NO.	INDEX NO.
SW501 (socket)	115 116

SYMBOL NO.	INDEX NO.
TP501	114
TP502	114
TP503	114
TP504	114
TP505	114
TP507	114
TP508	114
TP509	114
TP510	114
TP511	114

SYMBOL NO.	INDEX NO.
TP512	114
TP513	114
TP514	114
TP515	114
TP516	114

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q501	135
Q502	135
Q503	135
Q504	135
Q505	135
Q506	135
Q507	135
Q508	135
Q510	137
Q511	136

ZD

SYMBOL NO.	INDEX NO.
ZD501	139

50. Main Control Board (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 5101	Main Control Board	1
1	A096 5129	IC - M37409M2-155FFP	1
2	A109 5104	IC - 4MX8150SN	1
3	A109 5106	IC - 4MX8120SN	1

Index No.	Part No.	Description	Q'ty Per Assembly
114	1101 0328	Connector Pin Contact	
115	1101 0360	Connector - 3P	
116	1101 0395	IC Socket - 252	
117	1102 5003	Connector - 2P	
118	1102 5328	Connector - 12P	
119	1102 5340	Fiber Connector - 2P	
120	1102 5341	Fiber Connector	
121	1102 5342	Connector - 2P	
122	1102 5343	Connector - 2P	
123	1102 6134	IC Socket	
124	1102 6297	Connector - 4P	
125	1102 6299	Connector - 6P	
126	1102 6303	Connector - 10P	
127	1102 6395	Connector - 1P	
128	1102 6396	Connector - 1P	
129	1102 6402	Connector - 2P	
130	1102 6403	Connector - 30P	
131	1102 6408	Connector - 30P	
132	1103 3020	Connector - 20P	
133	1104 0589	Dip Socket - 32P	
134	1204 1542	Dip Switch	
135	1400 0528	Transistor - DTB113EK	
136	1400 0555	Transistor - DTC143EK	
137	1401 0296	Transistor - 2SA1162Y	
138	1402 0476	Diode - 1SS184	
139	1402 1152	Diode - RD7.5P	
140	1403 0558	LED - SEl2110RTP3	
141	1407 1309	IC - LS04	
142	1407 1311	IC - LS32	
143	1407 1596	IC - SN74LS14NS	
144	1407 2052	IC - SN74LS74ANS	
145	1407 2081	IC - SN74LS08NS	
146	1407 2135	TTLIC - 74F74SJ	
147	1407 2137	IC -74F138SJ : TTL	
148	1407 2138	TTLIC - 74F139SJ	

Index No.	Part No.	Description	Q'ty Per Assembly
149	1407 2187	IC - SN74LS07NS	
150	1407 2231	IC - TD62308AF	
151	1407 2253	IC - SN74LS393NS	
152	1407 2344	IC - TD62382F	
153	1407 2411	IC - SN74LS125F	
154	1407 2463	IC - SN74ALS08NS	
155	1407 2464	IC - SN74ALS74ANS	
156	1407 2588	IC - SN74ALS04BNS	
157	1407 2817	IC - SN74ALS32NS	
158	1407 3692	IC - RF5C86	
159	1407 3753	IC - TC4W53F	
160	1407 3852	IC - MB89371AH	
161	1407 4113	IC - HM6225ALFP-12SLT	
162	1407 4137	IC - MM1035XF	
163	1407 4143	IC - MC68331FC	
164	1407 4144	IC - H81532-HD6435328A00M	
165	1407 4146	LSI - MB89255AHPFS	
166	1407 4183	IC - uPD71051GU-10	
167	1407 4276	IC - LH5168-10L	
168	1408 0585	IC - AD7528JR	
169	1408 0595	IC - NJM2904M	
170	1408 0716	IC - NJM084M	
171	1503 0194	Crystal Oscillator - 32.768 Khz	
172	1503 0563	Oscillator-9.83MTz040	
173	1503 0307	Oscillator - 20Mhz	
174	1602 7029	Noise Filter - 22000PF 50V	
175	1604 1377	Capacitor - 0.47µF 50V	
176	1604 1382	Capacitor - 10µF 50V	
177	1604 1385	Capacitor - 47µF 50V	
178	1604 1386	Capacitor - 100µF ±20% 50V	
179	1605 0233	Capacitor - 15PF 50V	
180	1605 0636	Capacitor - 0.1µF	
181	1606 1135	Capacitor - 470PF 50V	
182	1606 1450	Capacitor - 10PF 50V	
183	1606 1452	Capacitor - 0.01µF 50V	

Index No.	Part No.	Description	Q'ty Per Assembly
184	1606 1537	Capacitor - 1000PF 50V	
185	1607 0477	Inductor - BLM21A05	
186	1610 0286	Capacitor - 100PF 50V ±10%	
187	1630 1101	Resistor - 100 Ω 1/4W ±5%	
188	1630 1151	Resistor - 150 Ω ±5% 1/4W	
189	1630 2102	Resistor - 1K Ω 1/8W ±5%	
190	1630 2103	Resistor - 10K Ω 1/8W	
191	1630 2104	Resistor - 100K Ω 1/8W ±5%	
192	1630 2105	Resistor - 1M Ω 1/8W	
193	1630 2121	Resistor - 120 Ω ±5% 1/8W	
194	1630 2123	Resistor - 12K Ω 1/8W ±5%	
195	1630 2206	Resistor - 20M Ω 1/8W ±5%	
196	1630 2220	Resistor - 22Ω 1/8W ±5%	
197	1630 2222	Resistor - 2.2K Ω 1/8W	
198	1630 2223	Resistor - 22K Ω 1/8W ±5%	
199	1630 2330	Resistor - 33Ω 1/8W ±5%	
200	1630 2334	Resistor - 330K Ω	
201	1630 2472	Resistor - 4.7K Ω 1/8W ±5%	
202	1630 2473	Resistor - 47K Ω 1/8W ±5%	
203	1630 2511	Resistor - 510 Ω 1/8W ±5%	
204	1630 2821	Resistor - 820 Ω 1/8W ±5%	
205	1632 5231	Resistor - 5.23K Ω ±1%	

51. IPU Board (A109)

AR

SYMBOL NO.	INDEX NO.
AR300	151
AR301	151
AR302	151
AR303	153
AR304	153
AR305	152
AR306	152
AR307	152
AR308	152
AR309	151

SYMBOL NO.	INDEX NO.
AR310	151
AR311	151

CAPACITOR

SYMBOL NO.	INDEX NO.
C300	193
C301	193
C302	193
C303	160
C304	194
C305	193
C306	194
C307	193
C308	194
C309	194

SYMBOL NO.	INDEX NO.
C310	193
C311	193
C312	193
C313	164
C314	164
C315	164
C316	164
C317	164
C318	164
C319	165

SYMBOL NO.	INDEX NO.
C320	165
C321	165
C325	164
C326	164
C327	164
C328	164
C329	164
C331	165
C332	165
C333	165

SYMBOL NO.	INDEX NO.
C334	165
C335	165
C342	164
C343	164
C344	164
C345	166
C346	164
C347	164
C348	164
C349	164

SYMBOL NO.	INDEX NO.
C350	166
C351	166
C355	165
C359	164
C360	164
C361	164
C362	165
C363	165
C364	165
C365	165

SYMBOL NO.	INDEX NO.
C369	164
C370	164
C371	164
C372	164
C373	164
C374	165
C375	165
C376	165
C377	165
C378	165

SYMBOL NO.	INDEX NO.
C379	164
C380	165
C381	165
C386	164
C387	164
C388	165
C389	164
C390	165
C392	165
C393	165

SYMBOL NO.	INDEX NO.
C395	165
C396	165
C397	165
C398	161
C399	163
C400	165
C401	165
C402	164
C406	165
C407	164

SYMBOL NO.	INDEX NO.
C408	165
C409	164
C410	165
C411	165
C412	164
C413	164
C414	164
C415	165
C416	164
C417	164

SYMBOL NO.	INDEX NO.
C418	164
C419	164
C420	164
C421	164
C422	164
C423	164
C424	165
C427	165
C428	162
C429	165

SYMBOL NO.	INDEX NO.
C430	165
C431	164
C432	164
C433	164
C434	164
C435	165
C436	165
C437	165
C438	165
C439	165

SYMBOL NO.	INDEX NO.
C440	164
C441	165
C442	165
C443	164
C444	165
C445	165
C446	164
C447	164
C448	164
C449	164

51. IPU Board (A109)

SYMBOL NO.	INDEX NO.
C450	164
C451	165
C452	165
C453	165
C454	165
C455	165
C456	164
C457	165
C458	164
C459	165

SYMBOL NO.	INDEX NO.
C460	164
C461	165
C462	164
C463	164
C464	164
C465	164
C466	165
C467	165
C468	164
C470	165

SYMBOL NO.	INDEX NO.
C471	164
C472	165
C473	165
C474	165
C475	165
C476	165
C477	165
C478	165
C479	165
C480	165

SYMBOL NO.	INDEX NO.
C481	165
C482	164
C483	165
C484	164
C485	162
C486	165
C487	165
C488	165
C489	165
C490	165

SYMBOL NO.	INDEX NO.
C491	165
C492	165
C493	165
C494	165
C495	165
C496	165
C498	161
C499	163
C500	165
C501	165

SYMBOL NO.	INDEX NO.
C502	164
C503	165
C504	165
C505	164
C506	164
C508	164
C509	164
C510	165
C511	165
C512	165

SYMBOL NO.	INDEX NO.
C513	165
C514	165
C515	165
C516	165
C517	165
C518	165
C519	165
C520	165
C521	165
C522	165

SYMBOL NO.	INDEX NO.
C523	165
C524	165
C525	165

CONNECTOR

SYMBOL NO.	INDEX NO.
CN301	101
CN302	106
CN303	100
CN304	105
CN305	103
CN306	102
CN307	104
CN308	107
CN309	103
CN310	108

IC

SYMBOL NO.	INDEX NO.
IC301	2
IC302	2
IC303	10
IC305	6
IC306	133
IC307	7
IC308	2
IC309	11
IC311	134
IC313	2

SYMBOL NO.	INDEX NO.
IC314	135
IC315	1
IC316	133
IC317	133
IC318	133
IC319	133
IC320	133
IC321	133
IC322	8
IC324	156

SYMBOL NO.	INDEX NO.
IC325	5
IC326	134
IC330	3
IC333	3
IC334	132
IC335	132
IC336	132

SYMBOL NO.	INDEX NO.
IC345	4
IC346	134
IC347	133
IC351	133
IC352	134
IC356	137
IC357	137
IC358	113
IC359	137
IC360	129

SYMBOL NO.	INDEX NO.
IC361	137
IC362	115
IC363	137
IC364	121
IC365	137
IC367	143
IC368	114
IC369	136
IC370	142
IC371	142

51. IPU Board (A109)

SYMBOL NO.	INDEX NO.
IC373	144
IC374	143
IC375	144
IC376	131
IC377	114
IC378	142
IC379	123
IC380	136
IC381	131
IC382	125

SYMBOL NO.	INDEX NO.
IC383	131
IC384	136
IC385	139
IC386	147
IC387	140
IC388	138
IC389	127
IC390	128
IC392	136
IC393	136

SYMBOL NO.	INDEX NO.
IC394	136
IC395	136
IC396	124
IC397	137
IC398	137
IC399	124
IC400	137
IC401	118
IC402	118
IC403	118

SYMBOL NO.	INDEX NO.
IC404	127
IC405	126
IC406	120
IC407	143
IC408	141
IC409	143
IC410	143
IC411	121
IC412	120
IC413	141

SYMBOL NO.	INDEX NO.
IC414	116
IC415	130
IC416	142
IC417	119
IC418	148
IC419	117
IC420	119
IC422	124
IC423	122
IC424	195

SYMBOL NO.	INDEX NO.
IC425	195
IC426	134
IC427	133
IC428	134
IC429	12
IC430	12
IC431	12
IC432	9
IC433	134
IC434	134

SYMBOL NO.	INDEX NO.
IC435	133
IC436	133
IC437	133
IC438	133

JP

SYMBOL NO.	INDEX NO.
JP300	182

LED

SYMBOL NO.	INDEX NO.
LED308	112
LED309	112

FIL

SYMBOL NO.	INDEX NO.
FIL300	154
FIL301	154
FIL302	159
FIL303	158
FIL304	158
FIL305	158
FIL306	158
FIL307	158
FIL308	158
FIL309	155

SYMBOL NO.	INDEX NO.
FIL310	154
FIL311	156
FIL312	157
FIL313	157
FIL314	157
FIL315	157
FIL316	157

REG

SYMBOL NO.	INDEX NO.
REG300	145
REG301	146
REG302	146

RESISTOR

SYMBOL NO.	INDEX NO.
R300	177
R301	177
R302	177
R314	177
R315	177
R316	169
R320	169
R321	171
R322	190
R323	190

SYMBOL NO.	INDEX NO.
R324	180
R325	177
R326	175
R327	175
R328	175
R329	175
R330	175
R334	169
R339	169
R348	175

51. IPU Board (A109)

SYMBOL NO.	INDEX NO.
R349	175
R350	175
R351	175
R352	175
R354	176
R355	177
R356	176
R358	175
R359	170
R360	168

SYMBOL NO.	INDEX NO.
R361	169
R362	169
R363	169
R364	177
R365	169
R366	169
R369	190
R370	190
R371	190
R379	169

SYMBOL NO.	INDEX NO.
R380	177
R381	177
R382	177
R386	177
R387	177
R390	169
R391	169
R393	172
R394	188
R395	187

SYMBOL NO.	INDEX NO.
R403	183
R404	184
R405	177
R407	177
R408	174
R410	171
R411	172
R413	180
R414	180
R415	177

SYMBOL NO.	INDEX NO.
R416	177
R421	180
R422	180
R423	180
R425	180
R426	180
R427	180
R429	173
R430	167
R432	169

SYMBOL NO.	INDEX NO.
R433	169
R434	175
R435	175
R436	168
R437	177
R438	175
R439	177
R440	168
R441	168
R447	177

SYMBOL NO.	INDEX NO.
R448	169
R449	169
R450	169
R451	169
R452	169
R453	169
R455	172
R456	191
R457	189
R465	177

SYMBOL NO.	INDEX NO.
R467	181
R468	181
R469	181
R470	181
R471	181
R472	181
R481	178
R482	178
R483	181
R484	181

SYMBOL NO.	INDEX NO.
R485	190
R486	190
R487	190
R488	190
R489	190
R490	190
R491	190
R492	190
R493	190
R494	190

SYMBOL NO.	INDEX NO.
R495	190
R497	192
R498	190
R499	190
R500	180
R501	180
R502	181
R503	181
R510	185
R511	185

SYMBOL NO.	INDEX NO.
R512	181
R513	181
R514	179
R515	172
R516	181
R524	186
R525	181
R526	190
R527	181
R528	181

SYMBOL NO.	INDEX NO.
R529	181
R530	181
R531	181
R532	181
R533	180
R534	180
R535	181
R536	181
R537	181
R538	181

SYMBOL NO.	INDEX NO.
R539	192
R540	180
R541	180
R542	180
R543	180
R544	180
R545	180
R546	180
R547	180
R548	180

SYMBOL NO.	INDEX NO.
R549	180
R550	180
R551	180
R552	180
R553	180
R554	180
R555	180
R556	180
R557	180
R558	180

51. IPU Board (A109)

SYMBOL NO.	INDEX NO.
R559	180
R560	180
R561	180
R562	180
R563	180

SW

SYMBOL NO.	INDEX NO.
SW300	109

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q300	110
Q301	110

XTL

SYMBOL NO.	INDEX NO.
XTL300	149
XTL301	150

ZD

SYMBOL NO.	INDEX NO.
ZD300	111

51. IPU Board (A109)


Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 5519	IPU Board	1
1	A049 5102	IC - TC23SC080AF-501	1
2	A109 5203	IC - 8K8BIT35NS	1
3	A109 5220	IC - RF5GU100-013	4
4	A109 5222	IC - RF5C221	1
5	A109 5224	IC - RF5C158	1
6	A109 5225	IC - RF5GU050-016	1
7	A109 5227	IC - MB87872	1
8	A109 5229	IC - HG62F43S17FH	1
9	A109 5230	IC - MPD65656GD-021-LML	1
10	A109 5528	IC - 128K 8BIT120NS	1
11	A109 5529	IC - 128K 8BIT120NS	1
12	A134 5209	LSI - MSM518222-30JS-1	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	1102 5003	Fiber Connector - Dc1002 - 2p	
101	1102 5310	Connector - 5p	
102	1102 6296	Connector - 3p	
103	1102 6335	Connector - 4p	
104	1102 6339	Connector - 8p	
105	1102 6398	Connector - 2p	
106	1102 6567	Connector - 40p	
107	1102 6570	Connector - Phec60r-r111	
108	1102 7021	Connector - IMSA-9224B-40Z10-GF	
109	1204 2156	Dip Switch - 51D-0501	
110	1401 0992	Transistor - 2SB1335	
111	1402 1172	Zener Diode - Hzm6.8b	
112	1403 0313	Diode - TLR102A	
113	1407 1741	TTL - SN74LS32NS	
114	1407 1792	IC - SN74LS374NS	
115	1407 2051	TTL - IC - SN74LS00NS	
116	1407 2127	TTL - IC74F00SJ	
117	1407 2128	TTL - IC74F02SJ	
118	1407 2137	IC -74F138SJ : TTL	
119	1407 2187	IC - SN74LS07NS	
120	1407 2249	TTL - SN74LS174NS	
121	1407 2409	IC - SN74LS04M	
122	1407 2462	TTL - IC - SN74ALS00ANS	
123	1407 2463	TTL - IC - SN74ALS08NS	
124	1407 2464	TTL - IC - SN74ALS74ANS	
125	1407 2588	TTLIC - SN74ALS04BNS	
126	1407 2816	TTL - SN74ALS374ANS	
127	1407 2817	TTL - SN74ALS32NS	
128	1407 3025	IC - SN74ALS02NS	
129	1407 3348	IC - SN74LS02M	
130	1407 3350	IC - SN74LS74AM	
131	1407 3481	IC - SN74AS32NS	
132	1407 4090	IC - M66250FP	
133	1407 4091	IC - M66251AFP	
134	1407 4092	IC - M66253FP	

Index No.	Part No.	Description	Q'ty Per Assembly
135	1407 4188	IC - HD6415108F10	
136	1407 4192	IC - SN74LS244M	
137	1407 4193	IC - SN74LS157M	
138	1407 4194	IC - SN74LS08M	
139	1407 4195	IC - HD74LS06FP	
140	1407 4196	IC - SN74LS151M	
141	1407 4197	IC - DM74ALS245ASJ	
142	1407 4198	IC - DM74ALS240ASJ	
143	1407 4199	IC - DM74ALS244ASJ	
144	1407 4275	IC - SN74AS240NS	
145	1408 0425	IC - NJM79L05	
146	1408 1011	IC - M5237ML	
147	1408 1029	Operational Amplifier - AD847JR	
148	1408 1033	IC - NJM2103M	
149	1503 0498	Oscillator - 19.6608Mhz	
150	1503 0540	Oscillator - 37.1843Mhz	
151	1601 2957	Resistor - RCE9A472J	
152	1601 4021	Resistor - RCE9A103J	
153	1601 7697	Resistor - RCB8C103J	
154	1602 0918	Filter - 270pf - Emi	
155	1602 7077	Capacitor - 270PF ±10% 50V	
156	1602 7085	Filter - TV50m	
157	1602 7087	Filter - TH18103MA	
158	1602 7092	Filter - MNF51R00P506	
159	1602 7096	Filter - TX14131NB	
160	1604 2587	Capacitor - 100µF ±2%	
161	1605 0283	Capacitor - 1µF	
162	1605 0435	Capacitor - 0.47µF +80% -20% 16V	
163	1606 1136	Capacitor - 1000PF	
164	1606 1139	Capacitor - 0.01µF ±20%	
165	1606 1140	Capacitor - 0.1µF +80%-20%	
166	1606 1477	Capacitor - 330PF	
167	1630 1121	Resistor - 120Ω±5% 1/8W	
168	1630 3102	Resistor - 1KΩ 1/10W ±5%	

Index No.	Part No.	Description	Q'ty Per Assembly
169	1630 3103	Resistor - 10KΩ 1/10W ±5%	
170	1630 3152	Resistor - 1.5kΩ - 1/10W	
171	1630 3153	Resistor - 15K Ω ±5% 1/10W	
172	1630 3221	Resistor - 220 Ω ±5% 1/10W	
173	1630 3222	Resistor - 2.2KΩ 1/10W ±5%	
174	1630 3302	Resistor - 3kΩ - 1/10W	
175	1630 3330	Resistor - 33 Ω ±5% 1/10W	
176	1630 3471	Resistor - 470Ω - 1/10W	
177	1630 3472	Resistor - 4.7KΩ 1/10W ±5%	
178	1630 4100	Resistor - 10 Ω ±5% 1/16W	
179	1630 4103	Resistor - 10KΩ ±5% 1/16W	
180	1630 4330	Resistor - 33Ω±5% 1/8W	
181	1630 4472	Resistor - 4.7KΩ ±5% 1/16W	
182	1633 0000	Resistor - 0Ω ±1% 1/10W	
183	1633 1001	Resistor - 1K Ω ±1% 1/10W	
184	1633 1401	Resistor - 1.4KΩ ±1% 1/8W	
185	1633 1601	Resistor - 1.6KΩ ±1% 1/8W	
186	1633 1801	Resistor - 1.8KΩ ±1% 1/8W	
187	1633 4301	Resistor - 4.3KΩ ±1% 1/8W	
188	1633 5901	Resistor - 5.9K Ω ±1% 1/10W	
189	1633 9311	Resistor - 9.3KΩ ±1% 1/8W	
190	1634 2209	Resistor - 22.0Ω ±1% 1/8W	
191	1634 4301	Resistor - 4.3KΩ ±1% 1/8W	
192	1634 6801	Resistor - 6.8KΩ ±1% 1/8W	
193	1642 0101	Resistor - 1K Ω ±1% 1/10W	
194	1643 2100	Resistor - 1.4K Ω ±1% 1/8W	
195	1902 0010	Resistor - 1.6K Ω ±1% 1/8W	

52. AC Main Harness (A109)



52. AC Main Harness (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A109 5372	AC Main Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1100 0863	Stud Pin	
102	1100 0864	Housing - AWG14-20	
103	1100 1241	Socket - MATE-N-LOCK	
104	1100 1339	Pin Contact	
105	1100 1344	Pin Contact	
106	1100 1669	Connector - 1P	
107	1102 0941	Connector - 4P	
108	1102 0946	Housing - 3P	
109	1102 0947	Housing - 3P	
110	1102 0948	Housing - 4P	
111	1102 1017	Housing - 2P Red	
112	1102 1171	Connector - 5P	
113	1102 1404	Connector - 1P	
114	1102 1517	Connector - 4P	
115	1102 5187	Connector - 14P	
116	1102 6213	Connector - 1P	

53. Decal And Document (A109)

1

****
THERMAL CUT OFF 169°C

2

Do not make copies of anything which is prohibited fro
following items are normally prohibited from copying b
national law.Other items may be prohibited by loca

- Money
- Stamps
- Bonds
- Stocks
- Bank drafts
- Check
-
-


3

- When the Add Toner indicator is on,add toner.
- Add only one bottle of toner at a time


4



6




5




53. Decal And Document (A109)


7



8




10




11

DANGER	NVISIBLE LASER RADIATION WHEN OPEN AVOID DIRECT EXPOSURE TO BEAM
VORSICHT	LASERSTRAHLUNG, WENN ABOECKUNG GEOFFNET.NICHT DEM STRAHL AUSSETZEN


12



9



13




14



15



53. Decal And Document (A109)




53. Decal And Document (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5203 4165	Fusing Thermofuse Decal	2
2	A072 1383	Caution Decal - English	1
3	A092 1393	Decal - Adding Toner	1
4	A096 1300	Decal - Main Switch	1
5	A109 1550	Decal - Adding Toner	1
6	A109 1551	Decal - Misfeed Removal C	1
7	A109 1552	Decal - Misfeed Removal A	1
8	A109 1553	Decal - Misfeed Removal B	1
9	A109 1554	Decal - Misfeed Removal D	1
10	A109 1555	Decal - Total Counter	1
11	AA00 0035	Decal - LD	4
12	AA00 0445	Decal - LD	1
13	AA00 1190	Decal - Ground	1
14	AA00 1213	Decal - B2	1
15	AA00 1281	Decal - Lever	1
16	AA00 0143	Decal - Cover - Paper Tray - No.1	1
17	AA00 0138	Decal - Cover - Paper Tray - No.2	1
18	AA00 0139	Decal - Cover - Paper Tray - No.3	1
19	AA00 2010	Decal - Paper Level	3
20	AA00 2177	Decal - Side Fence - LT	1
21	AA00 2179	Decal - End Fence LT	1
22	AA00 2181	Decal - LT	1
23	AA00 2192	Decal - Paper Size - LT	1
24	AA00 1330	Decal - Misfeed Removal A	1
25	AA00 0537	Decal - High Voltage	1
26	A109 8657	Operating Instructions - English	1


Index No.	Part No.	Description	Q'ty Per Assembly

54. Special Tools (A109)


1




2




3



4




5




6




7




8




9



11



10



54. Special Tools (A109)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5219 9300	MT - 1	1
2	5420 9550	Silicone Oil	1
3	5442 9101	Setting Powder	1
4	A006 9103	Omega Clamp	1
5	A008 9502	Silicone Grease - G40M	1
6	A012 9501	Scanner Positioning Pin - 4pcs/set	1
7	A028 9300	Grease Barrierta JFE 55/2	1
8	A092 9503	C4 Color Test Chart (3pcs/set)	1
9	5205 8730	Counter Set Key	1
10	A109 9001	DJF Fixing Band	1
11	C401 9503	20x Magnification Scope	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

Part No.	Description	Page and Index No.
A109 1031	Front Fixing Plate	109- 15
A109 1032	Rear Fixing Plate	109- 12
A109 1057	Grip Plate	109- 20
A109 1086	Upper Paper Feed Stay	95- 5
A109 1089	Left Upper Tray	105- 13
A109 1092	Right Upper Stay	95- 13
A109 1094	Left Side Stay	107- 12
A109 1096	Left Middle Stay	105- 14
A109 1101	Front Right Frame	95- 3
A109 1102	Front Upper Right Bracket	103- 12
A109 1104	Front Upper Left Frame	103- 6
A109 1105	Front Lower Left Frame	105- 22
A109 1107	Rear Right Frame	95- 18
A109 1109	Frame Bracket - Rear Upper Right	95- 17
A109 1111	Rear Left Frame	105- 11
A109 1113	Frame Bracket - Rear Upper Left	105- 12
A109 1115	Fusing Connector Bracket	97- 22
A109 1119	Rear Support Stay	99- 3
A109 1123	Inner Cooling Fan Bracket	109- 21
A109 1124	Right Bracket - Operation Panel	19- 31
A109 1129	Left Bracket	19- 27
A109 1131	Drum Gear Cover	91- 28
A109 1132	Drum Flange Cover	91- 16
A109 1135	Safety Switch Actuator	15- 28
A109 1136	Flange Bracket	77- 38
A109 1256	Upper Right Cover	13- 21
A109 1265	Right Cover	13- 1
A109 1267	Right Cover Cap	13- 2
A109 1273	Left Cover	13- 6
A109 1276	Left Cover Bracket	13- 7
A109 1277	Left Cover Louver	13- 22
A109 1290	Right Upper Door Hinge	15- 14
A109 1291	Right Lower Door Hinge	15- 15
A109 1306	Left Door Hinge Plate	15- 23
A109 1307	Left Upper Door Hinge	15- 21

Part No.	Description	Page and Index No
A109 1308	Left Lower Door Hinge	15- 25
A109 1309	Transport Lever Stopper	15- 26
A109 1310	Fusing Lever Stopper	15- 29
A109 1311	Left Door Stopper	103- 25
A109 1320	Rear Cover	13- 19
A109 1322	DF Connector Cap	13- 20
A109 1331	Operation Panel Holder	19- 29
A109 1332	Middle Bracket - Operation Panel	19- 30
A109 1366	Magnet Catch Bracket	77- 33
A109 1374	Right Inner Cover	15- 16
A109 1384	Lower Inner Cover	77- 4
A109 1387	Inner Cover - Main Switch	103- 4
A109 1393	Inner Cover - Total Counter	103- 10
A109 1397	Inner Cover - Transfer Unit	77- 35
A109 1455	Key Top - Start	17- 18
A109 1456	Key Top - Clear Modes	17- 19
A109 1457	Key Top - Memory Call	17- 20
A109 1458	Key Top - Color Adjust/memory	17- 21
A109 1459	Key Top - User Color - LT	17- 22
A109 1460	Key Top - White	17- 23
A109 1461	Key Top - Black	17- 24
A109 1462	Key Top - Red	17- 25
A109 1463	Key Top - Magenta	17- 26
A109 1464	Key Top - Blue	17- 27
A109 1465	Key Top - Cyan	17- 28
A109 1466	Key Top - Green	17- 29
A109 1467	Key Top - Light Green	17- 30
A109 1468	Key Top - Yellow	17- 31
A109 1469	Key Top - Orange	17- 32
A109 1472	Key Top - Option	17- 34
A109 1473	Key Top - Area Marker	17- 35
A109 1474	Lens Ass'y	17- 36
A109 1480	Grounding Wire	17- 37
A109 1481	Large Shielding Sheet	17- 38
A109 1482	Small Shielding Sheet	17- 39

Part No.	Description	Page and Index No.
A109 1484	Grounding Plate - LCD	17- 41
A109 1486	Operation Panel Bracket	17- 42
A109 1487	Operation Panel Hook	17- 2
A109 1488	Key Top - Program	17- 33
A109 1550	Decal - Adding Toner	55- 21
A109 1550	Decal - Adding Toner	125- 5
A109 1551	Decal - Misfeed Removal C	55- 22
A109 1551	Decal - Misfeed Removal C	125- 6
A109 1552	Decal - Misfeed Removal A	15- 18
A109 1552	Decal - Misfeed Removal A	125- 7
A109 1553	Decal - Misfeed Removal B	15- 17
A109 1553	Decal - Misfeed Removal B	125- 8
A109 1554	Decal - Misfeed Removal D	15- 27
A109 1554	Decal - Misfeed Removal D	125- 9
A109 1555	Decal - Total Counter	103- 11
A109 1555	Decal - Total Counter	125- 10
A109 1591	Operating Instructions Holder	35- 1
A109 1636	Lens Unit	23- 7
A109 1700	Reflector	21- 16
A109 1707	Reflector Cover	21- 17
A109 1708	Reflector Bracket	21- 19
A109 1711	Rear Terminal Holder	21- 14
A109 1713	Rear Terminal - Exposure Lamp	21- 15
A109 1715	Front Terminal Holder	21- 11
A109 1717	Front Terminal - Exposure Lamp	21- 12
A109 1731	1st Scanner Ass'y	21- 10
A109 1741	2nd Scanner Ass'y	21- 6
A109 1782	CCD Grounding Plate	23- 25
A109 1785	Spacer - 9.5x9.5x72	23- 15
A109 1789	Spring Plate	23- 9
A109 1805	Scanner Control Board Cover	23- 20
A109 1806	Original Sensor Cover	23- 1
A109 1818	Wire Adjuster	25- 8
A109 1831	Scanner Drive Board Bracket	25- 6
A109 1832	Scanner Drive Bracket	19- 17

Part No.	Description	Page and Index No
A109 1833	Upper Cover - Scanner Drive	19- 7
A109 1835	Lower Cover - Scanner Drive	19- 19
A109 1842	Scanner Drive Motor - DC24V	19- 13
A109 1844	Dust Filter Front Guide	25- 14
A109 1845	Dust Filter Rear Guide	25- 17
A109 1853	Scanner Control Board Bracket	23- 10
A109 1854	Scanner Louver	25- 20
A109 1867	Pin Guide	25- 3
A109 1868	Rear Slide Rail	25- 11
A109 1869	Front Slide Rail	25- 4
A109 1879	Scale Bracket	19- 1
A109 1881	H.P Sensor Bracket	25- 27
A109 1882	Original Sensor Bracket	23- 5
A109 1884	Optics Exhaust Bracket	23- 11
A109 1885	Support Plate	25- 28
A109 1886	Right Stay	19- 2
A109 1911	Exposure Glass Ass'y	13- 15
A109 1920	1st Mirror	21- 8
A109 1922	Second Mirror Assy	21- 1
A109 2065	Left Rail	29- 3
A109 2066	Right Rail	29- 2
A109 2069	Mirror - Synchronizing	29- 14
A109 2070	Synchronizing Harness Bracket	29- 21
A109 2072	LD Cooling Fan Bracket	29- 20
A109 2077	Toner Shielding Grass	103- 5
A109 2080	Optics Cooling Fan Duct	27- 13
A109 2128	Diode Bracket	29- 16
A109 2132	Drum Mirror Ass'y	29- 12
A109 2136	Mirror Cover	29- 4
A109 2159	Optical Housing Unit	29- 27
A109 2160	LD Unit	29- 32
A109 2270	Drum Shaft	91- 24
A109 2281	Drum Flange	49- 28
A109 2287	Drum Flange Knob	49- 22
A109 2291	Knob Screw	49- 27

Part No.	Description	Page and Index No.
A109 2300	Charge Corona Receptacle	97- 8
A109 2321	Pre Cleaning Corona Receptacle	97- 26
A109 2351	Spring Plate - Grid	49- 16
A109 2369	Grounding Plate - Pre - Cleaning	49- 3
A109 2371	ID Sensor Stay	49- 25
A109 2380	ID Sensor Duct	91- 25
A109 2381	Quenching Lamp	49- 23
A109 2385	Duct Tube Ass'y	91- 26
A109 2390	Charge Corona Duct - Large	99- 22
A109 2403	Charge Corona Duct - Small	99- 26
A109 2410	Charge Inlet Fan Filter	99- 25
A109 2421	Drum Heater Bracket	107- 18
A109 2426	Drum Potential Sensor Bracket	107- 20
A109 2430	Connector Bracket	109- 3
A109 2571	Registration Guide Plate	47- 27
A109 2574	Relay Guide Plate	47- 29
A109 2575	Lower Guide Plate - Registration	47- 25
A109 2582	Upper Guide Plate - Registration	47- 20
A109 2588	Upper Guide - Registration	47- 19
A109 2589	Large Guide - Registration	47- 21
A109 2594	Registration Sensor Holder	47- 7
A109 2610	Gear Holder	47- 24
A109 2621	Manual Feed Table	45- 17
A109 2627	Arm - Auxiliary - Manual Feed Table	45- 44
A109 2630	Cover - Manual Feed	45- 36
A109 2633	Side Fence - Front	45- 46
A109 2635	Side Fence - Rear	45- 45
A109 2638	Rear Side Fence Rack	45- 38
A109 2642	Paper End Sensor Bracket	45- 8
A109 2652	Separation Roller Shaft - By-pass	45- 25
A109 2653	Pressure Arm - By-pass	45- 5
A109 2661	Arm - Pick Up - Manual Feed	45- 32
A109 2662	Cover - Pick Up	45- 35
A109 2665	Feed Roller Shaft - By-pass	45- 13
A109 2666	Pick-up Arm Holder	45- 31

Part No.	Description	Page and Index No
A109 2670	Housing - Manual Feed	45- 16
A109 2675	Cover - Housing	45- 21
A109 2680	By-pass Pick-up Solenoid	45- 9
A109 2691	Oil Damper - GF.cm	45- 2
A109 2693	By-pass Feed Shaft	45- 3
A109 2696	Latch Bracket - By-pass	95- 25
A109 2697	Front Holder - By-pass Feed Table	95- 7
A109 2701	Sensor Feeler - By-pass Feed Table	95- 28
A109 2703	Sensor Feeler Holder	95- 27
A109 2707	Right Upper Stay	95- 30
A109 2711	Sensor Bracket - Registration Guide	47- 32
A109 2721	Upper Stay Vertical Transport	45- 1
A109 2722	Stay Angle	95- 16
A109 3051	Front Side Plate - B/C	59- 26
A109 3051	Front Side Plate - B/C	61- 11
A109 3054	Rear Side Plate - B/C	59- 11
A109 3054	Rear Side Plate - B/C	61- 18
A109 3059	Development Casing - Black	59- 7
A109 3062	Development Casing - Cyan	61- 20
A109 3064	Black Development Seal-rear	59- 38
A109 3065	Spacer - Toner Density Sensor	59- 4
A109 3065	Spacer - Toner Density Sensor	61- 21
A109 3065	Spacer - Toner Density Sensor	63- 21
A109 3065	Spacer - Toner Density Sensor	65- 26
A109 3066	Mixing Paddle Roller - B/C	59- 9
A109 3066	Mixing Paddle Roller - B/C	61- 17
A109 3067	Mixing Paddle Roller	63- 16
A109 3067	Mixing Paddle Roller	65- 16
A109 3068	Paddle Flange	59- 30
A109 3068	Paddle Flange	61- 26
A109 3068	Paddle Flange	63- 29
A109 3068	Paddle Flange	65- 33
A109 3070	Paddle Flange Stopper	59- 32
A109 3070	Paddle Flange Stopper	61- 6
A109 3070	Paddle Flange Stopper	63- 17

Part No.	Description	Page and Index No.
A109 3070	Paddle Flange Stopper	65- 34
A109 3073	Development Sleeve Ass'y - Black	59- 15
A109 3082	Development Sleeve Cover	59- 19
A109 3082	Development Sleeve Cover	61- 5
A109 3082	Development Sleeve Cover	63- 2
A109 3082	Development Sleeve Cover	65- 2
A109 3085	Positioning Adjuster	59- 24
A109 3085	Positioning Adjuster	61- 7
A109 3085	Positioning Adjuster	63- 5
A109 3085	Positioning Adjuster	65- 5
A109 3086	Development Casing Seal	59- 10
A109 3086	Development Casing Seal	61- 4
A109 3086	Development Casing Seal	63- 4
A109 3086	Development Casing Seal	65- 4
A109 3089	Development Unit Guide - Black	59- 2
A109 3095	Development Unit Cover - B/C	61- 1
A109 3096	Black Development Seal	59- 8
A109 3100	Toner Supply Receptacle	59- 27
A109 3100	Toner Supply Receptacle	61- 23
A109 3100	Toner Supply Receptacle	63- 24
A109 3100	Toner Supply Receptacle	65- 28
A109 3102	Toner Collection Cover	59- 17
A109 3102	Toner Collection Cover	61- 29
A109 3102	Toner Collection Cover	63- 27
A109 3102	Toner Collection Cover	65- 3
A109 3106	Development Support Plate	59- 36
A109 3107	Development Support Shaft	59- 34
A109 3108	Development Support Lever	59- 20
A109 3109	Lock - Spring	59- 35
A109 3111	Spring Plate	59- 37
A109 3112	Development Support Cam	55- 23
A109 3201	Front Side Plate - M/Y	63- 23
A109 3201	Front Side Plate - M/Y	65- 30
A109 3204	Rear Side Plate - M/Y	63- 12
A109 3204	Rear Side Plate - M/Y	65- 12

Part No.	Description	Page and Index No
A109 3209	Development Casing - Magenta	63- 20
A109 3212	Development Casing - Yellow	65- 19
A109 3216	Base Plate - M/Y	65- 24
A109 3219	Development Unit Stopper - M/Y	65- 23
A109 3222	Development Unit Cover - M/Y	65- 25
A109 3226	ID Sensor Rail	65- 20
A109 3301	Development Exhaust Fan Duct	105- 7
A109 3302	Development Exhaust Fan Bracket	105- 3
A109 3303	Shielding Plate - Development Duct	105- 6
A109 3307	Filter Holder	103- 16
A109 3312	Development Bias Terminal - B	97- 21
A109 3313	Development Bias - Terminal - C	97- 20
A109 3314	Development Bias Retminal - M	97- 19
A109 3315	Development Bias - Terminal - Y	97- 16
A109 3322	Development Unit Rail	107- 19
A109 3330	Lower Left Development Cover	105- 15
A109 3332	Development Unit Stopper - B.C	107- 11
A109 3335	Developer Supply Funnel	77- 34
A109 3352	Rear Casing - Toner Tank	57- 15
A109 3355	Front Casing - Toner Tank	57- 8
A109 3380	Toner Vibrating Mylar - Black	57- 19
A109 3381	Toner Vibrating Mylar - Cyan	57- 18
A109 3382	Toner Vibrating Mylar - Magenta	57- 17
A109 3383	Toner Vibrating Mylar - Yellow	57- 16
A109 3390	Toner Supply Cap	57- 23
A109 3393	Spacer - Toner Supply Coil	57- 13
A109 3395	Toner Supply Motor Bracket	55- 17
A109 3401	Toner Bottle Guide - Black	55- 5
A109 3402	Toner Bottle Guide - Magenta	55- 10
A109 3403	Toner Bottle Guide - Yellow	55- 12
A109 3404	Toner Bottle Guide - Cyan	55- 8
A109 3406	Top Cover Bottle - Black	55- 3
A109 3407	Top Cover Bottle - Cyan	55- 7
A109 3408	Top Cover Bottle - Magenta	55- 9
A109 3409	Top Cover Bottle - Yellow	55- 11

Part No.	Description	Page and Index No.
A109 3410	Toner Tank Cover	55- 19
A109 3420	Left Side Plate - Toner Tank	55- 1
A109 3427	Rear Side Plate - Toner Tank	55- 15
A109 3428	Right Side Plate - Toner Tank	55- 13
A109 3437	Latch Bracket - Toner Tank	103- 2
A109 3438	Connector Bracket	107- 13
A109 3440	Left Slide Rail Stay	107- 9
A109 3441	Right Slide Rail Stay	107- 1
A109 3446	Right Stay - Toner Tank	107- 3
A109 3455	Left Stay - Toner Tank	107- 6
A109 3459	Connector Cover - Hopper Harness	107- 7
A109 3460	Toner Hopper Stopper	19- 28
A109 3461	Stopper Lever - Toner Tank	19- 3
A109 3553	Front Side Plate - Drum	53- 6
A109 3556	Seal - 4x5x10	53- 10
A109 3557	Seal - 5x14x14	53- 9
A109 3558	Drum Grounding Plate	53- 7
A109 3560	Rear Side Plate - Drum	53- 27
A109 3565	Seal - 3x4x5	53- 22
A109 3566	Seal - 5x10x14	53- 26
A109 3567	Duct Seal - 3x22x27	53- 28
A109 3569	Charge Corona Housing	53- 4
A109 3570	Lower Louver	53- 1
A109 3571	Middle Louver	53- 2
A109 3572	Upper Louver	53- 3
A109 3573	Guide Rail - Charge Corona	53- 5
A109 3574	Pressure Plate - Cleaning Brush	51- 22
A109 3577	Pressure Spring - Cleaning Brush	51- 23
A109 3579	Right Side Stay - Drum Cleaning	53- 21
A109 3582	Pre-cleaning Corona Rail	53- 24
A109 3584	Cleaning Brush Cover	53- 19
A109 3585	Front Side Seal - Cleaning Brush Cover	53- 17
A109 3586	Rear Seal - Cleaning Brush Cover	53- 18
A109 3589	Cleaning Bracket	53- 15
A109 3593	Seal - 21x323	53- 25

Part No.	Description	Page and Index No
A109 3595	Cleaning Blade Holder	53- 13
A109 3596	Seal - 16x323	53- 12
A109 3597	Stepped Screw - M4	53- 14
A109 3598	Cleaning Blade	53- 11
A109 3598	Cleaning Blade	75- 12
A109 3601	Blade Stopper Lever	51- 21
A109 3603	Cleaning Brush	51- 14
A109 3605	Front Side Holder - Cleaning Brush	51- 13
A109 3610	Rear Side Holder - Cleaning Brush	51- 15
A109 3615	Bushing - Cleaning Brush	51- 12
A109 3615	Bushing - Cleaning Brush	53- 8
A109 3616	Gear - 16Z	51- 17
A109 3616	Gear - 16Z	53- 30
A109 3617	Cleaning Brush Bias Roller	53- 20
A109 3618	Toner Collection Coil	51- 27
A109 3623	Bias Roller Blade	51- 25
A109 3626	Blade Holder - Bias Roller	51- 24
A109 3629	Toner Collection Joint	51- 3
A109 3631	Gear - 18Z/20Z	51- 2
A109 3632	Toner Collection Auger	51- 4
A109 3635	Gear - 18Z	51- 1
A109 3637	Toner Collection Pipe	51- 6
A109 3639	Right Shutter - Toner Collection	51- 9
A109 3641	Left Shutter - Toner Collection	51- 10
A109 3642	Pressure Spring	51- 7
A109 3643	Joint Shutter - Toner Collection	51- 8
A109 3644	Shutter Stopper	51- 11
A109 3645	Toner Collection Tube	51- 5
A109 3646	Gear - 16Z	53- 29
A109 3647	Gear - 16/17Z	53- 23
A109 3648	Spacer - 6x8x14	53- 16
A109 3650	Knob Screw	51- 20
A109 3651	Gear - 20Z	51- 19
A109 3652	Front Drum Flange	51- 18
A109 3653	Rear Drum Flange	51- 26

Part No.	Description	Page and Index No.
A109 3659	Seal - 3x9x9	53- 31
A109 3660	Seal - 3x8x18	53- 32
A109 3661	Cover Bracket - Cleaning Brush	53- 33
A109 3852	Front Lift Arm - Transport	73- 13
A109 3853	Rear Lift Arm - Transport	73- 12
A109 3857	Support Roller - Lift Arm	73- 14
A109 3858	Lift Arm Stay	73- 16
A109 3859	Transport Fan Bracket	73- 11
A109 3871	Front Right Positioning Plate	109- 6
A109 3872	Front Left Positioning Plate	109- 5
A109 3873	Rear Right Positioning Plate	109- 11
A109 3874	Rear Left Positioning Plate	109- 8
A109 4063	Upper Pressure Lever	85- 19
A109 4064	Lower Pressure Lever	85- 22
A109 4072	Pressure Roller Lamp Holder	83- 7
A109 4100	Front Side Plate - Fusing	85- 13
A109 4107	Fusing Lamp Holder - Front	83- 6
A109 4110	Oil Supply Stopper	83- 5
A109 4130	Rear Side Plate - Fusing	85- 23
A109 4137	Fusing Lamp Holder - Rear	83- 22
A109 4141	Fusing Harness Bracket	83- 15
A109 4153	Oil Guide	83- 4
A109 4159	Upper Fusing Rail	85- 7
A109 4161	Spring Plate - Oil Supply Pad	81- 13
A109 4162	Oil Supply Bracket	81- 15
A109 4167	Lower Entrance Guide Plate	81- 21
A109 4169	Oil Pan	85- 11
A109 4180	Right Lower Stay - Fusing	85- 10
A109 4182	Left Lower Stay - Fusing	83- 3
A109 4190	Cleaning Roller Bracket	85- 3
A109 4192	Blade Bracket	85- 1
A109 4194	Cleaning Roller Scraper	85- 2
A109 4201	Hot Roller Stripper Bracket	79- 7
A109 4204	Slider - Hot Roller Stripper	79- 5
A109 4205	Paper Exit Frame	79- 29

Part No.	Description	Page and Index No
A109 4207	Exit Roller Guide	79- 8
A109 4208	Upper Exit Guide Plate	79- 4
A109 4209	Lower Exit Guide Plate	79- 34
A109 4210	Exit Sensor Bracket	79- 24
A109 4212	Exit Roller Holder	79- 11
A109 4213	Exit Roller Front Guide	79- 35
A109 4215	Exit Sensor Feeler	79- 27
A109 4217	Cover - Exit	79- 1
A109 4230	Oil Supply Bracket	81- 3
A109 4250	Front Fusing Cover	79- 19
A109 4251	Upper Fusing Cover	79- 20
A109 4253	Fusing Cover - Right	79- 21
A109 4270	Fusing Unit Rail	105- 17
A109 4271	Heat Insulating Plate	105- 24
A109 4273	Fusing Unit Stopper	105- 23
A109 4274	Copy Tray Holder	109- 2
A109 4300	Copy Tray	13- 11
A109 4621	Lubricant Motor Bracket	87- 7
A109 4627	Clutch Holder Bracket	87- 25
A109 4628	Clutch Holder	87- 23
A109 4630	Joint - Clutch	87- 21
A109 4642	Clutch Bracket - Lubricant Brush	87- 15
A109 4650	Fly-wheel Support Plate	91- 29
A109 4651	Fly Wheel - 195	89- 14
A109 4652	Fly Wheel - 190	89- 13
A109 4653	Drum Shaft Holder	91- 23
A109 4655	Drum Shaft Terminal	91- 22
A109 4656	Drum Motor	89- 15
A109 4670	Motor Cushion	91- 7
A109 4671	Transfer Belt Motor Bracket	91- 8
A109 4673	Pulley Cover	91- 18
A109 4674	Front Joint - Transfer Belt	91- 1
A109 4675	Rear Joint - Transfer Belt	91- 2
A109 4676	Belt Tightner	91- 10
A109 4679	Transfer Belt Drive Shaft	91- 4

Part No.	Description	Page and Index No.
A109 4692	Transport Motor Bracket	93- 15
A109 4694	Fusing Drive Gear Bracket	93- 24
A109 4695	Idle Gear Bracket - Front	93- 19
A109 4697	Idle Gear Bracket - Rear	93- 17
A109 4712	Belt Tightner	93- 10
A109 4714	Position Sensor Bracket	47- 40
A109 4723	Support Plate	89- 4
A109 4725	Sleeve Motor Bracket	89- 5
A109 4727	Collar - 10x17x18mm	89- 23
A109 4742	Drum Drive Motor Bracket	89- 20
A109 4752	Drive Motor Bracket	87- 33
A109 4771	Gear Release Arm	109- 7
A109 4772	Arm Bracket - Gear Release	109- 14
A109 4773	Wire Holder - Gear Release	109- 17
A109 4774	Gear Release Wire	109- 16
A109 4775	Stepped Screw - M5	13- 12
A109 4775	Stepped Screw - M5	109- 13
A109 4776	Hinge Support Plate	15- 24
A109 4812	Tightener	87- 9
A109 4910	Lower Left Hinge	109- 18
A109 5101	Main Control Board	99- 8
A109 5101	Main Control Board	113- *
A109 5104	IC - 4MX8150SN	99- 28
A109 5104	IC - 4MX8150SN	113- 2
A109 5106	IC - 4MX8120SN	99- 4
A109 5106	IC - 4MX8120SN	113- 3
A109 5111	Interface Board 1	95- 23
A109 5119	Interface Board 2	99- 10
A109 5145	IC - uPD78P312ACW	23- 22
A109 5146	IC - 512KX8120NS	23- 21
A109 5151	Scanner Motor Drive Board	25- 29
A109 5155	IC - MB7111LM	95- 34
A109 5156	IC - MB7111LM	95- 33
A109 5171	Laser Synchronizing Detector Board	29- 18
A109 5182	Transfer Belt Drive Board	95- 19

Part No.	Description	Page and Index No
A109 5184	IC - UPD78P312ACW	95- 11
A109 5192	ID Sensor Board	49- 24
A109 5196	Humidity Sensor	35- 22
A109 5203	IC - 8K8BIT35NS	119- 2
A109 5220	IC - RF5GU100-013	119- 3
A109 5222	IC - RF5C221	119- 4
A109 5224	IC - RF5C158	119- 5
A109 5225	IC - RF5GU050-016	119- 6
A109 5227	IC - MB87872	119- 7
A109 5229	IC - HG62F43S17FH	119- 8
A109 5230	IC - MPD65656GD-021-LML	119- 9
A109 5234	Display Editor Interface Board	99- 18
A109 5236	IPU Interface Board	27- 8
A109 5291	Scanner Control Board	23- 13
A109 5301	Front DC Harness	95- 24
A109 5302	Rear Upper DC Harness	97- 1
A109 5303	Rear Lower DC Harness	97- 13
A109 5304	Fusing Unit Harness	83- 21
A109 5305	Development Unit Harness	59- 12
A109 5305	Development Unit Harness	63- 13
A109 5306	Toner Tank Unit Harness	55- 2
A109 5307	Toner Tank Relay Harness - 1	107- 5
A109 5308	Toner Tank Relay Harness - 2	107- 14
A109 5309	IPU Board Relay Harness - 120V	27- 32
A109 5310	Relay Harness - Transport Fan	73- 7
A109 5310	Relay Harness - Transport Fan	109- 9
A109 5311	Sensor Relay Harness	47- 34
A109 5312	Relay Harness - Polygon Motor	29- 31
A109 5312	Relay Harness - Polygon Motor	95- 14
A109 5313	Relay Harness - Transport Sensor	105- 20
A109 5313	Relay Harness - Transport Sensor	109- 10
A109 5314	Relay Harness - Transport Unit	97- 17
A109 5315	Relay Harness - Brush Motor	95- 22
A109 5316	Relay Harness - Development Motor	87- 30
A109 5317	Key Counter Relay Harness	95- 32

Part No.	Description	Page and Index No.
A109 5318	Erase Lamp Relay Harness	97- 5
A109 5319	Separation Corona Cable	105- 5
A109 5320	Development Relay Harness - 1	97- 3
A109 5321	Development Relay Harness - 2	97- 18
A109 5322	By-pass Feed Harness - 1	45- 12
A109 5323	By-pass Feed Harness - 2	45- 43
A109 5324	Exit Unit Relay Harness	79- 22
A109 5324	Exit Unit Relay Harness	83- 1
A109 5326	IPU Harness	27- 33
A109 5327	Relay Harness - Oil End Sensor	81- 22
A109 5328	Solenoid Relay Harness	107- 29
A109 5329	Polygon Motor Relay Harness	95- 20
A109 5330	AC Power Pack Relay Harness	95- 21
A109 5331	Editor Relay Harness - 120V	99- 30
A109 5332	LD Unit Harness	29- 23
A109 5333	Synchronizing Detector Harness	29- 22
A109 5335	CCD Harness - 1	23- 18
A109 5336	CCD Harness - 2	23- 17
A109 5338	IPU Harness	23- 23
A109 5338	IPU Harness	27- 30
A109 5340	Scanner DC Harness	25- 21
A109 5341	Scanner Interface Harness	23- 16
A109 5341	Scanner Interface Harness	25- 13
A109 5342	Scanner Drive Harness	25- 25
A109 5344	Ccd Harness 3 - Exp	23- 19
A109 5355	Relay Harness - Paper Tray Unit	101- 3
A109 5361	By-pass Feed Harness - 3	45- 18
A109 5362	Humidity Sensor Harness	35- 23
A109 5365	Harness - Paper Feed Door Switch	39- 28
A109 5370	Operation Panel Relay Harness	25- 10
A109 5372	AC Main Harness - 120V	97- 23
A109 5372	AC Main Harness	121- *
A109 5373	Front AC Harness	27- 14
A109 5376	Scanner AC Harness	25- 5
A109 5377	Exposure Lamp Relay Harness	21- 20

Part No.	Description	Page and Index No
A109 5378	Exposure Lamp Harness - 120V	21- 7
A109 5378	Exposure Lamp Harness - 120V	23- 14
A109 5386	Transfer Belt Heater Hanrness	97- 7
A109 5390	Drum Bias Cable	91- 21
A109 5391	High Voltage Harness	95- 10
A109 5401	Toner Supply Motor	55- 16
A109 5405	Pressure Roller Thermistor	83- 2
A109 5406	Fusing Thermofuse - 150°C 15A	81- 14
A109 5408	Pressure Roller Thermofuse - 150°C 15A	81- 16
A109 5471	AC Drive Board - 100/115V	27- 15
A109 5519	IPU Board	27- 7
A109 5519	IPU Board	119- *
A109 5526	By-pass Feed Table Sensor - 115V	45- 40
A109 5528	IC - 128K 8BIT120NS	27- 28
A109 5528	IC - 128K 8BIT120NS	119- 10
A109 5529	IC - 128K 8BIT120NS	27- 29
A109 5529	IC - 128K 8BIT120NS	119- 11
A109 5553	Operation Panel Board - LT	17- 1
A109 5557	IC - AM27C4096 - 150DC (English - LT)	13- 26
A109 5557	IC - AM27C4096 - 150DC (English - LT)	17- 7
A109 5558	IC - AM27C4096 - 150DC (English - LT)	13- 25
A109 5558	IC - AM27C4096 - 150DC (English - LT)	17- 4
A109 5559	IC - AM27C4096 - 150DC (English - LT)	13- 24
A109 5559	IC - AM27C4096 - 150DC (English - LT)	17- 5
A109 5560	IC - AM27C4096 - 150DC (English - LT)	13- 23
A109 5560	IC - AM27C4096 - 150DC (English - LT)	17- 6
A109 5701	IPU Unit Base	27- 4
A109 5705	IPU Cooling Fan Louver	27- 5
A109 5707	IPU Board Cover	27- 6
A109 5711	IPU Unit Position Plate	25- 22
A109 5718	IPU Lower Harness Cover	29- 24
A109 5719	IPU Upper Harness Cover	29- 25
A109 5720	Seal - 9.5x9.5x125	27- 21
A109 5721	Seal - 9.5x9.5x66	27- 24
A109 5722	Front Guide Plate - IPU	27- 1

Part No.	Description	Page and Index No.
A109 5723	Rear Guide Plate - IPU	27- 3
A109 5724	IPU Fixing Bracket	27- 2
A109 5726	Scanner Stopper Rod	103- 1
A109 5729	IPU Cooling Fan Bracket	27- 25
A109 5730	Polygon Motor Fan Bracket	27- 27
A109 5731	IPU Cover Seal	27- 9
A109 5741	Main Control Board Bracket	99- 6
A109 5742	Editor Interface Board Bracket	99- 19
A109 5745	AC Drive Board Bracket	27- 19
A109 5747	Interface Board 1 Bracket	95- 15
A109 5751	Main Control Board Hinge	93- 2
A109 5755	Front Holder - Interface 1	95- 8
A109 5756	Front Holder - AC Drive	109- 1
A109 5758	Rear Holder - Interface 1	95- 12
A109 5760	Support Bracket - C	99- 20
A109 5761	Support Bracket - T	99- 1
A109 5762	Support Bracket - E	87- 4
A109 5765	Board Bracket - B	99- 13
A109 5771	Fusing Exhaust Fan Bracket	99- 15
A109 5781	Total Counter Bracket	103- 7
A109 5782	Counter Bracket Hinge	103- 13
A109 5786	Safety Switch Lever	103- 17
A109 5789	Safety Switch Bracket	103- 21
A109 5792	Safety Switch Link	103- 19
A109 5794	Safety Switch Holder	103- 24
A109 5798	Harness Clamp Plate	97- 9
A109 6000	Transfer Belt Unit	69- *
A109 6055	Front Side Plate - Transfer	67- 6
A109 6058	Rear Side Plate - Transfer	67- 16
A109 6060	Transfer Unit Stay	67- 13
A109 6063	Belt Drive Roller	67- 14
A109 6069	Belt Cleaning Roller	67- 5
A109 6082	Transfer Roller Joint	67- 18
A109 6087	Spring Holder Cover - Transfer	67- 10
A109 6089	Spring Holder - Transfer	67- 12

Part No.	Description	Page and Index No
A109 6091	Transfer Unit Frame	69- 15
A109 6096	Cam Shaft	69- 10
A109 6097	Release Cam	47- 16
A109 6097	Release Cam	69- 11
A109 6098	Tention Cam	69- 12
A109 6099	Cam Lever	69- 17
A109 6101	Bias Roller Bracket	69- 6
A109 6105	Belt Bias Roller	69- 1
A109 6110	Transfer Idle Roller	69- 2
A109 6117	Base - Spring	69- 24
A109 6118	Belt Tension Roller	69- 22
A109 6121	Tension Roller Bracket	69- 16
A109 6122	Tension Support Roller Holder	69- 19
A109 6124	Transfer Unit Grip Plate	67- 3
A109 6126	Transfer Unit Position Shaft	67- 8
A109 6130	Transfer Belt	67- 15
A109 6131	Transfer Unit Rail	107- 22
A109 6140	Transfer Unit Cover Plate	77- 14
A109 6150	Positioning Screw	91- 30
A109 6155	Cleaning Roller Front Bracket	67- 20
A109 6156	Cleaning Roller Rear Bracket	67- 21
A109 6157	Belt Support Roller	67- 22
A109 6200	Transfer Roller	71- 7
A109 6222	Transfer Roller Blade Bracket	71- 9
A109 6235	Lower Guide Plate - Transfer	71- 14
A109 6243	Entrance Seal Ass'y - Transfer	71- 3
A109 6247	Transfer Guide Plate Knob	71- 6
A109 6248	Upper Guide Plate - Transfer	71- 5
A109 6251	Paper Discharge Plate	71- 2
A109 6256	Paper Discharge Support Plate	71- 1
A109 6258	Roller	71- 17
A109 6260	Toner Catch Pan	71- 20
A109 6270	Right Positioning Plate	71- 19
A109 6284	Heat Sink	47- 41
A109 6285	Transfer Cam Positioning Plate	47- 14

Part No.	Description	Page and Index No.
A109 6286	Paper Transfer Unit Rail	47- 17
A109 6298	Sensor Feeler - Transfer Roller	47- 38
A109 6303	Blade Holder	75- 19
A109 6305	Front Side Plate - Belt Cleaning	75- 7
A109 6309	Front - Seal - 10x20	75- 8
A109 6310	Toner Collection Cap	75- 2
A109 6311	Toner Collection Spring	75- 3
A109 6314	Rear Side Plate - Belt Cleaning	75- 28
A109 6316	Rear Seal - 10x30	75- 29
A109 6317	Toner Collection Auger	75- 21
A109 6335	Seal - 8x327	77- 5
A109 6336	Belt Cleaning Casing	75- 14
A109 6338	Cleaning Blade Lever	75- 9
A109 6342	Cleaning Blade Roller	75- 10
A109 6344	Cleaning Blade Solenoid	75- 6
A109 6349	Cleaning Blade Spring	75- 13
A109 6350	Cleaning Blade Lever Spring	75- 11
A109 6351	Spring Stopper Seal	75- 15
A109 6352	Entrance Seal Spring	75- 25
A109 6354	Cleaning Entrance Seal Solenoid	75- 4
A109 6360	Release Spring	75- 30
A109 6364	Cleaning Blade Bracket	75- 26
A109 6367	Front Holder - Entrance Seal	75- 1
A109 6369	Entrance Seal Collar	75- 24
A109 6370	Entrance Seal Bracket	75- 22
A109 6372	Entrance Seal Bracket Sheet	75- 23
A109 6373	Base Plate - Belt Cleaning	75- 32
A109 6375	Base Plate Bracket	75- 33
A109 6377	Front Side Plate Cushion	75- 31
A109 6401	Lubricant Brush Roller Stay	107- 23
A109 6403	Solenoid Bracket	107- 8
A109 6406	Lubricant Brush Solenoid	107- 26
A109 6414	Roller	107- 24
A109 6415	Lever Spring	107- 25
A109 6416	Release Spring	107- 27

Part No.	Description	Page and Index No
A109 6418	Brush Roller Holder	77- 6
A109 6422	Lubricant Brush	77- 10
A109 6424	Shaft Roller	77- 9
A109 6425	Brush Roller Spacer	77- 8
A109 6426	Front Holder	77- 12
A109 6427	Release Spring	77- 13
A109 6430	Lubricant Bar	77- 7
A109 6435	Grounding Plate	77- 37
A109 6502	Drive Gear Bracket	47- 3
A109 6523	Lower Collection Joint	77- 16
A109 6531	Lower Collection Coil	77- 24
A109 6541	Joint Fixing Band	77- 15
A109 6543	Toner Collection Duct	77- 21
A109 6544	Collection Pipe - Transfer Belt	77- 22
A109 6545	Collection Pipe Support Plate	77- 19
A109 6546	Seal - 12mm	77- 20
A109 6547	Seal - 18mm	77- 17
A109 6548	Small Duct Upper Seal	77- 18
A109 6551	Joint Duct - Collection Bottle	77- 25
A109 6555	Lower Collection Tube	77- 23
A109 6561	Toner Collection Duct	77- 28
A109 6563	Upper Seal - 3x10x36	77- 30
A109 6564	Lower Seal - 8x13x7	77- 29
A109 7001	Top Cover	13- 5
A109 7042	Rear Lower Cover	35- 7
A109 7065	Operation Panel Ass'y - LT	13- 3
A109 7065	Operation Panel Ass'y - LT	17- *
A109 7347	Cap Left Cover	35- 3
A109 7362	Right Door	15- 13
A109 7526	Left Door	15- 19
A109 7702	Fusing Unit - 115V	79- *
A109 7702	Fusing Unit - 115V	81- *
A109 7702	Fusing Unit - 115V	83- *
A109 7702	Fusing Unit - 115V	85- *
A109 7821	Rear Scale - LT	13- 17

Part No.	Description	Page and Index No.
A109 8657	Operating Instructions - English	125- 26
A109 9001	DJF Fixing Band	127- 10
A109 9501	Drum Cleaning Entrance Seal	53- 34
A109 9502	Seal - Cleaning Blade	75- 17
A109 9503	Entrance Seal - Belt Cleaning	75- 27
A109 9504	Entrance Seal - Belt Cleaning Unit	75- 18

Part No.	Description	Page and Index No
AA00 0035	Decal - LD	125- 11
AA00 0134	Dacal - Universal Tray	31- 4
AA00 0138	Decal - Cover - Paper Tray - No.2	33- 2
AA00 0138	Decal - Cover - Paper Tray - No.2	125- 17
AA00 0139	Decal - Cover - Paper Tray - No.3	33- 2
AA00 0139	Decal - Cover - Paper Tray - No.3	125- 18
AA00 0143	Decal - Cover - Paper Tray - No.1	31- 2
AA00 0143	Decal - Cover - Paper Tray - No.1	125- 16
AA00 0339	Decal - Silicone Oil	79- 31
AA00 0445	Decal - LD	125- 12
AA00 0537	Decal - High Voltage	73- 2
AA00 0537	Decal - High Voltage	125- 25
AA00 1190	Decal - Ground	101- 16
AA00 1190	Decal - Ground	125- 13
AA00 1213	Decal - B2	125- 14
AA00 1281	Decal - Lever	125- 15
AA00 1330	Decal - Misfeed Removal A	39- 42
AA00 1330	Decal - Misfeed Removal A	125- 24
AA00 2010	Decal - Paper Level	31- 21
AA00 2010	Decal - Paper Level	33- 11
AA00 2010	Decal - Paper Level	125- 19
AA00 2177	Decal - Side Fence - LT	31- 3
AA00 2177	Decal - Side Fence - LT	125- 20
AA00 2179	Decal - End Fence LT	31- 10
AA00 2179	Decal - End Fence LT	125- 21
AA00 2181	Decal - LT	31- 25
AA00 2181	Decal - LT	125- 22
AA00 2192	Decal - Paper Size - LT	45- 42
AA00 2192	Decal - Paper Size - LT	125- 23
AA01 0080	Development Ozone Filter	103- 14
AA01 0081	Fusing Exhaust Ozone Filter	99- 16
AA01 1039	Correction Filter	23- 8
AA01 2066	Optics Cooling Fan Filter	25- 16
AA01 2068	Inner Cooling Fan Filter	77- 36
AA01 2069	Development Exhaust Fan Filter	105- 1

Part No.	Description	Page and Index No.
AA01 2070	Development Duct Lower Filter	105- 9
AA01 2084	Development Filter	103- 15
AA02 0018	Magnet	71- 13
AA03 1008	Oil Tank	81- 10
AA03 6007	Oil Tank Cap	81- 9
AA03 6013	Toner Collection Cap	35- 11
AA04 0023	Transfer Belt	73- 6
AA04 3234	Timing Belt - 200 TN15 10.0	91- 17
AA04 3239	Timing Belt - P3M6 486mm	37- 24
AA04 3360	Timing Belt - 200	19- 9
AA04 3408	Timing Belt - 453 - S3MV	87- 28
AA04 3409	Timing Belt - 600 - S3MV	93- 13
AA04 3410	Timing Belt - 699 - S3MV	87- 13
AA05 0079	Scanner Drive Wire - Front Left	19- 25
AA05 0080	Scanner Drive Wire - Rear Left	19- 23
AA05 0081	Scanner Drive Wire - Front Right	19- 21
AA05 0082	Scanner Drive Wier - Rear Right	19- 18
AA05 1019	Wire Stopper	19- 20
AA06 0064	Tension Spring	87- 32
AA06 0083	Tension Wire Spring	19- 24
AA06 0189	Spring - Stripper Pawl Plate	79- 6
AA06 0244	Spring	105- 25
AA06 0308	Spring	103- 23
AA06 0340	Spring - Thermistor	81- 19
AA06 0520	Lever Spring - 24.4mm	43- 19
AA06 0522	Stopper Spring	41- 13
AA06 0523	Pick-up Pressure Sping	41- 10
AA06 0534	Tray Lock Spring - 19mm	39- 4
AA06 0559	Release Spring	93- 11
AA06 0560	Release Spring	37- 18
AA06 2267	Spring	73- 20
AA06 2268	Spring	73- 19
AA06 2271	Release Spring	45- 11
AA06 2272	Release Spring	45- 4
AA06 2275	Release Spring	83- 14

Part No.	Description	Page and Index No
AA06 2283	Spring	45- 6
AA06 2288	Spring - Toner End Lever	47- 26
AA06 3026	Terminal - Spring	97- 25
AA06 3068	Spring Connector	97- 15
AA06 3068	Spring Connector	107- 15
AA06 3097	Spring - Fusing Drive	83- 19
AA06 3353	Pressure Spring	71- 15
AA06 3355	Pressure Spring	85- 21
AA06 3356	Pressure Spring	89- 8
AA06 3357	Pressure Spring	89- 6
AA06 3358	Pressure Spring	87- 22
AA06 3359	Pressure Spring	91- 3
AA06 3361	Spring	57- 22
AA06 3363	Spring	57- 12
AA06 3487	Spring - 10mm	39- 25
AA06 3487	Spring - 10mm	43- 17
AA06 3491	Pressure Spring	69- 21
AA06 3492	Spring	35- 9
AA06 3493	Pressure Spring	67- 11
AA06 6062	Spring - Front Release Lever	79- 32
AA06 6063	Spring - Rear Release Lever	79- 15
AA06 6079	Spring - Oil Pump Lever	81- 5
AA06 6189	Feed Sensor Spring	43- 22
AA06 6226	Spring	79- 26
AA06 6227	Receptacle Spring	97- 24
AA06 6231	Receptacle Spring	91- 15
AA06 6233	Stopper Spring	19- 33
AA06 6551	Stopper Spring - 22mm	31- 7
AA06 6553	Spring - Pressure Release - Reverse	43- 13
AA07 0022	Slide Rail	107- 2
AA08 0037	Bushing - 6 mm	47- 8
AA08 0156	Bushing - M4	39- 24
AA08 0156	Bushing - M4	43- 15
AA08 0162	Bushing - 8mm	71- 10
AA08 0163	Bushing - 8mm	71- 16

Part No.	Description	Page and Index No.
AA08 0166	Bushing - 8mm	47- 43
AA08 1003	Bushing - 5x7x3.8mm	69- 14
AA08 2021	Bushing - 8x12x10mm	47- 13
AA08 2046	Bushing - 6x12x6	43- 8
AA08 2058	Bushing - 6x10x9mm	47- 44
AA08 2070	Bushing - 8x16x7	41- 17
AA08 3003	Bushing - 6x18x5mm	45- 14
AA08 4044	Bearing Holder	69- 20
AA08 4045	Bearing Holder	69- 3
AA11 1020	Sensor Feeler	79- 28
AA13 2025	Spacer - 1x8x12	81- 4
AA13 2094	Spacer - Mounting Arm	85- 18
AA13 2094	Spacer - Mounting Arm	89- 24
AA13 2129	Spacer - 8x12x4.5	87- 8
AA13 2133	Spacer	89- 22
AA13 2166	Roller	69- 8
AA13 2167	Spacer	67- 17
AA13 2172	Spacer	69- 4
AA13 2178	Spacer - Drum Potential Sensor	107- 28
AA14 0065	Stepped Screw - M3x6	13- 18
AA14 0498	Feed Roller Shaft	41- 11
AA14 0510	Drive Shaft	57- 10
AA14 0512	Drive Shaft	83- 13
AA14 0515	Drive Shaft	89- 11
AA14 0517	Drive Shaft	73- 15
AA14 0518	Drive Shaft	73- 18
AA14 0522	Drive Shaft	45- 23
AA14 0526	Drive Shaft	19- 8
AA14 1081	Support Stay	69- 9
AA14 1082	Support Stay	69- 18
AA14 3025	Stepped Screw - M3	21- 18
AA14 3025	Stepped Screw - M3	21-105
AA14 3074	Stepped Screw - M4x5	39- 19
AA14 3074	Stepped Screw - M4x5	45- 20
AA14 3285	Shoulder Screw - M4	61- 8

Part No.	Description	Page and Index No
AA14 3285	Shoulder Screw - M4	63- 9
AA14 3285	Shoulder Screw - M4	65- 17
AA14 3301	Stepped Screw - M3x4	97- 2
AA14 3301	Stepped Screw - M3x4	107- 4
AA14 3358	Stepped Screw - M4x3	59- 33
AA14 3358	Stepped Screw - M4x3	65- 22
AA14 3358	Stepped Screw - M4x3	107- 10
AA14 3418	Positioning Pin	63- 26
AA14 3419	Support Stud	25- 24
AA14 3431	Stepped Screw - M4	19- 32
AA14 3707	Stepped Screw - M5	85- 17
AA14 3708	Stepped Screw - M4	91- 12
AA14 3708	Stepped Screw - M4	97- 10
AA14 3709	Stepped Screw - M4	67- 4
AA14 3733	Stepped Screw M4	75- 16
AA14 3733	Stepped Screw M4	105- 26
AA14 5180	Pin - Hinge	15- 22
AA14 5216	Pin - 6x54.9	71- 18
AA14 5217	Cam Shaft	47- 15
AA14 5219	Drive Shaft	87- 17
AA14 5220	Drive Shaft	93- 22
AA14 5223	Drive Shaft	37- 11
AA14 5224	Drive Shaft	37- 17
AA14 5248	Clutch Shaft	87- 24
AA14 5525	Pin - 4x66.2	103- 18
AA14 5526	Pin - 5x63	103- 20
AA14 7674	Pin - 6x12.7	39- 40
AA14 8391	Pin - 4x36	69- 7
AA14 8402	Drive Shaft	47- 4
AA14 8403	Shaft	37- 2
AA15 0266	Seal - 0.1x29x100	19- 26
AA15 0343	Toner Entrance Seal	57- 20
AA15 0345	Seal - 19.5x170	65- 21
AA15 0347	Shielding Sheet - 21.5x41	29- 15
AA15 0351	Sheet - 25x57	55- 18

Part No.	Description	Page and Index No.
AA15 0351	Sheet - 25x57	57- 5
AA15 0360	Seal - 13x20	49- 26
AA15 1779	Seal - 99x105.5	105- 2
AA15 1804	Lever Cushion	31- 11
AA15 1804	Lever Cushion	33- 12
AA15 1805	Bottom Plate Cushion	31- 13
AA15 1805	Bottom Plate Cushion	33- 18
AA15 1821	Seal - 5.5x356	71- 4
AA15 1822	Seal - 3x4x47	71- 21
AA15 1827	Seal - 12x12x97	105- 8
AA15 1828	Seal - 12x12x304	105- 10
AA15 1829	Seal - 72	55- 6
AA15 1840	Duct Seal - 2x5x34.5	99- 24
AA15 1841	Duct Seal - 2x5x84.5	99- 23
AA15 1842	Seal - 1x5x55.5	59- 14
AA15 1842	Seal - 1x5x55.5	61- 15
AA15 1842	Seal - 1x5x55.5	63- 14
AA15 1842	Seal - 1x5x55.5	65- 13
AA15 1843	Seal - 4x7x59.5	61- 14
AA15 1845	Seal - 4x8x333.5	61- 2
AA15 1846	Seal - 2x27x36	59- 28
AA15 1846	Seal - 2x27x36	61- 24
AA15 1846	Seal - 2x27x36	63- 25
AA15 1846	Seal - 2x27x36	65- 29
AA15 1847	Seal - 4x47	59- 29
AA15 1847	Seal - 4x47	61- 25
AA15 1847	Seal - 4x47	63- 28
AA15 1847	Seal - 4x47	65- 32
AA15 1849	Seal - 5x8x342	59- 3
AA15 1849	Seal - 5x8x342	61- 19
AA15 1849	Seal - 5x8x342	63- 18
AA15 1849	Seal - 5x8x342	65- 18
AA15 1851	Mirror Seal 1	29- 10
AA15 1852	Mirror Seal 2	29- 6
AA15 1853	Mirror Seal 3	29- 8

Part No.	Description	Page and Index No
AA15 1854	Mirror Seal 4	29- 7
AA15 1855	Mirror Seal 5	29- 5
AA15 1856	Mirror Seal 6	29- 9
AA15 1858	Seal - 5x18x40	29- 17
AA15 1860	Seal - 2x5.5x347.8	71- 22
AA15 1866	Seal - 3x7x30	27- 11
AA15 1867	Seal - 3x7x23.5	27- 12
AA15 1868	Seal - 3x7x64	27- 22
AA15 1869	Seal - 3x7x17.3	27- 23
AA15 1870	Seal - 3x20x76	27- 31
AA15 1875	Seal - 20x40	55- 4
AA15 2061	O-ring 83	29- 35
AA15 2094	Seal - 22x38x2	29- 1
AA15 2232	Packing - 18	57- 25
AA15 2233	Gasket - 10x36	83- 10
AA15 2234	Seal - 6x10x11	95- 29
AA15 2319	Seal - 16x36	59- 22
AA15 2319	Seal - 16x36	61- 9
AA15 2319	Seal - 16x36	63- 7
AA15 2319	Seal - 16x36	65- 7
AA15 2320	Seal - 16x36	59- 18
AA15 2320	Seal - 16x36	61- 12
AA15 2320	Seal - 16x36	63- 10
AA15 2320	Seal - 16x36	65- 10
AA16 1097	Cushion - 6.5x14	67- 9
AA16 1100	Stopper Cushion - 5.4x8.5x18	19- 11
AA16 2053	Platen Cover Pad	15- 3
AA17 4018	Sheet - 45x45	95- 6
AA18 0008	Oil Tube - 320mm	81- 1
AA18 0009	Oil Tube - 120mm	81- 8
AA18 0035	Sleeve - Oil Pump	81- 7
AB01 1148	Gear - 28Z	59- 23
AB01 1148	Gear - 28Z	61- 27
AB01 1148	Gear - 28Z	63- 6
AB01 1148	Gear - 28Z	65- 8

Part No.	Description	Page and Index No.
AB01 1149	Gear - 14Z	59- 21
AB01 1149	Gear - 14Z	61- 28
AB01 1149	Gear - 14Z	63- 3
AB01 1149	Gear - 14Z	65- 6
AB01 1342	Gear - 30Z	59- 16
AB01 1342	Gear - 30Z	61- 13
AB01 1342	Gear - 30Z	63- 11
AB01 1342	Gear - 30Z	65- 11
AB01 3318	Gear - 17Z	85- 24
AB01 3320	Gear - 19Z	79- 16
AB01 3355	Gear - 18Z	57- 6
AB01 3363	Gear - 16Z	83- 8
AB01 3492	Gear - 16Z	31- 24
AB01 3601	Gear - 20Z	47- 12
AB01 3729	Gear - 18Z	43- 21
AB01 3773	Gear - 18Z	43- 9
AB01 3774	Gear - 18Z	41- 26
AB01 3775	Gear - 33Z	41- 25
AB01 3776	Gear - 30Z	43- 6
AB01 3777	Gear - 32Z	43- 5
AB01 3781	Gear - 30Z	37- 8
AB01 3810	Gear - 52Z	57- 1
AB01 3811	Gear - 40Z	57- 4
AB01 3814	Gear - 40Z	59- 13
AB01 3814	Gear - 40Z	61- 16
AB01 3814	Gear - 40Z	63- 15
AB01 3814	Gear - 40Z	65- 15
AB01 3815	Gear - 30Z	65- 14
AB01 3817	Gear - 30Z	83- 20
AB01 3818	Gear - 61Z	85- 25
AB01 3819	Gear - 22Z	79- 18
AB01 3820	Gear - 17Z	85- 5
AB01 3823	Gear - 31Z	89- 12
AB01 3826	Gear - 21Z	87- 18
AB01 3827	Gear - 20Z	87- 2

Part No.	Description	Page and Index No
AB01 3828	Gear - 20Z	87- 3
AB01 3830	Gear - 40Z	89- 19
AB01 3832	Gear - 28Z	93- 20
AB01 3834	Gear - 30Z	93- 23
AB01 3835	Gear - 20Z	73- 5
AB01 3835	Gear - 20Z	93- 25
AB01 3836	Gear - 46Z	93- 7
AB01 3837	Gear - 42Z	93- 4
AB01 3838	Gear - 17Z	93- 5
AB01 3843	Gear - 12Z	47- 35
AB01 3844	Gear - 30Z	47- 30
AB01 3846	Gear - 28Z	45- 19
AB01 3847	Gear - 30Z	71- 11
AB01 3848	Gear - 12Z	75- 20
AB01 3849	Gear - 14Z	77- 2
AB01 3850	Gear - 21Z	77- 3
AB01 3852	Gear - 21Z	47- 1
AB01 3853	Gear - 18Z	77- 26
AB01 3854	Gear - 36Z	77- 27
AB01 3855	Gear - 68Z	37- 6
AB01 3856	Gear - 31Z	37- 3
AB01 3864	Gear - 30Z	89- 9
AB01 3865	Gear - 26Z	89- 10
AB01 3866	Front Side Fence Rack	45- 37
AB01 3870	Gear - 22Z	93- 16
AB01 3912	Gear - 80Z	91- 27
AB01 6001	Gear - 14Z	47- 6
AB01 7038	Gear - 32T	81- 12
AB01 7306	Gear - 18Z/40Z	57- 3
AB01 7307	Gear - 20Z/50Z	89- 7
AB01 7308	Gear - 25Z/56Z	89- 21
AB01 7309	Gear - 28Z/62Z	87- 29
AB01 7310	Gear - 26Z/89Z	87- 12
AB01 7311	Gear - 30Z/34Z	87- 6
AB01 7312	Gear - 19Z/26Z	87- 20

Part No.	Description	Page and Index No.
AB01 7313	Gear - 20Z/132Z	89- 18
AB01 7314	Gear - 20Z/33Z	93- 18
AB01 7316	Gear - 20Z/43Z	93- 12
AB01 7318	Gear - 29Z/33Z	93- 6
AB01 7320	Gear - 29Z/44Z	93- 3
AB01 7321	Gear - 20Z/30Z	93- 9
AB01 7322	Gear - 34Z/41Z	47- 31
AB01 7324	Gear - 26Z/70Z	37- 5
AB01 7325	Gear - 35Z	37- 4
AB01 7330	Gear - 20Z/34Z	59- 31
AB01 7330	Gear - 20Z/34Z	61- 10
AB01 7330	Gear - 20Z/34Z	63- 8
AB01 7330	Gear - 20Z/34Z	65- 9
AB03 0266	Pulley - 28Z	87- 11
AB03 0440	Timing Pulley - 28Z	89- 2
AB03 0442	Timing Pulley	87- 1
AB03 0443	Timing Pulley - 88Z	91- 19
AB03 0444	Timing Pulley - 66Z	91- 6
AB03 0445	Timing Pulley - 44Z	91- 11
AB03 0446	Timing Pulley	93- 8
AB03 0449	Timing Pulley - 23Z	37- 20
AB03 0452	Timing Pulley - 24Z	19- 15
AB03 0453	Timing Pulley - 48Z	19- 10
AB03 0456	Timing Pulley - 30Z	37- 12
AB03 2041	Pulley - 26Z	21- 5
AB03 3058	Timing Pulley - 22Z	37- 14
AC03 5020	Rear Spring Plate	29- 13
AC03 5021	Front Spring Plate	29- 11
AC03 5051	Spring Plate - 2nd Mirror	21- 3
AC04 2098	Left Scale - LT	13- 14
AD00 1041	Development Unit - M/Y	63- 0
AD00 1045	Development Unit - B/C	59- 0
AD00 4071	Pre - Cleaning Corona Unit	49- 1
AD00 4082	Charge Corona Unit	49- 11
AD02 0054	Charge Corona Wire	49- 18

Part No.	Description	Page and Index No
AD02 0055	Charge Corona Grid	49- 17
AD02 0056	PCC Wire	49- 6
AD02 1095	Transfer Roller Receptacle	91- 13
AD02 1103	Transfer Belt Receptacle	97- 11
AD02 2289	Front End Block Cover - Charge	49- 15
AD02 2290	Rear End Block Cover - Charge	49- 20
AD02 2291	Front End Block - Pre Cleaning	49- 4
AD02 2292	Rear End Block	49- 9
AD02 2293	Front End Block Cover - Pre Cleaning	49- 2
AD02 2294	Rear End Block Cover - Pre Cleaning	49- 8
AD02 2329	Front End Block - Charge	49- 13
AD02 2330	Rear End Block - Charge	49- 21
AD02 3084	Left Casing - Charge	49- 19
AD02 3085	Right Casing - Charge	49- 12
AD02 3086	Corona Casing - Pre Cleaning	49- 5
AD02 4025	Corona Wire Terminal	49- 10
AD03 7036	Toner Supply Coil - Color	57- 21
AD03 7039	Toner Supply Coil - Black	57- 24
AD03 9042	Agitator - Collor	57- 14
AD03 9045	Large Agitator - BK	57- 9
AD03 9048	Small Agitator - BK	57- 11
AD04 1026	Transfer Roller Blade	71- 8
AE01 0006	Hot Roller	85- 8
AE02 0035	Pressure Roller	85- 9
AE03 0013	Ball Bearing - 8x15.6x4mm	83- 18
AE03 0015	Ball Bearing - 35x47x7	85- 14
AE03 0019	Ball Bearing - 7x20x32	85- 16
AE03 1005	Bushing	83- 9
AE03 1013	Bushing - 6mm	85- 4
AE03 2017	Bushing - 30x40x14.5	85- 15
AE04 1002	Oil Blade	83- 16
AE04 2004	Fusing Cleaning Roller	85- 6
AE04 4016	Hot Roller Stripper	79- 9
AE04 5015	Oil Supply Pad	81- 17
AF01 3002	Bottom Plate Pad	31- 18

Part No.	Description	Page and Index No.
AF01 3002	Bottom Plate Pad	33- 9
AF01 7010	End Fence	33- 6
AF02 0280	Driven Roller	43- 14
AF02 0289	Grip Drive Roller	43- 2
AF02 0295	Vertical Driven Roller	39- 23
AF02 0310	Exit Roller	79- 23
AF02 0311	Upper Registration Roller	47- 18
AF02 0312	Relay Roller	47- 28
AF02 1049	Lower Registration Roller	47- 22
AF02 2069	Left Transport Roller	73- 4
AF02 2070	Right Transport Roller	73- 9
AF03 0020	Pick-up Roller	41- 19
AF03 0021	Pick-up Roller	45- 29
AF03 1022	Paper Feed Roller	41- 18
AF03 1023	Paper Feed Roller	45- 34
AF03 2021	Separation Roller	45- 27
AF03 2023	Separation Roller	43- 25
AF04 0031	Upper Exit Roller	79- 12
AG05 0069	Registration Knob	47- 11
AG05 0070	Fusing Knob	81- 11
AG05 1098	Transport Lever	73- 1
AG05 1099	Fusing Release Lever	105- 21
AG05 1100	Transfer Belt Unit Handle	67- 19
AG05 1104	Front Release Lever - Exit	79- 30
AG05 1105	Rear Release Lever - Exit	79- 13
AG05 1106	Transfer Belt Unit Band	67- 2
AG07 0004	Magnetic Catch	15- 20
AG07 0004	Magnetic Catch	39- 32
AG07 0004	Magnetic Catch	77- 32
AG07 0008	Magnet Catch	47- 23
AG07 1007	Latch - By Pass Feed Table	95- 31
AH01 3008	Leveling Foot Guide	39- 44
AW01 0033	Original Sensor Ass'y - H=3-50	23- 6
AW01 0034	Original Width Sensor	23- 3
AW01 0037	Original Length Sensor	23- 4

Part No.	Description	Page and Index No
AW01 0069	Photo Sensor Assy	105- 19
AW02 0056	Photointerruptor - EE-SX4235A-P1	41- 4
AW02 0056	Photointerruptor - EE-SX4235A-P1	47- 33
AW02 0056	Photointerruptor - EE-SX4235A-P1	79- 25
AW02 0061	Photointerruptor - EE-SX4019-P1	25- 26
AW02 0061	Photointerruptor - EE-SX4019-P1	43- 29
AW02 0062	Photointerruptor - EE-SX4019-P15	47- 39
AW02 0062	Photointerruptor - EE-SX4019-P15	87- 19
AW02 0065	Photointerruptor	25- 2
AW02 0065	Photointerruptor	95- 26
AW02 0066	Photointerruptor	45- 7
AW02 0067	Photointerruptor - EE-SX4119-P15	19- 5
AW03 0029	Fiber Cable - 800	27- 10
AW03 0034	Optics Fiber Cable - 1400mm	13- 4
AW03 0034	Optics Fiber Cable - 1400mm	25- 9
AW03 0035	Optics Fiber Cable - 900mm	23- 24
AW03 0036	Optics Fiber Cable - 1000mm	99- 7
AW10 0023	Fusing Thermistor	81- 18
AW11 0017	Thermostat 140°C AC120V 15A	21- 9
AW23 0007	Toner Density Sensor	59- 5
AW23 0007	Toner Density Sensor	61- 22
AW23 0007	Toner Density Sensor	63- 22
AW23 0007	Toner Density Sensor	65- 27
AW33 0004	Drum Potential Sensor	107- 21
AW50 0010	Push Switch	101- 6
AW50 0012	Push Switch	101- 10
AW50 0016	Touch Panel	17- 8
AX05 0066	Black Dev.Drive Motor - DC7.2W	89- 17
AX05 0067	Color Sleeve Motor - DC9.3W	89- 1
AX05 0070	Black Sleeve Motor - DC9.3W	89- 16
AX06 0084	Transport Motor - DC36W	93- 14
AX06 0085	Color Development Drive - DC26W	87- 34
AX06 0087	Papaer Feed Motor - DC22W	37- 23
AX06 0088	Transport Belt Motor - DC24V 2A	91- 5
AX06 0093	Lubricant Brush Motor - DC36W	87- 5

Part No.	Description	Page and Index No.
AX06 0094	Polygon Motor - DC24V	29- 29
AX20 0096	Magnetic Clutch	45- 15
AX20 0097	Magnetic Spring Clutch	87- 16
AX21 0037	Magnetic Clutch	41- 24
AX21 0040	Magnetic Clutch	47- 36
AX21 0041	Spring Clutch	47- 37
AX21 0055	Spring Clutch	87- 27
AX30 0002	LCD Display	17- 9
AX31 0017	Black Total Counter	103- 8
AX31 0019	Color Total Counter	103- 9
AX40 0008	Heater - 115V 18W	47- 42
AX40 0021	Anti-condensation Heater - 115V 18W	23- 2
AX40 0021	Heater - 115V 18W	39- 1
AX40 0057	Heater - 115V 9W	107- 17
AX43 0016	Pressure Roller Lamp - 115V 400W	83- 12
AX44 0073	Fusing Lamp - 115V 650W	83- 11
AX52 0017	Exposure Lamp - 7.5V 200W	21- 13
AX64 0041	Cooling Fan Motor - DC24 7.64W	27- 26
AX64 0041	Cooling Fan Motor - DC24 7.64W	99- 14
AX64 0041	Cooling Fan Motor - DC24 7.64W	109- 22
AX64 0042	Transport Fan Motor - DC24V 3.12W	73- 10
AX64 0043	Optics Cooling Fan Motor - DC24V 2.88	105- 4
AX64 0045	Cooling Fan Motor - DC24V 2.40W	23- 12
AX64 0045	Cooling Fan Motor - DC24V 2.40W	29- 19
AX64 0047	Dev. Exhaust Fan Motor - DC24V 3.36W	25- 19
AX64 0048	Dev. Exhaust Fan Motor - DC24V 2.88W	25- 18
AY10 0002	Polygon Motor Board	29- 26
AY20 0001	IC - C5C202	17- 3
AZ02 0006	Coil - 4.6mm 5A	27- 20
AZ23 0037	Lamp Regulator - 115V	25- 23
AZ24 0020	DC Power Supply Unit - 100/120V	101- 13
AZ30 0037	High Voltage Supply Board - C.G	99- 21
AZ30 0038	High Voltage Supply Board - T2	99- 17
AZ31 0016	High Voltage Supply Board - B	99- 12
AZ31 0017	High Voltage Supply Board - D	95- 9

Part No.	Description	Page and Index No
AZ32 0068	High Vol. Supply Board - T1,PCC,BR	99- 2
C105 2065	Bushing - 6mm	87- 26
C201 5125	Shoulder Screw - M4	67- 7
C202 3102	Collar - 6.35x10x4mm	103- 22
C401 9503	20x Magnification Scope	127- 11
G004 3762	Corona Wire Spring	49- 14
G011 3305	Gear - 16T	45- 39
H081 2118	Pressure Spring	19- 16

Part No.	Description	Page and Index No.
A006 1328	Small Cap	13- 10
A006 1329	Cap Left Cover	13- 9
A006 1352	Key Counter Cover	95- 1
A006 1721	Front Spring Plate	21- 2
A006 9103	Omega Clamp	127- 4
A007 3762	Sensor Holder	35- 13
A007 3763	Adhesive Tape - Sensor Holder	35- 12
A008 9502	Silicone Grease - G40M	127- 5
A010 5700	Sensor	45- 41
A010 5700	Sensor	47- 5
A012 1752	Lens Bracket Block	25- 1
A012 9501	Scanner Positioning Pin - 4pcs/set	127- 6
A024 1368	Sorter Cap - Left Cover	13- 8
A027 1673	Spring Plate	35- 6
A027 1673	Spring Plate	37- 13
A028 9300	Grease Barrierta JFE 55/2	127- 7
A029 7904	Pad - CFF	33- 4
A030 3403	Bracket	109- 4
A030 4133	Oil Pump Lever	81- 6
A030 4145	Pressure Spring Holder	85- 20
A033 7558	Grounding Plate	93- 1
A033 7558	Spring Plate - Grounding	99- 5
A037 2113	Optical Housing Spacer	29- 30
A048 1721	Spring Plate A	21- 21
A048 1870	Scanner Motor Pulley	19- 6
A048 2838	Nylon Rivet	31- 16
A048 2838	Nylon Rivet	33- 7
A049 1964	Cap - Scale	13- 13
A049 3282	Latch	103- 3
A049 3292	Tank Unit Stopper	55- 14
A049 5102	IC - TC23SC080AF-501	119- 1
A053 1957	Flex Hinge - Platen Cover	15- 5
A060 1325	Right Hinge Pin	95- 2
A060 1812	Sensor Bracket	25- 15
A060 1822	Scanner Wire Pulley	25- 7

Part No.	Description	Page and Index No
A060 1824	Scanner Wire Pulley	25- 12
A060 3826	Toner Collection Bottle Roller	35- 15
A060 3827	Roller Holder	35- 16
A060 5547	Polygon Motor Harness	29- 28
A069 1882	Exposure Glass Holder	19- 4
A069 1883	Shoe - Scanner	21- 4
A069 1972	Arm Holder	15- 38
A069 5352	Harness - Ground Wire - Scanner	19- 12
A072 1383	Caution Decal - English	125- 2
A072 4115	Upper Entrance Guide Plate	81- 20
A085 5571	Power Supply Cord - 115V	101- 14
A092 1393	Decal - Adding Toner	55- 20
A092 1393	Decal - Adding Toner	125- 3
A092 9503	C4 Color Test Chart (3pcs/set)	127- 8
A095 1394	Mounting Bracket - Platen Cover	15- 11
A096 1094	Grip Base	109- 19
A096 1300	Decal - Main Switch	125- 4
A096 1492	Keytop - C/S	17- 10
A096 1493	Keytop - Set12	17- 11
A096 1494	Keytop - Interrupt	17- 12
A096 1497	LCD Display Dial	17- 13
A096 1509	Cushion - 1	17- 14
A096 1510	Cushion - 2	17- 15
A096 1512	Grounding Harness - 2	17- 16
A096 1873	Scanner Shoe Pin	21- 22
A096 5129	IC - M37409M2-155FFP	113- 1
A096 5411	Upper Feed Unit Harness	41- 1
A096 5412	Lower Feed Unit Harness	43- 7
A096 6100	Lower Heater Sink	39- 10
A096 6266	Tray Lock Arm	39- 5
A096 6303	Separation Roller Stay	43- 20
A096 6306	Separation Drive Shaft	43- 10
A096 6307	Separation Driver Shaft	43- 23
A096 6308	Separation Pressure Lever	43- 18
A096 6311	Release Lever	43- 12

Part No.	Description	Page and Index No.
A096 6315	Release Solenoid	43- 11
A096 6321	Position Sensor Bracket	43- 27
A096 6322	Position Sensor Feeler	43- 28
A096 6330	Rear Side Plate	41- 22
A096 6335	Front Side Plate	41- 21
A096 6337	Paper Feed Guide	41- 14
A096 6338	Separation Guide	43- 3
A096 6344	Paper End Actuater	41- 2
A096 6345	End Sensor Bracket	41- 3
A096 6346	Paper Feed Stay	41- 8
A096 6351	Pick-up Arm	41- 15
A096 6352	Feed Roller Bracket	41- 16
A096 6353	Feed Roller Lever	41- 12
A096 6355	Pick-up Solenoid	41- 7
A096 6358	Photointerrupter Bracket	41- 6
A096 6360	Paper Flattener	41- 23
A096 6362	Paper End Feeler	41- 9
A096 6366	Clutch Stopper Arm	43- 4
A096 6369	Vertical Transport Guide	43- 16
A096 6375	Unit Fixing Plate	43- 1
A096 6520	Paper Tray	31- 20
A096 6520	Paper Tray	33- 17
A096 6524	Lift Shaft	31- 29
A096 6524	Lift Shaft	33- 15
A096 6526	Lift Lever	31- 30
A096 6526	Lift Lever	33- 16
A096 6527	Paper Guide Feeler	31- 28
A096 6527	Paper Guide Feeler	33- 14
A096 6534	Front Side Fence	31- 14
A096 6536	Side Fence Cover	31- 12
A096 6537	Stopper Lever	31- 5
A096 6539	Side Fence Gear	31- 23
A096 6541	Gear Side Fence	31- 19
A096 6545	Side Fence Plate - LT	31- 22
A096 6549	Front Side Fence	33- 3

Part No.	Description	Page and Index No
A096 6550	Rear Side Fence	33- 10
A096 6551	Position Plate - Side Fence	33- 13
A096 6553	Side Fence Pad	31- 15
A096 6556	Tray Bottom Plate	31- 17
A096 6556	Tray Bottom Plate	33- 8
A096 6562	End Fence	31- 8
A096 6563	End Fence Cover	31- 6
A096 6564	End Fence Plate	31- 9
A096 6568	Position Plate - End Fence	33- 5
A096 6577	Size Sensor Slider	31- 26
A096 6578	Size Sensor Plate	31- 27
A096 7636	DF Harness - 115V	99- 29
A097 6000	Separation Torque Limiter	43- 24
A097 6000	Separation Torque Limitter	45- 26
A100 1310	Platen Cover Hinge Ass'y	15- 9
A100 1311	Balancer Spring	15- 41
A100 1321	Front Platen Cover	15- 4
A100 1322	Rear Platen Cover	15- 6
A100 1323	Original Holder	15- 7
A100 1324	Positioning Sensor Shutter	15- 8
A100 1325	Hinge Spacer	15- 10
A100 1330	Platen Cover	15- 1
A100 5125	RAM Board	99- 9
A100 5378	Grounding Wire	91- 20
A134 1724	Cushion - Stepper Motor	19- 14
A134 5209	LSI - MSM518222-30JS-1	119- 12
A172 3074	Development Sleeve Assy - Cyan	61- 3
A172 3214	Development Sleeve - M/Y	63- 1
A172 3214	Development Sleeve - M/Y	65- 1
A172 3325	Development Unit Base	105- 16
A172 3606	Cleaning Bias Receptacle	97- 27
A172 3608	Cleaning Receptacle	97- 4
A172 3851	Transport Tank	73- 8
A172 3870	Spring Plate - Transport	109- 23
A172 3881	Transport Sensor Bracket	105- 18

Part No.	Description	Page and Index No.
A172 4171	Right Stay - Fusing	85- 26
A172 4754	Belt Tightener	87- 31
A172 5743	Interface Board 2 Bracket	99- 11
A172 6318	Cleaning Left Stay	75- 5
A172 9510	OPC Drum	51- 16
A406 9505	Platen Cover Sheet - 10 Sheet/1 Set	15- 2
A513 1033	Left Middle Frame	101- 18
A513 1034	Lower Rear Right Bracket	39- 45
A513 1035	Lower Rear Left Bracket	39- 46
A513 1036	Lower Front Right Bracket	39- 36
A513 1172	Interface Board Bracket	101- 5
A513 1173	Upper Hinge - Paper Feed Unit	37- 7
A513 1175	Lower Hinge - Paper Feed Unit	37- 15
A513 1177	Lower Cover Bracket	39- 38
A513 1178	Power Supply Cord Bracket	101- 15
A513 1179	Noise Filter Bracket	101- 17
A513 1180	Upper Stay - Rear Cover	35- 27
A513 1181	Lower Stay - Rear Cover	35- 28
A513 1335	Left Cover - Paper Feed Unit	35- 2
A513 1338	Left Cover Bracket	35- 4
A513 1341	Rear Left Cover - Paper Feed Unit	35- 5
A513 1349	Right Cover - Paper Feed Unit	35- 20
A513 1356	Front Cover - Paper Feed Unit	35- 8
A513 1366	Front Lower Cover	39- 39
A513 2752	Vertical Transport Guide	39- 29
A513 2760	Vertical Transport Guide Bracket	39- 15
A513 2762	Pressure Plate	39- 26
A513 2771	Switch Bracket - Vertical Transport	39- 27
A513 2775	Guide Plate Front Holder	39- 18
A513 2776	Guide Plate Stopper	39- 20
A513 2780	Vertical Transport Guide Cover	39- 31
A513 2782	Cover Release Plate	39- 21
A513 2783	Spring Plate	39- 22
A513 2785	Guide Plate Rear Holder	39- 16
A513 2786	Support Cover	39- 41

Part No.	Description	Page and Index No
A513 2801	Front Side Frame	39- 35
A513 2809	Rear Cover - Vertical Transport	39- 12
A513 2820	Belt Tightner	37- 19
A513 2829	Cover - Paper Tray	31- 1
A513 2829	Cover - Paper Tray	33- 1
A513 2832	Paper Size Sensor Bracket	101- 8
A513 2836	Tray Set Sensor Bracket	101- 9
A513 2840	Paper Lift Motor	37- 10
A513 2846	Paper Feed Motor Bracket	37- 21
A513 2850	Right Rail - Paper Tray	39- 37
A513 2861	Left Rail - Paper Tray	39- 3
A513 2870	Upper Tray Heater Bracket	39- 2
A513 5121	Paper Feed Interface Board	101- 4
A513 5350	Rear Harness - Paper Feed Unit	101- 2
A513 5351	Front Harness - Paper Feed Unit	35- 25
A513 5351	Front Harness - Paper Feed Unit	101- 1
A513 5353	Relay Harness - Lift Motor	37- 9
A513 5354	Relay Harness - Paper Size Sensor	101- 7
A513 5356	DC Relay Harness	101- 12
A513 5357	Relay Harness - Tray Set Sensor	101- 11
A513 5358	Relay Harness - Paper Feed Motor	37- 22
A513 5364	Relay Harness - Humidity Sensor	35- 24
A513 5380	AC Harness - Noise Filter Board (IN)	101- 20
A513 5381	Relay Harness	101- 21
A513 5383	Heater Harness	39- 11
A513 5383	Heater Harness	101- 22
A513 5384	AC Harness - Noise Filter Board (OUT)	101- 23
A513 5403	Toner Overflow Sensor	35- 14
A513 5431	Noise Filter Board - 100/115V	101- 19
A513 5542	Noise Filter - 115V	101- 24
A513 6152	Humidity Sensor Holder	35- 21
A513 6600	Toner Collection Bottle	35- 10
A513 6603	Seal - Toner Overflow Sensor	35- 26
A513 6612	Joint Case Bracket	39- 6
A513 6613	Collection Joint Case	39- 8

Part No.	Description	Page and Index No.
A513 6614	Upper Shielding Seal	39- 7
A513 6615	Lower Shielding Seal	39- 9
A513 6622	Tray Unit Gear Holder	37- 1
A513 6642	Right Side Plate	35- 18
A513 6643	Collection Bottle Guide Plate	35- 17
A513 6644	Right Lower Hinge - Tray Unit	35- 19
A513 6652	Collection Bottle Stopper	39- 13
A513 6653	Collection Bottle Cushion	39- 14
A513 6661	Cover Support Plate	39- 34
5053 0223	Bushing - 8mm	89- 3
5053 0447	Bushing - 6mm	37- 16
5053 0447	Bushing - 6mm	47- 2
5053 0447	Bushing - 6mm	73- 3
5053 0447	Bushing - 6mm	87- 14
5203 2679	Pinion Tightening Screw - M4x5	29- 33
5203 4165	Fusing Thermofuse Decal	125- 1
5205 1336	Front Cover Chain	59- 1
5205 2612	Gear - 19T	57- 7
5205 8730	Counter Set Key	127- 9
5206 2686	Snap Ring	69- 13
5208 6136	Spring - Hot Roller Stripper	79- 10
5209 5320	Oil End Sensor	81- 23
5215 1667	Platen Cover Stud	15- 12
5215 1924	Cushion	19- 34
5215 2836	Sleeve - 8 X 34 Mm	15- 40
5215 2837	Shaft 7 x 40 mm	15- 39
5215 2838	Rubber Magnet	15- 34
5215 2840	Pin - 4 x 115 mm	15- 33
5215 2842	Right Spring - Platen Cover	15- 31
5215 2843	Left Spring - Platen Cover	15- 30
5215 2844	Slide Supporter	15- 32
5215 2845	Plate - Magnet	15- 35
5215 2846	Platen Base	15- 36
5215 2847	Base Holder	15- 37
5215 4116	Oil Blade Holder	83- 17

Part No.	Description	Page and Index No
5215 4411	Spring Plate	81- 24
5215 4444	Pin	79- 14
5215 4497	Exit Antistatic Brush	79- 3
5219 9300	MT - 1	127- 1
5301 1662	Hexagon Bolt	39- 43
5350 1754	Stud - M5x4	65- 31
5353 3710	Gear - 18Z	45- 30
5361 2080	Plate : Wire Clamp	19- 22
5400 3404	Stepped Screw	71- 12
5403 6246	Stepped Screw - Cleaning	59- 25
5409 1855	Mounting Pin	69- 5
5413 2298	Screw - M4	77- 31
5415 1053	Caster	39- 33
5415 4310	Valve - Oil Pump	81- 25
5418 2859	Spring - Regist Roller (Front)	87- 10
5420 1515	Plate - Key Counter	95- 4
5420 9550	Silicone Oil	127- 2
5424 1064	Screw Stand	39- 17
5432 3265	Spring Lock Lever	91- 9
5442 2108	Spring - Corona Wire	49- 7
5442 2754	Spring - Registration Roller	47- 9
5442 4495	Slip Clutch	79- 17
5442 9101	Setting Powder	127- 3
5446 5832	Connector Guide Pin	97- 14
5446 5832	Connector Guide Pin	107- 16
5447 2681	Snap Ring	39- 30
5447 2681	Snap Ring	41- 5
5447 2681	Snap Ring	43- 26
5447 2681	Snap Ring	45- 28
5447 2681	Snap Ring	73- 17
5447 2681	Snap Ring	77- 1
5447 2681	Snap Ring	79- 33
5447 2683	Gear - 18T	45- 22
5447 2684	Gear - 18T	45- 24
5447 2706	Gear - 15T	41- 20

Part No.	Description	Page and Index No.
5447 2706	Gear - 15T	45- 33
5447 2743	Lever Spring	93- 21
5447 2927	Friction Pad - B	45- 10
5447 3200	Bushing - 6mm	57- 2
5447 3922	Gear - 16T	47- 10
5447 4241	Tube Clamp	81- 2
5840 1632	Stepped Screw	79- 2
5840 1632	Stepped Screw	85- 12
5875 2088	Shoulder Screw - M4	69- 23
5919 2201	Shoulder Screw - M4	67- 1
5919 2201	Shoulder Screw - M4	91- 14
5919 2201	Shoulder Screw - M4	97- 12
5922 2642	Edging	95- 35
6803 2273	Stepped Screw - M4	59- 6
6803 2273	Stepped Screw - M4	63- 19

Part No.	Description	Page and Index No
0313 0040B	Philips Pan Head Screw - M3x4	59-108
0313 0040B	Philips Pan Head Screw - M3x4	63-101
0313 0040B	Philips Pan Head Screw - M3x4	65-109
0313 0050B	Philips Pan Head Screw - M3x5	19-101
0313 0050B	Philips Pan Head Screw - M3x5	23-104
0313 0060B	Philips Pan Head Screw - M3x6	21-103
0313 0060B	Philips Pan Head Screw - M3x6	25-105
0313 0060B	Philips Pan Head Screw - M3x6	31-108
0313 0060B	Philips Pan Head Screw - M3x6	33-104
0313 0060B	Philips Pan Head Screw - M3x6	49-102
0313 0060B	Philips Pan Head Screw - M3x6	53-103
0313 0060B	Philips Pan Head Screw - M3x6	59-101
0313 0060B	Philips Pan Head Screw - M3x6	61-102
0313 0060B	Philips Pan Head Screw - M3x6	63-106
0313 0060B	Philips Pan Head Screw - M3x6	65-106
0313 0060B	Philips Pan Head Screw - M3x6	75-101
0313 0060B	Philips Pan Head Screw - M3x6	81-100
0313 0060B	Philips Pan Head Screw - M3x6	107-104
0313 0080B	Philips Pan Head Screw - M3x8	57-102
0313 0100B	Philips Pan Head Screw - M3x10	47-109
0313 0100B	Philips Pan Head Screw - M3x10	105-110
0313 0120B	Philips Pan Head Screw - M3x12	53-104
0314 0050B	Philips Pan Head Screw - M4x5	105-109
0314 0050B	Philips Pan Head Screw - M4x5	107-102
0314 0050W	Philips Pan Head Screw - M4x5	15-106
0314 0060B	Philips Pan Head Screw - M4x6	13-101
0314 0060B	Philips Pan Head Screw - M4x6	17-102
0314 0060B	Philips Pan Head Screw - M4x6	39-103
0314 0060B	Philips Pan Head Screw - M4x6	47-106
0314 0060B	Philips Pan Head Screw - M4x6	51-100
0314 0060B	Philips Pan Head Screw - M4x6	55-101
0314 0060B	Philips Pan Head Screw - M4x6	73-102
0314 0060B	Philips Pan Head Screw - M4x6	79-104
0314 0060B	Philips Pan Head Screw - M4x6	81-101
0314 0060B	Philips Pan Head Screw - M4x6	83-100

Part No.	Description	Page and Index No.
0314 0060B	Philips Pan Head Screw - M4x6	85-100
0314 0060B	Philips Pan Head Screw - M4x6	93-104
0314 0060B	Philips Pan Head Screw - M4x6	95-102
0314 0060B	Philips Pan Head Screw - M4x6	105-107
0314 0080B	Philips Pan Head Screw - M4x8	19-109
0314 0080B	Philips Pan Head Screw - M4x8	25-100
0314 0080B	Philips Pan Head Screw - M4x8	31-109
0314 0080B	Philips Pan Head Screw - M4x8	33-105
0314 0080B	Philips Pan Head Screw - M4x8	49-101
0314 0080B	Philips Pan Head Screw - M4x8	55-104
0314 0080B	Philips Pan Head Screw - M4x8	75-100
0314 0080B	Philips Pan Head Screw - M4x8	83-102
0314 0080M	Philips Pan Head Screw - M4x8	27-102
0314 0080M	Philips Pan Head Screw - M4x8	101-111
0314 0120B	Philips Pan Head Screw - M4x12	19-102
0314 0120B	Philips Pan Head Screw - M4x12	25-112
0314 0120B	Philips Pan Head Screw - M4x12	43-110
0314 0120B	Philips Pan Head Screw - M4x12	99-106
0314 0160B	Philips Pan Head Screw - M4x16	53-102
0314 0160B	Philips Pan Head Screw - M4x16	87-106
0314 0200B	Philips Pan Head Screw - M4x20	25-111
0314 0200B	Philips Pan Head Screw - M4x20	53-101
0314 0300B	Philips Pan Head Screw - M4x30	25-104
0314 0300B	Philips Pan Head Screw - M4x30	27-101
0314 0300B	Philips Pan Head Screw - M4x30	99-102
0314 0300B	Philips Pan Head Screw - M4x30	105-104
0314 0300B	Philips Pan Head Screw - M4x30	109-102
0323 0060B	Philips Sunk Screw - M3x6	95-105
0324 0060B	Philips Sunken Head Screw - M4x6	69-107
0324 0080B	Philips Sunken Head Screw - M4x8	75-103
0344 0060F	Philips Truss Head Screw - M4x6	13-100
0344 0060F	Philips Truss Head Screw - M4x6	15-101
0344 0060F	Philips Truss Head Screw - M4x6	17-103
0344 0060F	Philips Truss Head Screw - M4x6	19-110
0344 0060F	Philips Truss Head Screw - M4x6	35-103

Part No.	Description	Page and Index No
0344 0060F	Philips Truss Head Screw - M4x6	77-103
0344 0060F	Philips Truss Head Screw - M4x6	103-102
0344 0080F	Philips Truss Head Screw - M4x8	13-102
0344 0080F	Philips Truss Head Screw - M4x8	15-103
0353 0050B	Philips Truss Head Screw - M3x5	35-102
0353 0050B	Philips Truss Head Screw - M3x5	39-107
0353 0060F	Philips Truss Head Screw - M3x6	99-114
0354 0050F	Philips Pan Head Bind Screw - M4x5	31-104
0354 0050F	Philips Pan Head Bind Screw-M4x5	33-107
0354 0060B	Screw - M4X6	27-103
0354 0060B	Screw - M4X6	29-100
0354 0060B	Screw - M4X6	35-100
0354 0060B	Screw - M4X6	47-102
0354 0060B	Screw - M4X6	59-100
0354 0060B	Screw - M4X6	61-100
0354 0060B	Screw - M4X6	65-107
0354 0060B	Screw - M4X6	67-100
0354 0060B	Screw - M4x6	69-104
0354 0060B	Screw - M4X6	71-101
0354 0060B	Screw - M4X6	77-102
0354 0060B	Screw - M4X6	87-101
0354 0060B	Screw - M4X6	89-100
0354 0060B	Screw - M4X6	91-107
0354 0060B	Screw - M4x6	93-102
0354 0060B	Screw - M4X6	95-103
0354 0060B	Screw - M4X6	97-100
0354 0060B	Screw - M4x6	99-101
0354 0060B	Screw - M4X6	105-100
0354 0100B	Screw - M4x10	29-105
0354 0100B	Screw - M4X10	47-107
0354 0100B	Screw - M4X10	91-104
0354 0100B	Screw - M4x10	93-103
0354 0100W	Philips Pan Head Screw - M4x10	15-104
0413 0062W	Tapping Screw - M3x6	23-109
0413 0082B	Tapping Screw - M3x8	31-102

Part No.	Description	Page and Index No.
0413 0082B	Tapping Screw - M3x8	45-100
0413 0102B	Tapping Screw - M3x10	59-106
0413 0102B	Tapping Screw - M3x10	63-103
0413 0302B	Tapping Screw - M3x10	99-105
0414 0082B	Binding Self Tapping Screw - M4x8	35-104
0414 0082B	Binding Self Tapping Screw - M4x8	45-104
0414 0082B	Binding Self Tapping Screw - M4x8	55-103
0414 0082B	Binding Self Tapping Screw - M4x8	73-104
0414 0082B	Binding Self Tapping Screw - M4x8	81-102
0414 0082B	Binding Self Tapping Screw - M4x8	91-109
0414 0082F	Philips Truss Head Screw - M4x8	31-101
0414 0082F	Philips Truss Head Screw - M4x8	33-101
0414 0102B	Tapping Screw M4x10	105-101
0414 0102B	Tapping Screw M4x10	105-106
0414 0142W	Tapping Screw - M4x14	15-100
0433 0050B	Tapping Screw - M3x5	23-106
0433 0060B	Philips Tapping Screw - M3x6	35-105
0433 0060B	Philips Tapping Screw - M3x6	37-108
0433 0062B	Tapping Screw - M3 x 6 mm	49-100
0433 0082B	Tapping Screw - M3x8	17-101
0433 0082B	Tapping Screw - M3x8	31-107
0433 0102B	Tapping Screw - M3x10	97-102
0434 0060B	Philips Tapping Screw - M4x6	19-100
0434 0060B	Philips Tapping Screw - M4x6	23-100
0434 0060B	Philips Tapping Screw - M4x6	25-103
0434 0060B	Philips Tapping Screw - M4x6	41-101
0434 0060B	Philips Tapping Screw - M4x6	43-101
0434 0080B	Philips Tapping Screw - M4x8	27-100
0434 0080B	Philips Tapping Screw - M4x8	37-102
0434 0080B	Philips Tapping Screw - M4x8	39-101
0434 0080B	Philips Tapping Screw - M4x8	47-100
0434 0080B	Philips Tapping Screw - M4x8	73-100
0434 0080B	Philips Tapping Screw - M4x8	87-102
0434 0080B	Philips Tapping Screw - M4x8	95-100
0434 0080B	Philips Tapping Screw - M4x8	97-101

Part No.	Description	Page and Index No
0434 0080B	Philips Tapping Screw - M4x8	99-100
0434 0080B	Philips Tapping Screw - M4x8	101-104
0434 0080B	Philips Tapping Screw - M4x8	103-100
0434 0080B	Philips Tapping Screw - M4x8	105-105
0434 0080B	Philips Tapping Screw - M4x8	107-100
0434 0080B	Philips Tapping Screw - M4x8	109-100
0434 0082F	Tapping Screw - M3x10	39-105
0434 0102W	Tapping Screw - M4x10	15-102
0573 0040B	Hexagon Headless Set Screw - M3x4	41-105
0574 0040E	Hexagon Headless Set Screw - M4x4	43-108
0574 0060B	Hexagon Headless Set Screw - M4	37-109
0574 0060E	Hexagon Headless Set Screw - M4x6	19-103
0574 0060E	Hexagon Headless Set Screw - M4x6	91-105
0575 0050E	Hexagon Headless Set Screw - M5x5	91-110
0575 0050E	Hexagon Headless Set Screw - M5x5	93-101
0585 0161B	Hexagon Bolt - M5x16	85-104
0593 0060E	Bolt - M3x6	29-101
0701 0100B	Flat Washer - 10	91-114
0710 0100B	Hexagonal Nut - M10	91-113
0720 0030B	Retaining Ring - M3	43-111
0720 0030B	Retaining Ring - M3	69-102
0720 0030B	Retaining Ring - M3	75-104
0720 0030B	Retaining Ring - M3	103-106
0720 0030B	Retaining Ring - M3	107-106
0720 0030E	Retaining Ring - M3	15-105
0720 0030E	Retaining Ring - M3	57-103
0720 0040B	Retaining Ring - M4	19-107
0720 0040B	Retaining Ring - M4	37-100
0720 0040B	Retaining Ring - M4	37-106
0720 0040B	Retaining Ring - M4	39-106
0720 0040B	Retaining Ring - M4	41-104
0720 0040B	Retaining Ring - M4	43-106
0720 0040B	Retaining Ring - M4	45-102
0720 0040B	Retaining Ring - M4	47-101
0720 0040B	Retaining Ring - M4	51-102

Part No.	Description	Page and Index No.
0720 0040B	Retaining Ring - M4	53-105
0720 0040B	Retaining Ring - M4	57-100
0720 0040B	Retaining Ring - M4	59-107
0720 0040B	Retaining Ring - M4	61-101
0720 0040B	Retaining Ring - M4	63-108
0720 0040B	Retaining Ring - M4	65-101
0720 0040B	Retaining Ring - M4	71-102
0720 0040B	Retaining Ring - M4	73-101
0720 0040B	Retaining Ring - M4	75-107
0720 0040B	Retaining Ring - M4	77-105
0720 0040B	Retaining Ring - M4	87-104
0720 0040B	Retaining Ring - M4	107-105
0720 0040E	Retaining Ring - M4	45-105
0720 0040E	Retaining Ring - M4	79-100
0720 0040E	Retaining Ring - M4	85-101
0720 0040E	Retaining Ring - M4	89-102
0720 0040E	Retaining Ring - M4	93-105
0720 0040E	Retaining Ring - M4	109-101
0720 0050B	Retaining Ring - M5	21-100
0720 0050B	Retaining Ring - M5	47-108
0720 0050E	Retaining Ring - M5	37-103
0720 0060B	Retaining Ring - M6	31-110
0720 0060B	Retaining Ring - M6	33-106
0720 0060B	Retaining Ring - M6	37-105
0720 0060B	Retaining Ring - M6	41-102
0720 0060B	Retaining Ring - M6	43-102
0720 0060B	Retaining Ring - M6	47-104
0720 0060B	Retaining Ring - M6	65-104
0720 0060B	Retaining Ring - M6	67-102
0720 0060B	Retaining Ring - M6	69-100
0720 0060B	Retaining Ring - M6	71-100
0720 0060B	Retaining Ring - M6	77-100
0720 0060B	Retaining Ring - M6	81-103
0720 0060B	Retaining Ring - M6	83-101
0720 0060B	Retaining Ring - M6	85-102

Part No.	Description	Page and Index No
0720 0060B	Retaining Ring - M6	87-100
0720 0060B	Retaining Ring - M6	93-100
0720 0060E	Retaining Ring - M6	89-103
0720 0060E	Retaining Ring - M6	91-111
0720 0080B	Retaining Ring - M8	85-105
0725 0120E	Retaining Ring C - M12	59-104
0725 0120E	Retaining Ring C - M12	61-104
0725 0120E	Retaining Ring C - M12	63-102
0725 0120E	Retaining Ring C - M12	65-102
0725 0120E	Retaining Ring C - M12	91-100
0725 0300E	Retaining Ring C - M30	85-103
0727 0080E	Retaining Ring - M8	69-106
0727 0080E	Retaining Ring - M8	87-107
0740 3008	Ball Bearing - 8x22x7	37-107
0740 3008	Ball Bearing - 8x22x7	93-106
0741 3808	Ball Bearing - 8x16x5mm	91-102
0742 3808	Ball Bearing - 8x16x5	43-103
0800 0072	Philips Pan Head Screw - M2.6x4	99-113
0801 0142	Screw - Spring Washer - M5x8	101-112
0801 1007	Philips Pan Head Screw - M10x7	103-103
0803 0020	Positioning Pin	29-107
0805 0073	Retaining Ring - M5	31-106
0805 0083	Retaing Ring - M4	15-107
0805 3145	Ball Bearing - 6x12x4mm	19-105
0805 3145	Ball Bearing - 6x12x4mm	43-107
0805 3366	Bushing - 6mm	73-105
0805 3385	Bushing - 6mm	45-101
0805 3385	Bushing - 6mm	69-105
0805 3385	Bushing - 6mm	77-101
0805 3385	Bushing - 6mm	79-101
0805 3449	Ball Bearing - M12x24x6	59-103
0805 3449	Ball Bearing - M12x24x6	61-103
0805 3449	Ball Bearing - M12x24x6	63-105
0805 3449	Ball Bearing - M12x24x6	65-108
0805 3482	Ball Bearing - 8x14x3.5	67-103

Part No.	Description	Page and Index No.
0805 3482	Ball Bearing - 8x14x3.5	69-101
0807 3109	Spring Washer - M4	21-106
0807 4047	Wave Washer - 6mm	19-106
0807 4076	Washer - 8.2x6.1x0.3mm	19-104
0807 5053	Washer	91-103
0807 7049	Spacer - 12.3x18mmx0.2T	87-109
0807 7049	Spacer - 12.3x18mmx0.2T	89-104
0807 7049	Spacer - 12.3x18mmx0.2T	91-101
0950 3010B	Philips Screw With Spring Washer	89-101
0950 4008B	Philips Screw With Spring Washer	87-108
0950 4008M	Screw - M4X8	99-115
0950 4010B	Sem,s Screw M4 x 10	39-100
0951 3005B	Philips Screw With Flat Washer M3x5	55-105
0951 3006B	Philips Screw With Flat Washer-M3x6	21-102
0951 3006B	Philips Screw With Flat Washer - M3x6	23-105
0951 3006B	Philips Screw With Flat Washer - M3x6	25-101
0951 3006B	Philips Screw With Flat Washer - M3x6	47-105
0951 3006B	Philips Screw With Flat Washer-M3x6	55-100
0951 3006B	Philips Screw With Flat Washer - M3x6	69-103
0951 3006B	Philips Screw With Flat Washer - M3x6	75-108
0951 3008B	Philips Screw With Flat Washer - M3x8	23-103
0951 3008B	Philips Screw With Flat Washer - M3x8	31-105
0951 3008B	Philips Screw With Flat Washer - M3x8	57-101
0951 3008B	Philips Screw With Flat Washer - M3x8	101-108
0951 3014B	Philips Screw With Washer - M3x14	29-103
0951 3020B	Philips Screw With Flat Washer - 3x8	29-104
0951 4006B	Philips Screw With Washer - M4x6	19-111
0951 4006B	Philips Screw With Washer - M4x6	51-101
0951 4006B	Philips Screw With Washer - M4x6	79-103
0951 4006B	Philips Screw With Washer - M4x6	87-105
0951 4006B	Philips Screw With Washer - M4x6	91-106
0951 4008B	Philips Screw With Washer - M4x8	19-108
0951 4008B	Philips Screw With Washer - M4x8	25-102
0951 4008B	Philips Screw With Washer - M4x8	37-110
0951 4008B	Philips Screw With Washer - M4x8	47-103

Part No.	Description	Page and Index No
0951 4008B	Philips Screw With Washer - M4x8	67-101
0951 4008B	Philips Screw With Washer - M4x8	79-102
0951 4008B	Philips Screw With Washer - M4x8	83-108
0951 4008B	Philips Screw With Washer - M4x8	85-106
0951 4008B	Philips Screw With Washer - M4x8	87-103
0951 4008B	Philips Screw With Washer - M4x8	89-107
0951 4008B	Philips Screw With Washer - M4x8	91-108
0951 4010B	Philips Screw With Washer - M4x10	23-108
0951 4014B	Philips Screw With Washer - M4x14	23-107
0951 5040B	Screw - M5X40	89-106
0952 3008B	Screw - M3X8	21-101
0952 3008B	Screw - M3X8	33-103
0952 3008B	Screw - M3X8	55-102
0952 3008B	Screw - M3X8	83-104
0952 3008B	Screw - M3x8	107-108
0952 3012B	Screw - M5X12	21-104
0952 3012B	Screw - M5X12	23-101
0952 4010B	Screw - M4X10	59-105
0952 4010B	Screw - M4X10	61-106
0952 4010B	Screw - M4X10	63-107
0952 4010B	Screw - M4X10	65-105
0952 4014B	Screw - M4X14	59-102
0952 4014B	Screw - M4X14	61-105
0952 4014B	Screw - M4X14	63-104
0952 4014B	Screw - M4X14	65-103
0952 4014B	Screw - M4X14	75-102
0952 4014B	Screw - M4X14	79-105
0952 4014B	Screw - M4X14	83-103
0953 4008M	Screw - M4X8	29-102
0954 4008B	Philips Screw - M4x8	101-113
0957 4008B	Philips Screw W/F Washer - M4x8	23-102
0957 4008B	Philips Screw W/F Washer - M4x8	107-107
0960 4008B	Philips Flange Screw - M4x8	29-106
0964 4008B	Tapping Screw With Flat Washer - M4x8	37-104
0964 4008B	Tapping Screw With Flat Washer - M4x8	77-104

Part No.	Description	Page and Index No.
0964 4008B	Tapping Screw With Flat Washer - M4x8	95-101
0964 4008B	Tapping Screw With Flat Washer - M4x8	101-107
0965 3006B	Tapping Screw With Flat Washer M3x6	45-103
0965 3006W	Tapping Screw With Flat Washer - M3x6	35-101
0965 4008B	Tapping Screw - M4 x 8	31-103
0965 4008B	Tapping Screw - M4 x 8	33-102
0972 4006A	Philips Polycarbonate Screw - M4x6	53-100
1100 0863	Stud Pin	121-101
1100 0864	Housing - AWG14-20	121-102
1100 1241	Socket - MATE-N-LOCK	121-103
1100 1339	Pin Contact	121-104
1100 1344	Pin Contact	121-105
1100 1669	Connector - 1P	121-106
1101 0328	Connector Pin Contact	113-114
1101 0360	Connector - 3P	113-115
1101 0395	IC Socket - 252	113-116
1101 0474	Connector - 4P	83-106
1102 0941	Connector - 4P	121-107
1102 0946	Housing - 3P	121-108
1102 0947	Housing - 3P	121-109
1102 0948	Housing - 4P	121-110
1102 1017	Housing - 2P Red	121-111
1102 1171	Connector - 5P	121-112
1102 1404	Connector - 1P	121-113
1102 1517	Connector - 4P	121-114
1102 5003	Connector - 2P	113-117
1102 5003	Fiber Connector - Dc1002 - 2p	119-100
1102 5187	Connector - 14P	121-115
1102 5310	Connector - 5p	119-101
1102 5328	Connector - 12P	113-118
1102 5340	Fiber Connector - 2P	113-119
1102 5341	Fiber Connector	113-120
1102 5342	Connector - 2P	113-121
1102 5343	Connector - 2P	113-122
1102 5981	Fiber Connector	99-103

Part No.	Description	Page and Index No
1102 6134	IC Socket	113-123
1102 6213	Connector - 1P	121-116
1102 6245	Connector - 2P	43-112
1102 6246	Connector - 3P	75-105
1102 6250	Connector - 7P	43-105
1102 6260	Connector - Red 3P	75-106
1102 6265	Connector - Red 8P	43-104
1102 6265	Connector - Red 8P	107-101
1102 6296	Connector - 3p	119-102
1102 6297	Connector - 4P	113-124
1102 6299	Connector - 6P	113-125
1102 6303	Connector - 10P	113-126
1102 6335	Connector - 4p	119-103
1102 6339	Connector - 8p	119-104
1102 6395	Connector - 1P	113-127
1102 6396	Connector - 1P	113-128
1102 6398	Connector - 2p	119-105
1102 6402	Connector - 2P	113-129
1102 6403	Connector - 30P	113-130
1102 6408	Connector - 30P	113-131
1102 6567	Connector - 40p	119-106
1102 6570	Connector - Phec60r-r111	119-107
1102 7021	Connector - IMSA-9224B-40Z10-GF	119-108
1103 3020	Connector - 20P	113-132
1104 0589	Dip Socket - 32P	113-133
1105 0087	Clamp	41-103
1105 0087	Clamp	43-109
1105 0113	Edge - P108	25-108
1105 0113	Edge - P108	109-104
1105 0193	Nylon Stud	25-110
1105 0193	Nylon Stud	27-104
1105 0193	Nylon Stud	95-107
1105 0193	Nylon Stud	99-110
1105 0193	Nylon Stud	101-105
1105 0199	Clamp	25-106

Part No.	Description	Page and Index No.
1105 0199	Clamp	37-101
1105 0199	Clamp	73-103
1105 0199	Clamp	97-107
1105 0199	Clamp	99-112
1105 0199	Clamp	105-102
1105 0199	Clamp	109-106
1105 0200	Clamp	103-109
1105 0200	Clamp	105-111
1105 0230	Clamp	83-107
1105 0231	Clamp	89-105
1105 0246	Spacer	27-106
1105 0278	Harness Clamp	99-109
1105 0278	Harness Clamp	109-105
1105 0291	Wire Saddle	97-105
1105 0291	Wire Saddle	99-107
1105 0292	Wire Saddle	25-109
1105 0292	Wire Saddle	83-105
1105 0292	Wire Saddle	95-104
1105 0292	Wire Saddle	103-108
1105 0310	Wire Clamp	25-107
1105 0310	Wire Clamp	39-102
1105 0310	Wire Clamp	77-106
1105 0310	Wire Clamp	89-109
1105 0310	Wire Clamp	91-112
1105 0310	Wire Clamp	101-109
1105 0310	Wire Clamp	105-103
1105 0316	Clamp	97-103
1105 0334	Edge - 17	109-109
1105 0349	Edge Saddle	89-108
1105 0349	Edge Saddle	99-108
1105 0349	Edge Saddle	103-107
1105 0352	Clamp	109-107
1105 0409	Spacer	27-105
1105 0409	Spacer	95-106
1105 0409	Spacer	99-111

Part No.	Description	Page and Index No
1105 0409	Spacer	101-106
1105 0413	Harness Clamp	95-108
1105 0413	Harness Clamp	97-104
1105 0413	Harness Clamp	101-110
1106 0193	Bushing - 7.9mm	105-108
1106 0193	Bushing - 7.9mm	109-103
1106 0310	Bushing	25-113
1106 0430	Bushing - 13mm	109-108
1106 0459	Bushing - 20.2mm	97-106
1107 0391	Fuse - 5A, 125V	101-100
1107 0392	Fuse (glass Case) - 6.3A - 125V	101-101
1107 0629	Fuse (ceramic Case) - 15A - 125V	101-102
1107 0693	Circuit Breaker - 18A 250V	101-103
1107 0750	Fuse - 3.15A 250V	99-104
1204 1542	Dip Switch	113-134
1204 2156	Dip Switch - 51D-0501	119-109
1204 2355	Microswitch - AM51632A 531	103-110
1204 2356	Microswitch - AH51612A531	39-104
1204 2356	Microswitch - AM51612A 531	103-104
1204 2376	Microswitch - V-162-3C25	39-108
1204 2376	Microswitch - V-162-3C25	103-105
1204 2414	Main Switch	103-101
1400 0528	Transistor - DTB113EK	113-135
1400 0555	Transistor - DTC143EK	113-136
1401 0296	Transistor - 2SA1162Y	113-137
1401 0992	Transistor - 2SB1335	119-110
1402 0476	Diode - 1SS184	113-138
1402 1152	Diode - RD7.5P	113-139
1402 1172	Zener Diode - Hzm6.8b	119-111
1403 0313	Diode - TLR102A	119-112
1403 0558	LED - SEl2110RTP3	113-140
1407 1309	IC - LS04	113-141
1407 1311	IC - LS32	113-142
1407 1596	IC - SN74LS14NS	113-143
1407 1741	TTL - SN74LS32NS	119-113

Part No.	Description	Page and Index No.
1407 1792	IC - SN74LS374NS	119-114
1407 2051	TTL - IC - SN74LS00NS	119-115
1407 2052	IC - SN74LS74ANS	113-144
1407 2081	IC - SN74LS08NS	113-145
1407 2127	TTL - IC74F00SJ	119-116
1407 2128	TTL - IC74F02SJ	119-117
1407 2135	TTLIC - 74F74SJ	113-146
1407 2137	IC -74F138SJ : TTL	113-147
1407 2137	IC -74F138SJ : TTL	119-118
1407 2138	TTLIC - 74F139SJ	113-148
1407 2187	IC - SN74LS07NS	113-149
1407 2187	IC - SN74LS07NS	119-119
1407 2231	IC - TD62308AF	113-150
1407 2249	TTL - SN74LS174NS	119-120
1407 2253	IC - SN74LS393NS	113-151
1407 2344	IC - TD62382F	113-152
1407 2409	IC - SN74LS04M	119-121
1407 2411	IC - SN74LS125F	113-153
1407 2462	TTL - IC - SN74ALS00ANS	119-122
1407 2463	IC - SN74ALS08NS	113-154
1407 2463	TTL - IC - SN74ALS08NS	119-123
1407 2464	IC - SN74ALS74ANS	113-155
1407 2464	TTL - IC - SN74ALS74ANS	119-124
1407 2588	IC - SN74ALS04BNS	113-156
1407 2588	TTLIC - SN74ALS04BNS	119-125
1407 2816	TTL - SN74ALS374ANS	119-126
1407 2817	IC - SN74ALS32NS	113-157
1407 2817	TTL - SN74ALS32NS	119-127
1407 3025	IC - SN74ALS02NS	119-128
1407 3348	IC - SN74LS02M	119-129
1407 3350	IC - SN74LS74AM	119-130
1407 3481	IC - SN74AS32NS	119-131
1407 3692	IC - RF5C86	113-158
1407 3753	IC - TC4W53F	113-159
1407 3852	IC - MB89371AH	113-160

Part No.	Description	Page and Index No
1407 4090	IC - M66250FP	119-132
1407 4091	IC - M66251AFP	119-133
1407 4092	IC - M66253FP	119-134
1407 4113	IC - HM6225ALFP-12SLT	113-161
1407 4137	IC - MM1035XF	113-162
1407 4143	IC - MC68331FC	113-163
1407 4144	IC - H81532-HD6435328A00M	113-164
1407 4146	LSI - MB89255AHPFS	113-165
1407 4183	IC - uPD71051GU-10	113-166
1407 4188	IC - HD6415108F10	119-135
1407 4192	IC - SN74LS244M	119-136
1407 4193	IC - SN74LS157M	119-137
1407 4194	IC - SN74LS08M	119-138
1407 4195	IC - HD74LS06FP	119-139
1407 4196	IC - SN74LS151M	119-140
1407 4197	IC - DM74ALS245ASJ	119-141
1407 4198	IC - DM74ALS240ASJ	119-142
1407 4199	IC - DM74ALS244ASJ	119-143
1407 4275	IC - SN74AS240NS	119-144
1407 4276	IC - LH5168-10L	113-167
1408 0425	IC - NJM79L05	119-145
1408 0585	IC - AD7528JR	113-168
1408 0595	IC - NJM2904M	113-169
1408 0716	IC - NJM084M	113-170
1408 1011	IC - M5237ML	119-146
1408 1029	Operational Amplifier - AD847JR	119-147
1408 1033	IC - NJM2103M	119-148
1503 0194	Crystal Oscillator - 32.768 Khz	113-171
1503 0307	Oscillator - 20Mhz	113-173
1503 0498	Oscillator - 19.6608Mhz	119-149
1503 0540	Oscillator - 37.1843Mhz	119-150
1503 0563	Oscillator-9.83MTz040	113-172
1601 2957	Resistor - RCE9A472J	119-151
1601 4021	Resistor - RCE9A103J	119-152
1601 7697	Resistor - RCB8C103J	119-153

Part No.	Description	Page and Index No.
1602 0918	Filter - 270pf - Emi	119-154
1602 7029	Noise Filter - 22000PF 50V	113-174
1602 7077	Capacitor - 270PF ±10% 50V	119-155
1602 7085	Filter - TV50m	119-156
1602 7087	Filter - TH18103MA	119-157
1602 7092	Filter - MNF51R00P506	119-158
1602 7096	Filter - TX14131NB	119-159
1604 1377	Capacitor - 0.47µF 50V	113-175
1604 1382	Capacitor - 10µF 50V	113-176
1604 1385	Capacitor - 47µF 50V	113-177
1604 1386	Capacitor - 100µF ±20% 50V	113-178
1604 2587	Capacitor - 100µF ±2%	119-160
1605 0233	Capacitor - 15PF 50V	113-179
1605 0283	Capacitor - 1µF	119-161
1605 0435	Capacitor - 0.47µF +80% -20% 16V	119-162
1605 0636	Capacitor - 0.1µF	113-180
1606 1135	Capacitor - 470PF 50V	113-181
1606 1136	Capacitor - 1000PF	119-163
1606 1139	Capacitor - 0.01µF ±20%	119-164
1606 1140	Capacitor - 0.1µF +80%-20%	119-165
1606 1450	Capacitor - 10PF 50V	113-182
1606 1452	Capacitor - 0.01µF 50V	113-183
1606 1477	Capacitor - 330PF	119-166
1606 1537	Capacitor - 1000PF 50V	113-184
1607 0477	Inductor - BLM21A05	113-185
1607 0623	Ferrite Core - Small	13-103
1610 0286	Capacitor - 100PF 50V ±10%	113-186
1630 1101	Resistor - 100 Ω 1/4W ±5%	113-187
1630 1121	Resistor - 120Ω±5% 1/8W	119-167
1630 1151	Resistor - 150 Ω ±5% 1/4W	113-188
1630 2102	Resistor - 1K Ω 1/8W ±5%	113-189
1630 2103	Resistor - 10K Ω 1/8W	113-190
1630 2104	Resistor - 100K Ω 1/8W ±5%	113-191
1630 2105	Resistor - 1M Ω 1/8W	113-192

Part No.	Description	Page and Index No
1630 2121	Resistor - 120 Ω ±5% 1/8W	113-193
1630 2123	Resistor - 12K Ω 1/8W ±5%	113-194
1630 2206	Resistor - 20M Ω 1/8W ±5%	113-195
1630 2220	Resistor - 22Ω 1/8W ±5%	113-196
1630 2222	Resistor - 2.2K Ω 1/8W	113-197
1630 2223	Resistor - 22K Ω 1/8W ±5%	113-198
1630 2330	Resistor - 33Ω 1/8W ±5%	113-199
1630 2334	Resistor - 330K Ω	113-200
1630 2472	Resistor - 4.7K Ω 1/8W ±5%	113-201
1630 2473	Resistor - 47K Ω 1/8W ±5%	113-202
1630 2511	Resistor - 510 Ω 1/8W ±5%	113-203
1630 2821	Resistor - 820 Ω 1/8W ±5%	113-204
1630 3102	Resistor - 1KΩ 1/10W ±5%	119-168
1630 3103	Resistor - 10KΩ 1/10W ±5%	119-169
1630 3152	Resistor - 1.5kΩ - 1/10W	119-170
1630 3153	Resistor - 15K Ω ±5% 1/10W	119-171
1630 3221	Resistor - 220 Ω ±5% 1/10W	119-172
1630 3222	Resistor - 2.2KΩ 1/10W ±5%	119-173
1630 3302	Resistor - 3kΩ - 1/10W	119-174
1630 3330	Resistor - 33 Ω ±5% 1/10W	119-175
1630 3471	Resistor - 470Ω - 1/10W	119-176
1630 3472	Resistor - 4.7KΩ 1/10W ±5%	119-177
1630 4100	Resistor - 10 Ω ±5% 1/16W	119-178
1630 4103	Resistor - 10KΩ ±5% 1/16W	119-179
1630 4330	Resistor - 33Ω±5% 1/8W	119-180
1630 4472	Resistor - 4.7KΩ ±5% 1/16W	119-181
1632 5231	Resistor - 5.23K Ω ±1%	113-205
1633 0000	Resistor - 0Ω ±1% 1/10W	119-182
1633 1001	Resistor - 1K Ω ±1% 1/10W	119-183
1633 1401	Resistor - 1.4KΩ ±1% 1/8W	119-184
1633 1601	Resistor - 1.6KΩ ±1% 1/8W	119-185
1633 1801	Resistor - 1.8KΩ ±1% 1/8W	119-186
1633 4301	Resistor - 4.3KΩ ±1% 1/8W	119-187

Part No.	Description	Page and Index No.
1633 5901	Resistor - 5.9K Ω ±1% 1/10W	119-188
1633 9311	Resistor - 9.3KΩ ±1% 1/8W	119-189
1634 2209	Resistor - 22.0Ω ±1% 1/8W	119-190
1634 4301	Resistor - 4.3KΩ ±1% 1/8W	119-191
1634 6801	Resistor - 6.8KΩ ±1% 1/8W	119-192
1642 0101	Resistor - 1K Ω ±1% 1/10W	119-193
1643 2100	Resistor - 1.4K Ω ±1% 1/8W	119-194
1902 0010	Resistor - 1.6K Ω ±1% 1/8W	119-195

Part No.	Description	Page and Index No