Savin AR-DE80 (A997)
(Ricoh RE8)

PARTS CATALOG

INTRODUCTION


This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.Editor (A997) 2
Parts Index..... 5

March ,15 ’95

1. EDITOR (A997)



1.EDITOR (A997)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A997 1225	Upper Cover	1
2	A997 1217	LCD Display	1
3	A997 1218	LCD Harness	1
4	A997 1214	Main Control Board	1
5	A997 1230	Lower Cover	1
6	A997 1216	Operation Panel Board	1
7	A997 1219	Key Switch Harness	1
8	A997 1215	Inverter Board	1
9	A997 1220	Inverter Relay Harness	1
10	A997 1202	Keytop - Scan	1
11	A997 1203	Keytop - Full Image	1
12	A997 1204	Keytop - Zoom 1	1
13	A997 1205	Keytop - Zoom 2	1
14	A997 1206	Keytop - Zoom 3	1
15	A997 1207	Keytop - Image Shift	1
16	A997 1208	Keytop - Clear	1
17	A997 1209	Keytop - Point	1
18	A997 1210	Keytop - Close	1
19	A997 1211	Keytop - All Clear	1
20	A997 1212	Keytop - Cursor	1
21	A997 1213	Dial	2
23	A997 1222	LCD Filter	1
24	A997 1229	Decal - keytop	1
25	A997 5100	Editor Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0344 0080F	Philips Truss Head Screw - M4x8	

PARTS INDEX

Part No.	Description	Page and Index No.
A997 1202	Keytop - Scan	3- 10
A997 1203	Keytop - Full Image	3- 11
A997 1204	Keytop - Zoom 1	3- 12
A997 1205	Keytop - Zoom 2	3- 13
A997 1206	Keytop - Zoom 3	3- 14
A997 1207	Keytop - Image Shift	3- 15
A997 1208	Keytop - Clear	3- 16
A997 1209	Keytop - Point	3- 17
A997 1210	Keytop - Close	3- 18
A997 1211	Keytop - All Clear	3- 19
A997 1212	Keytop - Cursor	3- 20
A997 1213	Dial	3- 21
A997 1214	Main Control Board	3- 4
A997 1215	Inverter Board	3- 8
A997 1216	Operation Panel Board	3- 6
A997 1217	LCD Display	3- 2
A997 1218	LCD Harness	3- 3
A997 1219	Key Switch Harness	3- 7
A997 1220	Inverter Relay Harness	3- 9
A997 1222	LCD Filter	3- 23
A997 1225	Upper Cover	3- 1
A997 1229	Decal - keytop	3- 24
A997 1230	Lower Cover	3- 5
A997 5100	Editor Harness	3- 25

Part No.	Description	Page and Index No
0344 0080F	Philips Truss Head Screw - M4x8	3-101