TABLE OF CONTENTS

1. OVERALL MACHINE INFORMATION

1. SPECIFICATIONS 1-1

2. MACHINE CONFIGURATION 1-5

3. COPY PROCESS 1-6

3.1 OVERVIEW 1-6

3.2 DEVELOPMENT PROCESS 1-8

4. MECHANICAL COMPONENT LAYOUT 1-10

5. DRIVE LAYOUT 1-12

6. AIR FLOW 1-14

7. ELECTRICAL COMPONENT DESCRIPTIONS 1-15

2. DETAILED SECTION DESCRIPTIONS

1. PROCESS CONTROL 2-1

1.1 OVERVIEW 2-1

1.1.1 Latent Image Control 2-2

1.1.2 Toner Density Control 2-2

1.2 PROCESS CNTTROL SELF CHECK 2-3

1.3 LATENT IMAGE CNTTROL 2-4

1.3.1 Drum Potential Sensor Calibration 2-4

1.3.2 V_{SG} Adjustment 2-5

1.3.3 Gradation Patterns Detection 2-5

1.3.4 Pointer Control 2-6

1.3.5 Confirmation Procedure 2-6

1.3.6 Related Abnormal Conditions 2-7

1.4 TONER DENSITY CONTROL 2-8

1.4.1 Toner Density Sensor 2-8

1.4.2 Toner Density Sensor Initial Setting 2-8

1.4.3 Toner Supply Criteria 2-9

1.4.4 Toner Supply Motor ON Time 2-9
1.4.5 VCNT Correction 2-10
1.4.6 Toner End Detection 2-11
1.4.7 Toner End Recovery 2-11
2. DRUM UNIT 2-13
2.1 OVERVIEW. 2-13
2.2 OPC DRUM CHARACTERISTICS 2-14
2.3 DRUM CHARGE. 2-15
2.4 DRIVE MECHANISM 2-16
2.5 DRUM CLEANING 2-17
2.5.1 Counter Blade System 2-17
2.5.2 PCC and Cleaning Bias 2-18
2.5.3 Toner Collection Mechanism 2-19
2.6 QUENCHING 2-20
3. SCANNING 2-21
3.1 OVERVIEW. 2-21
3.2 SCANNER UNIT 2-22
3.3 SCANNER DRIVE 2-23
3.4 COLOR CCD 2-24
3.5 WHITE PLATE SCANNING 2-25
3.6 ORIGINAL SIZE DETECTION 2-26
3.7 OTHERS 2-28
3.8 SCANNER SECTION BLOCK DIAGRAM 2-29
4. IMAGE PROCESSING 2-30
4.1 OVERVIEW 2-30
4.2 SCANNER SECTION BLOCK DIAGRAM 2-31
4.3 CCD BOARD 2-32
4.4 SCANNER CONTROL BOARD 2-32
4.4.1 Signal Amplification 2-32
4.4.2 A/D Conversion and Signal Composition 2-32
4.4.3 Auto Shading. 2-33
4.4.4 D/A Conversion 2-34

4.4.5 Scan Line Correction 2-34
4.5 IPU SECTION BLOCK DIAGRAM 2-35
4.6 IPU INTERFACE BOARD 2-36
4.7 IPU BOARD 2-36
4.7.1 Scanner Gamma Correction 2-36
4.7.2 Picture Element Correction 2-37
4.7.3 Auto Color Selection (ACS) 2-38
4.7.4 Auto Letter/Photo Separation 2-39
4.7.5 Filter and Color Conversion 2-40
4.7.6 Main Scan Magnification 2-44
4.7.7 Image Creation 2-45
4.7.8 Filter 2-49
4.7.9 Auto Image Density (ADS) 2-50
4.7.10 Printer Gamma Correction 2-51
4.7.11 Gradation Treatment 2-55
4.7.12 Video Controller 2-56
4.7.13 Area Data Processing 2-57
5. LASER EXPOSURE 2-58
5.1 OVERVIEW 2-58
5.2 OPTICAL PATH 2-59
5.2.1 Laser Diode Unit 2-60
5.2.2 Cylindrical Lens 2-61
5.2.3 Polygon Mirror 2-61
5.2.4 F-Theta Lenses 2-62
5.2.5 Drum Mirror 2-63
5.2.6 Laser Synchronizing Mirror and Detector Board 2-63
5.3 LASER EXPOSURE CONTROL 2-64
5.4 GRADATION CONTROL 2-65
5.5 AUTO POWER CONTROL (APC) 2-67
5.6 LASER SYNCHRONIZING DETECTOR 2-68
5.7 LD SWITCH 2-69

6. DEVELOPMENT 2-70
6.1 OVERVIEW. 2-70
6.2 DRIVE MECHANISM 2-71
6.3 DEVELOPER SUPPLY AND RELEASE 2-72
6.4 DEVELOPMENT BIAS 2-73
7. TONER TANK 2-74
7.1 OVERVIEW 2-74
7.2 TONER TRANSPORTATION AND AGITATION 2-75
7.3 TONER BOTTLE 2-76
8. TRANSFER BELT UNIT 2-77
8.1 OVERVIEW. 2-77
8.2 TRANSFER BELT DRIVE MECHANISM 2-78
8.3 TRANSFER BELT DRIVE CONTROL 2-79
8.3.1 Switch Back Operation 2-79
8.3.2 Idling Rotation 2-81
8.4 TRANSFER BELT RELEASE MECHANISM 2-82
8.5 TRANSFER BELT BIAS 2-83
8.6 TRANSFER BELT CLEANING 2-85
8.6.1 Cleaning Mode 2-86
8.7 LUBRICATION MECHANISM. 2-86
9. TRANSFER ROLLER UNIT 2-87
9.1 OVERVIEW. 2-87
9.2 ROLLER TOUCH AND RELEASE MECHANISM 2-88
9.3 TRANSFER ROLLER DRIVE 2-89
9.4 TRANSFER ROLLER BIAS 2-90
9.5 PAPER DISCHARGE 2-92
9.6 TRANSFER ROLLER CLEANING 2-93
10. PAPER TRANSPORT AND IMAGE FUSING 2-94
10.1 OVERVIEW 2-94
10.2 FUSING ENTRANCE GUIDE 2-95
10.3 DRIVE MECHANISM 2-96

10.4 FUSING DRIVE RELEASE MECHANISM 2-97
10.5 OIL SUPPLY MECHANISM 2-98
10.6 CLEANING MECHANISM. 2-99
10.7 JAM DETECTION 2-100
10.8 FUSING PRESSURE MECHANISM 2-101
10.9 FUSING TEMPERATURE CONTROL 2-102
11. PAPER FEED 2-103
11.1 OVERVIEW 2-103
11.2 FRR FEED SYSTEM 2-104
11.2.1 Pick-up Roller 2-104
11.2.2 Feed and Separation Rollers 2-104
11.3 SLIP CLUTCH MECHANISM 2-106
11.4 FRR FEED DRIVE MECHANISM 2-107
11.5 SEPARATION ROLLER RELEASE MECHANISM 2-109
11.6 PAPER RETURN MECHANISM 2-110
11.7 PAPER SKEW PREVENTION MECHANISM 2-111
11.8 PAPER LIFT MECHANISM 2-112
11.9 PAPER END DETECTION 2-114
11.10 PAPER SIZE DETECTION 2-115
11.11 VERTICAL TRANSPORT MECHANISM 2-116
11.12 TRAY POSITIONING MECHANISM 2-117
11.13 BY-PASS FEED TABLE 2-118
11.13.1 Feed Mechanism / Paper End Detection 2-118
11.13.2 Table Open/Close Detection 2-119
11.13.3 Paper Size Detection 2-120
11.14 PAPER REGISTRATION 2-121
11.15 REGISTRATION DRIVE MECHANISM 2-122

3. INSTALLATION

1. INSTALLATION REQUIREMENTS 3-1

1.1 ENVIRONMENT 3-1

1.2 MACHINE LEVEL 3-1

1.3 MINIMUM SPACE REQUIREMENTS 3-2

1.4 POWER REQUIREMENTS 3-3

2. COPIER INSTALLATION 3-4

2.1 ACCESSORY CHECK 3-4

2.1.1 Copier 3-4

2.1.2 Optional Table (Option: A702) 3-4

2.2 COPIER SEPARATION 3-5

2.3 COPIER INSTALLATION PROCEDURE 3-6

2.4 PAPER SIZE CHANGE 3-23

2.5 OPTIONAL HOLDER (A702) INSTALLATION 3-25

2.6 KEY COUNTER INSTALLATION 3-27

2.7 UPPER AND LOWER HEATER INSTALLATION (OPTIONS) 3-28

4. SERVICE TABLES

1. SERVICE REMARKS 4-1

1.1 GENERAL CAUTION 4-1

1.2 DRUM 4-1

1.3 TRANSFER BELT UNIT 4-2

1.4 SCANNER UNIT 4-3

1.5 LASER UNIT 4-3

1.6 CHARGE CORONA 4-4

1.7 DEVELOPMENT 4-4

1.8 DRUM CLEANING 4-5

1.9 TRANSFER BELT CLEANING 4-6

1.10 FUSING UNIT 4-6

1.11 PAPER FEED 4-7

1.12 TRANSFER ROLLER UNIT 4-7

1.13 FILTER 4-7
1.14 USED TONER 4-7
2. SERVICE PROGRAM MODE 4-8
2.1 SERVICE PROGRAM MODE OPERATION 4-8
2.1.1 Service Program Access Procedure 4-8
2.1.2 To Exit SP Mode 4-8
2.1.3 To Return to the Index Menu 4-9
2.1.4 Change the Menu Screen 4-9
2.1.5 Access to "Copy in SP" Mode 4-9
2.1.6 To Input Data 4-10
2.1.7 To Clear The Counter 4-10
2.2 SERVICE PROGRAM MODE TABLE 4-11
2.2.1 SP ADJUSTMENT 4-11
2.2.2 SP Test Mode 4-17
2.2.3 SP Data Output 4-21
2.2.4 SP SPECIAL FEATURES 4-23
2.2.5 JAM / SC COUNTER 4-29
2.2.6 Operation Counter 4-30
2.2.7 Counter Clear 4-32
2.3 SENSOR/SWITCH/SIGNAL DATA CHECK (INPUT MODE) 4-33
2.3.1 Input Check Mode Table 4-34
2.4 ELECTRICAL COMPONENT CHECK (OUTPUT MODE) 4-36
2.4.1 Output Check Mode Table 4-38
2.5 SP MODES AFTER REPLACEMENT AND CLEANING 4-41
2.6 MEMORY ALL CLEAR PROCEDURE 4-42
3. USER TOOLS MENU 4-43
3.1 USER TOOLS ACCESS PROCDURE 1 4-43
3.2 USER TOOLS ACCESS PROCEDURE 2 4-44
4. TEST POINTS / DIP SWITCHES / LED'S 4-45
4.1 MAIN CONTROL BOARD 4-45
4.1.1 Test Points 4-45
4.1.2 DIP Switches 4-45

4.1.3 LED 4-45
4.2 IPU BOARD 4-46
4.2.1 DIP Switches 4-46
4.2.2 LED's 4-46
5. PREVENTIVE MAINTENANCE SCHEDULE 4-47
5.1 PM TABLE 4-47
5.2 REGULAR PM PROCEDURE 4-55

5. REPLACEMENT AND ADJUSTMENT

1. COLOR BALANCE ADJUSTMENT 5-1
2. COPY IMAGE ADJUSTMENT - PRINTING/SCANNING 5-5
2.1 PRINTING 5-5
2.1.1 Registration Adjustment 5-7
2.1.2 Blank Margin Adjustment 5-8
2.2 SCANNING 5-10
3. EXTERIOR AND INNER COVERS 5-12
3.1 EXTERIOR COVER REMOVAL 5-12
3.1.1 Front Door 5-12
3.1.2 Upper Rear Cover 5-13
3.1.3 Upper Left Cover 5-13
3.1.4 Lower Rear Cover 5-13
3.1.5 Lower Left Cover 5-13
3.1.6 Right Front Door 5-14
3.1.7 Upper Right Cover 5-14
3.1.8 Lower Front Cover 5-14
3.1.9 Top Cover 5-15
3.2 INNER COVER REMOVAL 5-16
3.2.1 Right Inner Cover 5-16
3.2.2 Total Counter Cover 5-16
3.2.3 Lower Left Inner Cover 5-16
3.2.4 Upper Left Inner Cover 5-16

4. SCANNER UNIT 5-17
4.1 EXPOSURE GLASS REMOVAL 5-17
4.2 EXPOSURE LAMP REPLACEMENT 5-18
4.3 OPTICS THERMOSWITCH REPLACEMENT 5-19
4.4 SCANNER CONTROL BOARD REPLACEMENT 5-20
4.5 LENS UNIT (CCD BOARD) REPLACEMENT 5-21
4.6 ORIGINAL LENGTH SENSOR (1) REPLACEMENT 5-22
4.7 ORIGINAL WIDTH SENSOR AND ORIGINAL LENGTH SENSOR (2) REPLACEMENT 5-23
4.8 SCANNER MOTOR REPLACEMENT 5-24
4.9 SCANNER DRIVE BELT REPLACEMENT 5-26
4.10 SCANNER HOME POSITION SENSOR/SCANNER MOTOR DRIVE BOARD /LAMP REGULATOR BOARD/SCANNER UNIT LIFT SENSOR REPLACEMENT 5-27
4.11 SCANNER WIRE REPLACEMENT 5-28
5. LASER UNIT 5-33
5.1 WARNING 5-33
5.2 OPTICAL HOUSING UNIT REPLACEMENT 5-34
5.3 LD UNIT AND POLYGON MOTOR REPLACEMENT 5-36
5.4 LASER SYNCHRONIZING DETECTOR BOARD REPLACEMENT 5-37
5.5 POLYGON MOTOR DRIVE BOARD REPLACEMENT 5-38
6. PAPER FEED SECTION 5-39
6.1 PICK-UP/PAPER FEED/SEPARATION ROLLER REPLACEMENT 5-39
6.2 PAPER FEED CLUTCH, PICK-UP AND SEPARATION ROLLER SOLENOID REPLACEMENT (1ST, 2ND AND 3RD FEED UNIT) 5-40
6.3 PAPER FEED MOTOR REPLACEMENT 5-44
6.4 TRAY LIFT MOTOR (1ST, 2ND, AND 3RD) REPLACEMENT 5-45
6.5 BY-PASS FEED TABLE 5-46
6.5.1 Pick-up, Paper Feed and Separation Roller Replacement 5-46
6.6 BY-PASS PAPER WIDTH SENSOR AND BY-PASS PAPER LENGTH SENSOR REPLACEMENT 5-47
6.7 BY-PASS FEED CLUTCH AND BY-PASS PICK-UP SOLENOID 5-48
6.8 REGISTRATION SENSOR REPLACEMENT 5-49
6.9 REGISTRATION CLUTCH REPLACEMENT 5-50

6.10 1ST PAPER TRAY PAPER SIZE SWITCH, 2ND AND 3RD TRAY SET SWITCH REPLACEMENT 5-51
6.11 REGISTRATION BUCKLE ADJUSTMENT 5-52
7. DRUM UNIT 5-53
7.1 DRUM UNIT REMOVAL AND OPC DRUM REPLACEMENT 5-53
7.2 INSTALLING A NEW DRUM 5-57
7.3 CLEANING BLADE REPLACEMENT 5-60
7.4 CLEANING BRUSH REPLACEMENT 5-61
7.5 BIAS ROLLER BLADE REPLACEMENT 5-62
7.6 CHARGE WIRE REPLACEMENT 5-63
7.7 PRE-CLEANING CORONA WIRE REPLACEMENT 5-64
7.8 DRUM MOTOR REPLACEMENT 5-65
7.9 USED TONER TANK REMOVAL 5-66
8. DEVELOPMENT SECTION 5-67
8.1 DEVELOPER COLLECTION 5-67
8.2 DEVELOPER INSTALLATION 5-69
8.3 TONER DENSITY SENSOR REPLACEMENT 5-73
8.4 DEVELOPMENT ROLLER ASSEMBLY REPLACEMENT 5-74
8.5 DUAL MIXING ROLLER REPLACEMENT (FOR ALL COLORS) 5-76
8.6 BLACK SLEEVE MOTOR REPLACEMENT 5-77
8.7 COLOR SLEEVE MOTOR REPLACEMENT 5-78
8.8 BLACK DEVELOPMENT DRIVE MOTOR REPLACEMENT 5-80
8.9 COLOR DEVELOPMENT DRIVE MOTOR REPLACEMENT 5-81
9. TRANSFER BELT SECTION 5-82
9.1 TRANSFER BELT REPLACEMENT 5-82
9.2 TRANSFER BELT POSITION CLUTCH AND TRANSFER BELT POSITION SENSOR REPLACEMENT 5-84
10. TRANSFER ROLLER UNIT 5-85
10.1 TRANSFER ROLLER UNIT REMOVAL 5-85
10.2 TRANSFER ROLLER BLADE REPLACEMENT 5-86
10.3 PAPER DISCHARGE PLATE REPLACEMENT 5-87
10.4 TRANSFER ROLLER REPLACEMENT 5-88

11. TRANSFER BELT CLEANING UNIT 5-89
11.1 TRANSFER BELT CLEANING BLADE REPLACEMENT 5-89
11.2 CLEANING BLADE SOLENOID REPLACEMENT 5-90
11.3 TRANSFER BELT CLEANING ENTRANCE SEAL SOLENOID REPLACEMENT 5-91
12. LUBRICANT UNIT 5-92
12.1 LUBRICANT BRUSH AND LUBRICANT BAR REPLACEMENT 5-92
12.2 LUBRICANT BRUSH CLUTCH REPLACEMENT 5-93
13. FUSING UNIT 5-94
13.1 FUSING UNIT REMOVAL 5-94
13.2 CLEANING ROLLER AND SCRAPER REPLACEMENT 5-95
13.3 OIL SUPPLY PAD REPLACEMENT 5-96
13.4 FUSING THERMISTOR REPLACEMENT 5-97
13.5 OIL BLADE REPLACEMENT 5-98
13.6 FUSING LAMP AND FUSING THERMOFUSE REPLACEMENT 5-99
13.7 HOT ROLLER REPLACEMENT 5-100
13.8 PRESSURE ROLLER LAMP REPLACEMENT 5-102
13.9 PRESSURE ROLLER REPLACEMENT 5-103
13.10 PRESSURE ROLLER THERMISTOR REPLACEMENT 5-104
13.11 TRANSPORT MOTOR REPLACEMENT 5-105
13.12 FUSING PRESSURE (NIP BAND WIDTH) CONFIRMATION 5-106
14. OTHERS 5-107
14.1 MAIN CONTROL BOARD REPLACEMENT 5-107
14.2 DEVELOPMENT FILTER AND DEVELOPMENT OZONE FILTER REPLACEMENT 5-108
14.3 FILTER REPLACEMENT (DEVELOPMENT EXHAUST, CHARGE INLET FAN, FUSING EXHAUST OZONE, OPTICS COOLING FAN AND INNER COOLING FAN) 5-109
14.4 TONER TANK AGITATOR REPLACEMENT 5-110
14.5 PAPER TRANSPORT BELT REPLACEMENT 5-111
14.6 POINT ACCURACY ADJUSTMENT 5-112

6. TROUBLESHOOTING

1. SERVICE CALL CONDITIONS 6-1

1.1 SUMMARY 6-1

1.2 SCANNING 6-3

1.3 PRINTING 6-6

1.4 DEVELOPMENT 6-8

1.5 AROUND THE DRUM 6-12

1.6 TRANSFER BELT / ROLLER 6-14

1.7 PAPER FEED 6-16

1.8 FUSING 6-17

1.9 COMMUNICATION 6-20

1.10 OPTIONAL EQUIPMENTS 6-23

1.11 OTHERS 6-24

2. BLOWN FUSE CONDITIONS 6-25

DUAL JOB FEEDER

1. SPECIFICATIONS 1

2. COMPONENT LAYOUT 3

2.1 MECHANICAL COMPONENT LAYOUT 3

3. ELECTRICAL COMPONENT DESCRIPTION 4

4. BASIC OPERATION 6

4.1 ONE-SIDED ORIGINAL FEED 6

4.2 TWO-SIDED ORIGINAL FEED 9

4.3 PRESET MODE 10

4.4 COMBINE 2 ORIGINALS MODE 11

4.4.1 Overview 11

4.4.2 Operation 12

5. ORIGINAL SEPARATION 14

6. SEPARATION BELT DRIVE MECHANISM 15

7. THIN / THICK ORIGINAL MODES 16
8. ORIGINAL SIZE DETECTION 17
9. LIFT MECHANISM 18
10. ORIGINAL MISFEED DETECTION 19
11. TIMING CHART 21
11.1 DJF TIMING CHART (1SIDED ORIGINAL MODE) 21
11.2 DJF TIMING CHART (COMBINE 2 ORIGINALS MODE). 22
12. INSTALLATION 23
12.1 ACCESSORY CHECK 23
12.2 INSTALLATION PROCEDURE 24
13. SERVICE TABLES 29
13.1 DIP SWITCHES AND SWITCHES 29
13.2 VARIABLE RESISTORS. 30
13.3 LEDs 30
13.4 FUSEs. 30
14. REPLACEMENTS AND ADJUSTMENTS 31
14.1 TRANSPORT BELT REPLACEMENT 31
14.2 ORIGINAL TABLE / ORIGINAL GUIDE REMOVAL 33
14.3 FEED ROLLER REPLACEMENT 35
14.4 SEPARATION BELT REPLACEMENT. 36
14.5 FEED-OUT MOTOR (FEED-OUT UNIT) REMOVAL 38
14.6 INVERTER SOLENOID REMOVAL AND ADJUSTMENT 40
14.7 BELT DRIVE MOTOR REPLACEMENT 41
14.8 FEED-IN CLUTCH (FEED-IN UNIT) REMOVAL 44
14.9 STOPPER SOLENOID REPLACEMENT 46
14.10 VERTICAL REGISTRATION ADJUSTMENT 47
14.10.1 One Sided Original Mode 47
14.10.2 Two Sided Original Mode 48
14.10.3 Combine 2 Originals Mode 49
14.11 SIDE TO SIDE REGISTRATION ADJUSTMENT. 50

14.12 MOTOR SPEED ADJUSTMENT 51

SORTER

1. OVERALL MACHINE INFORMATION 1
1.1 SPECIFICATIONS 1
1.2 COMPONENT LAYOUT 2
1.2.1 Mechanical Components 2
1.2.2 Electrical Components 3
1.3 ELECTRICAL COMPONENT DESCRIPTIONS 4
1.4 DRIVE LAYOUT 5
1.5 BASIC OPERATION 6
2. DETAILED SECTION DESCRIPTIONS 9
2.1 DRIVE MECHANISM 9
2.2 BIN GATE OPERATION 10
2.3 RELAY GUIDE PLATE RESET MECHANISM 11
2.4 ELECTRICAL CONTROL 12
2.5 JAM AND BIN COPY SENSORS 13
2.6 MISFEED SENSING 14
3. INSTALLATION 15
3.1 ACCESSORY CHECK 15
3.2 INSTALLATION PROCEDURE 16
4. SERVICE TABLES 22
4.1 TEST POINT 22
4.2 LEDs 22
4.3 DIP SWITCH 22
4.4 VARIABLE RESISTORS 22
5. REPLACEMENT AND ADJUSTMENT 23
5.1 SORTER MOTOR, SPONGE ROLLER, AND INLET SENSOR REPLACEMENT 23
5.2 JAM SENSOR REPLACEMENT 24
5.3 VERTICAL DRIVE ROLLER TIMING BELT ADJUSTMENT 25

5.4 SORTER MOTOR SPEED ADJUSTMENT 25

DISPLAY EDITOR

1. SPECIFICATIONS 1
2. OVERVIEW 2
3. EXPLANATION FOR EACH KEY 3
4. INSTALLATION 4
4.1 ACCESSORY CHECK 4
4.2 INSTALLATION PROCEDURE 5

FILM PROJECTOR UNIT

1. SPECIFICATION 1
2. ELECTRICAL COMPONENT LAYOUT AND DESCRIPTIONS 2
3. SECTIONAL DESCRIPTIONS 3
3.1 OVERVIEW 3
3.2 SHADING 4
3.3 MIRROR UNIT 5
4. INSTALLATION 6
4.1 ACCESSORY CHECK 6
4.2 INSTALLATION PROCEDURE 7